

(3)

FB-133


(3)

FILE COPY

WE
AUG 60

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

GAS-METERING HANDBOOK FOR HYDROGEN
BALLOON INFLATION



STAT

This document is part of an integrated
file. If separated from the file it must be
subjected to individual systematic review.

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

TABLE OF CONTENTS

	<u>Page</u>
INTRODUCTION	1
Hydrogen Cylinders	1
Description of Tables	1
SAFETY MEASURES	2
Preventing an Explosion	2
Minimizing the Effects of an Explosion	3
Fighting Fires	4
Summary	4
HOW TO USE THIS HANDBOOK	5
Weight of Flight Equipment and Free Lift	5
Temperature Measurement	5
Pressure Measurement	6
Cylinder Conversion Factors	6
Correction for Gas Impurities	6
Partial-Cylinder Correction	6
SAMPLE PROBLEMS	9
Example No. 1	9
Example No. 2	11
INFLATION TABLES	Following page 16

LIST OF FIGURES

Figure 1. Gas-Impurity Correction Chart for Nitrogen	7
Figure 2. Gas-Impurity Correction Chart for Oxygen	7
Figure 3. Gas-Impurity Correction Chart for Carbon Dioxide	8
Figure 4. Gas-Impurity Correction Chart for Ammonia	8
Figure 5. Pressure Computation for Partial Cylinders of Hydrogen	10

LIST OF TABLES

Table 1. Conversion Factors for Standard Hydrogen Cylinders	13
Table 2. Lift Conversion	14
Table 3. Pressure Conversion	15

INTRODUCTION

The purpose of this handbook is to provide tables which will enable an operator to determine accurately, from simple pressure and temperature readings, the amount of potential lift within various standard hydrogen containers. Directions for the use of the handbook, correction curves for partial cylinders and gas impurities, conversion tables, and other pertinent information have been included.

Hydrogen Cylinders

The usual method of packaging and shipping hydrogen is in seamless steel cylinders. Cylinders are given a hydrostatic test when made, and should be retested periodically. The hydrogen-cylinder valve is equipped with a safety device consisting of a frangible metal plug with a fusible metal core.

There are three types of controls commonly encountered in connection with hydrogen. The first is the needle valve which controls the rate of flow. A typical valve of this class might have a Monel stem and brass body.

The second type of control is a needle valve having a gage between the control point and the cylinder inlet. The gage shows the pressure remaining in the cylinder at any time, and thereby provides a fairly accurate indication of the amount of gas remaining in the cylinder.

The third type of control is the automatic regulator which serves to reduce the pressure and hold it at a desired value. Several kinds of such regulators are available, including the single-stage, two-stage, and high-pressure varieties. All reducing valves of this type have two gages, one of which shows the pressure in the cylinder and the other the outlet pressure.

Description of Tables

Table 1: Conversion factors for utilizing various other standard hydrogen containers.

Table 2: Lift-conversion table for converting pounds force to kilograms force. The table covers a range from 0.1 to 22.5 pounds in 0.1-pound increments.

Table 3. Pressure-conversion table for converting atmospheres gage (atü) to pounds per square inch gage (psig). The table covers the range from 0.5 to 200 atü in 0.5-atü increments. 14.7 psig = 1 atü.

Inflation tables are given following page 16 for the "6 cubic meter" (Type 4000/1) German hydrogen cylinder. These tables cover a pressure range from 0.5 to 200 atmospheres gage in 0.5-atü increments and a temperature range of -40 to +40°C (-40 to +104°F). The centigrade temperature appears at the top of each page, with corresponding Fahrenheit temperature shown at the bottom. The tables are based on 68 per cent relative humidity.

SAFETY MEASURES

Because of the possibility of the formation of explosive mixtures, the precautions for the handling of hydrogen should be studied in some detail. The basic methods of preventing a flammable-gas explosion consist both of avoiding an explosive concentration and eliminating sources of ignition. If an explosion should occur, it is essential that provision be made for minimizing its effects. Furthermore, a knowledge of fire fighting may be of considerable aid to the user of hydrogen.

Preventing an Explosion

Avoiding an Explosive Concentration

Even if small amounts of hydrogen are likely to be present with larger quantities of air, the hydrogen concentration should nevertheless be kept below the lower explosive limit. The best way to make sure of this is to maintain adequate ventilation. If the cylinders are to be stored and used out-of-doors, this factor is of less concern.

If it is decided to empty apparatus containing hydrogen, the equipment should be evacuated or purged with an inert gas until the hydrogen concentration is below the explosive limit. Air should never be used for purging, since the entire range of explosive concentrations of hydrogen and air would be encountered, thereby creating a great hazard. Furthermore, hydrogen should be segregated from oxygen, and the respective storage areas located so that, in the event of even the worst possible fire, there would be no explosion hazard.

Concentrations of hydrogen should not be guessed. Instruments for detecting hydrogen and measuring its concentration are available. These may range from small portable units to large fixed installations which can sample various places continuously. Furthermore, the instruments can be made either to indicate or to record. They can also be set up so as to actuate warning devices or other equipment.

Eliminating Sources of Ignition

The common sources of ignition, and means of guarding against them, are summarized as follows:

- (1) Open Flames. Smoking, welding, and any other activity that produces flames should be prohibited when working with hydrogen. Thus, fittings, piping, and cylinders should never be welded in the field, where hydrogen may be present.
- (2) Electrical. All electrical equipment should conform to current safety provisions. Even if the equipment is itself safe, steps should be taken to make sure that the interior of the equipment is not exposed while the circuit is operating with hydrogen present.
- (3) Metallic Sparks. The use of nonferrous tools will avoid spark formation. It is advisable to test the hydrogen concentration of the area in which work is to be done to make sure that it is safe.

- (4) Static Electricity. Buildup of static electricity should be avoided by grounding equipment and using conductive floors and shoes.
- (5) Lightning. The installation should be protected from lightning if possible.
- (6) Unsecured Cylinders. It is recommended that hydrogen cylinders be either chained to walls or blocked horizontally on a level surface. Valve caps and cylinder bonnets should be affixed, and the cylinders stored as far away from traffic as possible. It should be remembered that, when a cylinder falls, the cylinder valve may break off. This can be fatal, since the cylinder may act as a missile under such conditions.
- (7) Sudden Opening of Valves. If a hydrogen cylinder is not properly secured, sudden opening of the valve can cause a cylinder to be knocked over, with all the attendant dangers resulting. Furthermore, compressed gas may act as a high explosive if suddenly released; also, on rare occasions, the friction of the gas passing through the valve can cause ignition. Immediate closing of the valve will, of course, stop the flame.
- (8) General. Because of the possibility of ignition, the general procedure of opening valves slightly to check for fouling and/or to blow dirt out of the fittings should not be practiced with hydrogen cylinders.

Minimizing the Effects of an Explosion

Although the primary safety consideration is the prevention of an explosion, it is necessary to take steps to minimize injury and damage in the event that a hydrogen explosion does occur. People should be kept as far removed as possible and the number of exposed persons should always be at a minimum. Both equipment and buildings should be designed with these aims in mind.

Equipment

The ordinary hydrogen-cylinder valve is equipped with a standard safety device for use with high-pressure gases. This usually consists of a fuse plug with a bronze disk back of it. The plug is made of fusible metal, usually melting at about 70°C (158°F). The disk breaks at a pressure below the bursting point of the cylinder. Its purpose is to prevent the pressure in the cylinder from pushing out the fuse plug.

Buildings

Buildings in which any hydrogen explosion can occur should have special explosion vents in addition to the usual venting. Explosion vents may be in the form of windows, doors, panels, walls, or even the roof. In venting a blast, steps should be taken to assure that it is restricted to an area where people or other equipment will not be harmed. Venting devices should be periodically checked to insure that they will operate in the proper manner if needed.

Fighting Fires

The best way to fight a hydrogen fire is to stop the flow of gas.

If it is necessary to extinguish the flame in order to get to a place where the hydrogen flow can be shut off, a dry chemical extinguisher is considered best. Dry chemical is no more effective than carbon dioxide in extinguishing ability; this material is recommended because it provides better shielding of the operator, gives longer range, and causes the flame to be visible. However, in the event that a fire is extinguished while the gas is still flowing, an explosive mixture, more dangerous than the fire itself, may form. Consequently, the usual method of fighting hydrogen fires is to let the fire burn itself out, while taking the proper steps to see that it does not spread.

Summary

The safety measures described in this section may be summarized as follows:

- (1) After emptying the apparatus of hydrogen, either evacuate or purge the apparatus with inert gas.
- (2) Remove air from any cylinders to be filled with hydrogen.
- (3) Segregate hydrogen cylinders from oxygen sources.
- (4) Do not guess hydrogen concentrations.
- (5) Keep cylinders away from any open flames. No smoking or welding.
- (6) Keep hydrogen away from electrical circuits.
- (7) Use nonferrous tools to avoid sparks.
- (8) Ground equipment and use conductive floors and shoes to guard against static-electricity buildup.
- (9) Protect installation against lightning.
- (10) Keep cylinders secured and do not jar cylinders.
- (11) Do not open valves suddenly.
- (12) Do not open valves to check for fouling and/or to blow out dirt.
- (13) Do not experiment with unknown or unproved devices at high pressure.

HOW TO USE THIS HANDBOOK

- (1) Determine weight of balloon and other flight equipment.
- (2) Add free lift to determine total lift.
- (3) Measure cylinder temperature.
- (4) Using data from the inflation tables, determine lifts in individual cylinders from known gage pressures. Convert pressure to atü if necessary. If total lift is in pounds, individual cylinder lift can be converted from kilograms to pounds using the lift conversion table.
- (5) If cylinders are not standard (Type 4000/6 or 4000/1), apply necessary cylinder conversion factor.
- (6) If hydrogen contains impurities, use fractional lift charts to obtain actual lift.
- (7) Note number of cylinders required to supply total lift.
- (8) If it is necessary to use only a portion of the hydrogen in the final cylinder, proceed according to the directions in the section, "Partial-Cylinder Correction".

Weight of Flight Equipment and Free Lift

An accurate determination of pressure versus lift is of use only if the gross weight of the flight equipment is known with comparable accuracy. An error in determining this weight can produce results as unsatisfactory as if an error in inflation had been made. Thus, all flight equipment should be weighed on scales which have been periodically checked and are known to be accurate.

The free lift desired for a flight must be added to the gross weight in order to determine the total lift. This is the amount of lift which must be removed from the cylinders and is thus a value obtained by consulting the inflation tables.

Temperature Measurement

It may be assumed that the cylinder surface temperature is sufficiently close to the actual hydrogen temperature to allow direct use of the surface temperature when consulting the inflation tables. An error may be brought about by the fact that equilibrium may not be attained, but, because of practical limitations, it is often most convenient simply to read the temperature of the surface of the cylinder and use this value directly.

In the usual case, one thermometer in contact with the metal surface should be sufficient. The cylinder should be kept out of the sun during the temperature measurement; otherwise, the metal surface temperature, outside air temperature, and hydrogen temperature may differ considerably.

Pressure Measurement

The pressure may be read with an ordinary laboratory test gage, provided with a dial interpretable to 0.5 atü. It is advisable that gages be re-calibrated every 6 months, or after any shock. The dead-weight testing method is preferred. Gage dials should be tapped lightly before each reading to assure the most accurate reading.

The following general precautionary measures should be taken:

- (1) Always leave a 0.5 atü (7 psig) final pressure in the cylinders to insure purity of the residual gas. The inflation tables are based on the assumption that this will be done.
- (2) Replace any valves which leak after tightening by hand.
- (3) Tap gage dials lightly before each reading.

Cylinder Conversion Factors

The inflation tables are based on the use of a "6 cubic meter" hydrogen bottle. If a container of different size is to be used, the lift at any particular temperature and pressure can be obtained by dividing the tabulated lift by a conversion factor which depends on the internal volume of this container. The conversion is shown below:

$$\text{Actual Lift From Cylinder} = \frac{\text{Lift Determined From Tables}}{\text{Conversion Factor}}$$

The conversion factors for various other cylinders are given in Table 1.

Correction for Gas Impurities

When hydrogen contains impurities other than the 1.5 per cent nitrogen on which the inflation tables are based, a lift correction, necessitated by the presence of heavier gases, can be made by the use of the fractional lift charts. Charts are given for nitrogen, oxygen, carbon dioxide, and ammonia (Figures 1, 2, 3, and 4). To use the charts, it is necessary to know only the cylinder pressure and the per cent of the impurity. Corrections can be made for the presence of a single impurity only. The actual lift is obtained by multiplying the lift determined from the inflation tables by the fractional lift determined from the fractional lift chart, as follows:

$$\text{Actual Lift} = \text{Lift Determined From Tables} \times \text{Fractional Lift.}$$

Partial-Cylinder Correction

If the required total lift cannot be obtained by completely using a given number of whole cylinders, one cylinder may be only partially used. The initial lift in the cylinder may be determined, using the inflation tables, from




FIGURE 1. GAS-IMPURITY CORRECTION CHART FOR NITROGEN




FIGURE 2. GAS-IMPURITY CORRECTION CHART FOR OXYGEN




FIGURE 3. GAS-IMPURITY CORRECTION CHART FOR CARBON DIOXIDE




FIGURE 4. GAS-IMPURITY CORRECTION CHART FOR AMMONIA

the initial pressure and temperature. By subtracting the required lift to be taken from the cylinder, the lift which should be left remaining in the cylinder can be determined. Using this remaining lift value then and knowing the cylinder temperature, the final cylinder pressure corresponding to this lift-temperature combination can be found from the inflation tables. Using the known temperature, the final equilibrium pressure can be found from the inflation tables. However, because of the reduction of pressure in the cylinder, the gas remaining in the cylinder has been cooled. Hence, the pressure reading obtained immediately after using the cylinder is not an equilibrium value, and a regain of pressure will be experienced. It is necessary, therefore, to drain the cylinder to some value below this final pressure, so that the pressure finally attained is the equilibrium value determined from the tables.

The curves for Pressure Computation for Partial Cylinders (Figure 5) indicate how much excess drain (in atü) is necessary to achieve a desired equilibrium pressure, if the initial pressure is known.

As an example, assume that the initial pressure in a cylinder is 110 atü and that, in order to get the required lift from the cylinder, the final equilibrium pressure is found to be 80 atü. As shown by the dotted lines in Figure 5, these coordinates correspond to a required excess drain of 4 atü. In this case, it is necessary to bleed the cylinder to a pressure of 76 atü in order to attain the desired final pressure, and thus yield the desired lift.

SAMPLE PROBLEMS

Example No. 1

The weight of the flight equipment and balloon is found to be 95.3 kg. The cylinders available are German Type 4000/1 containing 98.5 per cent hydrogen at 150 atü. The cylinder temperature is 6°C.

- (1) For the purposes of this example only, assume that the free lift is 7 per cent of the weight of the flight equipment and balloon. The free lift then is: $0.07 \times 95.3 = 6.67$ kg.
- (2) The gross lift then is the sum of the gross load and free lift, or: gross lift = $95.3 + 6.67 = 101.97$ kg.
- (3) From the inflation tables, at 6°C and 150 atü each cylinder contains 6.16 kg lift. The number of cylinders required is: $101.97 / 6.16 = 16$ whole cylinders + 3.41 kg lift.
- (4) If an initially full cylinder is used to obtain the additional 3.41 kg lift, the lift remaining in the cylinder after use should be: $6.16 - 3.41 = 2.75$ kg.
- (5) From the inflation tables, the cylinder would have the required remaining lift of 2.75 kg (6°C) at a final pressure of 63 atü.

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6




FIGURE 5. PRESSURE COMPUTATION FOR PARTIAL CYLINDERS OF HYDROGEN

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- (6) From the partial-cylinder correction chart, at a final pressure of 63 atm and an initial pressure of 150 atm, the pressure correction is found to be 6 atm.
- (7) Therefore, to obtain the additional 3.41 kg lift required, a full cylinder should be drained to: $63 - 6 = 57$ atm.
- (8) Thus, for the purpose of this example, use 16 full Type 4000/1 cylinders + one full cylinder drained to a pressure of 57 atm.

Example No. 2

The weight of the flight equipment and balloon is found to be 239.0 lb. The cylinders available are the United States 191-cu ft (Linde Standard) type containing 97.0 per cent hydrogen and 3.0 per cent oxygen at 2020 psig. The cylinder temperature is 55.4°F.

- (1) For the purpose of this example only, assume that the free lift is 7 per cent of the weight of the flight equipment and balloon. The free lift then is: $0.07 \times 239.0 = 16.73$ lb.
- (2) The gross lift then is the sum of the gross load and free lift, or: gross lift = $239.0 + 16.73 = 255.73$ lb.
- (3) Using the pressure conversion table, 2020 psig is found to be equivalent to 137.5 atm.
- (4) From the inflation tables, at 55.4°F and 137.5 atm, each cylinder would contain 5.55 kg lift if the standard Type 4000/1 cylinder, with 98.5 per cent hydrogen and 1.5 per cent nitrogen, were used. The lift figure of 5.55 kg must be corrected for both cylinder size and gas purity.
- (5) From the cylinder conversion table, the conversion factor for the 191-cu ft cylinder is found to be 0.949.
- (6) From the fractional lift chart for oxygen, the fractional lift for 3.0 per cent oxygen at 137.5 atm is found to be 0.970.
- (7) Applying these two corrections, the actual lift in each cylinder is found to be: $\frac{5.55}{0.949} = 5.85$ kg (lift corrected for cylinder size), and $5.85 \times 0.970 = 5.67$ kg (lift corrected for cylinder size and impurities). Doing the calculation in one step: $5.55 \times \frac{0.970}{0.949} = 5.67$ kg.
- (8) Using the lift conversion table, 5.67 kg is found to be equivalent to 12.5 lb.
- (9) Therefore, the total number of cylinders required is:
$$\frac{255.73}{12.5} = 20 \text{ cylinders} + 5.70\text{-lb lift.}$$

- (10) The 5.70-lb lift (which corresponds to 2.58-kg lift) must be obtained by partially draining a cylinder. Since the 2.58 kg is actual lift, it must be converted back to table lift.
- (11) To convert 2.58-kg actual lift to table lift, the corrections for gas purity and cylinder size must be applied, the formula being:
$$\text{Actual Lift} \times \frac{\text{Cylinder Correction}}{\text{Gas-Purity Correction}} = \text{Table Lift.}$$

$$2.58 \times \frac{0.949}{0.970} = 2.52\text{-kg table lift.}$$
- (12) This 2.52-kg table lift must be removed from a cylinder. Since each cylinder contains 5.55-kg table lift, the lift remaining, after partial draining of the cylinder, should be $5.55 - 2.52 = 3.03$ kg.
- (13) From the inflation tables (by interpolation) the cylinder would have the required remaining lift of 3.03 kg (55.4°F) at a final pressure of 71.8 atm.
- (14) Since this is a partial cylinder, use the partial-cylinder correction chart to determine what pressure the cylinder should actually be drained to. At 137.5 atm initial pressure and 71.8 atm final pressure, the correction is 5 atm. Thus, the cylinder should be drained to $71.8 - 5 = 66.8$ atm.
- (15) From the pressure conversion table (by interpolation), 66.8 atm is found to be 982.4 psig, or approximately 980 psig.
- (16) Thus, for the purpose of this example, use 20 full 191-cu ft cylinders + one full cylinder drained to 980 psig.

TABLE 1. CONVERSION FACTORS FOR STANDARD HYDROGEN CYLINDERS

Type	Nominal Internal Volume	Working Pressure	Nominal Capacity at Working Pressure	Conversion Factor
<u>German Cylinders</u>				
	<u>Liters</u>	<u>At&</u>	<u>Cubic Meters</u>	
0500/1	5	150	0.75	8.000
0500/6	5	200	1	8.000
0700/6	7	200	1.4	5.714
1000/1	10	150	1.5	4.000
1000/6	10	200	2	4.000
2000/1	20	150	3	2.000
2000/6	20	200	4	2.000
2700/1	27	150	4.05	1.481
2700/6	27	200	5.4	1.481
4000/1	40	150	6	1.000
4000/6	40	200	8	1.000
5000/6	50	200	10	0.800
<u>United States Cylinders</u>				
	<u>Cubic Feet</u>	<u>Psig</u>	<u>Cubic Feet</u>	
Ohio E	-	1800	19	8.51
Matheson 3	-	1600	25	7.57
Ohio F	-	1800	62	2.63
Matheson 2	-	1600	62	2.52
Ohio M	-	1800	90	1.82
Matheson 1A	-	1600	200	0.949
Linde Standard	-	2000	191	0.949
Ohio H	-	1800	176	0.929
National Cylinder Gas Semitrailer	8.7096	2000 2500	205 -	0.875 0.1622

Note: The inflation table is based upon the Type 4000/(1 or 6) cylinders which have a nominal internal volume of 40,000 cubic centimeters. The formula to convert for other cylinder sizes is:

$$\text{Lift in Cylinder of Interest} = \frac{\text{Lift as Computed From Table}}{\text{Conversion Factor}}$$

TABLE 2. LIFT CONVERSION

For values not given in table:
 To convert from lb to kg, multiply by 0.454
 To convert from kg to lb, multiply by 2.205

lb -	kg -														
0.1	0.05	2.6	1.18	5.1	2.32	7.6	3.45	10.1	4.59	12.6	5.72	15.1	6.85	17.6	7.99
0.2	0.09	2.7	1.22	5.2	2.36	7.7	3.49	10.2	4.63	12.7	5.76	15.2	6.89	17.7	8.03
0.3	0.14	2.8	1.27	5.3	2.41	7.8	3.54	10.3	4.68	12.8	5.81	15.3	6.94	17.8	8.08
0.4	0.18	2.9	1.31	5.4	2.46	7.9	3.58	10.4	4.72	12.9	5.85	15.4	6.98	17.9	8.12
0.5	0.23	3.0	1.36	5.5	2.49	8.0	3.63	10.5	4.76	13.0	5.90	15.5	7.03	18.0	8.16
0.6	0.27	3.1	1.41	5.6	2.54	8.1	3.68	10.6	4.81	13.1	5.95	15.6	7.08	18.1	8.21
0.7	0.32	3.2	1.45	5.7	2.58	8.2	3.72	10.7	4.85	13.2	5.99	15.7	7.12	18.2	8.25
0.8	0.36	3.3	1.50	5.8	2.63	8.3	3.77	10.8	4.90	13.3	6.04	15.8	7.17	18.3	8.30
0.9	0.41	3.4	1.54	5.9	2.68	8.4	3.81	10.9	4.94	13.4	6.08	15.9	7.21	18.4	8.34
1.0	0.45	3.5	1.59	6.0	2.72	8.5	3.86	11.0	4.99	13.5	6.12	16.0	7.26	18.5	8.39
1.1	0.50	3.6	1.64	6.1	2.77	8.6	3.91	11.1	5.04	13.6	6.17	16.1	7.31	18.6	8.44
1.2	0.54	3.7	1.69	6.2	2.81	8.7	3.95	11.2	5.09	13.7	6.21	16.2	7.35	18.7	8.48
1.3	0.59	3.8	1.73	6.3	2.86	8.8	4.00	11.3	5.14	13.8	6.26	16.3	7.40	18.8	8.53
1.4	0.64	3.9	1.77	6.4	2.90	8.9	4.04	11.4	5.18	13.9	6.30	16.4	7.44	18.9	8.57
1.5	0.68	4.0	1.81	6.5	2.95	9.0	4.08	11.5	5.22	14.0	6.35	16.5	7.48	19.0	8.62
1.6	0.73	4.1	1.86	6.6	3.00	9.1	4.13	11.6	5.27	14.1	6.40	16.6	7.53	19.1	8.67
1.7	0.77	4.2	1.90	6.7	3.04	9.2	4.17	11.7	5.32	14.2	6.44	16.7	7.57	19.2	8.71
1.8	0.82	4.3	1.95	6.8	3.09	9.3	4.22	11.8	5.36	14.3	6.49	16.8	7.62	19.3	8.76
1.9	0.86	4.4	1.99	6.9	3.13	9.4	4.26	11.9	5.40	14.4	6.54	16.9	7.66	19.4	8.80
2.0	0.91	4.5	2.04	7.0	3.18	9.5	4.31	12.0	5.44	14.5	6.58	17.0	7.71	19.5	8.85
2.1	0.95	4.6	2.09	7.1	3.23	9.6	4.36	12.1	5.49	14.6	6.63	17.1	7.76	19.6	8.90
2.2	1.00	4.7	2.13	7.2	3.27	9.7	4.40	12.2	5.53	14.7	6.67	17.2	7.80	19.7	8.94
2.3	1.04	4.8	2.18	7.3	3.32	9.8	4.45	12.3	5.58	14.8	6.72	17.3	7.85	19.8	8.99
2.4	1.09	4.9	2.22	7.4	3.36	9.9	4.49	12.4	5.62	14.9	6.76	17.4	7.89	19.9	9.03
2.5	1.13	5.0	2.27	7.5	3.40	10.0	4.54	12.5	5.67	15.0	6.80	17.5	7.94	20.0	9.07

TABLE 3. PRESSURE CONVERSION

atü - psig	atü - psig	atü - psig	atü - psig
0.5 7.3	25.5 374.7	50.5 742.1	75.5 1109.5
1.0 14.7	26.0 382.1	51.0 749.5	76.0 1116.9
1.5 22.0	26.5 389.4	51.5 756.8	76.5 1124.2
2.0 29.4	27.0 396.8	52.0 764.2	77.0 1131.6
2.5 36.7	27.5 404.1	52.5 771.5	77.5 1138.9
3.0 44.1	28.0 411.5	53.0 778.9	78.0 1146.3
3.5 51.4	28.5 418.8	53.5 786.2	78.5 1153.6
4.0 58.8	29.0 426.2	54.0 793.6	79.0 1161.0
4.5 66.1	29.5 433.5	54.5 800.9	79.5 1168.3
5.0 73.5	30.0 440.9	55.0 808.3	80.0 1175.7
5.5 80.8	30.5 448.2	55.5 815.6	80.5 1183.0
6.0 88.2	31.0 455.6	56.0 823.0	81.0 1190.4
6.5 95.5	31.5 462.9	56.5 830.3	81.5 1197.7
7.0 102.9	32.0 470.3	57.0 837.7	82.0 1205.1
7.5 110.2	32.5 477.6	57.5 845.0	82.5 1212.4
8.0 117.6	33.0 485.0	58.0 852.4	83.0 1219.8
8.5 124.9	33.5 492.3	58.5 859.7	83.5 1227.1
9.0 132.3	34.0 499.7	59.0 867.1	84.0 1234.5
9.5 139.6	34.5 507.0	59.5 874.4	84.5 1241.8
10.0 147.0	35.0 514.4	60.0 881.8	85.0 1249.2
10.5 154.3	35.5 521.7	60.5 889.1	85.5 1256.5
11.0 161.7	36.0 529.1	61.0 896.5	86.0 1263.9
11.5 169.0	36.5 536.4	61.5 903.8	86.5 1271.2
12.0 176.4	37.0 543.8	62.0 911.2	87.0 1278.6
12.5 183.7	37.5 551.1	62.5 918.5	87.5 1285.9
13.0 191.0	38.0 558.4	63.0 925.8	88.0 1293.2
13.5 198.4	38.5 565.8	63.5 933.2	88.5 1300.6
14.0 205.7	39.0 573.1	64.0 940.5	89.0 1307.9
14.5 213.1	39.5 580.5	64.5 947.9	89.5 1315.3
15.0 220.4	40.0 587.8	65.0 955.2	90.0 1322.6
15.5 227.8	40.5 595.2	65.5 962.6	90.5 1330.0
16.0 235.1	41.0 602.5	66.0 969.9	91.0 1337.3
16.5 242.5	41.5 609.9	66.5 977.3	91.5 1344.7
17.0 249.8	42.0 617.2	67.0 984.6	92.0 1352.0
17.5 257.2	42.5 624.6	67.5 992.0	92.5 1359.4
18.0 264.5	43.0 631.9	68.0 999.3	93.0 1366.7
18.5 271.9	43.5 639.3	68.5 1006.7	93.5 1374.1
19.0 279.2	44.0 646.6	69.0 1014.0	94.0 1381.4
19.5 286.6	44.5 654.0	69.5 1021.4	94.5 1388.8
20.0 293.9	45.0 661.3	70.0 1028.7	95.0 1396.1
20.5 301.3	45.5 668.7	70.5 1036.1	95.5 1403.5
21.0 308.6	46.0 676.0	71.0 1043.4	96.0 1410.8
21.5 316.0	46.5 683.4	71.5 1050.8	96.5 1418.2
22.0 323.3	47.0 690.7	72.0 1058.1	97.0 1425.5
22.5 330.7	47.5 698.1	72.5 1065.5	97.5 1432.9
23.0 338.0	48.0 705.4	73.0 1072.8	98.0 1440.2
23.5 345.4	48.5 712.8	73.5 1080.2	98.5 1447.6
24.0 352.7	49.0 720.1	74.0 1087.5	99.0 1454.9
24.5 360.1	49.5 727.5	74.5 1094.9	99.5 1462.3
25.0 367.4	50.0 734.8	75.0 1102.2	100.0 1469.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

TABLE 3. PRESSURE CONVERSION (Continued)

atü	-	psig									
100.5		1476.9	125.5		1844.3	150.5		2211.7	175.5		2579.1
101.0		1484.3	126.0		1851.7	151.0		2219.1	176.0		2586.5
101.5		1491.6	126.5		1859.0	151.5		2226.4	176.5		2593.8
102.0		1499.0	127.0		1866.4	152.0		2233.8	177.0		2601.2
102.5		1506.3	127.5		1873.7	152.5		2241.1	177.5		2608.5
103.0		1513.7	128.0		1881.1	153.0		2248.5	178.0		2615.9
103.5		1521.0	128.5		1888.4	153.5		2255.8	178.5		2623.2
104.0		1528.4	129.0		1895.8	154.0		2263.2	179.0		2630.6
104.5		1535.7	129.5		1903.1	154.5		2270.5	179.5		2637.9
105.0		1543.1	130.0		1910.5	155.0		2277.9	180.0		2645.3
105.5		1550.4	130.5		1917.8	155.5		2285.2	180.5		2652.6
106.0		1557.8	131.0		1925.2	156.0		2292.6	181.0		2660.0
106.5		1565.1	131.5		1932.5	156.5		2299.9	181.5		2667.3
107.0		1572.5	132.0		1939.9	157.0		2307.3	182.0		2674.7
107.5		1579.8	132.5		1947.2	157.5		2314.6	182.5		2682.0
108.0		1587.2	133.0		1954.6	158.0		2322.0	183.0		2689.4
108.5		1594.5	133.5		1961.9	158.5		2329.3	183.5		2696.7
109.0		1601.9	134.0		1969.3	159.0		2336.7	184.0		2704.1
109.5		1609.2	134.5		1976.6	159.5		2344.0	184.5		2711.4
110.0		1616.6	135.0		1984.0	160.0		2351.4	185.0		2718.8
110.5		1623.9	135.5		1991.3	160.5		2358.7	185.5		2726.1
111.0		1631.3	136.0		1998.7	161.0		2366.1	186.0		2733.5
111.5		1638.6	136.5		2006.0	161.5		2373.4	186.5		2740.8
112.0		1646.0	137.0		2013.4	162.0		2380.8	187.0		2748.2
112.5		1653.3	137.5		2020.7	162.5		2388.1	187.5		2755.5
113.0		1660.6	138.0		2028.0	163.0		2395.4	188.0		2762.8
113.5		1668.0	138.5		2035.4	163.5		2402.8	188.5		2770.2
114.0		1675.3	139.0		2042.7	164.0		2410.1	189.0		2777.5
114.5		1682.7	139.5		2050.1	164.5		2417.5	189.5		2784.9
115.0		1690.0	140.0		2057.4	165.0		2424.8	190.0		2792.2
115.5		1697.4	140.5		2064.8	165.5		2432.2	190.5		2799.6
116.0		1704.7	141.0		2072.1	166.0		2439.5	191.0		2806.9
116.5		1712.1	141.5		2079.5	166.5		2446.9	191.5		2814.3
117.0		1719.4	142.0		2086.8	167.0		2454.2	192.0		2821.6
117.5		1726.8	142.5		2094.2	167.5		2461.6	192.5		2829.0
118.0		1734.1	143.0		2101.5	168.0		2468.9	193.0		2836.3
118.5		1741.5	143.5		2108.9	168.5		2476.3	193.5		2843.7
119.0		1748.8	144.0		2116.2	169.0		2483.6	194.0		2851.0
119.5		1756.2	144.5		2123.6	169.5		2491.0	194.5		2858.4
120.0		1763.5	145.0		2130.9	170.0		2498.3	195.0		2865.7
120.5		1770.9	145.5		2138.3	170.5		2505.7	195.5		2873.1
121.0		1778.2	146.0		2145.6	171.0		2513.0	196.0		2880.4
121.5		1785.6	146.5		2153.0	171.5		2520.4	196.5		2887.8
122.0		1792.9	147.0		2160.3	172.0		2527.7	197.0		2895.1
122.5		1800.3	147.5		2167.7	172.5		2535.1	197.5		2902.5
123.0		1807.6	148.0		2175.0	173.0		2542.4	198.0		2909.8
123.5		1815.0	148.5		2182.4	173.5		2549.8	198.5		2917.2
124.0		1822.3	149.0		2189.7	174.0		2557.1	199.0		2924.5
124.5		1829.7	149.5		2197.1	174.5		2564.5	199.5		2931.9
125.0		1837.0	150.0		2204.4	175.0		2571.8	200.0		2939.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

INFLATION TABLES
FOR
HYDROGEN
98.5 PER CENT PURITY
IN
6 CUBIC METER CYLINDERS

0.5 to 200 atü
-40 to +40°C

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6
 PRESSURE VERSUS LIFT

				Temperature, °C		- 40.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.36	50.5	2.67	75.5	3.92
1.0	0.03	26.0	1.39	51.0	2.69	76.0	3.95
1.5	0.06	26.5	1.41	51.5	2.72	76.5	3.97
2.0	0.08	27.0	1.44	52.0	2.74	77.0	3.99
2.5	0.11	27.5	1.47	52.5	2.77	77.5	4.02
3.0	0.14	28.0	1.49	53.0	2.79	78.0	4.04
3.5	0.17	28.5	1.52	53.5	2.82	78.5	4.07
4.0	0.19	29.0	1.55	54.0	2.84	79.0	4.09
4.5	0.22	29.5	1.57	54.5	2.87	79.5	4.12
5.0	0.25	30.0	1.60	55.0	2.90	80.0	4.14
5.5	0.28	30.5	1.62	55.5	2.92	80.5	4.17
6.0	0.30	31.0	1.65	56.0	2.95	81.0	4.19
6.5	0.33	31.5	1.68	56.5	2.97	81.5	4.21
7.0	0.36	32.0	1.70	57.0	3.00	82.0	4.24
7.5	0.39	32.5	1.73	57.5	3.02	82.5	4.26
8.0	0.41	33.0	1.76	58.0	3.05	83.0	4.29
8.5	0.44	33.5	1.78	58.5	3.07	83.5	4.31
9.0	0.47	34.0	1.81	59.0	3.10	84.0	4.34
9.5	0.50	34.5	1.84	59.5	3.12	84.5	4.36
10.0	0.52	35.0	1.86	60.0	3.15	85.0	4.38
10.5	0.55	35.5	1.89	60.5	3.17	85.5	4.41
11.0	0.58	36.0	1.91	61.0	3.20	86.0	4.43
11.5	0.60	36.5	1.94	61.5	3.22	86.5	4.46
12.0	0.63	37.0	1.97	62.0	3.25	87.0	4.48
12.5	0.66	37.5	1.99	62.5	3.27	87.5	4.50
13.0	0.69	38.0	2.02	63.0	3.30	88.0	4.53
13.5	0.71	38.5	2.05	63.5	3.32	88.5	4.55
14.0	0.74	39.0	2.07	64.0	3.35	89.0	4.58
14.5	0.77	39.5	2.10	64.5	3.38	89.5	4.60
15.0	0.79	40.0	2.12	65.0	3.40	90.0	4.63
15.5	0.82	40.5	2.15	65.5	3.43	90.5	4.65
16.0	0.85	41.0	2.18	66.0	3.45	91.0	4.67
16.5	0.88	41.5	2.20	66.5	3.47	91.5	4.70
17.0	0.90	42.0	2.23	67.0	3.50	92.0	4.72
17.5	0.93	42.5	2.25	67.5	3.52	92.5	4.74
18.0	0.96	43.0	2.28	68.0	3.55	93.0	4.77
18.5	0.98	43.5	2.31	68.5	3.57	93.5	4.79
19.0	1.01	44.0	2.33	69.0	3.60	94.0	4.82
19.5	1.04	44.5	2.36	69.5	3.62	94.5	4.84
20.0	1.06	45.0	2.38	70.0	3.65	95.0	4.86
20.5	1.09	45.5	2.41	70.5	3.67	95.5	4.89
21.0	1.12	46.0	2.43	71.0	3.70	96.0	4.91
21.5	1.15	46.5	2.46	71.5	3.72	96.5	4.94
22.0	1.17	47.0	2.49	72.0	3.75	97.0	4.96
22.5	1.20	47.5	2.51	72.5	3.77	97.5	4.98
23.0	1.23	48.0	2.54	73.0	3.80	98.0	5.01
23.5	1.25	48.5	2.56	73.5	3.82	98.5	5.03
24.0	1.28	49.0	2.59	74.0	3.85	99.0	5.05
24.5	1.31	49.5	2.61	74.5	3.87	99.5	5.08
25.0	1.33	50.0	2.64	75.0	3.90	100.0	5.10

Temperature, °F - 40.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				+ 40.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	5.12	125.5	6.28	150.5	7.38	175.5	8.44
101.0	5.15	126.0	6.30	151.0	7.40	176.0	8.46
101.5	5.17	126.5	6.32	151.5	7.43	176.5	8.48
102.0	5.19	127.0	6.35	152.0	7.45	177.0	8.50
102.5	5.22	127.5	6.37	152.5	7.47	177.5	8.52
103.0	5.24	128.0	6.39	153.0	7.49	178.0	8.54
103.5	5.27	128.5	6.41	153.5	7.51	178.5	8.56
104.0	5.29	129.0	6.44	154.0	7.53	179.0	8.58
104.5	5.31	129.5	6.46	154.5	7.55	179.5	8.60
105.0	5.34	130.0	6.48	155.0	7.58	180.0	8.62
105.5	5.36	130.5	6.50	155.5	7.60	180.5	8.64
106.0	5.38	131.0	6.52	156.0	7.62	181.0	8.66
106.5	5.41	131.5	6.55	156.5	7.64	181.5	8.68
107.0	5.43	132.0	6.57	157.0	7.66	182.0	8.70
107.5	5.45	132.5	6.59	157.5	7.68	182.5	8.73
108.0	5.48	133.0	6.61	158.0	7.70	183.0	8.75
108.5	5.50	133.5	6.64	158.5	7.73	183.5	8.77
109.0	5.52	134.0	6.66	159.0	7.75	184.0	8.79
109.5	5.55	134.5	6.68	159.5	7.77	184.5	8.81
110.0	5.57	135.0	6.70	160.0	7.79	185.0	8.83
110.5	5.59	135.5	6.73	160.5	7.81	185.5	8.85
111.0	5.61	136.0	6.75	161.0	7.83	186.0	8.87
111.5	5.64	136.5	6.77	161.5	7.85	186.5	8.89
112.0	5.66	137.0	6.79	162.0	7.87	187.0	8.91
112.5	5.68	137.5	6.81	162.5	7.89	187.5	8.93
113.0	5.71	138.0	6.84	163.0	7.92	188.0	8.95
113.5	5.73	138.5	6.86	163.5	7.94	188.5	8.97
114.0	5.75	139.0	6.88	164.0	7.96	189.0	8.99
114.5	5.78	139.5	6.90	164.5	7.98	189.5	9.01
115.0	5.80	140.0	6.92	165.0	8.00	190.0	9.03
115.5	5.82	140.5	6.95	165.5	8.02	190.5	9.05
116.0	5.85	141.0	6.97	166.0	8.04	191.0	9.07
116.5	5.87	141.5	6.99	166.5	8.06	191.5	9.09
117.0	5.89	142.0	7.01	167.0	8.08	192.0	9.11
117.5	5.91	142.5	7.03	167.5	8.11	192.5	9.13
118.0	5.94	143.0	7.06	168.0	8.13	193.0	9.15
118.5	5.96	143.5	7.08	168.5	8.15	193.5	9.17
119.0	5.98	144.0	7.10	169.0	8.17	194.0	9.19
119.5	6.01	144.5	7.12	169.5	8.19	194.5	9.21
120.0	6.03	145.0	7.14	170.0	8.21	195.0	9.23
120.5	6.05	145.5	7.17	170.5	8.23	195.5	9.25
121.0	6.07	146.0	7.19	171.0	8.25	196.0	9.27
121.5	6.10	146.5	7.21	171.5	8.27	196.5	9.29
122.0	6.12	147.0	7.23	172.0	8.29	197.0	9.31
122.5	6.14	147.5	7.25	172.5	8.31	197.5	9.33
123.0	6.16	148.0	7.27	173.0	8.33	198.0	9.35
123.5	6.19	148.5	7.30	173.5	8.36	198.5	9.37
124.0	6.21	149.0	7.32	174.0	8.38	199.0	9.39
124.5	6.23	149.5	7.34	174.5	8.40	199.5	9.41
125.0	6.26	150.0	7.36	175.0	8.42	200.0	9.43

Temperature, °F + 40.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C

= 39.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.35	50.5	2.65	75.5	3.90
1.0	0.03	26.0	1.38	51.0	2.68	76.0	3.93
1.5	0.06	26.5	1.41	51.5	2.71	76.5	3.95
2.0	0.08	27.0	1.43	52.0	2.73	77.0	3.98
2.5	0.11	27.5	1.46	52.5	2.76	77.5	4.00
3.0	0.14	28.0	1.49	53.0	2.78	78.0	4.03
3.5	0.17	28.5	1.51	53.5	2.81	78.5	4.05
4.0	0.19	29.0	1.54	54.0	2.83	79.0	4.07
4.5	0.22	29.5	1.57	54.5	2.86	79.5	4.10
5.0	0.25	30.0	1.59	55.0	2.88	80.0	4.12
5.5	0.27	30.5	1.62	55.5	2.91	80.5	4.15
6.0	0.30	31.0	1.64	56.0	2.93	81.0	4.17
6.5	0.33	31.5	1.67	56.5	2.96	81.5	4.20
7.0	0.36	32.0	1.70	57.0	2.98	82.0	4.22
7.5	0.38	32.5	1.72	57.5	3.01	82.5	4.24
8.0	0.41	33.0	1.75	58.0	3.03	83.0	4.27
8.5	0.44	33.5	1.78	58.5	3.06	83.5	4.29
9.0	0.47	34.0	1.80	59.0	3.09	84.0	4.32
9.5	0.49	34.5	1.83	59.5	3.11	84.5	4.34
10.0	0.52	35.0	1.85	60.0	3.14	85.0	4.37
10.5	0.55	35.5	1.88	60.5	3.16	85.5	4.39
11.0	0.57	36.0	1.91	61.0	3.19	86.0	4.41
11.5	0.60	36.5	1.93	61.5	3.21	86.5	4.44
12.0	0.63	37.0	1.96	62.0	3.24	87.0	4.46
12.5	0.66	37.5	1.98	62.5	3.26	87.5	4.49
13.0	0.68	38.0	2.01	63.0	3.29	88.0	4.51
13.5	0.71	38.5	2.04	63.5	3.31	88.5	4.53
14.0	0.74	39.0	2.06	64.0	3.34	89.0	4.56
14.5	0.76	39.5	2.09	64.5	3.36	89.5	4.58
15.0	0.79	40.0	2.11	65.0	3.39	90.0	4.61
15.5	0.82	40.5	2.14	65.5	3.41	90.5	4.63
16.0	0.85	41.0	2.17	66.0	3.44	91.0	4.65
16.5	0.87	41.5	2.19	66.5	3.46	91.5	4.68
17.0	0.90	42.0	2.22	67.0	3.48	92.0	4.70
17.5	0.93	42.5	2.24	67.5	3.51	92.5	4.72
18.0	0.95	43.0	2.27	68.0	3.53	93.0	4.75
18.5	0.98	43.5	2.30	68.5	3.56	93.5	4.77
19.0	1.01	44.0	2.32	69.0	3.58	94.0	4.80
19.5	1.03	44.5	2.35	69.5	3.61	94.5	4.82
20.0	1.06	45.0	2.37	70.0	3.63	95.0	4.84
20.5	1.09	45.5	2.40	70.5	3.66	95.5	4.87
21.0	1.11	46.0	2.42	71.0	3.68	96.0	4.89
21.5	1.14	46.5	2.45	71.5	3.71	96.5	4.91
22.0	1.17	47.0	2.48	72.0	3.73	97.0	4.94
22.5	1.19	47.5	2.50	72.5	3.76	97.5	4.96
23.0	1.22	48.0	2.53	73.0	3.78	98.0	4.99
23.5	1.25	48.5	2.55	73.5	3.81	98.5	5.01
24.0	1.27	49.0	2.58	74.0	3.83	99.0	5.03
24.5	1.30	49.5	2.60	74.5	3.86	99.5	5.06
25.0	1.33	50.0	2.63	75.0	3.88	100.0	5.08

Temperature, °F

= 38.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 39.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	5.10	125.5	6.25	150.5	7.35	175.5	8.40				
101.0	5.13	126.0	6.27	151.0	7.37	176.0	8.42				
101.5	5.15	126.5	6.30	151.5	7.39	176.5	8.44				
102.0	5.17	127.0	6.32	152.0	7.42	177.0	8.46				
102.5	5.20	127.5	6.34	152.5	7.44	177.5	8.49				
103.0	5.22	128.0	6.36	153.0	7.46	178.0	8.51				
103.5	5.24	128.5	6.39	153.5	7.48	178.5	8.53				
104.0	5.27	129.0	6.41	154.0	7.50	179.0	8.55				
104.5	5.29	129.5	6.43	154.5	7.52	179.5	8.57				
105.0	5.31	130.0	6.45	155.0	7.54	180.0	8.59				
105.5	5.34	130.5	6.48	155.5	7.57	180.5	8.61				
106.0	5.36	131.0	6.50	156.0	7.59	181.0	8.63				
106.5	5.38	131.5	6.52	156.5	7.61	181.5	8.65				
107.0	5.41	132.0	6.54	157.0	7.63	182.0	8.67				
107.5	5.43	132.5	6.56	157.5	7.65	182.5	8.69				
108.0	5.45	133.0	6.59	158.0	7.67	183.0	8.71				
108.5	5.48	133.5	6.61	158.5	7.69	183.5	8.73				
109.0	5.50	134.0	6.63	159.0	7.71	184.0	8.75				
109.5	5.52	134.5	6.65	159.5	7.74	184.5	8.77				
110.0	5.54	135.0	6.67	160.0	7.76	185.0	8.79				
110.5	5.57	135.5	6.70	160.5	7.78	185.5	8.81				
111.0	5.59	136.0	6.72	161.0	7.80	186.0	8.83				
111.5	5.61	136.5	6.74	161.5	7.82	186.5	8.85				
112.0	5.64	137.0	6.76	162.0	7.84	187.0	8.87				
112.5	5.66	137.5	6.79	162.5	7.86	187.5	8.89				
113.0	5.68	138.0	6.81	163.0	7.88	188.0	8.91				
113.5	5.71	138.5	6.83	163.5	7.90	188.5	8.93				
114.0	5.73	139.0	6.85	164.0	7.93	189.0	8.95				
114.5	5.75	139.5	6.87	164.5	7.95	189.5	8.97				
115.0	5.77	140.0	6.90	165.0	7.97	190.0	8.99				
115.5	5.80	140.5	6.92	165.5	7.99	190.5	9.01				
116.0	5.82	141.0	6.94	166.0	8.01	191.0	9.03				
116.5	5.84	141.5	6.96	166.5	8.03	191.5	9.05				
117.0	5.87	142.0	6.98	167.0	8.05	192.0	9.07				
117.5	5.89	142.5	7.00	167.5	8.07	192.5	9.09				
118.0	5.91	143.0	7.03	168.0	8.09	193.0	9.11				
118.5	5.93	143.5	7.05	168.5	8.11	193.5	9.13				
119.0	5.96	144.0	7.07	169.0	8.13	194.0	9.15				
119.5	5.98	144.5	7.09	169.5	8.16	194.5	9.17				
120.0	6.00	145.0	7.11	170.0	8.18	195.0	9.19				
120.5	6.03	145.5	7.14	170.5	8.20	195.5	9.21				
121.0	6.05	146.0	7.16	171.0	8.22	196.0	9.23				
121.5	6.07	146.5	7.18	171.5	8.24	196.5	9.25				
122.0	6.09	147.0	7.20	172.0	8.26	197.0	9.27				
122.5	6.12	147.5	7.22	172.5	8.28	197.5	9.29				
123.0	6.14	148.0	7.24	173.0	8.30	198.0	9.31				
123.5	6.16	148.5	7.26	173.5	8.32	198.5	9.33				
124.0	6.18	149.0	7.29	174.0	8.34	199.0	9.35				
124.5	6.21	149.5	7.31	174.5	8.36	199.5	9.37				
125.0	6.23	150.0	7.33	175.0	8.38	200.0	9.39				

Temperature, °F

- 38.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 38.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.35	50.5	2.64	75.5	3.89
1.0	0.03	26.0	1.37	51.0	2.67	76.0	3.91
1.5	0.05	26.5	1.40	51.5	2.69	76.5	3.94
2.0	0.08	27.0	1.43	52.0	2.72	77.0	3.96
2.5	0.11	27.5	1.45	52.5	2.74	77.5	3.98
3.0	0.14	28.0	1.48	53.0	2.77	78.0	4.01
3.5	0.16	28.5	1.51	53.5	2.80	78.5	4.03
4.0	0.19	29.0	1.53	54.0	2.82	79.0	4.06
4.5	0.22	29.5	1.56	54.5	2.85	79.5	4.08
5.0	0.25	30.0	1.58	55.0	2.87	80.0	4.11
5.5	0.27	30.5	1.61	55.5	2.90	80.5	4.13
6.0	0.30	31.0	1.64	56.0	2.92	81.0	4.15
6.5	0.33	31.5	1.66	56.5	2.95	81.5	4.18
7.0	0.36	32.0	1.69	57.0	2.97	82.0	4.20
7.5	0.38	32.5	1.72	57.5	3.00	82.5	4.23
8.0	0.41	33.0	1.74	58.0	3.02	83.0	4.25
8.5	0.44	33.5	1.77	58.5	3.05	83.5	4.27
9.0	0.46	34.0	1.79	59.0	3.07	84.0	4.30
9.5	0.49	34.5	1.82	59.5	3.10	84.5	4.32
10.0	0.52	35.0	1.85	60.0	3.12	85.0	4.35
10.5	0.55	35.5	1.87	60.5	3.15	85.5	4.37
11.0	0.57	36.0	1.90	61.0	3.17	86.0	4.39
11.5	0.60	36.5	1.92	61.5	3.20	86.5	4.42
12.0	0.63	37.0	1.95	62.0	3.22	87.0	4.44
12.5	0.65	37.5	1.98	62.5	3.25	87.5	4.47
13.0	0.68	38.0	2.00	63.0	3.27	88.0	4.49
13.5	0.71	38.5	2.03	63.5	3.30	88.5	4.51
14.0	0.73	39.0	2.05	64.0	3.32	89.0	4.54
14.5	0.76	39.5	2.08	64.5	3.35	89.5	4.56
15.0	0.79	40.0	2.11	65.0	3.37	90.0	4.59
15.5	0.81	40.5	2.13	65.5	3.40	90.5	4.61
16.0	0.84	41.0	2.16	66.0	3.42	91.0	4.63
16.5	0.87	41.5	2.18	66.5	3.45	91.5	4.66
17.0	0.90	42.0	2.21	67.0	3.47	92.0	4.68
17.5	0.92	42.5	2.23	67.5	3.49	92.5	4.70
18.0	0.95	43.0	2.26	68.0	3.52	93.0	4.73
18.5	0.98	43.5	2.29	68.5	3.54	93.5	4.75
19.0	1.00	44.0	2.31	69.0	3.57	94.0	4.78
19.5	1.03	44.5	2.34	69.5	3.59	94.5	4.80
20.0	1.06	45.0	2.36	70.0	3.62	95.0	4.82
20.5	1.08	45.5	2.39	70.5	3.64	95.5	4.85
21.0	1.11	46.0	2.41	71.0	3.67	96.0	4.87
21.5	1.14	46.5	2.44	71.5	3.69	96.5	4.89
22.0	1.16	47.0	2.47	72.0	3.72	97.0	4.92
22.5	1.19	47.5	2.49	72.5	3.74	97.5	4.94
23.0	1.22	48.0	2.52	73.0	3.77	98.0	4.96
23.5	1.24	48.5	2.54	73.5	3.79	98.5	4.99
24.0	1.27	49.0	2.57	74.0	3.81	99.0	5.01
24.5	1.29	49.5	2.59	74.5	3.84	99.5	5.03
25.0	1.32	50.0	2.62	75.0	3.86	100.0	5.06

Temperature, °F - 36.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 38.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	5.08	125.5	6.23	150.5	7.32	175.5	8.37				
101.0	5.10	126.0	6.25	151.0	7.34	176.0	8.39				
101.5	5.13	126.5	6.27	151.5	7.36	176.5	8.41				
102.0	5.15	127.0	6.29	152.0	7.38	177.0	8.43				
102.5	5.17	127.5	6.31	152.5	7.41	177.5	8.45				
103.0	5.20	128.0	6.34	153.0	7.43	178.0	8.47				
103.5	5.22	128.5	6.36	153.5	7.45	178.5	8.49				
104.0	5.24	129.0	6.38	154.0	7.47	179.0	8.51				
104.5	5.27	129.5	6.40	154.5	7.49	179.5	8.53				
105.0	5.29	130.0	6.43	155.0	7.51	180.0	8.55				
105.5	5.31	130.5	6.45	155.5	7.53	180.5	8.57				
106.0	5.34	131.0	6.47	156.0	7.56	181.0	8.59				
106.5	5.36	131.5	6.49	156.5	7.58	181.5	8.61				
107.0	5.38	132.0	6.51	157.0	7.60	182.0	8.63				
107.5	5.41	132.5	6.54	157.5	7.62	182.5	8.65				
108.0	5.43	133.0	6.56	158.0	7.64	183.0	8.67				
108.5	5.45	133.5	6.58	158.5	7.66	183.5	8.69				
109.0	5.48	134.0	6.60	159.0	7.68	184.0	8.71				
109.5	5.50	134.5	6.63	159.5	7.70	184.5	8.73				
110.0	5.52	135.0	6.65	160.0	7.72	185.0	8.75				
110.5	5.54	135.5	6.67	160.5	7.75	185.5	8.77				
111.0	5.57	136.0	6.69	161.0	7.77	186.0	8.79				
111.5	5.59	136.5	6.71	161.5	7.79	186.5	8.81				
112.0	5.61	137.0	6.74	162.0	7.81	187.0	8.84				
112.5	5.64	137.5	6.76	162.5	7.83	187.5	8.86				
113.0	5.66	138.0	6.78	163.0	7.85	188.0	8.88				
113.5	5.68	138.5	6.80	163.5	7.87	188.5	8.90				
114.0	5.71	139.0	6.82	164.0	7.89	189.0	8.92				
114.5	5.73	139.5	6.84	164.5	7.91	189.5	8.94				
115.0	5.75	140.0	6.87	165.0	7.93	190.0	8.96				
115.5	5.77	140.5	6.89	165.5	7.96	190.5	8.98				
116.0	5.80	141.0	6.91	166.0	7.98	191.0	9.00				
116.5	5.82	141.5	6.93	166.5	8.00	191.5	9.01				
117.0	5.84	142.0	6.95	167.0	8.02	192.0	9.03				
117.5	5.86	142.5	6.98	167.5	8.04	192.5	9.05				
118.0	5.89	143.0	7.00	168.0	8.06	193.0	9.07				
118.5	5.91	143.5	7.02	168.5	8.08	193.5	9.09				
119.0	5.93	144.0	7.04	169.0	8.10	194.0	9.11				
119.5	5.96	144.5	7.06	169.5	8.12	194.5	9.13				
120.0	5.98	145.0	7.08	170.0	8.14	195.0	9.15				
120.5	6.00	145.5	7.11	170.5	8.16	195.5	9.17				
121.0	6.02	146.0	7.13	171.0	8.18	196.0	9.19				
121.5	6.05	146.5	7.15	171.5	8.20	196.5	9.21				
122.0	6.07	147.0	7.17	172.0	8.22	197.0	9.23				
122.5	6.09	147.5	7.19	172.5	8.25	197.5	9.25				
123.0	6.11	148.0	7.21	173.0	8.27	198.0	9.27				
123.5	6.14	148.5	7.23	173.5	8.29	198.5	9.29				
124.0	6.16	149.0	7.26	174.0	8.31	199.0	9.31				
124.5	6.18	149.5	7.28	174.5	8.33	199.5	9.33				
125.0	6.20	150.0	7.30	175.0	8.35	200.0	9.35				

Temperature, °F

- 36.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C						- 37.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.34	50.5	2.63	75.5	3.87
1.0	0.03	26.0	1.37	51.0	2.66	76.0	3.90
1.5	0.05	26.5	1.39	51.5	2.68	76.5	3.92
2.0	0.08	27.0	1.42	52.0	2.71	77.0	3.94
2.5	0.11	27.5	1.45	52.5	2.73	77.5	3.97
3.0	0.14	28.0	1.47	53.0	2.76	78.0	3.99
3.5	0.16	28.5	1.50	53.5	2.78	78.5	4.02
4.0	0.19	29.0	1.53	54.0	2.81	79.0	4.04
4.5	0.22	29.5	1.55	54.5	2.83	79.5	4.06
5.0	0.25	30.0	1.58	55.0	2.86	80.0	4.09
5.5	0.27	30.5	1.60	55.5	2.88	80.5	4.11
6.0	0.30	31.0	1.63	56.0	2.91	81.0	4.14
6.5	0.33	31.5	1.66	56.5	2.93	81.5	4.16
7.0	0.35	32.0	1.68	57.0	2.96	82.0	4.18
7.5	0.38	32.5	1.71	57.5	2.98	82.5	4.21
8.0	0.41	33.0	1.73	58.0	3.01	83.0	4.23
8.5	0.44	33.5	1.76	58.5	3.03	83.5	4.26
9.0	0.46	34.0	1.79	59.0	3.06	84.0	4.28
9.5	0.49	34.5	1.81	59.5	3.08	84.5	4.30
10.0	0.52	35.0	1.84	60.0	3.11	85.0	4.33
10.5	0.54	35.5	1.86	60.5	3.13	85.5	4.35
11.0	0.57	36.0	1.89	61.0	3.16	86.0	4.38
11.5	0.60	36.5	1.92	61.5	3.18	86.5	4.40
12.0	0.62	37.0	1.94	62.0	3.21	87.0	4.42
12.5	0.65	37.5	1.97	62.5	3.23	87.5	4.45
13.0	0.68	38.0	1.99	63.0	3.26	88.0	4.47
13.5	0.70	38.5	2.02	63.5	3.28	88.5	4.50
14.0	0.73	39.0	2.05	64.0	3.31	89.0	4.52
14.5	0.76	39.5	2.07	64.5	3.33	89.5	4.54
15.0	0.78	40.0	2.10	65.0	3.36	90.0	4.57
15.5	0.81	40.5	2.12	65.5	3.38	90.5	4.59
16.0	0.84	41.0	2.15	66.0	3.41	91.0	4.61
16.5	0.86	41.5	2.17	66.5	3.43	91.5	4.64
17.0	0.89	42.0	2.20	67.0	3.46	92.0	4.66
17.5	0.92	42.5	2.22	67.5	3.48	92.5	4.68
18.0	0.94	43.0	2.25	68.0	3.50	93.0	4.71
18.5	0.97	43.5	2.28	68.5	3.53	93.5	4.73
19.0	1.00	44.0	2.30	69.0	3.55	94.0	4.76
19.5	1.02	44.5	2.33	69.5	3.58	94.5	4.78
20.0	1.05	45.0	2.35	70.0	3.60	95.0	4.80
20.5	1.08	45.5	2.38	70.5	3.63	95.5	4.83
21.0	1.10	46.0	2.40	71.0	3.65	96.0	4.85
21.5	1.13	46.5	2.43	71.5	3.68	96.5	4.87
22.0	1.16	47.0	2.45	72.0	3.70	97.0	4.90
22.5	1.18	47.5	2.48	72.5	3.73	97.5	4.92
23.0	1.21	48.0	2.51	73.0	3.75	98.0	4.94
23.5	1.24	48.5	2.53	73.5	3.77	98.5	4.97
24.0	1.26	49.0	2.56	74.0	3.80	99.0	4.99
24.5	1.29	49.5	2.58	74.5	3.82	99.5	5.01
25.0	1.32	50.0	2.61	75.0	3.85	100.0	5.04

Temperature, °F

- 34.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C											
				= 37.0							
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	5.06	125.5	6.20	150.5	7.29	175.5	8.33				
101.0	5.08	126.0	6.22	151.0	7.31	176.0	8.35				
101.5	5.11	126.5	6.24	151.5	7.33	176.5	8.38				
102.0	5.13	127.0	6.27	152.0	7.35	177.0	8.40				
102.5	5.15	127.5	6.29	152.5	7.38	177.5	8.42				
103.0	5.18	128.0	6.31	153.0	7.40	178.0	8.44				
103.5	5.20	128.5	6.33	153.5	7.42	178.5	8.46				
104.0	5.22	129.0	6.35	154.0	7.44	179.0	8.48				
104.5	5.25	129.5	6.38	154.5	7.46	179.5	8.50				
105.0	5.27	130.0	6.40	155.0	7.48	180.0	8.52				
105.5	5.29	130.5	6.42	155.5	7.50	180.5	8.54				
106.0	5.31	131.0	6.44	156.0	7.52	181.0	8.56				
106.5	5.34	131.5	6.47	156.5	7.55	181.5	8.58				
107.0	5.36	132.0	6.49	157.0	7.57	182.0	8.60				
107.5	5.38	132.5	6.51	157.5	7.59	182.5	8.62				
108.0	5.41	133.0	6.53	158.0	7.61	183.0	8.64				
108.5	5.43	133.5	6.55	158.5	7.63	183.5	8.66				
109.0	5.45	134.0	6.58	159.0	7.65	184.0	8.68				
109.5	5.48	134.5	6.60	159.5	7.67	184.5	8.70				
110.0	5.50	135.0	6.62	160.0	7.69	185.0	8.72				
110.5	5.52	135.5	6.64	160.5	7.71	185.5	8.74				
111.0	5.54	136.0	6.66	161.0	7.73	186.0	8.76				
111.5	5.57	136.5	6.69	161.5	7.76	186.5	8.78				
112.0	5.59	137.0	6.71	162.0	7.78	187.0	8.80				
112.5	5.61	137.5	6.73	162.5	7.80	187.5	8.82				
113.0	5.64	138.0	6.75	163.0	7.82	188.0	8.84				
113.5	5.66	138.5	6.77	163.5	7.84	188.5	8.86				
114.0	5.68	139.0	6.79	164.0	7.86	189.0	8.88				
114.5	5.70	139.5	6.82	164.5	7.88	189.5	8.90				
115.0	5.73	140.0	6.84	165.0	7.90	190.0	8.92				
115.5	5.75	140.5	6.86	165.5	7.92	190.5	8.94				
116.0	5.77	141.0	6.88	166.0	7.94	191.0	8.96				
116.5	5.79	141.5	6.90	166.5	7.96	191.5	8.98				
117.0	5.82	142.0	6.92	167.0	7.98	192.0	9.00				
117.5	5.84	142.5	6.95	167.5	8.01	192.5	9.02				
118.0	5.86	143.0	6.97	168.0	8.03	193.0	9.04				
118.5	5.89	143.5	6.99	168.5	8.05	193.5	9.06				
119.0	5.91	144.0	7.01	169.0	8.07	194.0	9.08				
119.5	5.93	144.5	7.03	169.5	8.09	1	•				
120.0	5.95	145.0	7.05	170.0	8.11	195.0	9.12				
120.5	5.98	145.5	7.08	170.5	8.13	195.5	9.14				
121.0	6.00	146.0	7.10	171.0	8.15	196.0	9.16				
121.5	6.02	146.5	7.12	171.5	8.17	196.5	9.18				
122.0	6.04	147.0	7.14	172.0	8.19	197.0	9.20				
122.5	6.07	147.5	7.16	172.5	8.21	197.5	9.21				
123.0	6.09	148.0	7.18	173.0	8.23	198.0	9.23				
123.5	6.11	148.5	7.20	173.5	8.25	198.5	9.25				
124.0	6.13	149.0	7.23	174.0	8.27	199.0	9.27				
124.5	6.15	149.5	7.25	174.5	8.29	199.5	9.29				
125.0	6.18	150.0	7.27	175.0	8.31	200.0	9.31				

Temperature, °F = 34.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				- 36.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg		
0.5	0.00	25.5	1.34	50.5	2.62	75.5	3.85		
1.0	0.03	26.0	1.36	51.0	2.65	76.0	3.88		
1.5	0.05	26.5	1.39	51.5	2.67	76.5	3.90		
2.0	0.08	27.0	1.41	52.0	2.70	77.0	3.93		
2.5	0.11	27.5	1.44	52.5	2.72	77.5	3.95		
3.0	0.14	28.0	1.47	53.0	2.75	78.0	3.98		
3.5	0.16	28.5	1.49	53.5	2.77	78.5	4.00		
4.0	0.19	29.0	1.52	54.0	2.80	79.0	4.02		
4.5	0.22	29.5	1.55	54.5	2.82	79.5	4.05		
5.0	0.24	30.0	1.57	55.0	2.85	80.0	4.07		
5.5	0.27	30.5	1.60	55.5	2.87	80.5	4.10		
6.0	0.30	31.0	1.62	56.0	2.90	81.0	4.12		
6.5	0.33	31.5	1.65	56.5	2.92	81.5	4.14		
7.0	0.35	32.0	1.68	57.0	2.95	82.0	4.17		
7.5	0.38	32.5	1.70	57.5	2.97	82.5	4.19		
8.0	0.41	33.0	1.73	58.0	3.00	83.0	4.22		
8.5	0.43	33.5	1.75	58.5	3.02	83.5	4.24		
9.0	0.46	34.0	1.78	59.0	3.05	84.0	4.26		
9.5	0.49	34.5	1.80	59.5	3.07	84.5	4.29		
10.0	0.51	35.0	1.83	60.0	3.10	85.0	4.31		
10.5	0.54	35.5	1.86	60.5	3.12	85.5	4.33		
11.0	0.57	36.0	1.88	61.0	3.15	86.0	4.36		
11.5	0.59	36.5	1.91	61.5	3.17	86.5	4.38		
12.0	0.62	37.0	1.93	62.0	3.19	87.0	4.41		
12.5	0.65	37.5	1.96	62.5	3.22	87.5	4.43		
13.0	0.67	38.0	1.98	63.0	3.24	88.0	4.45		
13.5	0.70	38.5	2.01	63.5	3.27	88.5	4.48		
14.0	0.73	39.0	2.04	64.0	3.29	89.0	4.50		
14.5	0.75	39.5	2.06	64.5	3.32	89.5	4.52		
15.0	0.78	40.0	2.09	65.0	3.34	90.0	4.55		
15.5	0.81	40.5	2.11	65.5	3.37	90.5	4.57		
16.0	0.83	41.0	2.14	66.0	3.39	91.0	4.59		
16.5	0.86	41.5	2.16	66.5	3.42	91.5	4.62		
17.0	0.89	42.0	2.19	67.0	3.44	92.0	4.64		
17.5	0.91	42.5	2.22	67.5	3.47	92.5	4.67		
18.0	0.94	43.0	2.24	68.0	3.49	93.0	4.69		
18.5	0.97	43.5	2.27	68.5	3.51	93.5	4.71		
19.0	0.99	44.0	2.29	69.0	3.54	94.0	4.74		
19.5	1.02	44.5	2.32	69.5	3.56	94.5	4.76		
20.0	1.05	45.0	2.34	70.0	3.59	95.0	4.78		
20.5	1.07	45.5	2.37	70.5	3.61	95.5	4.81		
21.0	1.10	46.0	2.39	71.0	3.64	96.0	4.83		
21.5	1.13	46.5	2.42	71.5	3.66	96.5	4.85		
22.0	1.15	47.0	2.44	72.0	3.69	97.0	4.88		
22.5	1.18	47.5	2.47	72.5	3.71	97.5	4.90		
23.0	1.20	48.0	2.49	73.0	3.73	98.0	4.92		
23.5	1.23	48.5	2.52	73.5	3.76	98.5	4.95		
24.0	1.26	49.0	2.55	74.0	3.78	99.0	4.97		
24.5	1.28	49.5	2.57	74.5	3.81	99.5	4.99		
25.0	1.31	50.0	2.60	75.0	3.83	100.0	5.02		

Temperature, °F

- 32.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 36.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	5.04	125.5	6.17	150.5	7.26	175.5	8.30				
101.0	5.06	126.0	6.20	151.0	7.28	176.0	8.32				
101.5	5.08	126.5	6.22	151.5	7.30	176.5	8.34				
102.0	5.11	127.0	6.24	152.0	7.32	177.0	8.36				
102.5	5.13	127.5	6.26	152.5	7.35	177.5	8.38				
103.0	5.15	128.0	6.28	153.0	7.37	178.0	8.40				
103.5	5.18	128.5	6.31	153.5	7.39	178.5	8.42				
104.0	5.20	129.0	6.33	154.0	7.41	179.0	8.44				
104.5	5.22	129.5	6.35	154.5	7.43	179.5	8.46				
105.0	5.25	130.0	6.37	155.0	7.45	180.0	8.48				
105.5	5.27	130.5	6.39	155.5	7.47	180.5	8.50				
106.0	5.29	131.0	6.42	156.0	7.49	181.0	8.52				
106.5	5.32	131.5	6.44	156.5	7.51	181.5	8.54				
107.0	5.34	132.0	6.46	157.0	7.54	182.0	8.56				
107.5	5.36	132.5	6.48	157.5	7.56	182.5	8.58				
108.0	5.38	133.0	6.50	158.0	7.58	183.0	8.60				
108.5	5.41	133.5	6.53	158.5	7.60	183.5	8.62				
109.0	5.43	134.0	6.55	159.0	7.62	184.0	8.64				
109.5	5.45	134.5	6.57	159.5	7.64	184.5	8.66				
110.0	5.48	135.0	6.59	160.0	7.66	185.0	8.68				
110.5	5.50	135.5	6.61	160.5	7.68	185.5	8.70				
111.0	5.52	136.0	6.64	161.0	7.70	186.0	8.72				
111.5	5.54	136.5	6.66	161.5	7.72	186.5	8.74				
112.0	5.57	137.0	6.68	162.0	7.74	187.0	8.76				
112.5	5.59	137.5	6.70	162.5	7.77	187.5	8.78				
113.0	5.61	138.0	6.72	163.0	7.79	188.0	8.80				
113.5	5.63	138.5	6.74	163.5	7.81	188.5	8.82				
114.0	5.66	139.0	6.77	164.0	7.83	189.0	8.84				
114.5	5.68	139.5	6.79	164.5	7.85	189.5	8.86				
115.0	5.70	140.0	6.81	165.0	7.87	190.0	8.88				
115.5	5.73	140.5	6.83	165.5	7.89	190.5	8.90				
116.0	5.75	141.0	6.85	166.0	7.91	191.0	8.92				
116.5	5.77	141.5	6.87	166.5	7.93	191.5	8.94				
117.0	5.79	142.0	6.90	167.0	7.95	192.0	8.96				
117.5	5.82	142.5	6.92	167.5	7.97	192.5	8.98				
118.0	5.84	143.0	6.94	168.0	7.99	193.0	9.00				
118.5	5.86	143.5	6.96	168.5	8.01	193.5	9.02				
119.0	5.88	144.0	6.98	169.0	8.03	194.0	9.04				
119.5	5.91	144.5	7.00	169.5	8.05	194.5	9.06				
120.0	5.93	145.0	7.03	170.0	8.08	195.0	9.08				
120.5	5.95	145.5	7.05	170.5	8.10	195.5	9.10				
121.0	5.97	146.0	7.07	171.0	8.12	196.0	9.12				
121.5	6.00	146.5	7.09	171.5	8.14	196.5	9.14				
122.0	6.02	147.0	7.11	172.0	8.16	197.0	9.16				
122.5	6.04	147.5	7.13	172.5	8.18	197.5	9.18				
123.0	6.06	148.0	7.15	173.0	8.20	198.0	9.20				
123.5	6.08	148.5	7.18	173.5	8.22	198.5	9.22				
124.0	6.11	149.0	7.20	174.0	8.24	199.0	9.24				
124.5	6.13	149.5	7.22	174.5	8.26	199.5	9.26				
125.0	6.15	150.0	7.24	175.0	8.28	200.0	9.28				

Temperature, °F - 32.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 35.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.33	50.5	2.61	75.5	3.84	
1.0	0.03	26.0	1.36	51.0	2.63	76.0	3.86	
1.5	0.05	26.5	1.38	51.5	2.66	76.5	3.89	
2.0	0.08	27.0	1.41	52.0	2.69	77.0	3.91	
2.5	0.11	27.5	1.43	52.5	2.71	77.5	3.93	
3.0	0.14	28.0	1.46	53.0	2.74	78.0	3.96	
3.5	0.16	28.5	1.49	53.5	2.76	78.5	3.98	
4.0	0.19	29.0	1.51	54.0	2.78	79.0	4.01	
4.5	0.22	29.5	1.54	54.5	2.81	79.5	4.03	
5.0	0.24	30.0	1.56	55.0	2.83	80.0	4.05	
5.5	0.27	30.5	1.59	55.5	2.86	80.5	4.08	
6.0	0.30	31.0	1.62	56.0	2.88	81.0	4.10	
6.5	0.32	31.5	1.64	56.5	2.91	81.5	4.13	
7.0	0.35	32.0	1.67	57.0	2.93	82.0	4.15	
7.5	0.38	32.5	1.69	57.5	2.96	82.5	4.17	
8.0	0.40	33.0	1.72	58.0	2.98	83.0	4.20	
8.5	0.43	33.5	1.75	58.5	3.01	83.5	4.22	
9.0	0.46	34.0	1.77	59.0	3.03	84.0	4.24	
9.5	0.48	34.5	1.80	59.5	3.06	84.5	4.27	
10.0	0.51	35.0	1.82	60.0	3.08	85.0	4.29	
10.5	0.54	35.5	1.85	60.5	3.11	85.5	4.32	
11.0	0.57	36.0	1.87	61.0	3.13	86.0	4.34	
11.5	0.59	36.5	1.90	61.5	3.16	86.5	4.36	
12.0	0.62	37.0	1.93	62.0	3.18	87.0	4.39	
12.5	0.65	37.5	1.95	62.5	3.21	87.5	4.41	
13.0	0.67	38.0	1.98	63.0	3.23	88.0	4.43	
13.5	0.70	38.5	2.00	63.5	3.26	88.5	4.46	
14.0	0.72	39.0	2.03	64.0	3.28	89.0	4.48	
14.5	0.75	39.5	2.05	64.5	3.30	89.5	4.50	
15.0	0.78	40.0	2.08	65.0	3.33	90.0	4.53	
15.5	0.80	40.5	2.10	65.5	3.35	90.5	4.55	
16.0	0.83	41.0	2.13	66.0	3.38	91.0	4.58	
16.5	0.86	41.5	2.16	66.5	3.40	91.5	4.60	
17.0	0.88	42.0	2.18	67.0	3.43	92.0	4.62	
17.5	0.91	42.5	2.21	67.5	3.45	92.5	4.65	
18.0	0.94	43.0	2.23	68.0	3.48	93.0	4.67	
18.5	0.96	43.5	2.26	68.5	3.50	93.5	4.69	
19.0	0.99	44.0	2.28	69.0	3.52	94.0	4.72	
19.5	1.02	44.5	2.31	69.5	3.55	94.5	4.74	
20.0	1.04	45.0	2.33	70.0	3.57	95.0	4.76	
20.5	1.07	45.5	2.36	70.5	3.60	95.5	4.79	
21.0	1.09	46.0	2.38	71.0	3.62	96.0	4.81	
21.5	1.12	46.5	2.41	71.5	3.65	96.5	4.83	
22.0	1.15	47.0	2.43	72.0	3.67	97.0	4.86	
22.5	1.17	47.5	2.46	72.5	3.69	97.5	4.88	
23.0	1.20	48.0	2.48	73.0	3.72	98.0	4.90	
23.5	1.23	48.5	2.51	73.5	3.74	98.5	4.93	
24.0	1.25	49.0	2.53	74.0	3.77	99.0	4.95	
24.5	1.28	49.5	2.56	74.5	3.79	99.5	4.97	
25.0	1.30	50.0	2.58	75.0	3.81	100.0	4.99	

Temperature, °F

- 31.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		- 35.0	
atü	-	kg		atü	-	kg	
100.5	5.02	125.5	6.15	150.5	7.23	175.5	8.27
101.0	5.04	126.0	6.17	151.0	7.25	176.0	8.29
101.5	5.06	126.5	6.19	151.5	7.27	176.5	8.31
102.0	5.09	127.0	6.21	152.0	7.29	177.0	8.33
102.5	5.11	127.5	6.24	152.5	7.32	177.5	8.35
103.0	5.13	128.0	6.26	153.0	7.34	178.0	8.37
103.5	5.16	128.5	6.28	153.5	7.36	178.5	8.39
104.0	5.18	129.0	6.30	154.0	7.38	179.0	8.41
104.5	5.20	129.5	6.32	154.5	7.40	179.5	8.43
105.0	5.22	130.0	6.35	155.0	7.42	180.0	8.45
105.5	5.25	130.5	6.37	155.5	7.44	180.5	8.47
106.0	5.27	131.0	6.39	156.0	7.46	181.0	8.49
106.5	5.29	131.5	6.41	156.5	7.48	181.5	8.51
107.0	5.32	132.0	6.43	157.0	7.50	182.0	8.53
107.5	5.34	132.5	6.46	157.5	7.53	182.5	8.55
108.0	5.36	133.0	6.48	158.0	7.55	183.0	8.57
108.5	5.38	133.5	6.50	158.5	7.57	183.5	8.59
109.0	5.41	134.0	6.52	159.0	7.59	184.0	8.61
109.5	5.43	134.5	6.54	159.5	7.61	184.5	8.63
110.0	5.45	135.0	6.56	160.0	7.63	185.0	8.65
110.5	5.48	135.5	6.59	160.5	7.65	185.5	8.67
111.0	5.50	136.0	6.61	161.0	7.67	186.0	8.69
111.5	5.52	136.5	6.63	161.5	7.69	186.5	8.71
112.0	5.54	137.0	6.65	162.0	7.71	187.0	8.73
112.5	5.57	137.5	6.67	162.5	7.73	187.5	8.75
113.0	5.59	138.0	6.70	163.0	7.75	188.0	8.77
113.5	5.61	138.5	6.72	163.5	7.77	188.5	8.79
114.0	5.63	139.0	6.74	164.0	7.80	189.0	8.81
114.5	5.66	139.5	6.76	164.5	7.82	189.5	8.83
115.0	5.68	140.0	6.78	165.0	7.84	190.0	8.85
115.5	5.70	140.5	6.80	165.5	7.86	190.5	8.87
116.0	5.72	141.0	6.82	166.0	7.88	191.0	8.89
116.5	5.75	141.5	6.85	166.5	7.90	191.5	8.91
117.0	5.77	142.0	6.87	167.0	7.92	192.0	8.93
117.5	5.79	142.5	6.89	167.5	7.94	192.5	8.95
118.0	5.81	143.0	6.91	168.0	7.96	193.0	8.96
118.5	5.84	143.5	6.93	168.5	7.98	193.5	8.98
119.0	5.86	144.0	6.95	169.0	8.00	194.0	9.00
119.5	5.88	144.5	6.97	169.5	8.02	194.5	9.02
120.0	5.90	145.0	7.00	170.0	8.04	195.0	9.04
120.5	5.93	145.5	7.02	170.5	8.06	195.5	9.06
121.0	5.95	146.0	7.04	171.0	8.08	196.0	9.08
121.5	5.97	146.5	7.06	171.5	8.10	196.5	9.10
122.0	5.99	147.0	7.08	172.0	8.12	197.0	9.12
122.5	6.01	147.5	7.10	172.5	8.14	197.5	9.14
123.0	6.04	148.0	7.12	173.0	8.17	198.0	9.16
123.5	6.06	148.5	7.15	173.5	8.19	198.5	9.18
124.0	6.08	149.0	7.17	174.0	8.21	199.0	9.20
124.5	6.10	149.5	7.19	174.5	8.23	199.5	9.22
125.0	6.13	150.0	7.21	175.0	8.25	200.0	9.24

Temperature, °F

• 31.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.33	50.5	2.60	75.5	3.82
1.0	0.03	26.0	1.35	51.0	2.62	76.0	3.85
1.5	0.05	26.5	1.38	51.5	2.65	76.5	3.87
2.0	0.08	27.0	1.40	52.0	2.67	77.0	3.89
2.5	0.11	27.5	1.43	52.5	2.70	77.5	3.92
3.0	0.13	28.0	1.45	53.0	2.72	78.0	3.94
3.5	0.16	28.5	1.48	53.5	2.75	78.5	3.97
4.0	0.19	29.0	1.51	54.0	2.77	79.0	3.99
4.5	0.22	29.5	1.53	54.5	2.80	79.5	4.01
5.0	0.24	30.0	1.56	55.0	2.82	80.0	4.04
5.5	0.27	30.5	1.58	55.5	2.85	80.5	4.06
6.0	0.30	31.0	1.61	56.0	2.87	81.0	4.09
6.5	0.32	31.5	1.64	56.5	2.90	81.5	4.11
7.0	0.35	32.0	1.66	57.0	2.92	82.0	4.13
7.5	0.38	32.5	1.69	57.5	2.95	82.5	4.16
8.0	0.40	33.0	1.71	58.0	2.97	83.0	4.18
8.5	0.43	33.5	1.74	58.5	3.00	83.5	4.20
9.0	0.46	34.0	1.76	59.0	3.02	84.0	4.23
9.5	0.48	34.5	1.79	59.5	3.05	84.5	4.25
10.0	0.51	35.0	1.82	60.0	3.07	85.0	4.27
10.5	0.54	35.5	1.84	60.5	3.09	85.5	4.30
11.0	0.56	36.0	1.87	61.0	3.12	86.0	4.32
11.5	0.59	36.5	1.89	61.5	3.14	86.5	4.35
12.0	0.62	37.0	1.92	62.0	3.17	87.0	4.37
12.5	0.64	37.5	1.94	62.5	3.19	87.5	4.39
13.0	0.67	38.0	1.97	63.0	3.22	88.0	4.42
13.5	0.70	38.5	1.99	63.5	3.24	88.5	4.44
14.0	0.72	39.0	2.02	64.0	3.27	89.0	4.46
14.5	0.75	39.5	2.04	64.5	3.29	89.5	4.49
15.0	0.77	40.0	2.07	65.0	3.31	90.0	4.51
15.5	0.80	40.5	2.10	65.5	3.34	90.5	4.53
16.0	0.83	41.0	2.12	66.0	3.36	91.0	4.56
16.5	0.85	41.5	2.15	66.5	3.39	91.5	4.58
17.0	0.88	42.0	2.17	67.0	3.41	92.0	4.60
17.5	0.91	42.5	2.20	67.5	3.44	92.5	4.63
18.0	0.93	43.0	2.22	68.0	3.46	93.0	4.65
18.5	0.96	43.5	2.25	68.5	3.48	93.5	4.67
19.0	0.99	44.0	2.27	69.0	3.51	94.0	4.70
19.5	1.01	44.5	2.30	69.5	3.53	94.5	4.72
20.0	1.04	45.0	2.32	70.0	3.56	95.0	4.74
20.5	1.06	45.5	2.35	70.5	3.58	95.5	4.77
21.0	1.09	46.0	2.37	71.0	3.61	96.0	4.79
21.5	1.12	46.5	2.40	71.5	3.63	96.5	4.81
22.0	1.14	47.0	2.42	72.0	3.65	97.0	4.84
22.5	1.17	47.5	2.45	72.5	3.68	97.5	4.86
23.0	1.19	48.0	2.47	73.0	3.70	98.0	4.88
23.5	1.22	48.5	2.50	73.5	3.73	98.5	4.90
24.0	1.25	49.0	2.52	74.0	3.75	99.0	4.93
24.5	1.27	49.5	2.55	74.5	3.77	99.5	4.95
25.0	1.30	50.0	2.57	75.0	3.80	100.0	4.97

Temperature, °F - 29.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 34.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	5.00	125.5	6.12	150.5	7.20	175.5	8.23				
101.0	5.02	126.0	6.14	151.0	7.22	176.0	8.25				
101.5	5.04	126.5	6.17	151.5	7.24	176.5	8.27				
102.0	5.07	127.0	6.19	152.0	7.26	177.0	8.29				
102.5	5.09	127.5	6.21	152.5	7.29	177.5	8.31				
103.0	5.11	128.0	6.23	153.0	7.31	178.0	8.33				
103.5	5.13	128.5	6.25	153.5	7.33	178.5	8.35				
104.0	5.16	129.0	6.28	154.0	7.35	179.0	8.37				
104.5	5.18	129.5	6.30	154.5	7.37	179.5	8.39				
105.0	5.20	130.0	6.32	155.0	7.39	180.0	8.41				
105.5	5.23	130.5	6.34	155.5	7.41	180.5	8.43				
106.0	5.25	131.0	6.36	156.0	7.43	181.0	8.45				
106.5	5.27	131.5	6.39	156.5	7.45	181.5	8.47				
107.0	5.29	132.0	6.41	157.0	7.47	182.0	8.49				
107.5	5.32	132.5	6.43	157.5	7.49	182.5	8.51				
108.0	5.34	133.0	6.45	158.0	7.52	183.0	8.53				
108.5	5.36	133.5	6.47	158.5	7.54	183.5	8.55				
109.0	5.38	134.0	6.49	159.0	7.56	184.0	8.57				
109.5	5.41	134.5	6.52	159.5	7.58	184.5	8.59				
110.0	5.43	135.0	6.54	160.0	7.60	185.0	8.61				
110.5	5.45	135.5	6.56	160.5	7.62	185.5	8.63				
111.0	5.48	136.0	6.58	161.0	7.64	186.0	8.65				
111.5	5.50	136.5	6.60	161.5	7.66	186.5	8.67				
112.0	5.52	137.0	6.62	162.0	7.68	187.0	8.69				
112.5	5.54	137.5	6.65	162.5	7.70	187.5	8.71				
113.0	5.57	138.0	6.67	163.0	7.72	188.0	8.73				
113.5	5.59	138.5	6.69	163.5	7.74	188.5	8.75				
114.0	5.61	139.0	6.71	164.0	7.76	189.0	8.77				
114.5	5.63	139.5	6.73	164.5	7.78	189.5	8.79				
115.0	5.66	140.0	6.75	165.0	7.81	190.0	8.81				
115.5	5.68	140.5	6.78	165.5	7.83	190.5	8.83				
116.0	5.70	141.0	6.80	166.0	7.85	191.0	8.85				
116.5	5.72	141.5	6.82	166.5	7.87	191.5	8.87				
117.0	5.75	142.0	6.84	167.0	7.89	192.0	8.89				
117.5	5.77	142.5	6.86	167.5	7.91	192.5	8.91				
118.0	5.79	143.0	6.88	168.0	7.93	193.0	8.93				
118.5	5.81	143.5	6.90	168.5	7.95	193.5	8.95				
119.0	5.83	144.0	6.93	169.0	7.97	194.0	8.97				
119.5	5.86	144.5	6.95	169.5	7.99	194.5	8.99				
120.0	5.88	145.0	6.97	170.0	8.01	195.0	9.01				
120.5	5.90	145.5	6.99	170.5	8.03	195.5	9.03				
121.0	5.92	146.0	7.01	171.0	8.05	196.0	9.05				
121.5	5.95	146.5	7.03	171.5	8.07	196.5	9.07				
122.0	5.97	147.0	7.05	172.0	8.09	197.0	9.08				
122.5	5.99	147.5	7.07	172.5	8.11	197.5	9.10				
123.0	6.01	148.0	7.10	173.0	8.13	198.0	9.12				
123.5	6.03	148.5	7.12	173.5	8.15	198.5	9.14				
124.0	6.06	149.0	7.14	174.0	8.17	199.0	9.16				
124.5	6.08	149.5	7.16	174.5	8.19	199.5	9.18				
125.0	6.10	150.0	7.18	175.0	8.21	200.0	9.20				

Temperature, °F

- 29.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 33.0							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.32	50.5	2.59	75.5	3.81
1.0	0.03	26.0	1.35	51.0	2.61	76.0	3.83
1.5	0.05	26.5	1.37	51.5	2.64	76.5	3.85
2.0	0.08	27.0	1.40	52.0	2.66	77.0	3.88
2.5	0.11	27.5	1.42	52.5	2.69	77.5	3.90
3.0	0.13	28.0	1.45	53.0	2.71	78.0	3.93
3.5	0.16	28.5	1.47	53.5	2.74	78.5	3.95
4.0	0.19	29.0	1.50	54.0	2.76	79.0	3.97
4.5	0.21	29.5	1.53	54.5	2.79	79.5	4.00
5.0	0.24	30.0	1.55	55.0	2.81	80.0	4.02
5.5	0.27	30.5	1.58	55.5	2.84	80.5	4.04
6.0	0.29	31.0	1.60	56.0	2.86	81.0	4.07
6.5	0.32	31.5	1.63	56.5	2.89	81.5	4.09
7.0	0.35	32.0	1.65	57.0	2.91	82.0	4.12
7.5	0.37	32.5	1.68	57.5	2.93	82.5	4.14
8.0	0.40	33.0	1.71	58.0	2.96	83.0	4.16
8.5	0.43	33.5	1.73	58.5	2.98	83.5	4.19
9.0	0.45	34.0	1.76	59.0	3.01	84.0	4.21
9.5	0.48	34.5	1.78	59.5	3.03	84.5	4.23
10.0	0.51	35.0	1.81	60.0	3.06	85.0	4.26
10.5	0.53	35.5	1.83	60.5	3.08	85.5	4.28
11.0	0.56	36.0	1.86	61.0	3.11	86.0	4.30
11.5	0.59	36.5	1.88	61.5	3.13	86.5	4.33
12.0	0.61	37.0	1.91	62.0	3.15	87.0	4.35
12.5	0.64	37.5	1.93	62.5	3.18	87.5	4.37
13.0	0.67	38.0	1.96	63.0	3.20	88.0	4.40
13.5	0.69	38.5	1.99	63.5	3.23	88.5	4.42
14.0	0.72	39.0	2.01	64.0	3.25	89.0	4.44
14.5	0.75	39.5	2.04	64.5	3.28	89.5	4.47
15.0	0.77	40.0	2.06	65.0	3.30	90.0	4.49
15.5	0.80	40.5	2.09	65.5	3.33	90.5	4.51
16.0	0.82	41.0	2.11	66.0	3.35	91.0	4.54
16.5	0.85	41.5	2.14	66.5	3.37	91.5	4.56
17.0	0.88	42.0	2.16	67.0	3.40	92.0	4.58
17.5	0.90	42.5	2.19	67.5	3.42	92.5	4.61
18.0	0.93	43.0	2.21	68.0	3.45	93.0	4.63
18.5	0.96	43.5	2.24	68.5	3.47	93.5	4.65
19.0	0.98	44.0	2.26	69.0	3.49	94.0	4.68
19.5	1.01	44.5	2.29	69.5	3.52	94.5	4.70
20.0	1.03	45.0	2.31	70.0	3.54	95.0	4.72
20.5	1.06	45.5	2.34	70.5	3.57	95.5	4.75
21.0	1.09	46.0	2.36	71.0	3.59	96.0	4.77
21.5	1.11	46.5	2.39	71.5	3.62	96.5	4.79
22.0	1.14	47.0	2.41	72.0	3.64	97.0	4.82
22.5	1.16	47.5	2.44	72.5	3.66	97.5	4.84
23.0	1.19	48.0	2.46	73.0	3.69	98.0	4.86
23.5	1.22	48.5	2.49	73.5	3.71	98.5	4.88
24.0	1.24	49.0	2.51	74.0	3.73	99.0	4.91
24.5	1.27	49.5	2.54	74.5	3.76	99.5	4.93
25.0	1.29	50.0	2.56	75.0	3.78	100.0	4.95

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 33.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.98	125.5	6.10	150.5	7.17	175.5	8.20				
101.0	5.00	126.0	6.12	151.0	7.19	176.0	8.22				
101.5	5.02	126.5	6.14	151.5	7.21	176.5	8.24				
102.0	5.04	127.0	6.16	152.0	7.23	177.0	8.26				
102.5	5.07	127.5	6.19	152.5	7.26	177.5	8.28				
103.0	5.09	128.0	6.21	153.0	7.28	178.0	8.30				
103.5	5.11	128.5	6.23	153.5	7.30	178.5	8.32				
104.0	5.14	129.0	6.25	154.0	7.32	179.0	8.34				
104.5	5.16	129.5	6.27	154.5	7.34	179.5	8.36				
105.0	5.18	130.0	6.29	155.0	7.36	180.0	8.38				
105.5	5.20	130.5	6.32	155.5	7.38	180.5	8.40				
106.0	5.23	131.0	6.34	156.0	7.40	181.0	8.42				
106.5	5.25	131.5	6.36	156.5	7.42	181.5	8.44				
107.0	5.27	132.0	6.38	157.0	7.44	182.0	8.46				
107.5	5.29	132.5	6.40	157.5	7.46	182.5	8.48				
108.0	5.32	133.0	6.42	158.0	7.48	183.0	8.50				
108.5	5.34	133.5	6.45	158.5	7.51	183.5	8.52				
109.0	5.36	134.0	6.47	159.0	7.53	184.0	8.54				
109.5	5.39	134.5	6.49	159.5	7.55	184.5	8.56				
110.0	5.41	135.0	6.51	160.0	7.57	185.0	8.58				
110.5	5.43	135.5	6.53	160.5	7.59	185.5	8.60				
111.0	5.45	136.0	6.55	161.0	7.61	186.0	8.62				
111.5	5.48	136.5	6.58	161.5	7.63	186.5	8.64				
112.0	5.50	137.0	6.60	162.0	7.65	187.0	8.66				
112.5	5.52	137.5	6.62	162.5	7.67	187.5	8.68				
113.0	5.54	138.0	6.64	163.0	7.69	188.0	8.70				
113.5	5.57	138.5	6.66	163.5	7.71	188.5	8.72				
114.0	5.59	139.0	6.68	164.0	7.73	189.0	8.74				
114.5	5.61	139.5	6.70	164.5	7.75	189.5	8.76				
115.0	5.63	140.0	6.73	165.0	7.77	190.0	8.78				
115.5	5.65	140.5	6.75	165.5	7.79	190.5	8.80				
116.0	5.68	141.0	6.77	166.0	7.81	191.0	8.81				
116.5	5.70	141.5	6.79	166.5	7.83	191.5	8.83				
117.0	5.72	142.0	6.81	167.0	7.86	192.0	8.85				
117.5	5.74	142.5	6.83	167.5	7.88	192.5	8.87				
118.0	5.77	143.0	6.85	168.0	7.90	193.0	8.89				
118.5	5.79	143.5	6.88	168.5	7.92	193.5	8.91				
119.0	5.81	144.0	6.90	169.0	7.94	194.0	8.93				
119.5	5.83	144.5	6.92	169.5	7.96	194.5	8.95				
120.0	5.85	145.0	6.94	170.0	7.98	195.0	8.97				
120.5	5.88	145.5	6.96	170.5	8.00	195.5	8.99				
121.0	5.90	146.0	6.98	171.0	8.02	196.0	9.01				
121.5	5.92	146.5	7.00	171.5	8.04	196.5	9.03				
122.0	5.94	147.0	7.02	172.0	8.06	197.0	9.05				
122.5	5.97	147.5	7.05	172.5	8.08	197.5	9.07				
123.0	5.99	148.0	7.07	173.0	8.10	198.0	9.09				
123.5	6.01	148.5	7.09	173.5	8.12	198.5	9.11				
124.0	6.03	149.0	7.11	174.0	8.14	199.0	9.13				
124.5	6.05	149.5	7.13	174.5	8.16	199.5	9.14				
125.0	6.08	150.0	7.15	175.0	8.18	200.0	9.16				

Temperature, °F - 27.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C							
				- 32.0			
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.31	50.5	2.58	75.5	3.79
1.0	0.03	26.0	1.34	51.0	2.60	76.0	3.81
1.5	0.05	26.5	1.37	51.5	2.63	76.5	3.84
2.0	0.08	27.0	1.39	52.0	2.65	77.0	3.86
2.5	0.11	27.5	1.42	52.5	2.68	77.5	3.89
3.0	0.13	28.0	1.44	53.0	2.70	78.0	3.91
3.5	0.16	28.5	1.47	53.5	2.73	78.5	3.93
4.0	0.19	29.0	1.49	54.0	2.75	79.0	3.96
4.5	0.21	29.5	1.52	54.5	2.77	79.5	3.98
5.0	0.24	30.0	1.55	55.0	2.80	80.0	4.00
5.5	0.27	30.5	1.57	55.5	2.82	80.5	4.03
6.0	0.29	31.0	1.60	56.0	2.85	81.0	4.05
6.5	0.32	31.5	1.62	56.5	2.87	81.5	4.07
7.0	0.35	32.0	1.65	57.0	2.90	82.0	4.10
7.5	0.37	32.5	1.67	57.5	2.92	82.5	4.12
8.0	0.40	33.0	1.70	58.0	2.95	83.0	4.15
8.5	0.43	33.5	1.72	58.5	2.97	83.5	4.17
9.0	0.45	34.0	1.75	59.0	3.00	84.0	4.19
9.5	0.48	34.5	1.77	59.5	3.02	84.5	4.22
10.0	0.51	35.0	1.80	60.0	3.04	85.0	4.24
10.5	0.53	35.5	1.83	60.5	3.07	85.5	4.26
11.0	0.56	36.0	1.85	61.0	3.09	86.0	4.29
11.5	0.58	36.5	1.88	61.5	3.12	86.5	4.31
12.0	0.61	37.0	1.90	62.0	3.14	87.0	4.33
12.5	0.64	37.5	1.93	62.5	3.17	87.5	4.36
13.0	0.66	38.0	1.95	63.0	3.19	88.0	4.38
13.5	0.69	38.5	1.98	63.5	3.21	88.5	4.40
14.0	0.72	39.0	2.00	64.0	3.24	89.0	4.43
14.5	0.74	39.5	2.03	64.5	3.26	89.5	4.45
15.0	0.77	40.0	2.05	65.0	3.29	90.0	4.47
15.5	0.79	40.5	2.08	65.5	3.31	90.5	4.50
16.0	0.82	41.0	2.10	66.0	3.34	91.0	4.52
16.5	0.85	41.5	2.13	66.5	3.36	91.5	4.54
17.0	0.87	42.0	2.15	67.0	3.38	92.0	4.57
17.5	0.90	42.5	2.18	67.5	3.41	92.5	4.59
18.0	0.93	43.0	2.20	68.0	3.43	93.0	4.61
18.5	0.95	43.5	2.23	68.5	3.46	93.5	4.63
19.0	0.98	44.0	2.25	69.0	3.48	94.0	4.66
19.5	1.00	44.5	2.28	69.5	3.50	94.5	4.68
20.0	1.03	45.0	2.30	70.0	3.53	95.0	4.70
20.5	1.06	45.5	2.33	70.5	3.55	95.5	4.73
21.0	1.08	46.0	2.35	71.0	3.58	96.0	4.75
21.5	1.11	46.5	2.38	71.5	3.60	96.5	4.77
22.0	1.13	47.0	2.40	72.0	3.62	97.0	4.80
22.5	1.16	47.5	2.43	72.5	3.65	97.5	4.82
23.0	1.18	48.0	2.45	73.0	3.67	98.0	4.84
23.5	1.21	48.5	2.48	73.5	3.70	98.5	4.86
24.0	1.24	49.0	2.50	74.0	3.72	99.0	4.89
24.5	1.26	49.5	2.53	74.5	3.74	99.5	4.91
25.0	1.29	50.0	2.55	75.0	3.77	100.0	4.93

Temperature, °F - 25.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 32.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.96	125.5	6.07	150.5	7.14	175.5	8.17				
101.0	4.98	126.0	6.09	151.0	7.16	176.0	8.19				
101.5	5.00	126.5	6.12	151.5	7.18	176.5	8.21				
102.0	5.02	127.0	6.14	152.0	7.21	177.0	8.23				
102.5	5.05	127.5	6.16	152.5	7.23	177.5	8.25				
103.0	5.07	128.0	6.18	153.0	7.25	178.0	8.27				
103.5	5.09	128.5	6.20	153.5	7.27	178.5	8.29				
104.0	5.11	129.0	6.23	154.0	7.29	179.0	8.31				
104.5	5.14	129.5	6.25	154.5	7.31	179.5	8.33				
105.0	5.16	130.0	6.27	155.0	7.33	180.0	8.35				
105.5	5.18	130.5	6.29	155.5	7.35	180.5	8.37				
106.0	5.21	131.0	6.31	156.0	7.37	181.0	8.39				
106.5	5.23	131.5	6.33	156.5	7.39	181.5	8.41				
107.0	5.25	132.0	6.36	157.0	7.41	182.0	8.43				
107.5	5.27	132.5	6.38	157.5	7.43	182.5	8.45				
108.0	5.30	133.0	6.40	158.0	7.45	183.0	8.47				
108.5	5.32	133.5	6.42	158.5	7.48	183.5	8.49				
109.0	5.34	134.0	6.44	159.0	7.50	184.0	8.50				
109.5	5.36	134.5	6.46	159.5	7.52	184.5	8.52				
110.0	5.39	135.0	6.48	160.0	7.54	185.0	8.54				
110.5	5.41	135.5	6.51	160.5	7.56	185.5	8.56				
111.0	5.43	136.0	6.53	161.0	7.58	186.0	8.58				
111.5	5.45	136.5	6.55	161.5	7.60	186.5	8.60				
112.0	5.48	137.0	6.57	162.0	7.62	187.0	8.62				
112.5	5.50	137.5	6.59	162.5	7.64	187.5	8.64				
113.0	5.52	138.0	6.61	163.0	7.66	188.0	8.66				
113.5	5.54	138.5	6.63	163.5	7.68	188.5	8.68				
114.0	5.56	139.0	6.66	164.0	7.70	189.0	8.70				
114.5	5.59	139.5	6.68	164.5	7.72	189.5	8.72				
115.0	5.61	140.0	6.70	165.0	7.74	190.0	8.74				
115.5	5.63	140.5	6.72	165.5	7.76	190.5	8.76				
116.0	5.65	141.0	6.74	166.0	7.78	191.0	8.78				
116.5	5.68	141.5	6.76	166.5	7.80	191.5	8.80				
117.0	5.70	142.0	6.78	167.0	7.82	192.0	8.82				
117.5	5.72	142.5	6.81	167.5	7.84	192.5	8.84				
118.0	5.74	143.0	6.83	168.0	7.86	193.0	8.86				
118.5	5.76	143.5	6.85	168.5	7.88	193.5	8.88				
119.0	5.79	144.0	6.87	169.0	7.90	194.0	8.90				
119.5	5.81	144.5	6.89	169.5	7.93	194.5	8.92				
120.0	5.83	145.0	6.91	170.0	7.95	195.0	8.93				
120.5	5.85	145.5	6.93	170.5	7.97	195.5	8.95				
121.0	5.87	146.0	6.95	171.0	7.99	196.0	8.97				
121.5	5.90	146.5	6.97	171.5	8.01	196.5	8.99				
122.0	5.92	147.0	7.00	172.0	8.03	197.0	9.01				
122.5	5.94	147.5	7.02	172.5	8.05	197.5	9.03				
123.0	5.96	148.0	7.04	173.0	8.07	198.0	9.05				
123.5	5.98	148.5	7.06	173.5	8.09	198.5	9.07				
124.0	6.01	149.0	7.08	174.0	8.11	199.0	9.09				
124.5	6.03	149.5	7.10	174.5	8.13	199.5	9.11				
125.0	6.05	150.0	7.12	175.0	8.15	200.0	9.13				

Temperature, °F - 25.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 31.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.31	50.5	2.57	75.5	3.78	
1.0	0.03	26.0	1.33	51.0	2.59	76.0	3.80	
1.5	0.05	26.5	1.36	51.5	2.62	76.5	3.82	
2.0	0.08	27.0	1.39	52.0	2.64	77.0	3.85	
2.5	0.11	27.5	1.41	52.5	2.67	77.5	3.87	
3.0	0.13	28.0	1.44	53.0	2.69	78.0	3.89	
3.5	0.16	28.5	1.46	53.5	2.71	78.5	3.92	
4.0	0.19	29.0	1.49	54.0	2.74	79.0	3.94	
4.5	0.21	29.5	1.51	54.5	2.76	79.5	3.96	
5.0	0.24	30.0	1.54	55.0	2.79	80.0	3.99	
5.5	0.27	30.5	1.56	55.5	2.81	80.5	4.01	
6.0	0.29	31.0	1.59	56.0	2.84	81.0	4.03	
6.5	0.32	31.5	1.62	56.5	2.86	81.5	4.06	
7.0	0.35	32.0	1.64	57.0	2.89	82.0	4.08	
7.5	0.37	32.5	1.67	57.5	2.91	82.5	4.10	
8.0	0.40	33.0	1.69	58.0	2.93	83.0	4.13	
8.5	0.42	33.5	1.72	58.5	2.96	83.5	4.15	
9.0	0.45	34.0	1.74	59.0	2.98	84.0	4.18	
9.5	0.48	34.5	1.77	59.5	3.01	84.5	4.20	
10.0	0.50	35.0	1.79	60.0	3.03	85.0	4.22	
10.5	0.53	35.5	1.82	60.5	3.06	85.5	4.25	
11.0	0.56	36.0	1.84	61.0	3.08	86.0	4.27	
11.5	0.58	36.5	1.87	61.5	3.10	86.5	4.29	
12.0	0.61	37.0	1.89	62.0	3.13	87.0	4.31	
12.5	0.63	37.5	1.92	62.5	3.15	87.5	4.34	
13.0	0.66	38.0	1.94	63.0	3.18	88.0	4.36	
13.5	0.69	38.5	1.97	63.5	3.20	88.5	4.38	
14.0	0.71	39.0	1.99	64.0	3.23	89.0	4.41	
14.5	0.74	39.5	2.02	64.5	3.25	89.5	4.43	
15.0	0.77	40.0	2.04	65.0	3.27	90.0	4.45	
15.5	0.79	40.5	2.07	65.5	3.30	90.5	4.48	
16.0	0.82	41.0	2.09	66.0	3.32	91.0	4.50	
16.5	0.84	41.5	2.12	66.5	3.35	91.5	4.52	
17.0	0.87	42.0	2.14	67.0	3.37	92.0	4.55	
17.5	0.90	42.5	2.17	67.5	3.39	92.5	4.57	
18.0	0.92	43.0	2.19	68.0	3.42	93.0	4.59	
18.5	0.95	43.5	2.22	68.5	3.44	93.5	4.62	
19.0	0.97	44.0	2.24	69.0	3.47	94.0	4.64	
19.5	1.00	44.5	2.27	69.5	3.49	94.5	4.66	
20.0	1.02	45.0	2.29	70.0	3.51	95.0	4.68	
20.5	1.05	45.5	2.32	70.5	3.54	95.5	4.71	
21.0	1.08	46.0	2.34	71.0	3.56	96.0	4.73	
21.5	1.10	46.5	2.37	71.5	3.59	96.5	4.75	
22.0	1.13	47.0	2.39	72.0	3.61	97.0	4.78	
22.5	1.15	47.5	2.42	72.5	3.63	97.5	4.80	
23.0	1.18	48.0	2.44	73.0	3.66	98.0	4.82	
23.5	1.21	48.5	2.47	73.5	3.68	98.5	4.84	
24.0	1.23	49.0	2.49	74.0	3.70	99.0	4.87	
24.5	1.26	49.5	2.52	74.5	3.73	99.5	4.89	
25.0	1.28	50.0	2.54	75.0	3.75	100.0	4.91	

Temperature, °F

- 23.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 31.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.94	125.5	6.05	150.5	7.11	175.5	8.13				
101.0	4.96	126.0	6.07	151.0	7.13	176.0	8.15				
101.5	4.98	126.5	6.09	151.5	7.16	176.5	8.17				
102.0	5.00	127.0	6.11	152.0	7.18	177.0	8.19				
102.5	5.03	127.5	6.13	152.5	7.20	177.5	8.21				
103.0	5.05	128.0	6.16	153.0	7.22	178.0	8.23				
103.5	5.07	128.5	6.18	153.5	7.24	178.5	8.25				
104.0	5.09	129.0	6.20	154.0	7.26	179.0	8.27				
104.5	5.12	129.5	6.22	154.5	7.28	179.5	8.29				
105.0	5.14	130.0	6.24	155.0	7.30	180.0	8.31				
105.5	5.16	130.5	6.26	155.5	7.32	180.5	8.33				
106.0	5.18	131.0	6.29	156.0	7.34	181.0	8.35				
106.5	5.21	131.5	6.31	156.5	7.36	181.5	8.37				
107.0	5.23	132.0	6.33	157.0	7.38	182.0	8.39				
107.5	5.25	132.5	6.35	157.5	7.40	182.5	8.41				
108.0	5.27	133.0	6.37	158.0	7.42	183.0	8.43				
108.5	5.30	133.5	6.39	158.5	7.45	183.5	8.45				
109.0	5.32	134.0	6.42	159.0	7.47	184.0	8.47				
109.5	5.34	134.5	6.44	159.5	7.49	184.5	8.49				
110.0	5.36	135.0	6.46	160.0	7.51	185.0	8.51				
110.5	5.39	135.5	6.48	160.5	7.53	185.5	8.53				
111.0	5.41	136.0	6.50	161.0	7.55	186.0	8.55				
111.5	5.43	136.5	6.52	161.5	7.57	186.5	8.57				
112.0	5.45	137.0	6.54	162.0	7.59	187.0	8.59				
112.5	5.48	137.5	6.57	162.5	7.61	187.5	8.61				
113.0	5.50	138.0	6.59	163.0	7.63	188.0	8.63				
113.5	5.52	138.5	6.61	163.5	7.65	188.5	8.65				
114.0	5.54	139.0	6.63	164.0	7.67	189.0	8.67				
114.5	5.56	139.5	6.65	164.5	7.69	189.5	8.69				
115.0	5.59	140.0	6.67	165.0	7.71	190.0	8.71				
115.5	5.61	140.5	6.69	165.5	7.73	190.5	8.73				
116.0	5.63	141.0	6.71	166.0	7.75	191.0	8.74				
116.5	5.65	141.5	6.74	166.5	7.77	191.5	8.76				
117.0	5.67	142.0	6.76	167.0	7.79	192.0	8.78				
117.5	5.70	142.5	6.78	167.5	7.81	192.5	8.80				
118.0	5.72	143.0	6.80	168.0	7.83	193.0	8.82				
118.5	5.74	143.5	6.82	168.5	7.85	193.5	8.84				
119.0	5.76	144.0	6.84	169.0	7.87	194.0	8.86				
119.5	5.78	144.5	6.86	169.5	7.89	194.5	8.88				
120.0	5.81	145.0	6.88	170.0	7.91	195.0	8.90				
120.5	5.83	145.5	6.90	170.5	7.93	195.5	8.92				
121.0	5.85	146.0	6.93	171.0	7.95	196.0	8.94				
121.5	5.87	146.5	6.95	171.5	7.97	196.5	8.96				
122.0	5.89	147.0	6.97	172.0	7.99	197.0	8.98				
122.5	5.92	147.5	6.99	172.5	8.01	197.5	9.00				
123.0	5.94	148.0	7.01	173.0	8.03	198.0	9.01				
123.5	5.96	148.5	7.03	173.5	8.05	198.5	9.03				
124.0	5.98	149.0	7.05	174.0	8.07	199.0	9.05				
124.5	6.00	149.5	7.07	174.5	8.09	199.5	9.07				
125.0	6.03	150.0	7.09	175.0	8.11	200.0	9.09				

Temperature, °F - 23.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C							
				= 30.0			
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.30	50.5	2.56	75.5	3.76
1.0	0.03	26.0	1.33	51.0	2.58	76.0	3.78
1.5	0.05	26.5	1.35	51.5	2.61	76.5	3.81
2.0	0.08	27.0	1.38	52.0	2.63	77.0	3.83
2.5	0.11	27.5	1.41	52.5	2.65	77.5	3.85
3.0	0.13	28.0	1.43	53.0	2.68	78.0	3.88
3.5	0.16	28.5	1.46	53.5	2.70	78.5	3.90
4.0	0.19	29.0	1.48	54.0	2.73	79.0	3.92
4.5	0.21	29.5	1.51	54.5	2.75	79.5	3.95
5.0	0.24	30.0	1.53	55.0	2.78	80.0	3.97
5.5	0.26	30.5	1.56	55.5	2.80	80.5	3.99
6.0	0.29	31.0	1.58	56.0	2.83	81.0	4.02
6.5	0.32	31.5	1.61	56.5	2.85	81.5	4.04
7.0	0.34	32.0	1.63	57.0	2.87	82.0	4.06
7.5	0.37	32.5	1.66	57.5	2.90	82.5	4.09
8.0	0.40	33.0	1.68	58.0	2.92	83.0	4.11
8.5	0.42	33.5	1.71	58.5	2.95	83.5	4.13
9.0	0.45	34.0	1.73	59.0	2.97	84.0	4.16
9.5	0.47	34.5	1.76	59.5	2.99	84.5	4.18
10.0	0.50	35.0	1.79	60.0	3.02	85.0	4.20
10.5	0.53	35.5	1.81	60.5	3.04	85.5	4.23
11.0	0.55	36.0	1.84	61.0	3.07	86.0	4.25
11.5	0.58	36.5	1.86	61.5	3.09	86.5	4.27
12.0	0.61	37.0	1.89	62.0	3.12	87.0	4.30
12.5	0.63	37.5	1.91	62.5	3.14	87.5	4.32
13.0	0.66	38.0	1.94	63.0	3.16	88.0	4.34
13.5	0.68	38.5	1.96	63.5	3.19	88.5	4.37
14.0	0.71	39.0	1.99	64.0	3.21	89.0	4.39
14.5	0.74	39.5	2.01	64.5	3.24	89.5	4.41
15.0	0.76	40.0	2.04	65.0	3.26	90.0	4.44
15.5	0.79	40.5	2.06	65.5	3.28	90.5	4.46
16.0	0.81	41.0	2.09	66.0	3.31	91.0	4.48
16.5	0.84	41.5	2.11	66.5	3.33	91.5	4.50
17.0	0.87	42.0	2.14	67.0	3.36	92.0	4.53
17.5	0.89	42.5	2.16	67.5	3.38	92.5	4.55
18.0	0.92	43.0	2.19	68.0	3.40	93.0	4.57
18.5	0.94	43.5	2.21	68.5	3.43	93.5	4.60
19.0	0.97	44.0	2.24	69.0	3.45	94.0	4.62
19.5	0.99	44.5	2.26	69.5	3.48	94.5	4.64
20.0	1.02	45.0	2.28	70.0	3.50	95.0	4.66
20.5	1.05	45.5	2.31	70.5	3.52	95.5	4.69
21.0	1.07	46.0	2.33	71.0	3.55	96.0	4.71
21.5	1.10	46.5	2.36	71.5	3.57	96.5	4.73
22.0	1.12	47.0	2.38	72.0	3.59	97.0	4.76
22.5	1.15	47.5	2.41	72.5	3.62	97.5	4.78
23.0	1.18	48.0	2.43	73.0	3.64	98.0	4.80
23.5	1.20	48.5	2.46	73.5	3.67	98.5	4.82
24.0	1.23	49.0	2.48	74.0	3.69	99.0	4.85
24.5	1.25	49.5	2.51	74.5	3.71	99.5	4.87
25.0	1.28	50.0	2.53	75.0	3.74	100.0	4.89

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 30.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.92	125.5	6.02	150.5	7.08	175.5	8.10				
101.0	4.94	126.0	6.04	151.0	7.11	176.0	8.12				
101.5	4.96	126.5	6.07	151.5	7.13	176.5	8.14				
102.0	4.98	127.0	6.09	152.0	7.15	177.0	8.16				
102.5	5.01	127.5	6.11	152.5	7.17	177.5	8.18				
103.0	5.03	128.0	6.13	153.0	7.19	178.0	8.20				
103.5	5.05	128.5	6.15	153.5	7.21	178.5	8.22				
104.0	5.07	129.0	6.17	154.0	7.23	179.0	8.24				
104.5	5.10	129.5	6.20	154.5	7.25	179.5	8.26				
105.0	5.12	130.0	6.22	155.0	7.27	180.0	8.28				
105.5	5.14	130.5	6.24	155.5	7.29	180.5	8.30				
106.0	5.16	131.0	6.26	156.0	7.31	181.0	8.32				
106.5	5.19	131.5	6.28	156.5	7.33	181.5	8.34				
107.0	5.21	132.0	6.30	157.0	7.35	182.0	8.36				
107.5	5.23	132.5	6.33	157.5	7.37	182.5	8.38				
108.0	5.25	133.0	6.35	158.0	7.39	183.0	8.40				
108.5	5.27	133.5	6.37	158.5	7.42	183.5	8.42				
109.0	5.30	134.0	6.39	159.0	7.44	184.0	8.44				
109.5	5.32	134.5	6.41	159.5	7.46	184.5	8.46				
110.0	5.34	135.0	6.43	160.0	7.48	185.0	8.48				
110.5	5.36	135.5	6.45	160.5	7.50	185.5	8.50				
111.0	5.39	136.0	6.47	161.0	7.52	186.0	8.52				
111.5	5.41	136.5	6.50	161.5	7.54	186.5	8.54				
112.0	5.43	137.0	6.52	162.0	7.56	187.0	8.55				
112.5	5.45	137.5	6.54	162.5	7.58	187.5	8.57				
113.0	5.47	138.0	6.56	163.0	7.60	188.0	8.59				
113.5	5.50	138.5	6.58	163.5	7.62	188.5	8.61				
114.0	5.52	139.0	6.60	164.0	7.64	189.0	8.63				
114.5	5.54	139.5	6.62	164.5	7.66	189.5	8.65				
115.0	5.56	140.0	6.64	165.0	7.68	190.0	8.67				
115.5	5.59	140.5	6.67	165.5	7.70	190.5	8.69				
116.0	5.61	141.0	6.69	166.0	7.72	191.0	8.71				
116.5	5.63	141.5	6.71	166.5	7.74	191.5	8.73				
117.0	5.65	142.0	6.73	167.0	7.76	192.0	8.75				
117.5	5.67	142.5	6.75	167.5	7.78	192.5	8.77				
118.0	5.70	143.0	6.77	168.0	7.80	193.0	8.79				
118.5	5.72	143.5	6.79	168.5	7.82	193.5	8.81				
119.0	5.74	144.0	6.81	169.0	7.84	194.0	8.83				
119.5	5.76	144.5	6.83	169.5	7.86	194.5	8.85				
120.0	5.78	145.0	6.86	170.0	7.88	195.0	8.86				
120.5	5.81	145.5	6.88	170.5	7.90	195.5	8.88				
121.0	5.83	146.0	6.90	171.0	7.92	196.0	8.90				
121.5	5.85	146.5	6.92	171.5	7.94	196.5	8.92				
122.0	5.87	147.0	6.94	172.0	7.96	197.0	8.94				
122.5	5.89	147.5	6.96	172.5	7.98	197.5	8.96				
123.0	5.91	148.0	6.98	173.0	8.00	198.0	8.98				
123.5	5.94	148.5	7.00	173.5	8.02	198.5	9.00				
124.0	5.96	149.0	7.02	174.0	8.04	199.0	9.02				
124.5	5.98	149.5	7.04	174.5	8.06	199.5	9.04				
125.0	6.00	150.0	7.06	175.0	8.08	200.0	9.06				

Temperature, °F - 22.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 29.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.30	50.5	2.55	75.5	3.74
1.0	0.03	26.0	1.32	51.0	2.57	76.0	3.77
1.5	0.05	26.5	1.35	51.5	2.59	76.5	3.79
2.0	0.08	27.0	1.37	52.0	2.62	77.0	3.81
2.5	0.11	27.5	1.40	52.5	2.64	77.5	3.84
3.0	0.13	28.0	1.42	53.0	2.67	78.0	3.86
3.5	0.16	28.5	1.45	53.5	2.69	78.5	3.88
4.0	0.18	29.0	1.48	54.0	2.72	79.0	3.91
4.5	0.21	29.5	1.50	54.5	2.74	79.5	3.93
5.0	0.24	30.0	1.53	55.0	2.76	80.0	3.95
5.5	0.26	30.5	1.55	55.5	2.79	80.5	3.98
6.0	0.29	31.0	1.58	56.0	2.81	81.0	4.00
6.5	0.32	31.5	1.60	56.5	2.84	81.5	4.02
7.0	0.34	32.0	1.63	57.0	2.86	82.0	4.05
7.5	0.37	32.5	1.65	57.5	2.89	82.5	4.07
8.0	0.39	33.0	1.68	58.0	2.91	83.0	4.09
8.5	0.42	33.5	1.70	58.5	2.93	83.5	4.12
9.0	0.45	34.0	1.73	59.0	2.96	84.0	4.14
9.5	0.47	34.5	1.75	59.5	2.98	84.5	4.16
10.0	0.50	35.0	1.78	60.0	3.01	85.0	4.19
10.5	0.53	35.5	1.80	60.5	3.03	85.5	4.21
11.0	0.55	36.0	1.83	61.0	3.05	86.0	4.23
11.5	0.58	36.5	1.85	61.5	3.08	86.5	4.26
12.0	0.60	37.0	1.88	62.0	3.10	87.0	4.28
12.5	0.63	37.5	1.90	62.5	3.13	87.5	4.30
13.0	0.66	38.0	1.93	63.0	3.15	88.0	4.33
13.5	0.68	38.5	1.95	63.5	3.17	88.5	4.35
14.0	0.71	39.0	1.98	64.0	3.20	89.0	4.37
14.5	0.73	39.5	2.00	64.5	3.22	89.5	4.39
15.0	0.76	40.0	2.03	65.0	3.25	90.0	4.42
15.5	0.78	40.5	2.05	65.5	3.27	90.5	4.44
16.0	0.81	41.0	2.08	66.0	3.29	91.0	4.46
16.5	0.84	41.5	2.10	66.5	3.32	91.5	4.49
17.0	0.86	42.0	2.13	67.0	3.34	92.0	4.51
17.5	0.89	42.5	2.15	67.5	3.37	92.5	4.53
18.0	0.91	43.0	2.18	68.0	3.39	93.0	4.55
18.5	0.94	43.5	2.20	68.5	3.41	93.5	4.58
19.0	0.97	44.0	2.23	69.0	3.44	94.0	4.60
19.5	0.99	44.5	2.25	69.5	3.46	94.5	4.62
20.0	1.02	45.0	2.28	70.0	3.48	95.0	4.65
20.5	1.04	45.5	2.30	70.5	3.51	95.5	4.67
21.0	1.07	46.0	2.32	71.0	3.53	96.0	4.69
21.5	1.09	46.5	2.35	71.5	3.56	96.5	4.71
22.0	1.12	47.0	2.37	72.0	3.58	97.0	4.74
22.5	1.14	47.5	2.40	72.5	3.60	97.5	4.76
23.0	1.17	48.0	2.42	73.0	3.63	98.0	4.78
23.5	1.20	48.5	2.45	73.5	3.65	98.5	4.80
24.0	1.22	49.0	2.47	74.0	3.67	99.0	4.83
24.5	1.25	49.5	2.50	74.5	3.70	99.5	4.85
25.0	1.27	50.0	2.52	75.0	3.72	100.0	4.87

Temperature, °F

- 20.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 29.0								
atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.90	125.5	6.00	150.5	7.06	175.5	8.07	
101.0	4.92	126.0	6.02	151.0	7.08	176.0	8.09	
101.5	4.94	126.5	6.04	151.5	7.10	176.5	8.11	
102.0	4.96	127.0	6.06	152.0	7.12	177.0	8.13	
102.5	4.99	127.5	6.09	152.5	7.14	177.5	8.15	
103.0	5.01	128.0	6.11	153.0	7.16	178.0	8.17	
103.5	5.03	128.5	6.13	153.5	7.18	178.5	8.19	
104.0	5.05	129.0	6.15	154.0	7.20	179.0	8.21	
104.5	5.07	129.5	6.17	154.5	7.22	179.5	8.23	
105.0	5.10	130.0	6.19	155.0	7.24	180.0	8.25	
105.5	5.12	130.5	6.21	155.5	7.26	180.5	8.27	
106.0	5.14	131.0	6.24	156.0	7.28	181.0	8.29	
106.5	5.16	131.5	6.26	156.5	7.30	181.5	8.31	
107.0	5.19	132.0	6.28	157.0	7.32	182.0	8.33	
107.5	5.21	132.5	6.30	157.5	7.34	182.5	8.35	
108.0	5.23	133.0	6.32	158.0	7.37	183.0	8.36	
108.5	5.25	133.5	6.34	158.5	7.39	183.5	8.38	
109.0	5.28	134.0	6.36	159.0	7.41	184.0	8.40	
109.5	5.30	134.5	6.38	159.5	7.43	184.5	8.42	
110.0	5.32	135.0	6.41	160.0	7.45	185.0	8.44	
110.5	5.34	135.5	6.43	160.5	7.47	185.5	8.46	
111.0	5.36	136.0	6.45	161.0	7.49	186.0	8.48	
111.5	5.39	136.5	6.47	161.5	7.51	186.5	8.50	
112.0	5.41	137.0	6.49	162.0	7.53	187.0	8.52	
112.5	5.43	137.5	6.51	162.5	7.55	187.5	8.54	
113.0	5.45	138.0	6.53	163.0	7.57	188.0	8.56	
113.5	5.47	138.5	6.55	163.5	7.59	188.5	8.58	
114.0	5.50	139.0	6.58	164.0	7.61	189.0	8.60	
114.5	5.52	139.5	6.60	164.5	7.63	189.5	8.62	
115.0	5.54	140.0	6.62	165.0	7.65	190.0	8.64	
115.5	5.56	140.5	6.64	165.5	7.67	190.5	8.66	
116.0	5.58	141.0	6.66	166.0	7.69	191.0	8.68	
116.5	5.61	141.5	6.68	166.5	7.71	191.5	8.69	
117.0	5.63	142.0	6.70	167.0	7.73	192.0	8.71	
117.5	5.65	142.5	6.72	167.5	7.75	192.5	8.73	
118.0	5.67	143.0	6.74	168.0	7.77	193.0	8.75	
118.5	5.69	143.5	6.76	168.5	7.79	193.5	8.77	
119.0	5.72	144.0	6.79	169.0	7.81	194.0	8.79	
119.5	5.74	144.5	6.81	169.5	7.83	194.5	8.81	
120.0	5.76	145.0	6.83	170.0	7.85	195.0	8.83	
120.5	5.78	145.5	6.85	170.5	7.87	195.5	8.85	
121.0	5.80	146.0	6.87	171.0	7.89	196.0	8.87	
121.5	5.83	146.5	6.89	171.5	7.91	196.5	8.89	
122.0	5.85	147.0	6.91	172.0	7.93	197.0	8.91	
122.5	5.87	147.5	6.93	172.5	7.95	197.5	8.92	
123.0	5.89	148.0	6.95	173.0	7.97	198.0	8.94	
123.5	5.91	148.5	6.97	173.5	7.99	198.5	8.96	
124.0	5.93	149.0	6.99	174.0	8.01	199.0	8.98	
124.5	5.96	149.5	7.02	174.5	8.03	199.5	9.00	
125.0	5.98	150.0	7.04	175.0	8.05	200.0	9.02	

Temperature, °F - 20.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 28.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.29	50.5	2.54	75.5	3.73
1.0	0.03	26.0	1.32	51.0	2.56	76.0	3.75
1.5	0.05	26.5	1.34	51.5	2.58	76.5	3.78
2.0	0.08	27.0	1.37	52.0	2.61	77.0	3.80
2.5	0.11	27.5	1.39	52.5	2.63	77.5	3.82
3.0	0.13	28.0	1.42	53.0	2.66	78.0	3.85
3.5	0.16	28.5	1.44	53.5	2.68	78.5	3.87
4.0	0.18	29.0	1.47	54.0	2.71	79.0	3.89
4.5	0.21	29.5	1.49	54.5	2.73	79.5	3.92
5.0	0.24	30.0	1.52	55.0	2.75	80.0	3.94
5.5	0.26	30.5	1.54	55.5	2.78	80.5	3.96
6.0	0.29	31.0	1.57	56.0	2.80	81.0	3.99
6.5	0.31	31.5	1.60	56.5	2.83	81.5	4.01
7.0	0.34	32.0	1.62	57.0	2.85	82.0	4.03
7.5	0.37	32.5	1.65	57.5	2.87	82.5	4.05
8.0	0.39	33.0	1.67	58.0	2.90	83.0	4.08
8.5	0.42	33.5	1.70	58.5	2.92	83.5	4.10
9.0	0.45	34.0	1.72	59.0	2.95	84.0	4.12
9.5	0.47	34.5	1.75	59.5	2.97	84.5	4.15
10.0	0.50	35.0	1.77	60.0	2.99	85.0	4.17
10.5	0.52	35.5	1.80	60.5	3.02	85.5	4.19
11.0	0.55	36.0	1.82	61.0	3.04	86.0	4.22
11.5	0.57	36.5	1.85	61.5	3.07	86.5	4.24
12.0	0.60	37.0	1.87	62.0	3.09	87.0	4.26
12.5	0.63	37.5	1.90	62.5	3.11	87.5	4.29
13.0	0.65	38.0	1.92	63.0	3.14	88.0	4.31
13.5	0.68	38.5	1.94	63.5	3.16	88.5	4.33
14.0	0.70	39.0	1.97	64.0	3.19	89.0	4.35
14.5	0.73	39.5	1.99	64.5	3.21	89.5	4.38
15.0	0.76	40.0	2.02	65.0	3.23	90.0	4.40
15.5	0.78	40.5	2.04	65.5	3.26	90.5	4.42
16.0	0.81	41.0	2.07	66.0	3.28	91.0	4.45
16.5	0.83	41.5	2.09	66.5	3.30	91.5	4.47
17.0	0.86	42.0	2.12	67.0	3.33	92.0	4.49
17.5	0.88	42.5	2.14	67.5	3.35	92.5	4.51
18.0	0.91	43.0	2.17	68.0	3.38	93.0	4.54
18.5	0.94	43.5	2.19	68.5	3.40	93.5	4.56
19.0	0.96	44.0	2.22	69.0	3.42	94.0	4.58
19.5	0.99	44.5	2.24	69.5	3.45	94.5	4.60
20.0	1.01	45.0	2.27	70.0	3.47	95.0	4.63
20.5	1.04	45.5	2.29	70.5	3.49	95.5	4.65
21.0	1.06	46.0	2.32	71.0	3.52	96.0	4.67
21.5	1.09	46.5	2.34	71.5	3.54	96.5	4.69
22.0	1.11	47.0	2.36	72.0	3.56	97.0	4.72
22.5	1.14	47.5	2.39	72.5	3.59	97.5	4.74
23.0	1.17	48.0	2.41	73.0	3.61	98.0	4.76
23.5	1.19	48.5	2.44	73.5	3.64	98.5	4.79
24.0	1.22	49.0	2.46	74.0	3.66	99.0	4.81
24.5	1.24	49.5	2.49	74.5	3.68	99.5	4.83
25.0	1.27	50.0	2.51	75.0	3.71	100.0	4.85

Temperature, °F - 18.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C											
				- 28.0							
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.88	125.5	5.97	150.5	7.03	175.5	8.04				
101.0	4.90	126.0	6.00	151.0	7.05	176.0	8.06				
101.5	4.92	126.5	6.02	151.5	7.07	176.5	8.08				
102.0	4.94	127.0	6.04	152.0	7.09	177.0	8.10				
102.5	4.96	127.5	6.06	152.5	7.11	177.5	8.12				
103.0	4.99	128.0	6.08	153.0	7.13	178.0	8.14				
103.5	5.01	128.5	6.10	153.5	7.15	178.5	8.16				
104.0	5.03	129.0	6.12	154.0	7.17	179.0	8.18				
104.5	5.05	129.5	6.15	154.5	7.19	179.5	8.19				
105.0	5.08	130.0	6.17	155.0	7.21	180.0	8.21				
105.5	5.10	130.5	6.19	155.5	7.23	180.5	8.23				
106.0	5.12	131.0	6.21	156.0	7.25	181.0	8.25				
106.5	5.14	131.5	6.23	156.5	7.27	181.5	8.27				
107.0	5.17	132.0	6.25	157.0	7.29	182.0	8.29				
107.5	5.19	132.5	6.27	157.5	7.32	182.5	8.31				
108.0	5.21	133.0	6.30	158.0	7.34	183.0	8.33				
108.5	5.23	133.5	6.32	158.5	7.36	183.5	8.35				
109.0	5.25	134.0	6.34	159.0	7.38	184.0	8.37				
109.5	5.28	134.5	6.36	159.5	7.40	184.5	8.39				
110.0	5.30	135.0	6.38	160.0	7.42	185.0	8.41				
110.5	5.32	135.5	6.40	160.5	7.44	185.5	8.43				
111.0	5.34	136.0	6.42	161.0	7.46	186.0	8.45				
111.5	5.36	136.5	6.44	161.5	7.48	186.5	8.47				
112.0	5.39	137.0	6.46	162.0	7.50	187.0	8.49				
112.5	5.41	137.5	6.49	162.5	7.52	187.5	8.51				
113.0	5.43	138.0	6.51	163.0	7.54	188.0	8.53				
113.5	5.45	138.5	6.53	163.5	7.56	188.5	8.55				
114.0	5.47	139.0	6.55	164.0	7.58	189.0	8.56				
114.5	5.50	139.5	6.57	164.5	7.60	189.5	8.58				
115.0	5.52	140.0	6.59	165.0	7.62	190.0	8.60				
115.5	5.54	140.5	6.61	165.5	7.64	190.5	8.62				
116.0	5.56	141.0	6.63	166.0	7.66	191.0	8.64				
116.5	5.58	141.5	6.65	166.5	7.68	191.5	8.66				
117.0	5.61	142.0	6.68	167.0	7.70	192.0	8.68				
117.5	5.63	142.5	6.70	167.5	7.72	192.5	8.70				
118.0	5.65	143.0	6.72	168.0	7.74	193.0	8.72				
118.5	5.67	143.5	6.74	168.5	7.76	193.5	8.74				
119.0	5.69	144.0	6.76	169.0	7.78	194.0	8.76				
119.5	5.71	144.5	6.78	169.5	7.80	194.5	8.78				
120.0	5.74	145.0	6.80	170.0	7.82	195.0	8.79				
120.5	5.76	145.5	6.82	170.5	7.84	195.5	8.81				
121.0	5.78	146.0	6.84	171.0	7.86	196.0	8.83				
121.5	5.80	146.5	6.86	171.5	7.88	196.5	8.85				
122.0	5.82	147.0	6.88	172.0	7.90	197.0	8.87				
122.5	5.85	147.5	6.90	172.5	7.92	197.5	8.89				
123.0	5.87	148.0	6.92	173.0	7.94	198.0	8.91				
123.5	5.89	148.5	6.95	173.5	7.96	198.5	8.93				
124.0	5.91	149.0	6.97	174.0	7.98	199.0	8.95				
124.5	5.93	149.5	6.99	174.5	8.00	199.5	8.97				
125.0	5.95	150.0	7.01	175.0	8.02	200.0	8.98				

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 27.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.29	50.5	2.52	75.5	3.71
1.0	0.03	26.0	1.31	51.0	2.55	76.0	3.74
1.5	0.05	26.5	1.34	51.5	2.57	76.5	3.76
2.0	0.08	27.0	1.36	52.0	2.60	77.0	3.78
2.5	0.10	27.5	1.39	52.5	2.62	77.5	3.81
3.0	0.13	28.0	1.41	53.0	2.65	78.0	3.83
3.5	0.16	28.5	1.44	53.5	2.67	78.5	3.85
4.0	0.18	29.0	1.46	54.0	2.69	79.0	3.88
4.5	0.21	29.5	1.49	54.5	2.72	79.5	3.90
5.0	0.24	30.0	1.51	55.0	2.74	80.0	3.92
5.5	0.26	30.5	1.54	55.5	2.77	80.5	3.95
6.0	0.29	31.0	1.56	56.0	2.79	81.0	3.97
6.5	0.31	31.5	1.59	56.5	2.81	81.5	3.99
7.0	0.34	32.0	1.61	57.0	2.84	82.0	4.02
7.5	0.37	32.5	1.64	57.5	2.86	82.5	4.04
8.0	0.39	33.0	1.66	58.0	2.89	83.0	4.06
8.5	0.42	33.5	1.69	58.5	2.91	83.5	4.08
9.0	0.44	34.0	1.71	59.0	2.93	84.0	4.11
9.5	0.47	34.5	1.74	59.5	2.96	84.5	4.13
10.0	0.49	35.0	1.76	60.0	2.98	85.0	4.15
10.5	0.52	35.5	1.79	60.5	3.01	85.5	4.18
11.0	0.55	36.0	1.81	61.0	3.03	86.0	4.20
11.5	0.57	36.5	1.84	61.5	3.05	86.5	4.22
12.0	0.60	37.0	1.86	62.0	3.08	87.0	4.24
12.5	0.62	37.5	1.89	62.5	3.10	87.5	4.27
13.0	0.65	38.0	1.91	63.0	3.13	88.0	4.29
13.5	0.68	38.5	1.94	63.5	3.15	88.5	4.31
14.0	0.70	39.0	1.96	64.0	3.17	89.0	4.34
14.5	0.73	39.5	1.99	64.5	3.20	89.5	4.36
15.0	0.75	40.0	2.01	65.0	3.22	90.0	4.38
15.5	0.78	40.5	2.04	65.5	3.24	90.5	4.40
16.0	0.80	41.0	2.06	66.0	3.27	91.0	4.43
16.5	0.83	41.5	2.08	66.5	3.29	91.5	4.45
17.0	0.86	42.0	2.11	67.0	3.31	92.0	4.47
17.5	0.88	42.5	2.13	67.5	3.34	92.5	4.50
18.0	0.91	43.0	2.16	68.0	3.36	93.0	4.52
18.5	0.93	43.5	2.18	68.5	3.39	93.5	4.54
19.0	0.96	44.0	2.21	69.0	3.41	94.0	4.56
19.5	0.98	44.5	2.23	69.5	3.43	94.5	4.59
20.0	1.01	45.0	2.26	70.0	3.46	95.0	4.61
20.5	1.03	45.5	2.28	70.5	3.48	95.5	4.63
21.0	1.06	46.0	2.31	71.0	3.50	96.0	4.65
21.5	1.08	46.5	2.33	71.5	3.53	96.5	4.68
22.0	1.11	47.0	2.35	72.0	3.55	97.0	4.70
22.5	1.14	47.5	2.38	72.5	3.57	97.5	4.72
23.0	1.16	48.0	2.40	73.0	3.60	98.0	4.74
23.5	1.19	48.5	2.43	73.5	3.62	98.5	4.77
24.0	1.21	49.0	2.45	74.0	3.64	99.0	4.79
24.5	1.24	49.5	2.48	74.5	3.67	99.5	4.81
25.0	1.26	50.0	2.50	75.0	3.69	100.0	4.83

Temperature, °F - 16.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 27.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.86	125.5	5.95	150.5	7.00	175.5	8.01				
101.0	4.88	126.0	5.97	151.0	7.02	176.0	8.03				
101.5	4.90	126.5	5.99	151.5	7.04	176.5	8.05				
102.0	4.92	127.0	6.01	152.0	7.06	177.0	8.06				
102.5	4.94	127.5	6.04	152.5	7.08	177.5	8.08				
103.0	4.97	128.0	6.06	153.0	7.10	178.0	8.10				
103.5	4.99	128.5	6.08	153.5	7.12	178.5	8.12				
104.0	5.01	129.0	6.10	154.0	7.14	179.0	8.14				
104.5	5.03	129.5	6.12	154.5	7.16	179.5	8.16				
105.0	5.06	130.0	6.14	155.0	7.18	180.0	8.18				
105.5	5.08	130.5	6.16	155.5	7.20	180.5	8.20				
106.0	5.10	131.0	6.19	156.0	7.23	181.0	8.22				
106.5	5.12	131.5	6.21	156.5	7.25	181.5	8.24				
107.0	5.14	132.0	6.23	157.0	7.27	182.0	8.26				
107.5	5.17	132.5	6.25	157.5	7.29	182.5	8.28				
108.0	5.19	133.0	6.27	158.0	7.31	183.0	8.30				
108.5	5.21	133.5	6.29	158.5	7.33	183.5	8.32				
109.0	5.23	134.0	6.31	159.0	7.35	184.0	8.34				
109.5	5.26	134.5	6.33	159.5	7.37	184.5	8.36				
110.0	5.28	135.0	6.35	160.0	7.39	185.0	8.38				
110.5	5.30	135.5	6.38	160.5	7.41	185.5	8.40				
111.0	5.32	136.0	6.40	161.0	7.43	186.0	8.42				
111.5	5.34	136.5	6.42	161.5	7.45	186.5	8.43				
112.0	5.36	137.0	6.44	162.0	7.47	187.0	8.45				
112.5	5.39	137.5	6.46	162.5	7.49	187.5	8.47				
113.0	5.41	138.0	6.48	163.0	7.51	188.0	8.49				
113.5	5.43	138.5	6.50	163.5	7.53	188.5	8.51				
114.0	5.45	139.0	6.52	164.0	7.55	189.0	8.53				
114.5	5.47	139.5	6.54	164.5	7.57	189.5	8.55				
115.0	5.50	140.0	6.56	165.0	7.59	190.0	8.57				
115.5	5.52	140.5	6.59	165.5	7.61	190.5	8.59				
116.0	5.54	141.0	6.61	166.0	7.63	191.0	8.61				
116.5	5.56	141.5	6.63	166.5	7.65	191.5	8.63				
117.0	5.58	142.0	6.65	167.0	7.67	192.0	8.65				
117.5	5.61	142.5	6.67	167.5	7.69	192.5	8.66				
118.0	5.63	143.0	6.69	168.0	7.71	193.0	8.68				
118.5	5.65	143.5	6.71	168.5	7.73	193.5	8.70				
119.0	5.67	144.0	6.73	169.0	7.75	194.0	8.72				
119.5	5.69	144.5	6.75	169.5	7.77	194.5	8.74				
120.0	5.71	145.0	6.77	170.0	7.79	195.0	8.76				
120.5	5.74	145.5	6.79	170.5	7.81	195.5	8.78				
121.0	5.76	146.0	6.81	171.0	7.83	196.0	8.80				
121.5	5.78	146.5	6.84	171.5	7.85	196.5	8.82				
122.0	5.80	147.0	6.86	172.0	7.87	197.0	8.84				
122.5	5.82	147.5	6.88	172.5	7.89	197.5	8.86				
123.0	5.84	148.0	6.90	173.0	7.91	198.0	8.87				
123.5	5.86	148.5	6.92	173.5	7.93	198.5	8.89				
124.0	5.89	149.0	6.94	174.0	7.95	199.0	8.91				
124.5	5.91	149.5	6.96	174.5	7.97	199.5	8.93				
125.0	5.93	150.0	6.98	175.0	7.99	200.0	8.95				

Temperature, °F - 16.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C							
						- 26.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.28	50.5	2.51	75.5	3.70
1.0	0.03	26.0	1.31	51.0	2.54	76.0	3.72
1.5	0.05	26.5	1.33	51.5	2.56	76.5	3.75
2.0	0.08	27.0	1.36	52.0	2.59	77.0	3.77
2.5	0.10	27.5	1.38	52.5	2.61	77.5	3.79
3.0	0.13	28.0	1.41	53.0	2.64	78.0	3.81
3.5	0.16	28.5	1.43	53.5	2.66	78.5	3.84
4.0	0.18	29.0	1.46	54.0	2.68	79.0	3.86
4.5	0.21	29.5	1.48	54.5	2.71	79.5	3.88
5.0	0.23	30.0	1.51	55.0	2.73	80.0	3.91
5.5	0.26	30.5	1.53	55.5	2.76	80.5	3.93
6.0	0.29	31.0	1.56	56.0	2.78	81.0	3.95
6.5	0.31	31.5	1.58	56.5	2.80	81.5	3.98
7.0	0.34	32.0	1.61	57.0	2.83	82.0	4.00
7.5	0.36	32.5	1.63	57.5	2.85	82.5	4.02
8.0	0.39	33.0	1.66	58.0	2.87	83.0	4.04
8.5	0.42	33.5	1.68	58.5	2.90	83.5	4.07
9.0	0.44	34.0	1.71	59.0	2.92	84.0	4.09
9.5	0.47	34.5	1.73	59.5	2.95	84.5	4.11
10.0	0.49	35.0	1.76	60.0	2.97	85.0	4.14
10.5	0.52	35.5	1.78	60.5	2.99	85.5	4.16
11.0	0.54	36.0	1.81	61.0	3.02	86.0	4.18
11.5	0.57	36.5	1.83	61.5	3.04	86.5	4.20
12.0	0.60	37.0	1.85	62.0	3.07	87.0	4.23
12.5	0.62	37.5	1.88	62.5	3.09	87.5	4.25
13.0	0.65	38.0	1.90	63.0	3.11	88.0	4.27
13.5	0.67	38.5	1.93	63.5	3.14	88.5	4.30
14.0	0.70	39.0	1.95	64.0	3.16	89.0	4.32
14.5	0.72	39.5	1.98	64.5	3.18	89.5	4.34
15.0	0.75	40.0	2.00	65.0	3.21	90.0	4.36
15.5	0.78	40.5	2.03	65.5	3.23	90.5	4.39
16.0	0.80	41.0	2.05	66.0	3.25	91.0	4.41
16.5	0.83	41.5	2.08	66.5	3.28	91.5	4.43
17.0	0.85	42.0	2.10	67.0	3.30	92.0	4.45
17.5	0.88	42.5	2.13	67.5	3.33	92.5	4.48
18.0	0.90	43.0	2.15	68.0	3.35	93.0	4.50
18.5	0.93	43.5	2.17	68.5	3.37	93.5	4.52
19.0	0.95	44.0	2.20	69.0	3.40	94.0	4.54
19.5	0.98	44.5	2.22	69.5	3.42	94.5	4.57
20.0	1.00	45.0	2.25	70.0	3.44	95.0	4.59
20.5	1.03	45.5	2.27	70.5	3.47	95.5	4.61
21.0	1.05	46.0	2.30	71.0	3.49	96.0	4.63
21.5	1.08	46.5	2.32	71.5	3.51	96.5	4.66
22.0	1.11	47.0	2.34	72.0	3.54	97.0	4.68
22.5	1.13	47.5	2.37	72.5	3.56	97.5	4.70
23.0	1.16	48.0	2.39	73.0	3.58	98.0	4.72
23.5	1.18	48.5	2.42	73.5	3.61	98.5	4.75
24.0	1.21	49.0	2.44	74.0	3.63	99.0	4.77
24.5	1.23	49.5	2.47	74.5	3.65	99.5	4.79
25.0	1.26	50.0	2.49	75.0	3.68	100.0	4.81

Temperature, °F - 14.8

		Temperature, °C					
		- 26.0					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	4.84	125.5	5.93	150.5	6.97	175.5	7.97
101.0	4.86	126.0	5.95	151.0	6.99	176.0	7.99
101.5	4.88	126.5	5.97	151.5	7.01	176.5	8.01
102.0	4.90	127.0	5.99	152.0	7.03	177.0	8.03
102.5	4.92	127.5	6.01	152.5	7.05	177.5	8.05
103.0	4.95	128.0	6.03	153.0	7.07	178.0	8.07
103.5	4.97	128.5	6.05	153.5	7.10	178.5	8.09
104.0	4.99	129.0	6.08	154.0	7.12	179.0	8.11
104.5	5.01	129.5	6.10	154.5	7.14	179.5	8.13
105.0	5.04	130.0	6.12	155.0	7.16	180.0	8.15
105.5	5.06	130.5	6.14	155.5	7.18	180.5	8.17
106.0	5.08	131.0	6.16	156.0	7.20	181.0	8.19
106.5	5.10	131.5	6.18	156.5	7.22	181.5	8.21
107.0	5.12	132.0	6.20	157.0	7.24	182.0	8.23
107.5	5.15	132.5	6.22	157.5	7.26	182.5	8.25
108.0	5.17	133.0	6.25	158.0	7.28	183.0	8.27
108.5	5.19	133.5	6.27	158.5	7.30	183.5	8.29
109.0	5.21	134.0	6.29	159.0	7.32	184.0	8.31
109.5	5.23	134.5	6.31	159.5	7.34	184.5	8.32
110.0	5.26	135.0	6.33	160.0	7.36	185.0	8.34
110.5	5.28	135.5	6.35	160.5	7.38	185.5	8.36
111.0	5.30	136.0	6.37	161.0	7.40	186.0	8.38
111.5	5.32	136.5	6.39	161.5	7.42	186.5	8.40
112.0	5.34	137.0	6.41	162.0	7.44	187.0	8.42
112.5	5.37	137.5	6.43	162.5	7.46	187.5	8.44
113.0	5.39	138.0	6.46	163.0	7.48	188.0	8.46
113.5	5.41	138.5	6.48	163.5	7.50	188.5	8.48
114.0	5.43	139.0	6.50	164.0	7.52	189.0	8.50
114.5	5.45	139.5	6.52	164.5	7.54	189.5	8.52
115.0	5.47	140.0	6.54	165.0	7.56	190.0	8.54
115.5	5.50	140.5	6.56	165.5	7.58	190.5	8.55
116.0	5.52	141.0	6.58	166.0	7.60	191.0	8.57
116.5	5.54	141.5	6.60	166.5	7.62	191.5	8.59
117.0	5.56	142.0	6.62	167.0	7.64	192.0	8.61
117.5	5.58	142.5	6.64	167.5	7.66	192.5	8.63
118.0	5.60	143.0	6.66	168.0	7.68	193.0	8.65
118.5	5.63	143.5	6.68	168.5	7.70	193.5	8.67
119.0	5.65	144.0	6.70	169.0	7.72	194.0	8.69
119.5	5.67	144.5	6.73	169.5	7.74	194.5	8.71
120.0	5.69	145.0	6.75	170.0	7.76	195.0	8.73
120.5	5.71	145.5	6.77	170.5	7.78	195.5	8.74
121.0	5.73	146.0	6.79	171.0	7.80	196.0	8.76
121.5	5.76	146.5	6.81	171.5	7.82	196.5	8.78
122.0	5.78	147.0	6.83	172.0	7.84	197.0	8.80
122.5	5.80	147.5	6.85	172.5	7.86	197.5	8.82
123.0	5.82	148.0	6.87	173.0	7.88	198.0	8.84
123.5	5.84	148.5	6.89	173.5	7.90	198.5	8.86
124.0	5.86	149.0	6.91	174.0	7.92	199.0	8.88
124.5	5.88	149.5	6.93	174.5	7.94	199.5	8.90
125.0	5.91	150.0	6.95	175.0	7.95	200.0	8.91

Temperature, °F - 14.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				- 25.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.28	50.5	2.50	75.5	3.68
1.0	0.03	26.0	1.30	51.0	2.53	76.0	3.71
1.5	0.05	26.5	1.33	51.5	2.55	76.5	3.73
2.0	0.08	27.0	1.35	52.0	2.58	77.0	3.75
2.5	0.10	27.5	1.38	52.5	2.60	77.5	3.78
3.0	0.13	28.0	1.40	53.0	2.62	78.0	3.80
3.5	0.16	28.5	1.43	53.5	2.65	78.5	3.82
4.0	0.18	29.0	1.45	54.0	2.67	79.0	3.85
4.5	0.21	29.5	1.48	54.5	2.70	79.5	3.87
5.0	0.23	30.0	1.50	55.0	2.72	80.0	3.89
5.5	0.26	30.5	1.53	55.5	2.74	80.5	3.91
6.0	0.29	31.0	1.55	56.0	2.77	81.0	3.94
6.5	0.31	31.5	1.58	56.5	2.79	81.5	3.96
7.0	0.34	32.0	1.60	57.0	2.82	82.0	3.98
7.5	0.36	32.5	1.63	57.5	2.84	82.5	4.01
8.0	0.39	33.0	1.65	58.0	2.86	83.0	4.03
8.5	0.41	33.5	1.67	58.5	2.89	83.5	4.05
9.0	0.44	34.0	1.70	59.0	2.91	84.0	4.07
9.5	0.47	34.5	1.72	59.5	2.93	84.5	4.10
10.0	0.49	35.0	1.75	60.0	2.96	85.0	4.12
10.5	0.52	35.5	1.77	60.5	2.98	85.5	4.14
11.0	0.54	36.0	1.80	61.0	3.01	86.0	4.17
11.5	0.57	36.5	1.82	61.5	3.03	86.5	4.19
12.0	0.59	37.0	1.85	62.0	3.05	87.0	4.21
12.5	0.62	37.5	1.87	62.5	3.08	87.5	4.23
13.0	0.64	38.0	1.90	63.0	3.10	88.0	4.26
13.5	0.67	38.5	1.92	63.5	3.12	88.5	4.28
14.0	0.70	39.0	1.95	64.0	3.15	89.0	4.30
14.5	0.72	39.5	1.97	64.5	3.17	89.5	4.32
15.0	0.75	40.0	1.99	65.0	3.19	90.0	4.35
15.5	0.77	40.5	2.02	65.5	3.22	90.5	4.37
16.0	0.80	41.0	2.04	66.0	3.24	91.0	4.39
16.5	0.82	41.5	2.07	66.5	3.26	91.5	4.41
17.0	0.85	42.0	2.09	67.0	3.29	92.0	4.44
17.5	0.87	42.5	2.12	67.5	3.31	92.5	4.46
18.0	0.90	43.0	2.14	68.0	3.34	93.0	4.48
18.5	0.92	43.5	2.17	68.5	3.36	93.5	4.50
19.0	0.95	44.0	2.19	69.0	3.38	94.0	4.53
19.5	0.97	44.5	2.21	69.5	3.41	94.5	4.55
20.0	1.00	45.0	2.24	70.0	3.43	95.0	4.57
20.5	1.03	45.5	2.26	70.5	3.45	95.5	4.59
21.0	1.05	46.0	2.29	71.0	3.48	96.0	4.62
21.5	1.08	46.5	2.31	71.5	3.50	96.5	4.64
22.0	1.10	47.0	2.34	72.0	3.52	97.0	4.66
22.5	1.13	47.5	2.36	72.5	3.54	97.5	4.68
23.0	1.15	48.0	2.38	73.0	3.57	98.0	4.71
23.5	1.18	48.5	2.41	73.5	3.59	98.5	4.73
24.0	1.20	49.0	2.43	74.0	3.61	99.0	4.75
24.5	1.23	49.5	2.46	74.5	3.64	99.5	4.77
25.0	1.25	50.0	2.48	75.0	3.66	100.0	4.79

Temperature, °F - 13.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 25.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.82	125.5	5.90	150.5	6.94	175.5	7.94				
101.0	4.84	126.0	5.92	151.0	6.97	176.0	7.96				
101.5	4.86	126.5	5.95	151.5	6.99	176.5	7.98				
102.0	4.88	127.0	5.97	152.0	7.01	177.0	8.00				
102.5	4.91	127.5	5.99	152.5	7.03	177.5	8.02				
103.0	4.93	128.0	6.01	153.0	7.05	178.0	8.04				
103.5	4.95	128.5	6.03	153.5	7.07	178.5	8.06				
104.0	4.97	129.0	6.05	154.0	7.09	179.0	8.08				
104.5	4.99	129.5	6.07	154.5	7.11	179.5	8.10				
105.0	5.02	130.0	6.09	155.0	7.13	180.0	8.12				
105.5	5.04	130.5	6.12	155.5	7.15	180.5	8.14				
106.0	5.06	131.0	6.14	156.0	7.17	181.0	8.16				
106.5	5.08	131.5	6.16	156.5	7.19	181.5	8.18				
107.0	5.10	132.0	6.18	157.0	7.21	182.0	8.20				
107.5	5.13	132.5	6.20	157.5	7.23	182.5	8.21				
108.0	5.15	133.0	6.22	158.0	7.25	183.0	8.23				
108.5	5.17	133.5	6.24	158.5	7.27	183.5	8.25				
109.0	5.19	134.0	6.26	159.0	7.29	184.0	8.27				
109.5	5.21	134.5	6.28	159.5	7.31	184.5	8.29				
110.0	5.23	135.0	6.30	160.0	7.33	185.0	8.31				
110.5	5.26	135.5	6.33	160.5	7.35	185.5	8.33				
111.0	5.28	136.0	6.35	161.0	7.37	186.0	8.35				
111.5	5.30	136.5	6.37	161.5	7.39	186.5	8.37				
112.0	5.32	137.0	6.39	162.0	7.41	187.0	8.39				
112.5	5.34	137.5	6.41	162.5	7.43	187.5	8.41				
113.0	5.37	138.0	6.43	163.0	7.45	188.0	8.43				
113.5	5.39	138.5	6.45	163.5	7.47	188.5	8.45				
114.0	5.41	139.0	6.47	164.0	7.49	189.0	8.46				
114.5	5.43	139.5	6.49	164.5	7.51	189.5	8.48				
115.0	5.45	140.0	6.51	165.0	7.53	190.0	8.50				
115.5	5.47	140.5	6.53	165.5	7.55	190.5	8.52				
116.0	5.50	141.0	6.55	166.0	7.57	191.0	8.54				
116.5	5.52	141.5	6.57	166.5	7.59	191.5	8.56				
117.0	5.54	142.0	6.60	167.0	7.61	192.0	8.58				
117.5	5.56	142.5	6.62	167.5	7.63	192.5	8.60				
118.0	5.58	143.0	6.64	168.0	7.65	193.0	8.62				
118.5	5.60	143.5	6.66	168.5	7.67	193.5	8.64				
119.0	5.62	144.0	6.68	169.0	7.69	194.0	8.65				
119.5	5.65	144.5	6.70	169.5	7.71	194.5	8.67				
120.0	5.67	145.0	6.72	170.0	7.73	195.0	8.69				
120.5	5.69	145.5	6.74	170.5	7.75	195.5	8.71				
121.0	5.71	146.0	6.76	171.0	7.77	196.0	8.73				
121.5	5.73	146.5	6.78	171.5	7.79	196.5	8.75				
122.0	5.75	147.0	6.80	172.0	7.81	197.0	8.77				
122.5	5.78	147.5	6.82	172.5	7.83	197.5	8.79				
123.0	5.80	148.0	6.84	173.0	7.85	198.0	8.81				
123.5	5.82	148.5	6.86	173.5	7.86	198.5	8.82				
124.0	5.84	149.0	6.88	174.0	7.88	199.0	8.84				
124.5	5.86	149.5	6.90	174.5	7.90	199.5	8.86				
125.0	5.88	150.0	6.92	175.0	7.92	200.0	8.88				

Temperature, °F - 13.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 24.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.27	50.5	2.49	75.5	3.67
1.0	0.03	26.0	1.30	51.0	2.52	76.0	3.69
1.5	0.05	26.5	1.32	51.5	2.54	76.5	3.72
2.0	0.08	27.0	1.35	52.0	2.57	77.0	3.74
2.5	0.10	27.5	1.37	52.5	2.59	77.5	3.76
3.0	0.13	28.0	1.40	53.0	2.61	78.0	3.78
3.5	0.16	28.5	1.42	53.5	2.64	78.5	3.81
4.0	0.18	29.0	1.45	54.0	2.66	79.0	3.83
4.5	0.21	29.5	1.47	54.5	2.69	79.5	3.85
5.0	0.23	30.0	1.50	55.0	2.71	80.0	3.88
5.5	0.26	30.5	1.52	55.5	2.73	80.5	3.90
6.0	0.28	31.0	1.54	56.0	2.76	81.0	3.92
6.5	0.31	31.5	1.57	56.5	2.78	81.5	3.94
7.0	0.34	32.0	1.59	57.0	2.80	82.0	3.97
7.5	0.36	32.5	1.62	57.5	2.83	82.5	3.99
8.0	0.39	33.0	1.64	58.0	2.85	83.0	4.01
8.5	0.41	33.5	1.67	58.5	2.88	83.5	4.04
9.0	0.44	34.0	1.69	59.0	2.90	84.0	4.06
9.5	0.46	34.5	1.72	59.5	2.92	84.5	4.08
10.0	0.49	35.0	1.74	60.0	2.95	85.0	4.10
10.5	0.51	35.5	1.77	60.5	2.97	85.5	4.13
11.0	0.54	36.0	1.79	61.0	2.99	86.0	4.15
11.5	0.57	36.5	1.82	61.5	3.02	86.5	4.17
12.0	0.59	37.0	1.84	62.0	3.04	87.0	4.19
12.5	0.62	37.5	1.86	62.5	3.06	87.5	4.22
13.0	0.64	38.0	1.89	63.0	3.09	88.0	4.24
13.5	0.67	38.5	1.91	63.5	3.11	88.5	4.26
14.0	0.69	39.0	1.94	64.0	3.13	89.0	4.28
14.5	0.72	39.5	1.96	64.5	3.16	89.5	4.31
15.0	0.74	40.0	1.99	65.0	3.18	90.0	4.33
15.5	0.77	40.5	2.01	65.5	3.20	90.5	4.35
16.0	0.79	41.0	2.04	66.0	3.23	91.0	4.37
16.5	0.82	41.5	2.06	66.5	3.25	91.5	4.40
17.0	0.84	42.0	2.08	67.0	3.27	92.0	4.42
17.5	0.87	42.5	2.11	67.5	3.30	92.5	4.44
18.0	0.90	43.0	2.13	68.0	3.32	93.0	4.46
18.5	0.92	43.5	2.16	68.5	3.34	93.5	4.49
19.0	0.95	44.0	2.18	69.0	3.37	94.0	4.51
19.5	0.97	44.5	2.21	69.5	3.39	94.5	4.53
20.0	1.00	45.0	2.23	70.0	3.41	95.0	4.55
20.5	1.02	45.5	2.25	70.5	3.44	95.5	4.58
21.0	1.05	46.0	2.28	71.0	3.46	96.0	4.60
21.5	1.07	46.5	2.30	71.5	3.48	96.5	4.62
22.0	1.10	47.0	2.33	72.0	3.51	97.0	4.64
22.5	1.12	47.5	2.35	72.5	3.53	97.5	4.66
23.0	1.15	48.0	2.37	73.0	3.55	98.0	4.69
23.5	1.17	48.5	2.40	72.5	3.58	98.5	4.71
24.0	1.20	49.0	2.42	74.0	3.60	99.0	4.73
24.5	1.22	49.5	2.45	74.5	3.62	99.5	4.75
25.0	1.25	50.0	2.47	75.0	3.65	100.0	4.78

Temperature, °F

- 11.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 24.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.80	125.5	5.88	150.5	6.92	175.5	7.91				
101.0	4.82	126.0	5.90	151.0	6.94	176.0	7.93				
101.5	4.84	126.5	5.92	151.5	6.96	176.5	7.95				
102.0	4.86	127.0	5.94	152.0	6.98	177.0	7.97				
102.5	4.89	127.5	5.96	152.5	7.00	177.5	7.99				
103.0	4.91	128.0	5.99	153.0	7.02	178.0	8.01				
103.5	4.93	128.5	6.01	153.5	7.04	178.5	8.03				
104.0	4.95	129.0	6.03	154.0	7.06	179.0	8.05				
104.5	4.97	129.5	6.05	154.5	7.08	179.5	8.07				
105.0	5.00	130.0	6.07	155.0	7.10	180.0	8.09				
105.5	5.02	130.5	6.09	155.5	7.12	180.5	8.11				
106.0	5.04	131.0	6.11	156.0	7.14	181.0	8.13				
106.5	5.06	131.5	6.13	156.5	7.16	181.5	8.14				
107.0	5.08	132.0	6.15	157.0	7.18	182.0	8.16				
107.5	5.10	132.5	6.17	157.5	7.20	182.5	8.18				
108.0	5.13	133.0	6.20	158.0	7.22	183.0	8.20				
108.5	5.15	133.5	6.22	158.5	7.24	183.5	8.22				
109.0	5.17	134.0	6.24	159.0	7.26	184.0	8.24				
109.5	5.19	134.5	6.26	159.5	7.28	184.5	8.26				
110.0	5.21	135.0	6.28	160.0	7.30	185.0	8.28				
110.5	5.24	135.5	6.30	160.5	7.32	185.5	8.30				
111.0	5.26	136.0	6.32	161.0	7.34	186.0	8.32				
111.5	5.28	136.5	6.34	161.5	7.36	186.5	8.34				
112.0	5.30	137.0	6.36	162.0	7.38	187.0	8.36				
112.5	5.32	137.5	6.38	162.5	7.40	187.5	8.37				
113.0	5.34	138.0	6.40	163.0	7.42	188.0	8.39				
113.5	5.37	138.5	6.42	163.5	7.44	188.5	8.41				
114.0	5.39	139.0	6.45	164.0	7.46	189.0	8.43				
114.5	5.41	139.5	6.47	164.5	7.48	189.5	8.45				
115.0	5.43	140.0	6.49	165.0	7.50	190.0	8.47				
115.5	5.45	140.5	6.51	165.5	7.52	190.5	8.49				
116.0	5.47	141.0	6.53	166.0	7.54	191.0	8.51				
116.5	5.50	141.5	6.55	166.5	7.56	191.5	8.53				
117.0	5.52	142.0	6.57	167.0	7.58	192.0	8.55				
117.5	5.54	142.5	6.59	167.5	7.60	192.5	8.56				
118.0	5.56	143.0	6.61	168.0	7.62	193.0	8.58				
118.5	5.58	143.5	6.63	168.5	7.64	193.5	8.60				
119.0	5.60	144.0	6.65	169.0	7.66	194.0	8.62				
119.5	5.62	144.5	6.67	169.5	7.68	194.5	8.64				
120.0	5.65	145.0	6.69	170.0	7.70	195.0	8.66				
120.5	5.67	145.5	6.71	170.5	7.72	195.5	8.68				
121.0	5.69	146.0	6.73	171.0	7.74	196.0	8.70				
121.5	5.71	146.5	6.75	171.5	7.76	196.5	8.71				
122.0	5.73	147.0	6.77	172.0	7.78	197.0	8.73				
122.5	5.75	147.5	6.80	172.5	7.79	197.5	8.75				
123.0	5.77	148.0	6.82	173.0	7.81	198.0	8.77				
123.5	5.79	148.5	6.84	173.5	7.83	198.5	8.79				
124.0	5.82	149.0	6.86	174.0	7.85	199.0	8.81				
124.5	5.84	149.5	6.88	174.5	7.87	199.5	8.83				
125.0	5.86	150.0	6.90	175.0	7.89	200.0	8.85				

Temperature, °F

- 11.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

← 23.0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.27	50.5	2.48	75.5	3.65
1.0	0.03	26.0	1.29	51.0	2.51	76.0	3.68
1.5	0.05	26.5	1.32	51.5	2.53	76.5	3.70
2.0	0.08	27.0	1.34	52.0	2.56	77.0	3.72
2.5	0.10	27.5	1.37	52.5	2.58	77.5	3.75
3.0	0.13	28.0	1.39	53.0	2.60	78.0	3.77
3.5	0.15	28.5	1.42	53.5	2.63	78.5	3.79
4.0	0.18	29.0	1.44	54.0	2.65	79.0	3.81
4.5	0.21	29.5	1.46	54.5	2.67	79.5	3.84
5.0	0.23	30.0	1.49	55.0	2.70	80.0	3.86
5.5	0.26	30.5	1.51	55.5	2.72	80.5	3.88
6.0	0.28	31.0	1.54	56.0	2.75	81.0	3.91
6.5	0.31	31.5	1.56	56.5	2.77	81.5	3.93
7.0	0.33	32.0	1.59	57.0	2.79	82.0	3.95
7.5	0.36	32.5	1.61	57.5	2.82	82.5	3.97
8.0	0.39	33.0	1.64	58.0	2.84	83.0	4.00
8.5	0.41	33.5	1.66	58.5	2.86	83.5	4.02
9.0	0.44	34.0	1.69	59.0	2.89	84.0	4.04
9.5	0.46	34.5	1.71	59.5	2.91	84.5	4.06
10.0	0.49	35.0	1.73	60.0	2.93	85.0	4.09
10.5	0.51	35.5	1.76	60.5	2.96	85.5	4.11
11.0	0.54	36.0	1.78	61.0	2.98	86.0	4.13
11.5	0.56	36.5	1.81	61.5	3.00	86.5	4.15
12.0	0.59	37.0	1.83	62.0	3.03	87.0	4.18
12.5	0.61	37.5	1.86	62.5	3.05	87.5	4.20
13.0	0.64	38.0	1.88	63.0	3.08	88.0	4.22
13.5	0.66	38.5	1.91	63.5	3.10	88.5	4.24
14.0	0.69	39.0	1.93	64.0	3.12	89.0	4.27
14.5	0.72	39.5	1.95	64.5	3.15	89.5	4.29
15.0	0.74	40.0	1.98	65.0	3.17	90.0	4.31
15.5	0.77	40.5	2.00	65.5	3.19	90.5	4.33
16.0	0.79	41.0	2.03	66.0	3.22	91.0	4.36
16.5	0.82	41.5	2.05	66.5	3.24	91.5	4.38
17.0	0.84	42.0	2.08	67.0	3.26	92.0	4.40
17.5	0.87	42.5	2.10	67.5	3.29	92.5	4.42
18.0	0.89	43.0	2.12	68.0	3.31	93.0	4.45
18.5	0.92	43.5	2.15	68.5	3.33	93.5	4.47
19.0	0.94	44.0	2.17	69.0	3.35	94.0	4.49
19.5	0.97	44.5	2.20	69.5	3.38	94.5	4.51
20.0	0.99	45.0	2.22	70.0	3.40	95.0	4.53
20.5	1.02	45.5	2.24	70.5	3.42	95.5	4.56
21.0	1.04	46.0	2.27	71.0	3.45	96.0	4.58
21.5	1.07	46.5	2.29	71.5	3.47	96.5	4.60
22.0	1.09	47.0	2.32	72.0	3.49	97.0	4.62
22.5	1.12	47.5	2.34	72.5	3.52	97.5	4.65
23.0	1.14	48.0	2.36	73.0	3.54	98.0	4.67
23.5	1.17	48.5	2.39	73.5	3.56	98.5	4.69
24.0	1.19	49.0	2.41	74.0	3.59	99.0	4.71
24.5	1.22	49.5	2.44	74.5	3.61	99.5	4.73
25.0	1.24	50.0	2.46	75.0	3.63	100.0	4.76

Temperature, °F

← 9.4

Temperature, °C

- 23.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.78	125.5	5.86	150.5	6.89	175.5	7.88				
101.0	4.80	126.0	5.88	151.0	6.91	176.0	7.90				
101.5	4.82	126.5	5.90	151.5	6.93	176.5	7.92				
102.0	4.84	127.0	5.92	152.0	6.95	177.0	7.94				
102.5	4.87	127.5	5.94	152.5	6.97	177.5	7.96				
103.0	4.89	128.0	5.96	153.0	6.99	178.0	7.98				
103.5	4.91	128.5	5.98	153.5	7.01	178.5	8.00				
104.0	4.93	129.0	6.00	154.0	7.03	179.0	8.02				
104.5	4.95	129.5	6.02	154.5	7.05	179.5	8.04				
105.0	4.98	130.0	6.05	155.0	7.07	180.0	8.06				
105.5	5.00	130.5	6.07	155.5	7.09	180.5	8.07				
106.0	5.02	131.0	6.09	156.0	7.11	181.0	8.09				
106.5	5.04	131.5	6.11	156.5	7.13	181.5	8.11				
107.0	5.06	132.0	6.13	157.0	7.15	182.0	8.13				
107.5	5.08	132.5	6.15	157.5	7.17	182.5	8.15				
108.0	5.11	133.0	6.17	158.0	7.19	183.0	8.17				
108.5	5.13	133.5	6.19	158.5	7.21	183.5	8.19				
109.0	5.15	134.0	6.21	159.0	7.23	184.0	8.21				
109.5	5.17	134.5	6.23	159.5	7.25	184.5	8.23				
110.0	5.19	135.0	6.25	160.0	7.27	185.0	8.25				
110.5	5.21	135.5	6.28	160.5	7.29	185.5	8.27				
111.0	5.24	136.0	6.30	161.0	7.31	186.0	8.28				
111.5	5.26	136.5	6.32	161.5	7.33	186.5	8.30				
112.0	5.28	137.0	6.34	162.0	7.35	187.0	8.32				
112.5	5.30	137.5	6.36	162.5	7.37	187.5	8.34				
113.0	5.32	138.0	6.38	163.0	7.39	188.0	8.36				
113.5	5.34	138.5	6.40	163.5	7.41	188.5	8.38				
114.0	5.37	139.0	6.42	164.0	7.43	189.0	8.40				
114.5	5.39	139.5	6.44	164.5	7.45	189.5	8.42				
115.0	5.41	140.0	6.46	165.0	7.47	190.0	8.44				
115.5	5.43	140.5	6.48	165.5	7.49	190.5	8.46				
116.0	5.45	141.0	6.50	166.0	7.51	191.0	8.47				
116.5	5.47	141.5	6.52	166.5	7.53	191.5	8.49				
117.0	5.49	142.0	6.54	167.0	7.55	192.0	8.51				
117.5	5.52	142.5	6.56	167.5	7.57	192.5	8.53				
118.0	5.54	143.0	6.58	168.0	7.59	193.0	8.55				
118.5	5.56	143.5	6.61	168.5	7.61	193.5	8.57				
119.0	5.58	144.0	6.63	169.0	7.63	194.0	8.59				
119.5	5.60	144.5	6.65	169.5	7.65	194.5	8.61				
120.0	5.62	145.0	6.67	170.0	7.67	195.0	8.62				
120.5	5.64	145.5	6.69	170.5	7.69	195.5	8.64				
121.0	5.67	146.0	6.71	171.0	7.71	196.0	8.66				
121.5	5.69	146.5	6.73	171.5	7.73	196.5	8.68				
122.0	5.71	147.0	6.75	172.0	7.75	197.0	8.70				
122.5	5.73	147.5	6.77	172.5	7.76	197.5	8.72				
123.0	5.75	148.0	6.79	173.0	7.78	198.0	8.74				
123.5	5.77	148.5	6.81	173.5	7.80	198.5	8.76				
124.0	5.79	149.0	6.83	174.0	7.82	199.0	8.77				
124.5	5.81	149.5	6.85	174.5	7.84	199.5	8.79				
125.0	5.84	150.0	6.87	175.0	7.86	200.0	8.81				

Temperature, °F

- 9.4

- 22 • 0 -

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•26	50•5	2•47	75•5	3•64
1•0	0•03	26•0	1•29	51•0	2•50	76•0	3•66
1•5	0•05	26•5	1•31	51•5	2•52	76•5	3•69
2•0	0•08	27•0	1•34	52•0	2•55	77•0	3•71
2•5	0•10	27•5	1•36	52•5	2•57	77•5	3•73
3•0	0•13	28•0	1•38	53•0	2•59	78•0	3•75
3•5	0•15	28•5	1•41	53•5	2•62	78•5	3•78
4•0	0•18	29•0	1•43	54•0	2•64	79•0	3•80
4•5	0•21	29•5	1•46	54•5	2•66	79•5	3•82
5•0	0•23	30•0	1•48	55•0	2•69	80•0	3•84
5•5	0•26	30•5	1•51	55•5	2•71	80•5	3•87
6•0	0•28	31•0	1•53	56•0	2•73	81•0	3•89
6•5	0•31	31•5	1•56	56•5	2•76	81•5	3•91
7•0	0•33	32•0	1•58	57•0	2•78	82•0	3•94
7•5	0•36	32•5	1•61	57•5	2•81	82•5	3•96
8•0	0•38	33•0	1•63	58•0	2•83	83•0	3•98
8•5	0•41	33•5	1•65	58•5	2•85	83•5	4•00
9•0	0•43	34•0	1•68	59•0	2•88	84•0	4•03
9•5	0•46	34•5	1•70	59•5	2•90	84•5	4•05
10•0	0•49	35•0	1•73	60•0	2•92	85•0	4•07
10•5	0•51	35•5	1•75	60•5	2•95	85•5	4•09
11•0	0•54	36•0	1•78	61•0	2•97	86•0	4•12
11•5	0•56	36•5	1•80	61•5	2•99	86•5	4•14
12•0	0•59	37•0	1•83	62•0	3•02	87•0	4•16
12•5	0•61	37•5	1•85	62•5	3•04	87•5	4•18
13•0	0•64	38•0	1•87	63•0	3•06	88•0	4•21
13•5	0•66	38•5	1•90	63•5	3•09	88•5	4•23
14•0	0•69	39•0	1•92	64•0	3•11	89•0	4•25
14•5	0•71	39•5	1•95	64•5	3•13	89•5	4•27
15•0	0•74	40•0	1•97	65•0	3•16	90•0	4•29
15•5	0•76	40•5	1•99	65•5	3•18	90•5	4•32
16•0	0•79	41•0	2•02	66•0	3•20	91•0	4•34
16•5	0•81	41•5	2•04	66•5	3•23	91•5	4•36
17•0	0•84	42•0	2•07	67•0	3•25	92•0	4•38
17•5	0•86	42•5	2•09	67•5	3•27	92•5	4•41
18•0	0•89	43•0	2•12	68•0	3•30	93•0	4•43
18•5	0•91	43•5	2•14	68•5	3•32	93•5	4•45
19•0	0•94	44•0	2•16	69•0	3•34	94•0	4•47
19•5	0•96	44•5	2•19	69•5	3•36	94•5	4•49
20•0	0•99	45•0	2•21	70•0	3•39	95•0	4•52
20•5	1•01	45•5	2•24	70•5	3•41	95•5	4•54
21•0	1•04	46•0	2•26	71•0	3•43	96•0	4•56
21•5	1•06	46•5	2•28	71•5	3•46	96•5	4•58
22•0	1•09	47•0	2•31	72•0	3•48	97•0	4•61
22•5	1•11	47•5	2•33	72•5	3•50	97•5	4•63
23•0	1•14	48•0	2•36	73•0	3•53	98•0	4•65
23•5	1•16	48•5	2•38	73•5	3•55	98•5	4•67
24•0	1•19	49•0	2•40	74•0	3•57	99•0	4•69
24•5	1•21	49•5	2•43	74•5	3•59	99•5	4•72
25•0	1•24	50•0	2•45	75•0	3•62	100•0	4•74

Temperature, °F

- 7•6 -

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 22.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.76	125.5	5.83	150.5	6.86	175.5	7.85				
101.0	4.78	126.0	5.85	151.0	6.88	176.0	7.87				
101.5	4.80	126.5	5.88	151.5	6.90	176.5	7.89				
102.0	4.82	127.0	5.90	152.0	6.92	177.0	7.91				
102.5	4.85	127.5	5.92	152.5	6.94	177.5	7.93				
103.0	4.87	128.0	5.94	153.0	6.96	178.0	7.95				
103.5	4.89	128.5	5.96	153.5	6.98	178.5	7.97				
104.0	4.91	129.0	5.98	154.0	7.00	179.0	7.99				
104.5	4.93	129.5	6.00	154.5	7.02	179.5	8.00				
105.0	4.96	130.0	6.02	155.0	7.04	180.0	8.02				
105.5	4.98	130.5	6.04	155.5	7.06	180.5	8.04				
106.0	5.00	131.0	6.06	156.0	7.08	181.0	8.06				
106.5	5.02	131.5	6.08	156.5	7.10	181.5	8.08				
107.0	5.04	132.0	6.11	157.0	7.12	182.0	8.10				
107.5	5.06	132.5	6.13	157.5	7.14	182.5	8.12				
108.0	5.09	133.0	6.15	158.0	7.16	183.0	8.14				
108.5	5.11	133.5	6.17	158.5	7.18	183.5	8.16				
109.0	5.13	134.0	6.19	159.0	7.20	184.0	8.18				
109.5	5.15	134.5	6.21	159.5	7.22	184.5	8.20				
110.0	5.17	135.0	6.23	160.0	7.24	185.0	8.21				
110.5	5.19	135.5	6.25	160.5	7.26	185.5	8.23				
111.0	5.22	136.0	6.27	161.0	7.28	186.0	8.25				
111.5	5.24	136.5	6.29	161.5	7.30	186.5	8.27				
112.0	5.26	137.0	6.31	162.0	7.32	187.0	8.29				
112.5	5.28	137.5	6.33	162.5	7.34	187.5	8.31				
113.0	5.30	138.0	6.35	163.0	7.36	188.0	8.33				
113.5	5.32	138.5	6.37	163.5	7.38	188.5	8.35				
114.0	5.34	139.0	6.39	164.0	7.40	189.0	8.37				
114.5	5.37	139.5	6.42	164.5	7.42	189.5	8.39				
115.0	5.39	140.0	6.44	165.0	7.44	190.0	8.40				
115.5	5.41	140.5	6.46	165.5	7.46	190.5	8.42				
116.0	5.43	141.0	6.48	166.0	7.48	191.0	8.44				
116.5	5.45	141.5	6.50	166.5	7.50	191.5	8.46				
117.0	5.47	142.0	6.52	167.0	7.52	192.0	8.48				
117.5	5.49	142.5	6.54	167.5	7.54	192.5	8.50				
118.0	5.52	143.0	6.56	168.0	7.56	193.0	8.52				
118.5	5.54	143.5	6.58	168.5	7.58	193.5	8.54				
119.0	5.56	144.0	6.60	169.0	7.60	194.0	8.55				
119.5	5.58	144.5	6.62	169.5	7.62	194.5	8.57				
120.0	5.60	145.0	6.64	170.0	7.64	195.0	8.59				
120.5	5.62	145.5	6.66	170.5	7.66	195.5	8.61				
121.0	5.64	146.0	6.68	171.0	7.68	196.0	8.63				
121.5	5.66	146.5	6.70	171.5	7.70	196.5	8.65				
122.0	5.69	147.0	6.72	172.0	7.71	197.0	8.67				
122.5	5.71	147.5	6.74	172.5	7.73	197.5	8.68				
123.0	5.73	148.0	6.76	173.0	7.75	198.0	8.70				
123.5	5.75	148.5	6.78	173.5	7.77	198.5	8.72				
124.0	5.77	149.0	6.80	174.0	7.79	199.0	8.74				
124.5	5.79	149.5	6.82	174.5	7.81	199.5	8.76				
125.0	5.81	150.0	6.84	175.0	7.83	200.0	8.78				

Temperature, °F - 7.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C							
				- 21.0			
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.26	50.5	2.46	75.5	3.63
1.0	0.03	26.0	1.28	51.0	2.49	76.0	3.65
1.5	0.05	26.5	1.31	51.5	2.51	76.5	3.67
2.0	0.08	27.0	1.33	52.0	2.54	77.0	3.69
2.5	0.10	27.5	1.35	52.5	2.56	77.5	3.72
3.0	0.13	28.0	1.38	53.0	2.58	78.0	3.74
3.5	0.15	28.5	1.40	53.5	2.61	78.5	3.76
4.0	0.18	29.0	1.43	54.0	2.63	79.0	3.78
4.5	0.20	29.5	1.45	54.5	2.65	79.5	3.81
5.0	0.23	30.0	1.48	55.0	2.68	80.0	3.83
5.5	0.26	30.5	1.50	55.5	2.70	80.5	3.85
6.0	0.28	31.0	1.53	56.0	2.72	81.0	3.87
6.5	0.31	31.5	1.55	56.5	2.75	81.5	3.90
7.0	0.33	32.0	1.57	57.0	2.77	82.0	3.92
7.5	0.36	32.5	1.60	57.5	2.79	82.5	3.94
8.0	0.38	33.0	1.62	58.0	2.82	83.0	3.96
8.5	0.41	33.5	1.65	58.5	2.84	83.5	3.99
9.0	0.43	34.0	1.67	59.0	2.86	84.0	4.01
9.5	0.46	34.5	1.70	59.5	2.89	84.5	4.03
10.0	0.48	35.0	1.72	60.0	2.91	85.0	4.05
10.5	0.51	35.5	1.75	60.5	2.93	85.5	4.08
11.0	0.53	36.0	1.77	61.0	2.96	86.0	4.10
11.5	0.56	36.5	1.79	61.5	2.98	86.5	4.12
12.0	0.58	37.0	1.82	62.0	3.00	87.0	4.14
12.5	0.61	37.5	1.84	62.5	3.03	87.5	4.17
13.0	0.63	38.0	1.87	63.0	3.05	88.0	4.19
13.5	0.66	38.5	1.89	63.5	3.07	88.5	4.21
14.0	0.68	39.0	1.91	64.0	3.10	89.0	4.23
14.5	0.71	39.5	1.94	64.5	3.12	89.5	4.26
15.0	0.73	40.0	1.96	65.0	3.14	90.0	4.28
15.5	0.76	40.5	1.99	65.5	3.17	90.5	4.30
16.0	0.78	41.0	2.01	66.0	3.19	91.0	4.32
16.5	0.81	41.5	2.03	66.5	3.21	91.5	4.34
17.0	0.83	42.0	2.06	67.0	3.24	92.0	4.37
17.5	0.86	42.5	2.08	67.5	3.26	92.5	4.39
18.0	0.88	43.0	2.11	68.0	3.28	93.0	4.41
18.5	0.91	43.5	2.13	68.5	3.30	93.5	4.43
19.0	0.93	44.0	2.15	69.0	3.33	94.0	4.45
19.5	0.96	44.5	2.18	69.5	3.35	94.5	4.48
20.0	0.98	45.0	2.20	70.0	3.37	95.0	4.50
20.5	1.01	45.5	2.23	70.5	3.40	95.5	4.52
21.0	1.03	46.0	2.25	71.0	3.42	96.0	4.54
21.5	1.06	46.5	2.27	71.5	3.44	96.5	4.56
22.0	1.08	47.0	2.30	72.0	3.47	97.0	4.59
22.5	1.11	47.5	2.32	72.5	3.49	97.5	4.61
23.0	1.13	48.0	2.35	73.0	3.51	98.0	4.63
23.5	1.16	48.5	2.37	73.5	3.53	98.5	4.65
24.0	1.18	49.0	2.39	74.0	3.56	99.0	4.67
24.5	1.21	49.5	2.42	74.5	3.58	99.5	4.70
25.0	1.23	50.0	2.44	75.0	3.60	100.0	4.72

Temperature, °F ~ 5.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 21.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.74	125.5	5.81	150.5	6.84	175.5	7.82				
101.0	4.76	126.0	5.83	151.0	6.86	176.0	7.84				
101.5	4.78	126.5	5.85	151.5	6.88	176.5	7.86				
102.0	4.81	127.0	5.87	152.0	6.90	177.0	7.88				
102.5	4.83	127.5	5.89	152.5	6.92	177.5	7.90				
103.0	4.85	128.0	5.91	153.0	6.94	178.0	7.92				
103.5	4.87	128.5	5.94	153.5	6.96	178.5	7.94				
104.0	4.89	129.0	5.96	154.0	6.98	179.0	7.95				
104.5	4.91	129.5	5.98	154.5	7.00	179.5	7.97				
105.0	4.94	130.0	6.00	155.0	7.02	180.0	7.99				
105.5	4.96	130.5	6.02	155.5	7.04	180.5	8.01				
106.0	4.98	131.0	6.04	156.0	7.06	181.0	8.03				
106.5	5.00	131.5	6.06	156.5	7.08	181.5	8.05				
107.0	5.02	132.0	6.08	157.0	7.10	182.0	8.07				
107.5	5.04	132.5	6.10	157.5	7.12	182.5	8.09				
108.0	5.07	133.0	6.12	158.0	7.14	183.0	8.11				
108.5	5.09	133.5	6.14	158.5	7.16	183.5	8.13				
109.0	5.11	134.0	6.16	159.0	7.18	184.0	8.15				
109.5	5.13	134.5	6.18	159.5	7.20	184.5	8.16				
110.0	5.15	135.0	6.21	160.0	7.22	185.0	8.18				
110.5	5.17	135.5	6.23	160.5	7.24	185.5	8.20				
111.0	5.20	136.0	6.25	161.0	7.25	186.0	8.22				
111.5	5.22	136.5	6.27	161.5	7.27	186.5	8.24				
112.0	5.24	137.0	6.29	162.0	7.29	187.0	8.26				
112.5	5.26	137.5	6.31	162.5	7.31	187.5	8.28				
113.0	5.28	138.0	6.33	163.0	7.33	188.0	8.30				
113.5	5.30	138.5	6.35	163.5	7.35	188.5	8.32				
114.0	5.32	139.0	6.37	164.0	7.37	189.0	8.33				
114.5	5.34	139.5	6.39	164.5	7.39	189.5	8.35				
115.0	5.37	140.0	6.41	165.0	7.41	190.0	8.37				
115.5	5.39	140.5	6.43	165.5	7.43	190.5	8.39				
116.0	5.41	141.0	6.45	166.0	7.45	191.0	8.41				
116.5	5.43	141.5	6.47	166.5	7.47	191.5	8.43				
117.0	5.45	142.0	6.49	167.0	7.49	192.0	8.45				
117.5	5.47	142.5	6.51	167.5	7.51	192.5	8.47				
118.0	5.49	143.0	6.53	168.0	7.53	193.0	8.48				
118.5	5.52	143.5	6.55	168.5	7.55	193.5	8.50				
119.0	5.54	144.0	6.57	169.0	7.57	194.0	8.52				
119.5	5.56	144.5	6.59	169.5	7.59	194.5	8.54				
120.0	5.58	145.0	6.61	170.0	7.61	195.0	8.56				
120.5	5.60	145.5	6.63	170.5	7.63	195.5	8.58				
121.0	5.62	146.0	6.66	171.0	7.65	196.0	8.60				
121.5	5.64	146.5	6.68	171.5	7.67	196.5	8.61				
122.0	5.66	147.0	6.70	172.0	7.69	197.0	8.63				
122.5	5.68	147.5	6.72	172.5	7.70	197.5	8.65				
123.0	5.71	148.0	6.74	173.0	7.72	198.0	8.67				
123.5	5.73	148.5	6.76	173.5	7.74	198.5	8.69				
124.0	5.75	149.0	6.78	174.0	7.76	199.0	8.71				
124.5	5.77	149.5	6.80	174.5	7.78	199.5	8.73				
125.0	5.79	150.0	6.82	175.0	7.80	200.0	8.74				

Temperature, °F

- 5.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 20.0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.25	50.5	2.45	75.5	3.61
1.0	0.03	26.0	1.28	51.0	2.48	76.0	3.63
1.5	0.05	26.5	1.30	51.5	2.50	76.5	3.66
2.0	0.08	27.0	1.32	52.0	2.53	77.0	3.68
2.5	0.10	27.5	1.35	52.5	2.55	77.5	3.70
3.0	0.13	28.0	1.37	53.0	2.57	78.0	3.72
3.5	0.15	28.5	1.40	53.5	2.60	78.5	3.75
4.0	0.18	29.0	1.42	54.0	2.62	79.0	3.77
4.5	0.20	29.5	1.45	54.5	2.64	79.5	3.79
5.0	0.23	30.0	1.47	55.0	2.67	80.0	3.81
5.5	0.25	30.5	1.50	55.5	2.69	80.5	3.84
6.0	0.28	31.0	1.52	56.0	2.71	81.0	3.86
6.5	0.30	31.5	1.54	56.5	2.74	81.5	3.88
7.0	0.33	32.0	1.57	57.0	2.76	82.0	3.90
7.5	0.36	32.5	1.59	57.5	2.78	82.5	3.93
8.0	0.38	33.0	1.62	58.0	2.81	83.0	3.95
8.5	0.41	33.5	1.64	58.5	2.83	83.5	3.97
9.0	0.43	34.0	1.67	59.0	2.85	84.0	3.99
9.5	0.46	34.5	1.69	59.5	2.88	84.5	4.02
10.0	0.48	35.0	1.71	60.0	2.90	85.0	4.04
10.5	0.51	35.5	1.74	60.5	2.92	85.5	4.06
11.0	0.53	36.0	1.76	61.0	2.95	86.0	4.08
11.5	0.56	36.5	1.79	61.5	2.97	86.5	4.11
12.0	0.58	37.0	1.81	62.0	2.99	87.0	4.13
12.5	0.61	37.5	1.83	62.5	3.02	87.5	4.15
13.0	0.63	38.0	1.86	63.0	3.04	88.0	4.17
13.5	0.66	38.5	1.88	63.5	3.06	88.5	4.19
14.0	0.68	39.0	1.91	64.0	3.08	89.0	4.22
14.5	0.71	39.5	1.93	64.5	3.11	89.5	4.24
15.0	0.73	40.0	1.95	65.0	3.13	90.0	4.26
15.5	0.76	40.5	1.98	65.5	3.15	90.5	4.28
16.0	0.78	41.0	2.00	66.0	3.18	91.0	4.30
16.5	0.81	41.5	2.03	66.5	3.20	91.5	4.33
17.0	0.83	42.0	2.05	67.0	3.22	92.0	4.35
17.5	0.86	42.5	2.07	67.5	3.25	92.5	4.37
18.0	0.88	43.0	2.10	68.0	3.27	93.0	4.39
18.5	0.91	43.5	2.12	68.5	3.29	93.5	4.42
19.0	0.93	44.0	2.15	69.0	3.31	94.0	4.44
19.5	0.96	44.5	2.17	69.5	3.34	94.5	4.46
20.0	0.98	45.0	2.19	70.0	3.36	95.0	4.48
20.5	1.00	45.5	2.22	70.5	3.38	95.5	4.50
21.0	1.03	46.0	2.24	71.0	3.41	96.0	4.53
21.5	1.05	46.5	2.27	71.5	3.43	96.5	4.55
22.0	1.08	47.0	2.29	72.0	3.45	97.0	4.57
22.5	1.10	47.5	2.31	72.5	3.47	97.5	4.59
23.0	1.13	48.0	2.34	73.0	3.50	98.0	4.61
23.5	1.15	48.5	2.36	73.5	3.52	98.5	4.63
24.0	1.18	49.0	2.38	74.0	3.54	99.0	4.66
24.5	1.20	49.5	2.41	74.5	3.57	99.5	4.68
25.0	1.23	50.0	2.43	75.0	3.59	100.0	4.70

Temperature, °F - 4.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 20.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.72	125.5	5.79	150.5	6.81	175.5	7.79				
101.0	4.74	126.0	5.81	151.0	6.83	176.0	7.81				
101.5	4.77	126.5	5.83	151.5	6.85	176.5	7.83				
102.0	4.79	127.0	5.85	152.0	6.87	177.0	7.85				
102.5	4.81	127.5	5.87	152.5	6.89	177.5	7.87				
103.0	4.83	128.0	5.89	153.0	6.91	178.0	7.89				
103.5	4.85	128.5	5.91	153.5	6.93	178.5	7.90				
104.0	4.87	129.0	5.93	154.0	6.95	179.0	7.92				
104.5	4.90	129.5	5.95	154.5	6.97	179.5	7.94				
105.0	4.92	130.0	5.97	155.0	6.99	180.0	7.96				
105.5	4.94	130.5	6.00	155.5	7.01	180.5	7.98				
106.0	4.96	131.0	6.02	156.0	7.03	181.0	8.00				
106.5	4.98	131.5	6.04	156.5	7.05	181.5	8.02				
107.0	5.00	132.0	6.06	157.0	7.07	182.0	8.04				
107.5	5.02	132.5	6.08	157.5	7.09	182.5	8.06				
108.0	5.05	133.0	6.10	158.0	7.11	183.0	8.08				
108.5	5.07	133.5	6.12	158.5	7.13	183.5	8.10				
109.0	5.09	134.0	6.14	159.0	7.15	184.0	8.11				
109.5	5.11	134.5	6.16	159.5	7.17	184.5	8.13				
110.0	5.13	135.0	6.18	160.0	7.19	185.0	8.15				
110.5	5.15	135.5	6.20	160.5	7.21	185.5	8.17				
111.0	5.17	136.0	6.22	161.0	7.23	186.0	8.19				
111.5	5.20	136.5	6.24	161.5	7.25	186.5	8.21				
112.0	5.22	137.0	6.26	162.0	7.27	187.0	8.23				
112.5	5.24	137.5	6.28	162.5	7.29	187.5	8.25				
113.0	5.26	138.0	6.30	163.0	7.31	188.0	8.26				
113.5	5.28	138.5	6.32	163.5	7.32	188.5	8.28				
114.0	5.30	139.0	6.35	164.0	7.34	189.0	8.30				
114.5	5.32	139.5	6.37	164.5	7.36	189.5	8.32				
115.0	5.35	140.0	6.39	165.0	7.38	190.0	8.34				
115.5	5.37	140.5	6.41	165.5	7.40	190.5	8.36				
116.0	5.39	141.0	6.43	166.0	7.42	191.0	8.38				
116.5	5.41	141.5	6.45	166.5	7.44	191.5	8.40				
117.0	5.43	142.0	6.47	167.0	7.46	192.0	8.41				
117.5	5.45	142.5	6.49	167.5	7.48	192.5	8.43				
118.0	5.47	143.0	6.51	168.0	7.50	193.0	8.45				
118.5	5.49	143.5	6.53	168.5	7.52	193.5	8.47				
119.0	5.51	144.0	6.55	169.0	7.54	194.0	8.49				
119.5	5.54	144.5	6.57	169.5	7.56	194.5	8.51				
120.0	5.56	145.0	6.59	170.0	7.58	195.0	8.53				
120.5	5.58	145.5	6.61	170.5	7.60	195.5	8.54				
121.0	5.60	146.0	6.63	171.0	7.62	196.0	8.56				
121.5	5.62	146.5	6.65	171.5	7.64	196.5	8.58				
122.0	5.64	147.0	6.67	172.0	7.66	197.0	8.60				
122.5	5.66	147.5	6.69	172.5	7.67	197.5	8.62				
123.0	5.68	148.0	6.71	173.0	7.69	198.0	8.64				
123.5	5.70	148.5	6.73	173.5	7.71	198.5	8.66				
124.0	5.72	149.0	6.75	174.0	7.73	199.0	8.67				
124.5	5.75	149.5	6.77	174.5	7.75	199.5	8.69				
125.0	5.77	150.0	6.79	175.0	7.77	200.0	8.71				

Temperature, °F - 4.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 19•0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•25	50•5	2•44	75•5	3•60
1•0	0•03	26•0	1•27	51•0	2•47	76•0	3•62
1•5	0•05	26•5	1•30	51•5	2•49	76•5	3•64
2•0	0•08	27•0	1•32	52•0	2•52	77•0	3•66
2•5	0•10	27•5	1•34	52•5	2•54	77•5	3•69
3•0	0•13	28•0	1•37	53•0	2•56	78•0	3•71
3•5	0•15	28•5	1•39	53•5	2•59	78•5	3•73
4•0	0•18	29•0	1•42	54•0	2•61	79•0	3•75
4•5	0•20	29•5	1•44	54•5	2•63	79•5	3•78
5•0	0•23	30•0	1•47	55•0	2•66	80•0	3•80
5•5	0•25	30•5	1•49	55•5	2•68	80•5	3•82
6•0	0•28	31•0	1•51	56•0	2•70	81•0	3•84
6•5	0•30	31•5	1•54	56•5	2•73	81•5	3•87
7•0	0•33	32•0	1•56	57•0	2•75	82•0	3•89
7•5	0•35	32•5	1•59	57•5	2•77	82•5	3•91
8•0	0•38	33•0	1•61	58•0	2•80	83•0	3•93
8•5	0•40	33•5	1•63	58•5	2•82	83•5	3•96
9•0	0•43	34•0	1•66	59•0	2•84	84•0	3•98
9•5	0•45	34•5	1•68	59•5	2•86	84•5	4•00
10•0	0•48	35•0	1•71	60•0	2•89	85•0	4•02
10•5	0•50	35•5	1•73	60•5	2•91	85•5	4•04
11•0	0•53	36•0	1•76	61•0	2•93	86•0	4•07
11•5	0•55	36•5	1•78	61•5	2•96	86•5	4•09
12•0	0•58	37•0	1•80	62•0	2•98	87•0	4•11
12•5	0•60	37•5	1•83	62•5	3•00	87•5	4•13
13•0	0•63	38•0	1•85	63•0	3•03	88•0	4•16
13•5	0•65	38•5	1•88	63•5	3•05	88•5	4•18
14•0	0•68	39•0	1•90	64•0	3•07	89•0	4•20
14•5	0•70	39•5	1•92	64•5	3•10	89•5	4•22
15•0	0•73	40•0	1•95	65•0	3•12	90•0	4•24
15•5	0•75	40•5	1•97	65•5	3•14	90•5	4•27
16•0	0•78	41•0	1•99	66•0	3•16	91•0	4•29
16•5	0•80	41•5	2•02	66•5	3•19	91•5	4•31
17•0	0•83	42•0	2•04	67•0	3•21	92•0	4•33
17•5	0•85	42•5	2•07	67•5	3•23	92•5	4•35
18•0	0•88	43•0	2•09	68•0	3•26	93•0	4•38
18•5	0•90	43•5	2•11	68•5	3•28	93•5	4•40
19•0	0•93	44•0	2•14	69•0	3•30	94•0	4•42
19•5	0•95	44•5	2•16	69•5	3•32	94•5	4•44
20•0	0•98	45•0	2•19	70•0	3•35	95•0	4•46
20•5	1•00	45•5	2•21	70•5	3•37	95•5	4•49
21•0	1•03	46•0	2•23	71•0	3•39	96•0	4•51
21•5	1•05	46•5	2•26	71•5	3•42	96•5	4•53
22•0	1•07	47•0	2•28	72•0	3•44	97•0	4•55
22•5	1•10	47•5	2•30	72•5	3•46	97•5	4•57
23•0	1•12	48•0	2•33	73•0	3•48	98•0	4•59
23•5	1•15	48•5	2•35	73•5	3•51	98•5	4•62
24•0	1•17	49•0	2•37	74•0	3•53	99•0	4•64
24•5	1•20	49•5	2•40	74•5	3•55	99•5	4•66
25•0	1•22	50•0	2•42	75•0	3•57	100•0	4•68

Temperature, °F

- 2•2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C - 19.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.70	125.5	5.76	150.5	6.78	175.5	7.76				
101.0	4.72	126.0	5.79	151.0	6.80	176.0	7.78				
101.5	4.75	126.5	5.81	151.5	6.82	176.5	7.80				
102.0	4.77	127.0	5.83	152.0	6.84	177.0	7.82				
102.5	4.79	127.5	5.85	152.5	6.86	177.5	7.84				
103.0	4.81	128.0	5.87	153.0	6.88	178.0	7.86				
103.5	4.83	128.5	5.89	153.5	6.90	178.5	7.87				
104.0	4.85	129.0	5.91	154.0	6.92	179.0	7.89				
104.5	4.88	129.5	5.93	154.5	6.94	179.5	7.91				
105.0	4.90	130.0	5.95	155.0	6.96	180.0	7.93				
105.5	4.92	130.5	5.97	155.5	6.98	180.5	7.95				
106.0	4.94	131.0	5.99	156.0	7.00	181.0	7.97				
106.5	4.96	131.5	6.01	156.5	7.02	181.5	7.99				
107.0	4.98	132.0	6.03	157.0	7.04	182.0	8.01				
107.5	5.00	132.5	6.05	157.5	7.06	182.5	8.03				
108.0	5.03	133.0	6.08	158.0	7.08	183.0	8.05				
108.5	5.05	133.5	6.10	158.5	7.10	183.5	8.06				
109.0	5.07	134.0	6.12	159.0	7.12	184.0	8.08				
109.5	5.09	134.5	6.14	159.5	7.14	184.5	8.10				
110.0	5.11	135.0	6.16	160.0	7.16	185.0	8.12				
110.5	5.13	135.5	6.18	160.5	7.18	185.5	8.14				
111.0	5.15	136.0	6.20	161.0	7.20	186.0	8.16				
111.5	5.18	136.5	6.22	161.5	7.22	186.5	8.18				
112.0	5.20	137.0	6.24	162.0	7.24	187.0	8.20				
112.5	5.22	137.5	6.26	162.5	7.26	187.5	8.21				
113.0	5.24	138.0	6.28	163.0	7.28	188.0	8.23				
113.5	5.26	138.5	6.30	163.5	7.30	188.5	8.25				
114.0	5.28	139.0	6.32	164.0	7.32	189.0	8.27				
114.5	5.30	139.5	6.34	164.5	7.34	189.5	8.29				
115.0	5.32	140.0	6.36	165.0	7.36	190.0	8.31				
115.5	5.35	140.5	6.38	165.5	7.37	190.5	8.33				
116.0	5.37	141.0	6.40	166.0	7.39	191.0	8.35				
116.5	5.39	141.5	6.42	166.5	7.41	191.5	8.36				
117.0	5.41	142.0	6.44	167.0	7.43	192.0	8.38				
117.5	5.43	142.5	6.46	167.5	7.45	192.5	8.40				
118.0	5.45	143.0	6.48	168.0	7.47	193.0	8.42				
118.5	5.47	143.5	6.50	168.5	7.49	193.5	8.44				
119.0	5.49	144.0	6.52	169.0	7.51	194.0	8.46				
119.5	5.51	144.5	6.54	169.5	7.53	194.5	8.47				
120.0	5.54	145.0	6.56	170.0	7.55	195.0	8.49				
120.5	5.56	145.5	6.58	170.5	7.57	195.5	8.51				
121.0	5.58	146.0	6.60	171.0	7.59	196.0	8.53				
121.5	5.60	146.5	6.62	171.5	7.61	196.5	8.55				
122.0	5.62	147.0	6.64	172.0	7.63	197.0	8.57				
122.5	5.64	147.5	6.66	172.5	7.65	197.5	8.59				
123.0	5.66	148.0	6.68	173.0	7.66	198.0	8.60				
123.5	5.68	148.5	6.70	173.5	7.68	198.5	8.62				
124.0	5.70	149.0	6.72	174.0	7.70	199.0	8.64				
124.5	5.72	149.5	6.74	174.5	7.72	199.5	8.66				
125.0	5.74	150.0	6.76	175.0	7.74	200.0	8.68				

Temperature, °F - 20.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 180

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.24	50.5	2.44	75.5	3.58
1.0	0.03	26.0	1.27	51.0	2.46	76.0	3.60
1.5	0.05	26.5	1.29	51.5	2.48	76.5	3.63
2.0	0.08	27.0	1.31	52.0	2.51	77.0	3.65
2.5	0.10	27.5	1.34	52.5	2.53	77.5	3.67
3.0	0.13	28.0	1.36	53.0	2.55	78.0	3.69
3.5	0.15	28.5	1.39	53.5	2.58	78.5	3.72
4.0	0.18	29.0	1.41	54.0	2.60	79.0	3.74
4.5	0.20	29.5	1.44	54.5	2.62	79.5	3.76
5.0	0.23	30.0	1.46	55.0	2.65	80.0	3.78
5.5	0.25	30.5	1.48	55.5	2.67	80.5	3.81
6.0	0.28	31.0	1.51	56.0	2.69	81.0	3.83
6.5	0.30	31.5	1.53	56.5	2.71	81.5	3.85
7.0	0.33	32.0	1.56	57.0	2.74	82.0	3.87
7.5	0.35	32.5	1.58	57.5	2.76	82.5	3.90
8.0	0.38	33.0	1.60	58.0	2.78	83.0	3.92
8.5	0.40	33.5	1.63	58.5	2.81	83.5	3.94
9.0	0.43	34.0	1.65	59.0	2.83	84.0	3.96
9.5	0.45	34.5	1.68	59.5	2.85	84.5	3.98
10.0	0.48	35.0	1.70	60.0	2.88	85.0	4.01
10.5	0.50	35.5	1.72	60.5	2.90	85.5	4.03
11.0	0.53	36.0	1.75	61.0	2.92	86.0	4.05
11.5	0.55	36.5	1.77	61.5	2.95	86.5	4.07
12.0	0.58	37.0	1.80	62.0	2.97	87.0	4.10
12.5	0.60	37.5	1.82	62.5	2.99	87.5	4.12
13.0	0.63	38.0	1.84	63.0	3.01	88.0	4.14
13.5	0.65	38.5	1.87	63.5	3.04	88.5	4.16
14.0	0.68	39.0	1.89	64.0	3.06	89.0	4.18
14.5	0.70	39.5	1.92	64.5	3.08	89.5	4.21
15.0	0.73	40.0	1.94	65.0	3.11	90.0	4.23
15.5	0.75	40.5	1.96	65.5	3.13	90.5	4.25
16.0	0.78	41.0	1.99	66.0	3.15	91.0	4.27
16.5	0.80	41.5	2.01	66.5	3.17	91.5	4.29
17.0	0.82	42.0	2.03	67.0	3.20	92.0	4.31
17.5	0.85	42.5	2.06	67.5	3.22	92.5	4.34
18.0	0.87	43.0	2.08	68.0	3.24	93.0	4.36
18.5	0.90	43.5	2.11	68.5	3.27	93.5	4.38
19.0	0.92	44.0	2.13	69.0	3.29	94.0	4.40
19.5	0.95	44.5	2.15	69.5	3.31	94.5	4.42
20.0	0.97	45.0	2.18	70.0	3.33	95.0	4.45
20.5	1.00	45.5	2.20	70.5	3.36	95.5	4.47
21.0	1.02	46.0	2.22	71.0	3.38	96.0	4.49
21.5	1.05	46.5	2.25	71.5	3.40	96.5	4.51
22.0	1.07	47.0	2.27	72.0	3.42	97.0	4.53
22.5	1.09	47.5	2.29	72.5	3.45	97.5	4.55
23.0	1.12	48.0	2.32	73.0	3.47	98.0	4.58
23.5	1.14	48.5	2.34	73.5	3.49	98.5	4.60
24.0	1.17	49.0	2.36	74.0	3.51	99.0	4.62
24.5	1.19	49.5	2.39	74.5	3.54	99.5	4.64
25.0	1.22	50.0	2.41	75.0	3.56	100.0	4.66

Temperature, °F - 0.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		- 18.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
100.5	4.68	125.5	5.74	150.5	6.76	175.5	7.73	
101.0	4.71	126.0	5.76	151.0	6.78	176.0	7.75	
101.5	4.73	126.5	5.78	151.5	6.80	176.5	7.77	
102.0	4.75	127.0	5.80	152.0	6.82	177.0	7.79	
102.5	4.77	127.5	5.83	152.5	6.84	177.5	7.81	
103.0	4.79	128.0	5.85	153.0	6.86	178.0	7.83	
103.5	4.81	128.5	5.87	153.5	6.88	178.5	7.84	
104.0	4.84	129.0	5.89	154.0	6.90	179.0	7.86	
104.5	4.86	129.5	5.91	154.5	6.92	179.5	7.88	
105.0	4.88	130.0	5.93	155.0	6.94	180.0	7.90	
105.5	4.90	130.5	5.95	155.5	6.96	180.5	7.92	
106.0	4.92	131.0	5.97	156.0	6.98	181.0	7.94	
106.5	4.94	131.5	5.99	156.5	6.99	181.5	7.96	
107.0	4.96	132.0	6.01	157.0	7.01	182.0	7.98	
107.5	4.99	132.5	6.03	157.5	7.03	182.5	8.00	
108.0	5.01	133.0	6.05	158.0	7.05	183.0	8.01	
108.5	5.03	133.5	6.07	158.5	7.07	183.5	8.03	
109.0	5.05	134.0	6.09	159.0	7.09	184.0	8.05	
109.5	5.07	134.5	6.11	159.5	7.11	184.5	8.07	
110.0	5.09	135.0	6.13	160.0	7.13	185.0	8.09	
110.5	5.11	135.5	6.15	160.5	7.15	185.5	8.11	
111.0	5.13	136.0	6.17	161.0	7.17	186.0	8.13	
111.5	5.16	136.5	6.19	161.5	7.19	186.5	8.15	
112.0	5.18	137.0	6.21	162.0	7.21	187.0	8.16	
112.5	5.20	137.5	6.23	162.5	7.23	187.5	8.18	
113.0	5.22	138.0	6.26	163.0	7.25	188.0	8.20	
113.5	5.24	138.5	6.28	163.5	7.27	188.5	8.22	
114.0	5.26	139.0	6.30	164.0	7.29	189.0	8.24	
114.5	5.28	139.5	6.32	164.5	7.31	189.5	8.26	
115.0	5.30	140.0	6.34	165.0	7.33	190.0	8.28	
115.5	5.32	140.5	6.36	165.5	7.35	190.5	8.29	
116.0	5.35	141.0	6.38	166.0	7.37	191.0	8.31	
116.5	5.37	141.5	6.40	166.5	7.38	191.5	8.33	
117.0	5.39	142.0	6.42	167.0	7.40	192.0	8.35	
117.5	5.41	142.5	6.44	167.5	7.42	192.5	8.37	
118.0	5.43	143.0	6.46	168.0	7.44	193.0	8.39	
118.5	5.45	143.5	6.48	168.5	7.46	193.5	8.41	
119.0	5.47	144.0	6.50	169.0	7.48	194.0	8.42	
119.5	5.49	144.5	6.52	169.5	7.50	194.5	8.44	
120.0	5.51	145.0	6.54	170.0	7.52	195.0	8.46	
120.5	5.53	145.5	6.56	170.5	7.54	195.5	8.48	
121.0	5.56	146.0	6.58	171.0	7.56	196.0	8.50	
121.5	5.58	146.5	6.60	171.5	7.58	196.5	8.52	
122.0	5.60	147.0	6.62	172.0	7.60	197.0	8.53	
122.5	5.62	147.5	6.64	172.5	7.62	197.5	8.55	
123.0	5.64	148.0	6.66	173.0	7.64	198.0	8.57	
123.5	5.66	148.5	6.68	173.5	7.65	198.5	8.59	
124.0	5.68	149.0	6.70	174.0	7.67	199.0	8.61	
124.5	5.70	149.5	6.72	174.5	7.69	199.5	8.63	
125.0	5.72	150.0	6.74	175.0	7.71	200.0	8.64	

Temperature, °F - 0.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 17.0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.24	50.5	2.43	75.5	3.57
1.0	0.03	26.0	1.26	51.0	2.45	76.0	3.59
1.5	0.05	26.5	1.28	51.5	2.47	76.5	3.61
2.0	0.08	27.0	1.31	52.0	2.50	77.0	3.64
2.5	0.10	27.5	1.33	52.5	2.52	77.5	3.66
3.0	0.13	28.0	1.36	53.0	2.54	78.0	3.68
3.5	0.15	28.5	1.38	53.5	2.57	78.5	3.70
4.0	0.18	29.0	1.41	54.0	2.59	79.0	3.72
4.5	0.20	29.5	1.43	54.5	2.61	79.5	3.75
5.0	0.23	30.0	1.45	55.0	2.63	80.0	3.77
5.5	0.25	30.5	1.48	55.5	2.66	80.5	3.79
6.0	0.28	31.0	1.50	56.0	2.68	81.0	3.81
6.5	0.30	31.5	1.53	56.5	2.70	81.5	3.84
7.0	0.33	32.0	1.55	57.0	2.73	82.0	3.86
7.5	0.35	32.5	1.57	57.5	2.75	82.5	3.88
8.0	0.38	33.0	1.60	58.0	2.77	83.0	3.90
8.5	0.40	33.5	1.62	58.5	2.80	83.5	3.92
9.0	0.43	34.0	1.65	59.0	2.82	84.0	3.95
9.5	0.45	34.5	1.67	59.5	2.84	84.5	3.97
10.0	0.48	35.0	1.69	60.0	2.87	85.0	3.99
10.5	0.50	35.5	1.72	60.5	2.89	85.5	4.01
11.0	0.53	36.0	1.74	61.0	2.91	86.0	4.03
11.5	0.55	36.5	1.77	61.5	2.93	86.5	4.06
12.0	0.57	37.0	1.79	62.0	2.96	87.0	4.08
12.5	0.60	37.5	1.81	62.5	2.98	87.5	4.10
13.0	0.62	38.0	1.84	63.0	3.00	88.0	4.12
13.5	0.65	38.5	1.86	63.5	3.03	88.5	4.14
14.0	0.67	39.0	1.88	64.0	3.05	89.0	4.17
14.5	0.70	39.5	1.91	64.5	3.07	89.5	4.19
15.0	0.72	40.0	1.93	65.0	3.09	90.0	4.21
15.5	0.75	40.5	1.96	65.5	3.12	90.5	4.23
16.0	0.77	41.0	1.98	66.0	3.14	91.0	4.25
16.5	0.80	41.5	2.00	66.5	3.16	91.5	4.28
17.0	0.82	42.0	2.03	67.0	3.18	92.0	4.30
17.5	0.85	42.5	2.05	67.5	3.21	92.5	4.32
18.0	0.87	43.0	2.07	68.0	3.23	93.0	4.34
18.5	0.89	43.5	2.10	68.5	3.25	93.5	4.36
19.0	0.92	44.0	2.12	69.0	3.28	94.0	4.39
19.5	0.94	44.5	2.14	69.5	3.30	94.5	4.41
20.0	0.97	45.0	2.17	70.0	3.32	95.0	4.43
20.5	0.99	45.5	2.19	70.5	3.34	95.5	4.45
21.0	1.02	46.0	2.21	71.0	3.37	96.0	4.47
21.5	1.04	46.5	2.24	71.5	3.39	96.5	4.49
22.0	1.07	47.0	2.26	72.0	3.41	97.0	4.52
22.5	1.09	47.5	2.29	72.5	3.43	97.5	4.54
23.0	1.11	48.0	2.31	73.0	3.46	98.0	4.56
23.5	1.14	48.5	2.33	73.5	3.48	98.5	4.58
24.0	1.16	49.0	2.36	74.0	3.50	99.0	4.60
24.5	1.19	49.5	2.38	74.5	3.52	99.5	4.62
25.0	1.21	50.0	2.40	75.0	3.55	100.0	4.64

Temperature, °F

1.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		- 17.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
100.5	4.67	125.5	5.72	150.5	6.73	175.5	7.70	
101.0	4.69	126.0	5.74	151.0	6.75	176.0	7.72	
101.5	4.71	126.5	5.76	151.5	6.77	176.5	7.74	
102.0	4.73	127.0	5.78	152.0	6.79	177.0	7.76	
102.5	4.75	127.5	5.80	152.5	6.81	177.5	7.78	
103.0	4.77	128.0	5.82	153.0	6.83	178.0	7.80	
103.5	4.80	128.5	5.84	153.5	6.85	178.5	7.81	
104.0	4.82	129.0	5.86	154.0	6.87	179.0	7.83	
104.5	4.84	129.5	5.88	154.5	6.89	179.5	7.85	
105.0	4.86	130.0	5.91	155.0	6.91	180.0	7.87	
105.5	4.88	130.5	5.93	155.5	6.93	180.5	7.89	
106.0	4.90	131.0	5.95	156.0	6.95	181.0	7.91	
106.5	4.92	131.5	5.97	156.5	6.97	181.5	7.93	
107.0	4.94	132.0	5.99	157.0	6.99	182.0	7.95	
107.5	4.97	132.5	6.01	157.5	7.01	182.5	7.97	
108.0	4.99	133.0	6.03	158.0	7.03	183.0	7.98	
108.5	5.01	133.5	6.05	158.5	7.05	183.5	8.00	
109.0	5.03	134.0	6.07	159.0	7.07	184.0	8.02	
109.5	5.05	134.5	6.09	159.5	7.09	184.5	8.04	
110.0	5.07	135.0	6.11	160.0	7.10	185.0	8.06	
110.5	5.09	135.5	6.13	160.5	7.12	185.5	8.08	
111.0	5.11	136.0	6.15	161.0	7.14	186.0	8.10	
111.5	5.14	136.5	6.17	161.5	7.16	186.5	8.11	
112.0	5.16	137.0	6.19	162.0	7.18	187.0	8.13	
112.5	5.18	137.5	6.21	162.5	7.20	187.5	8.15	
113.0	5.20	138.0	6.23	163.0	7.22	188.0	8.17	
113.5	5.22	138.5	6.25	163.5	7.24	188.5	8.19	
114.0	5.24	139.0	6.27	164.0	7.26	189.0	8.21	
114.5	5.26	139.5	6.29	164.5	7.28	189.5	8.23	
115.0	5.28	140.0	6.31	165.0	7.30	190.0	8.24	
115.5	5.30	140.5	6.33	165.5	7.32	190.5	8.26	
116.0	5.32	141.0	6.35	166.0	7.34	191.0	8.28	
116.5	5.35	141.5	6.37	166.5	7.36	191.5	8.30	
117.0	5.37	142.0	6.39	167.0	7.38	192.0	8.32	
117.5	5.39	142.5	6.41	167.5	7.40	192.5	8.34	
118.0	5.41	143.0	6.43	168.0	7.41	193.0	8.36	
118.5	5.43	143.5	6.45	168.5	7.43	193.5	8.37	
119.0	5.45	144.0	6.47	169.0	7.45	194.0	8.39	
119.5	5.47	144.5	6.49	169.5	7.47	194.5	8.41	
120.0	5.49	145.0	6.51	170.0	7.49	195.0	8.43	
120.5	5.51	145.5	6.53	170.5	7.51	195.5	8.45	
121.0	5.53	146.0	6.55	171.0	7.53	196.0	8.47	
121.5	5.55	146.5	6.57	171.5	7.55	196.5	8.48	
122.0	5.58	147.0	6.59	172.0	7.57	197.0	8.50	
122.5	5.60	147.5	6.61	172.5	7.59	197.5	8.52	
123.0	5.62	148.0	6.63	173.0	7.61	198.0	8.54	
123.5	5.64	148.5	6.65	173.5	7.62	198.5	8.56	
124.0	5.66	149.0	6.67	174.0	7.64	199.0	8.58	
124.5	5.68	149.5	6.69	174.5	7.66	199.5	8.59	
125.0	5.70	150.0	6.71	175.0	7.68	200.0	8.61	

Temperature, °F

1•4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 16.0

		Temperature, °C			
atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.23	50.5	2.42
1.0	0.03	26.0	1.26	51.0	2.44
1.5	0.05	26.5	1.28	51.5	2.46
2.0	0.08	27.0	1.30	52.0	2.49
2.5	0.10	27.5	1.33	52.5	2.51
3.0	0.13	28.0	1.35	53.0	2.53
3.5	0.15	28.5	1.38	53.5	2.56
4.0	0.18	29.0	1.40	54.0	2.58
4.5	0.20	29.5	1.42	54.5	2.60
5.0	0.23	30.0	1.45	55.0	2.62
5.5	0.25	30.5	1.47	55.5	2.65
6.0	0.28	31.0	1.50	56.0	2.67
6.5	0.30	31.5	1.52	56.5	2.69
7.0	0.32	32.0	1.54	57.0	2.72
7.5	0.35	32.5	1.57	57.5	2.74
8.0	0.37	33.0	1.59	58.0	2.76
8.5	0.40	33.5	1.62	58.5	2.79
9.0	0.42	34.0	1.64	59.0	2.81
9.5	0.45	34.5	1.66	59.5	2.83
10.0	0.47	35.0	1.69	60.0	2.85
10.5	0.50	35.5	1.71	60.5	2.88
11.0	0.52	36.0	1.73	61.0	2.90
11.5	0.55	36.5	1.76	61.5	2.92
12.0	0.57	37.0	1.78	62.0	2.95
12.5	0.60	37.5	1.81	62.5	2.97
13.0	0.62	38.0	1.83	63.0	2.99
13.5	0.65	38.5	1.85	63.5	3.01
14.0	0.67	39.0	1.88	64.0	3.04
14.5	0.70	39.5	1.90	64.5	3.06
15.0	0.72	40.0	1.92	65.0	3.08
15.5	0.74	40.5	1.95	65.5	3.10
16.0	0.77	41.0	1.97	66.0	3.13
16.5	0.79	41.5	1.99	66.5	3.15
17.0	0.82	42.0	2.02	67.0	3.17
17.5	0.84	42.5	2.04	67.5	3.20
18.0	0.87	43.0	2.07	68.0	3.22
18.5	0.89	43.5	2.09	68.5	3.24
19.0	0.92	44.0	2.11	69.0	3.26
19.5	0.94	44.5	2.14	69.5	3.29
20.0	0.96	45.0	2.16	70.0	3.31
20.5	0.99	45.5	2.18	70.5	3.33
21.0	1.01	46.0	2.21	71.0	3.35
21.5	1.04	46.5	2.23	71.5	3.38
22.0	1.06	47.0	2.25	72.0	3.40
22.5	1.09	47.5	2.28	72.5	3.42
23.0	1.11	48.0	2.30	73.0	3.44
23.5	1.13	48.5	2.32	73.5	3.47
24.0	1.16	49.0	2.35	74.0	3.49
24.5	1.18	49.5	2.37	74.5	3.51
25.0	1.21	50.0	2.39	75.0	3.53

Temperature, °F

3.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C	- 16.0
atü	- kg								
100.5	4.65	125.5	5.70	150.5	6.71	175.5	7.67		
101.0	4.67	126.0	5.72	151.0	6.73	176.0	7.69		
101.5	4.69	126.5	5.74	151.5	6.74	176.5	7.71		
102.0	4.71	127.0	5.76	152.0	6.76	177.0	7.73		
102.5	4.73	127.5	5.78	152.5	6.78	177.5	7.75		
103.0	4.76	128.0	5.80	153.0	6.80	178.0	7.77		
103.5	4.78	128.5	5.82	153.5	6.82	178.5	7.78		
104.0	4.80	129.0	5.84	154.0	6.84	179.0	7.80		
104.5	4.82	129.5	5.86	154.5	6.86	179.5	7.82		
105.0	4.84	130.0	5.88	155.0	6.88	180.0	7.84		
105.5	4.86	130.5	5.90	155.5	6.90	180.5	7.86		
106.0	4.88	131.0	5.92	156.0	6.92	181.0	7.88		
106.5	4.90	131.5	5.94	156.5	6.94	181.5	7.90		
107.0	4.93	132.0	5.96	157.0	6.96	182.0	7.92		
107.5	4.95	132.5	5.98	157.5	6.98	182.5	7.93		
108.0	4.97	133.0	6.00	158.0	7.00	183.0	7.95		
108.5	4.99	133.5	6.03	158.5	7.02	183.5	7.97		
109.0	5.01	134.0	6.05	159.0	7.04	184.0	7.99		
109.5	5.03	134.5	6.07	159.5	7.06	184.5	8.01		
110.0	5.05	135.0	6.09	160.0	7.08	185.0	8.03		
110.5	5.07	135.5	6.11	160.5	7.10	185.5	8.05		
111.0	5.09	136.0	6.13	161.0	7.12	186.0	8.07		
111.5	5.12	136.5	6.15	161.5	7.14	186.5	8.08		
112.0	5.14	137.0	6.17	162.0	7.15	187.0	8.10		
112.5	5.16	137.5	6.19	162.5	7.17	187.5	8.12		
113.0	5.18	138.0	6.21	163.0	7.19	188.0	8.14		
113.5	5.20	138.5	6.23	163.5	7.21	188.5	8.16		
114.0	5.22	139.0	6.25	164.0	7.23	189.0	8.18		
114.5	5.24	139.5	6.27	164.5	7.25	189.5	8.20		
115.0	5.26	140.0	6.29	165.0	7.27	190.0	8.21		
115.5	5.28	140.5	6.31	165.5	7.29	190.5	8.23		
116.0	5.30	141.0	6.33	166.0	7.31	191.0	8.25		
116.5	5.33	141.5	6.35	166.5	7.33	191.5	8.27		
117.0	5.35	142.0	6.37	167.0	7.35	192.0	8.29		
117.5	5.37	142.5	6.39	167.5	7.37	192.5	8.31		
118.0	5.39	143.0	6.41	168.0	7.39	193.0	8.32		
118.5	5.41	143.5	6.43	168.5	7.41	193.5	8.34		
119.0	5.43	144.0	6.45	169.0	7.42	194.0	8.36		
119.5	5.45	144.5	6.47	169.5	7.44	194.5	8.38		
120.0	5.47	145.0	6.49	170.0	7.46	195.0	8.40		
120.5	5.49	145.5	6.51	170.5	7.48	195.5	8.42		
121.0	5.51	146.0	6.53	171.0	7.50	196.0	8.43		
121.5	5.53	146.5	6.55	171.5	7.52	196.5	8.45		
122.0	5.55	147.0	6.57	172.0	7.54	197.0	8.47		
122.5	5.57	147.5	6.59	172.5	7.56	197.5	8.49		
123.0	5.60	148.0	6.61	173.0	7.58	198.0	8.51		
123.5	5.62	148.5	6.63	173.5	7.60	198.5	8.52		
124.0	5.64	149.0	6.65	174.0	7.61	199.0	8.54		
124.5	5.66	149.5	6.67	174.5	7.63	199.5	8.56		
125.0	5.68	150.0	6.69	175.0	7.65	200.0	8.58		

Temperature, °F

3•2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				- 15.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.23	50.5	2.41	75.5	3.54
1.0	0.02	26.0	1.25	51.0	2.43	76.0	3.56
1.5	0.05	26.5	1.27	51.5	2.45	76.5	3.59
2.0	0.07	27.0	1.30	52.0	2.48	77.0	3.61
2.5	0.10	27.5	1.32	52.5	2.50	77.5	3.63
3.0	0.12	28.0	1.35	53.0	2.52	78.0	3.65
3.5	0.15	28.5	1.37	53.5	2.55	78.5	3.67
4.0	0.17	29.0	1.39	54.0	2.57	79.0	3.70
4.5	0.20	29.5	1.42	54.5	2.59	79.5	3.72
5.0	0.22	30.0	1.44	55.0	2.61	80.0	3.74
5.5	0.25	30.5	1.47	55.5	2.64	80.5	3.76
6.0	0.27	31.0	1.49	56.0	2.66	81.0	3.78
6.5	0.30	31.5	1.51	56.5	2.68	81.5	3.81
7.0	0.32	32.0	1.54	57.0	2.71	82.0	3.83
7.5	0.35	32.5	1.56	57.5	2.73	82.5	3.85
8.0	0.37	33.0	1.59	58.0	2.75	83.0	3.87
8.5	0.40	33.5	1.61	58.5	2.77	83.5	3.89
9.0	0.42	34.0	1.63	59.0	2.80	84.0	3.92
9.5	0.45	34.5	1.66	59.5	2.82	84.5	3.94
10.0	0.47	35.0	1.68	60.0	2.84	85.0	3.96
10.5	0.50	35.5	1.70	60.5	2.87	85.5	3.98
11.0	0.52	36.0	1.73	61.0	2.89	86.0	4.00
11.5	0.55	36.5	1.75	61.5	2.91	86.5	4.03
12.0	0.57	37.0	1.78	62.0	2.93	87.0	4.05
12.5	0.59	37.5	1.80	62.5	2.96	87.5	4.07
13.0	0.62	38.0	1.82	63.0	2.98	88.0	4.09
13.5	0.64	38.5	1.85	63.5	3.00	88.5	4.11
14.0	0.67	39.0	1.87	64.0	3.02	89.0	4.13
14.5	0.69	39.5	1.89	64.5	3.05	89.5	4.16
15.0	0.72	40.0	1.92	65.0	3.07	90.0	4.18
15.5	0.74	40.5	1.94	65.5	3.09	90.5	4.20
16.0	0.77	41.0	1.96	66.0	3.11	91.0	4.22
16.5	0.79	41.5	1.99	66.5	3.14	91.5	4.24
17.0	0.81	42.0	2.01	67.0	3.16	92.0	4.26
17.5	0.84	42.5	2.03	67.5	3.18	92.5	4.29
18.0	0.86	43.0	2.06	68.0	3.21	93.0	4.31
18.5	0.89	43.5	2.08	68.5	3.23	93.5	4.33
19.0	0.91	44.0	2.10	69.0	3.25	94.0	4.35
19.5	0.94	44.5	2.13	69.5	3.27	94.5	4.37
20.0	0.96	45.0	2.15	70.0	3.29	95.0	4.39
20.5	0.99	45.5	2.17	70.5	3.32	95.5	4.42
21.0	1.01	46.0	2.20	71.0	3.34	96.0	4.44
21.5	1.03	46.5	2.22	71.5	3.36	96.5	4.46
22.0	1.06	47.0	2.24	72.0	3.38	97.0	4.48
22.5	1.08	47.5	2.27	72.5	3.41	97.5	4.50
23.0	1.11	48.0	2.29	73.0	3.43	98.0	4.52
23.5	1.13	48.5	2.31	73.5	3.45	98.5	4.54
24.0	1.15	49.0	2.34	74.0	3.47	99.0	4.57
24.5	1.18	49.5	2.36	74.5	3.50	99.5	4.59
25.0	1.20	50.0	2.38	75.0	3.52	100.0	4.61

Temperature, °F

5.0

- 15.0

Temperature, °C

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.63	125.5	5.68	150.5	6.68	175.5	7.64				
101.0	4.65	126.0	5.70	151.0	6.70	176.0	7.66				
101.5	4.67	126.5	5.72	151.5	6.72	176.5	7.68				
102.0	4.69	127.0	5.74	152.0	6.74	177.0	7.70				
102.5	4.72	127.5	5.76	152.5	6.76	177.5	7.72				
103.0	4.74	128.0	5.78	153.0	6.78	178.0	7.74				
103.5	4.76	128.5	5.80	153.5	6.80	178.5	7.76				
104.0	4.78	129.0	5.82	154.0	6.82	179.0	7.77				
104.5	4.80	129.5	5.84	154.5	6.84	179.5	7.79				
105.0	4.82	130.0	5.86	155.0	6.86	180.0	7.81				
105.5	4.84	130.5	5.88	155.5	6.88	180.5	7.83				
106.0	4.86	131.0	5.90	156.0	6.90	181.0	7.85				
106.5	4.89	131.5	5.92	156.5	6.91	181.5	7.87				
107.0	4.91	132.0	5.94	157.0	6.93	182.0	7.89				
107.5	4.93	132.5	5.96	157.5	6.95	182.5	7.90				
108.0	4.95	133.0	5.98	158.0	6.97	183.0	7.92				
108.5	4.97	133.5	6.00	158.5	6.99	183.5	7.94				
109.0	4.99	134.0	6.02	159.0	7.01	184.0	7.96				
109.5	5.01	134.5	6.04	159.5	7.03	184.5	7.98				
110.0	5.03	135.0	6.06	160.0	7.05	185.0	8.00				
110.5	5.05	135.5	6.08	160.5	7.07	185.5	8.02				
111.0	5.07	136.0	6.10	161.0	7.09	186.0	8.03				
111.5	5.10	136.5	6.12	161.5	7.11	186.5	8.05				
112.0	5.12	137.0	6.14	162.0	7.13	187.0	8.07				
112.5	5.14	137.5	6.16	162.5	7.15	187.5	8.09				
113.0	5.16	138.0	6.18	163.0	7.17	188.0	8.11				
113.5	5.18	138.5	6.20	163.5	7.19	188.5	8.13				
114.0	5.20	139.0	6.22	164.0	7.20	189.0	8.15				
114.5	5.22	139.5	6.24	164.5	7.22	189.5	8.16				
115.0	5.24	140.0	6.26	165.0	7.24	190.0	8.18				
115.5	5.26	140.5	6.28	165.5	7.26	190.5	8.20				
116.0	5.28	141.0	6.30	166.0	7.28	191.0	8.22				
116.5	5.30	141.5	6.32	166.5	7.30	191.5	8.24				
117.0	5.33	142.0	6.34	167.0	7.32	192.0	8.26				
117.5	5.35	142.5	6.36	167.5	7.34	192.5	8.27				
118.0	5.37	143.0	6.38	168.0	7.36	193.0	8.29				
118.5	5.39	143.5	6.40	168.5	7.38	193.5	8.31				
119.0	5.41	144.0	6.42	169.0	7.40	194.0	8.33				
119.5	5.43	144.5	6.44	169.5	7.42	194.5	8.35				
120.0	5.45	145.0	6.46	170.0	7.43	195.0	8.37				
120.5	5.47	145.5	6.48	170.5	7.45	195.5	8.38				
121.0	5.49	146.0	6.50	171.0	7.47	196.0	8.40				
121.5	5.51	146.5	6.52	171.5	7.49	196.5	8.42				
122.0	5.53	147.0	6.54	172.0	7.51	197.0	8.44				
122.5	5.55	147.5	6.56	172.5	7.53	197.5	8.46				
123.0	5.57	148.0	6.58	173.0	7.55	198.0	8.47				
123.5	5.59	148.5	6.60	173.5	7.57	198.5	8.49				
124.0	5.61	149.0	6.62	174.0	7.59	199.0	8.51				
124.5	5.64	149.5	6.64	174.5	7.60	199.5	8.53				
125.0	5.66	150.0	6.66	175.0	7.62	200.0	8.55				

Temperature, °F

5.0

= 14.0

		Temperature, °C			
atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.22	50.5	2.40
1.0	0.02	26.0	1.25	51.0	2.42
1.5	0.05	26.5	1.27	51.5	2.44
2.0	0.07	27.0	1.29	52.0	2.47
2.5	0.10	27.5	1.32	52.5	2.49
3.0	0.12	28.0	1.34	53.0	2.51
3.5	0.15	28.5	1.37	53.5	2.54
4.0	0.17	29.0	1.39	54.0	2.56
4.5	0.20	29.5	1.41	54.5	2.58
5.0	0.22	30.0	1.44	55.0	2.60
5.5	0.25	30.5	1.46	55.5	2.63
6.0	0.27	31.0	1.48	56.0	2.65
6.5	0.30	31.5	1.51	56.5	2.67
7.0	0.32	32.0	1.53	57.0	2.70
7.5	0.35	32.5	1.56	57.5	2.72
8.0	0.37	33.0	1.58	58.0	2.74
8.5	0.40	33.5	1.60	58.5	2.76
9.0	0.42	34.0	1.63	59.0	2.79
9.5	0.45	34.5	1.65	59.5	2.81
10.0	0.47	35.0	1.67	60.0	2.83
10.5	0.49	35.5	1.70	60.5	2.85
11.0	0.52	36.0	1.72	61.0	2.88
11.5	0.54	36.5	1.74	61.5	2.90
12.0	0.57	37.0	1.77	62.0	2.92
12.5	0.59	37.5	1.79	62.5	2.94
13.0	0.62	38.0	1.82	63.0	2.97
13.5	0.64	38.5	1.84	63.5	2.99
14.0	0.67	39.0	1.86	64.0	3.01
14.5	0.69	39.5	1.89	64.5	3.04
15.0	0.71	40.0	1.91	65.0	3.06
15.5	0.74	40.5	1.93	65.5	3.08
16.0	0.76	41.0	1.96	66.0	3.10
16.5	0.79	41.5	1.98	66.5	3.13
17.0	0.81	42.0	2.00	67.0	3.15
17.5	0.84	42.5	2.03	67.5	3.17
18.0	0.86	43.0	2.05	68.0	3.19
18.5	0.88	43.5	2.07	68.5	3.22
19.0	0.91	44.0	2.10	69.0	3.24
19.5	0.93	44.5	2.12	69.5	3.26
20.0	0.96	45.0	2.14	70.0	3.28
20.5	0.98	45.5	2.17	70.5	3.30
21.0	1.01	46.0	2.19	71.0	3.33
21.5	1.03	46.5	2.21	71.5	3.35
22.0	1.05	47.0	2.24	72.0	3.37
22.5	1.08	47.5	2.26	72.5	3.39
23.0	1.10	48.0	2.28	73.0	3.42
23.5	1.13	48.5	2.30	73.5	3.44
24.0	1.15	49.0	2.33	74.0	3.46
24.5	1.17	49.5	2.35	74.5	3.48
25.0	1.20	50.0	2.37	75.0	3.50

Temperature, °F

6.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		- 14.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
100.5	4.61	125.5	5.65	150.5	6.65	175.5	7.61	
101.0	4.63	126.0	5.67	151.0	6.67	176.0	7.63	
101.5	4.65	126.5	5.70	151.5	6.69	176.5	7.65	
102.0	4.68	127.0	5.72	152.0	6.71	177.0	7.67	
102.5	4.70	127.5	5.74	152.5	6.73	177.5	7.69	
103.0	4.72	128.0	5.76	153.0	6.75	178.0	7.71	
103.5	4.74	128.5	5.78	153.5	6.77	178.5	7.73	
104.0	4.76	129.0	5.80	154.0	6.79	179.0	7.74	
104.5	4.78	129.5	5.82	154.5	6.81	179.5	7.76	
105.0	4.80	130.0	5.84	155.0	6.83	180.0	7.78	
105.5	4.82	130.5	5.86	155.5	6.85	180.5	7.80	
106.0	4.85	131.0	5.88	156.0	6.87	181.0	7.82	
106.5	4.87	131.5	5.90	156.5	6.89	181.5	7.84	
107.0	4.89	132.0	5.92	157.0	6.91	182.0	7.86	
107.5	4.91	132.5	5.94	157.5	6.93	182.5	7.87	
108.0	4.93	133.0	5.96	158.0	6.95	183.0	7.89	
108.5	4.95	133.5	5.98	158.5	6.97	183.5	7.91	
109.0	4.97	134.0	6.00	159.0	6.99	184.0	7.93	
109.5	4.99	134.5	6.02	159.5	7.00	184.5	7.95	
110.0	5.01	135.0	6.04	160.0	7.02	185.0	7.97	
110.5	5.03	135.5	6.06	160.5	7.04	185.5	7.99	
111.0	5.06	136.0	6.08	161.0	7.06	186.0	8.00	
111.5	5.08	136.5	6.10	161.5	7.08	186.5	8.02	
112.0	5.10	137.0	6.12	162.0	7.10	187.0	8.04	
112.5	5.12	137.5	6.14	162.5	7.12	187.5	8.06	
113.0	5.14	138.0	6.16	163.0	7.14	188.0	8.08	
113.5	5.16	138.5	6.18	163.5	7.16	188.5	8.10	
114.0	5.18	139.0	6.20	164.0	7.18	189.0	8.11	
114.5	5.20	139.5	6.22	164.5	7.20	189.5	8.13	
115.0	5.22	140.0	6.24	165.0	7.22	190.0	8.15	
115.5	5.24	140.5	6.26	165.5	7.23	190.5	8.17	
116.0	5.26	141.0	6.28	166.0	7.25	191.0	8.19	
116.5	5.28	141.5	6.30	166.5	7.27	191.5	8.21	
117.0	5.30	142.0	6.32	167.0	7.29	192.0	8.22	
117.5	5.33	142.5	6.34	167.5	7.31	192.5	8.24	
118.0	5.35	143.0	6.36	168.0	7.33	193.0	8.26	
118.5	5.37	143.5	6.38	168.5	7.35	193.5	8.28	
119.0	5.39	144.0	6.40	169.0	7.37	194.0	8.30	
119.5	5.41	144.5	6.42	169.5	7.39	194.5	8.32	
120.0	5.43	145.0	6.44	170.0	7.41	195.0	8.33	
120.5	5.45	145.5	6.46	170.5	7.42	195.5	8.35	
121.0	5.47	146.0	6.48	171.0	7.44	196.0	8.37	
121.5	5.49	146.5	6.50	171.5	7.46	196.5	8.39	
122.0	5.51	147.0	6.52	172.0	7.48	197.0	8.41	
122.5	5.53	147.5	6.54	172.5	7.50	197.5	8.42	
123.0	5.55	148.0	6.56	173.0	7.52	198.0	8.44	
123.5	5.57	148.5	6.58	173.5	7.54	198.5	8.46	
124.0	5.59	149.0	6.60	174.0	7.56	199.0	8.48	
124.5	5.61	149.5	6.62	174.5	7.58	199.5	8.50	
125.0	5.63	150.0	6.63	175.0	7.59	200.0	8.52	

Temperature, °F 6.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C	- 13.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg		
0.5	0.00	25.5	1.22	50.5	2.39	75.5	3.51		
1.0	0.02	26.0	1.24	51.0	2.41	76.0	3.54		
1.5	0.05	26.5	1.26	51.5	2.43	76.5	3.56		
2.0	0.07	27.0	1.29	52.0	2.46	77.0	3.58		
2.5	0.10	27.5	1.31	52.5	2.48	77.5	3.60		
3.0	0.12	28.0	1.34	53.0	2.50	78.0	3.62		
3.5	0.15	28.5	1.36	53.5	2.53	78.5	3.65		
4.0	0.17	29.0	1.38	54.0	2.55	79.0	3.67		
4.5	0.20	29.5	1.41	54.5	2.57	79.5	3.69		
5.0	0.22	30.0	1.43	55.0	2.59	80.0	3.71		
5.5	0.25	30.5	1.45	55.5	2.62	80.5	3.73		
6.0	0.27	31.0	1.48	56.0	2.64	81.0	3.75		
6.5	0.30	31.5	1.50	56.5	2.66	81.5	3.78		
7.0	0.32	32.0	1.53	57.0	2.68	82.0	3.80		
7.5	0.35	32.5	1.55	57.5	2.71	82.5	3.82		
8.0	0.37	33.0	1.57	58.0	2.73	83.0	3.84		
8.5	0.39	33.5	1.60	58.5	2.75	83.5	3.86		
9.0	0.42	34.0	1.62	59.0	2.78	84.0	3.89		
9.5	0.44	34.5	1.64	59.5	2.80	84.5	3.91		
10.0	0.47	35.0	1.67	60.0	2.82	85.0	3.93		
10.5	0.49	35.5	1.69	60.5	2.84	85.5	3.95		
11.0	0.52	36.0	1.71	61.0	2.87	86.0	3.97		
11.5	0.54	36.5	1.74	61.5	2.89	86.5	3.99		
12.0	0.57	37.0	1.76	62.0	2.91	87.0	4.02		
12.5	0.59	37.5	1.78	62.5	2.93	87.5	4.04		
13.0	0.61	38.0	1.81	63.0	2.96	88.0	4.06		
13.5	0.64	38.5	1.83	63.5	2.98	88.5	4.08		
14.0	0.66	39.0	1.85	64.0	3.00	89.0	4.10		
14.5	0.69	39.5	1.88	64.5	3.02	89.5	4.12		
15.0	0.71	40.0	1.90	65.0	3.05	90.0	4.15		
15.5	0.74	40.5	1.93	65.5	3.07	90.5	4.17		
16.0	0.76	41.0	1.95	66.0	3.09	91.0	4.19		
16.5	0.78	41.5	1.97	66.5	3.11	91.5	4.21		
17.0	0.81	42.0	1.99	67.0	3.14	92.0	4.23		
17.5	0.83	42.5	2.02	67.5	3.16	92.5	4.25		
18.0	0.86	43.0	2.04	68.0	3.18	93.0	4.27		
18.5	0.88	43.5	2.06	68.5	3.20	93.5	4.30		
19.0	0.91	44.0	2.09	69.0	3.22	94.0	4.32		
19.5	0.93	44.5	2.11	69.5	3.25	94.5	4.34		
20.0	0.95	45.0	2.13	70.0	3.27	95.0	4.36		
20.5	0.98	45.5	2.16	70.5	3.29	95.5	4.38		
21.0	1.00	46.0	2.18	71.0	3.31	96.0	4.40		
21.5	1.03	46.5	2.20	71.5	3.34	96.5	4.42		
22.0	1.05	47.0	2.23	72.0	3.36	97.0	4.45		
22.5	1.07	47.5	2.25	72.5	3.38	97.5	4.47		
23.0	1.10	48.0	2.27	73.0	3.40	98.0	4.49		
23.5	1.12	48.5	2.30	73.5	3.42	98.5	4.51		
24.0	1.15	49.0	2.32	74.0	3.45	99.0	4.53		
24.5	1.17	49.5	2.34	74.5	3.47	99.5	4.55		
25.0	1.19	50.0	2.36	75.0	3.49	100.0	4.57		

Temperature, °F

8.6

Temperature, °C - 13.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.59	125.5	5.63	150.5	6.63	175.5	7.58				
101.0	4.62	126.0	5.65	151.0	6.65	176.0	7.60				
101.5	4.64	126.5	5.67	151.5	6.67	176.5	7.62				
102.0	4.66	127.0	5.69	152.0	6.69	177.0	7.64				
102.5	4.68	127.5	5.71	152.5	6.71	177.5	7.66				
103.0	4.70	128.0	5.73	153.0	6.73	178.0	7.68				
103.5	4.72	128.5	5.75	153.5	6.75	178.5	7.70				
104.0	4.74	129.0	5.77	154.0	6.77	179.0	7.72				
104.5	4.76	129.5	5.79	154.5	6.78	179.5	7.73				
105.0	4.78	130.0	5.81	155.0	6.80	180.0	7.75				
105.5	4.81	130.5	5.84	155.5	6.82	180.5	7.77				
106.0	4.83	131.0	5.86	156.0	6.84	181.0	7.79				
106.5	4.85	131.5	5.88	156.5	6.86	181.5	7.81				
107.0	4.87	132.0	5.90	157.0	6.88	182.0	7.83				
107.5	4.89	132.5	5.92	157.5	6.90	182.5	7.85				
108.0	4.91	133.0	5.94	158.0	6.92	183.0	7.86				
108.5	4.93	133.5	5.96	158.5	6.94	183.5	7.88				
109.0	4.95	134.0	5.98	159.0	6.96	184.0	7.90				
109.5	4.97	134.5	6.00	159.5	6.98	184.5	7.92				
110.0	4.99	135.0	6.02	160.0	7.00	185.0	7.94				
110.5	5.01	135.5	6.04	160.5	7.02	185.5	7.96				
111.0	5.04	136.0	6.06	161.0	7.04	186.0	7.97				
111.5	5.06	136.5	6.08	161.5	7.05	186.5	7.99				
112.0	5.08	137.0	6.10	162.0	7.07	187.0	8.01				
112.5	5.10	137.5	6.12	162.5	7.09	187.5	8.03				
113.0	5.12	138.0	6.14	163.0	7.11	188.0	8.05				
113.5	5.14	138.5	6.16	163.5	7.13	188.5	8.07				
114.0	5.16	139.0	6.18	164.0	7.15	189.0	8.08				
114.5	5.18	139.5	6.20	164.5	7.17	189.5	8.10				
115.0	5.20	140.0	6.22	165.0	7.19	190.0	8.12				
115.5	5.22	140.5	6.24	165.5	7.21	190.5	8.14				
116.0	5.24	141.0	6.26	166.0	7.23	191.0	8.16				
116.5	5.26	141.5	6.28	166.5	7.25	191.5	8.18				
117.0	5.28	142.0	6.29	167.0	7.26	192.0	8.19				
117.5	5.30	142.5	6.31	167.5	7.28	192.5	8.21				
118.0	5.33	143.0	6.33	168.0	7.30	193.0	8.23				
118.5	5.35	143.5	6.35	168.5	7.32	193.5	8.25				
119.0	5.37	144.0	6.37	169.0	7.34	194.0	8.27				
119.5	5.39	144.5	6.39	169.5	7.36	194.5	8.28				
120.0	5.41	145.0	6.41	170.0	7.38	195.0	8.30				
120.5	5.43	145.5	6.43	170.5	7.40	195.5	8.32				
121.0	5.45	146.0	6.45	171.0	7.42	196.0	8.34				
121.5	5.47	146.5	6.47	171.5	7.43	196.5	8.36				
122.0	5.49	147.0	6.49	172.0	7.45	197.0	8.38				
122.5	5.51	147.5	6.51	172.5	7.47	197.5	8.39				
123.0	5.53	148.0	6.53	173.0	7.49	198.0	8.41				
123.5	5.55	148.5	6.55	173.5	7.51	198.5	8.43				
124.0	5.57	149.0	6.57	174.0	7.53	199.0	8.45				
124.5	5.59	149.5	6.59	174.5	7.55	199.5	8.47				
125.0	5.61	150.0	6.61	175.0	7.57	200.0	8.48				

Temperature, °F

8.6

		Temperature, °C				= 12.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.21	50.5	2.38	75.5	3.50
1.0	0.02	26.0	1.24	51.0	2.40	76.0	3.52
1.5	0.05	26.5	1.26	51.5	2.42	76.5	3.54
2.0	0.07	27.0	1.28	52.0	2.45	77.0	3.57
2.5	0.10	27.5	1.31	52.5	2.47	77.5	3.59
3.0	0.12	28.0	1.33	53.0	2.49	78.0	3.61
3.5	0.15	28.5	1.35	53.5	2.52	78.5	3.63
4.0	0.17	29.0	1.38	54.0	2.54	79.0	3.65
4.5	0.20	29.5	1.40	54.5	2.56	79.5	3.67
5.0	0.22	30.0	1.43	55.0	2.58	80.0	3.70
5.5	0.25	30.5	1.45	55.5	2.61	80.5	3.72
6.0	0.27	31.0	1.47	56.0	2.63	81.0	3.74
6.5	0.30	31.5	1.50	56.5	2.65	81.5	3.76
7.0	0.32	32.0	1.52	57.0	2.67	82.0	3.78
7.5	0.34	32.5	1.54	57.5	2.70	82.5	3.81
8.0	0.37	33.0	1.57	58.0	2.72	83.0	3.83
8.5	0.39	33.5	1.59	58.5	2.74	83.5	3.85
9.0	0.42	34.0	1.61	59.0	2.76	84.0	3.87
9.5	0.44	34.5	1.64	59.5	2.79	84.5	3.89
10.0	0.47	35.0	1.66	60.0	2.81	85.0	3.91
10.5	0.49	35.5	1.68	60.5	2.83	85.5	3.94
11.0	0.51	36.0	1.71	61.0	2.85	86.0	3.96
11.5	0.54	36.5	1.73	61.5	2.88	86.5	3.98
12.0	0.56	37.0	1.75	62.0	2.90	87.0	4.00
12.5	0.59	37.5	1.78	62.5	2.92	87.5	4.02
13.0	0.61	38.0	1.80	63.0	2.94	88.0	4.04
13.5	0.64	38.5	1.82	63.5	2.97	88.5	4.07
14.0	0.66	39.0	1.85	64.0	2.99	89.0	4.09
14.5	0.68	39.5	1.87	64.5	3.01	89.5	4.11
15.0	0.71	40.0	1.89	65.0	3.03	90.0	4.13
15.5	0.73	40.5	1.92	65.5	3.06	90.5	4.15
16.0	0.76	41.0	1.94	66.0	3.08	91.0	4.17
16.5	0.78	41.5	1.96	66.5	3.10	91.5	4.19
17.0	0.81	42.0	1.99	67.0	3.12	92.0	4.22
17.5	0.83	42.5	2.01	67.5	3.15	92.5	4.24
18.0	0.85	43.0	2.03	68.0	3.17	93.0	4.26
18.5	0.88	43.5	2.06	68.5	3.19	93.5	4.28
19.0	0.90	44.0	2.08	69.0	3.21	94.0	4.30
19.5	0.93	44.5	2.10	69.5	3.23	94.5	4.32
20.0	0.95	45.0	2.13	70.0	3.26	95.0	4.34
20.5	0.97	45.5	2.15	70.5	3.28	95.5	4.36
21.0	1.00	46.0	2.17	71.0	3.30	96.0	4.39
21.5	1.02	46.5	2.20	71.5	3.32	96.5	4.41
22.0	1.05	47.0	2.22	72.0	3.35	97.0	4.43
22.5	1.07	47.5	2.24	72.5	3.37	97.5	4.45
23.0	1.09	48.0	2.26	73.0	3.39	98.0	4.47
23.5	1.12	48.5	2.29	73.5	3.41	98.5	4.49
24.0	1.14	49.0	2.31	74.0	3.43	99.0	4.51
24.5	1.16	49.5	2.33	74.5	3.46	99.5	4.53
25.0	1.19	50.0	2.36	75.0	3.48	100.0	4.56

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C = 12.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.58	125.5	5.61	150.5	6.60	175.5	7.56				
101.0	4.60	126.0	5.63	151.0	6.62	176.0	7.57				
101.5	4.62	126.5	5.65	151.5	6.64	176.5	7.59				
102.0	4.64	127.0	5.67	152.0	6.66	177.0	7.61				
102.5	4.66	127.5	5.69	152.5	6.68	177.5	7.63				
103.0	4.68	128.0	5.71	153.0	6.70	178.0	7.65				
103.5	4.70	128.5	5.73	153.5	6.72	178.5	7.67				
104.0	4.72	129.0	5.75	154.0	6.74	179.0	7.69				
104.5	4.75	129.5	5.77	154.5	6.76	179.5	7.70				
105.0	4.77	130.0	5.79	155.0	6.78	180.0	7.72				
105.5	4.79	130.5	5.81	155.5	6.80	180.5	7.74				
106.0	4.81	131.0	5.83	156.0	6.82	181.0	7.76				
106.5	4.83	131.5	5.85	156.5	6.84	181.5	7.78				
107.0	4.85	132.0	5.87	157.0	6.86	182.0	7.80				
107.5	4.87	132.5	5.89	157.5	6.87	182.5	7.82				
108.0	4.89	133.0	5.91	158.0	6.89	183.0	7.83				
108.5	4.91	133.5	5.93	158.5	6.91	183.5	7.85				
109.0	4.93	134.0	5.95	159.0	6.93	184.0	7.87				
109.5	4.95	134.5	5.97	159.5	6.95	184.5	7.89				
110.0	4.97	135.0	5.99	160.0	6.97	185.0	7.91				
110.5	5.00	135.5	6.01	160.5	6.99	185.5	7.93				
111.0	5.02	136.0	6.03	161.0	7.01	186.0	7.94				
111.5	5.04	136.5	6.05	161.5	7.03	186.5	7.96				
112.0	5.06	137.0	6.07	162.0	7.05	187.0	7.98				
112.5	5.08	137.5	6.09	162.5	7.07	187.5	8.00				
113.0	5.10	138.0	6.11	163.0	7.09	188.0	8.02				
113.5	5.12	138.5	6.13	163.5	7.10	188.5	8.04				
114.0	5.14	139.0	6.15	164.0	7.12	189.0	8.05				
114.5	5.16	139.5	6.17	164.5	7.14	189.5	8.07				
115.0	5.18	140.0	6.19	165.0	7.16	190.0	8.09				
115.5	5.20	140.5	6.21	165.5	7.18	190.5	8.11				
116.0	5.22	141.0	6.23	166.0	7.20	191.0	8.13				
116.5	5.24	141.5	6.25	166.5	7.22	191.5	8.15				
117.0	5.26	142.0	6.27	167.0	7.24	192.0	8.16				
117.5	5.28	142.5	6.29	167.5	7.26	192.5	8.18				
118.0	5.31	143.0	6.31	168.0	7.27	193.0	8.20				
118.5	5.33	143.5	6.33	168.5	7.29	193.5	8.22				
119.0	5.35	144.0	6.35	169.0	7.31	194.0	8.24				
119.5	5.37	144.5	6.37	169.5	7.33	194.5	8.25				
120.0	5.39	145.0	6.39	170.0	7.35	195.0	8.27				
120.5	5.41	145.5	6.41	170.5	7.37	195.5	8.29				
121.0	5.43	146.0	6.43	171.0	7.39	196.0	8.31				
121.5	5.45	146.5	6.45	171.5	7.41	196.5	8.33				
122.0	5.47	147.0	6.47	172.0	7.43	197.0	8.34				
122.5	5.49	147.5	6.49	172.5	7.44	197.5	8.36				
123.0	5.51	148.0	6.51	173.0	7.46	198.0	8.38				
123.5	5.53	148.5	6.53	173.5	7.48	198.5	8.40				
124.0	5.55	149.0	6.55	174.0	7.50	199.0	8.42				
124.5	5.57	149.5	6.56	174.5	7.52	199.5	8.43				
125.0	5.59	150.0	6.58	175.0	7.54	200.0	8.45				

Temperature, °F

10.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		- 11.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.21	50.5	2.37	75.5	3.49	
1.0	0.02	26.0	1.23	51.0	2.39	76.0	3.51	
1.5	0.05	26.5	1.26	51.5	2.41	76.5	3.53	
2.0	0.07	27.0	1.28	52.0	2.44	77.0	3.55	
2.5	0.10	27.5	1.30	52.5	2.46	77.5	3.57	
3.0	0.12	28.0	1.33	53.0	2.48	78.0	3.60	
3.5	0.15	28.5	1.35	53.5	2.51	78.5	3.62	
4.0	0.17	29.0	1.37	54.0	2.53	79.0	3.64	
4.5	0.20	29.5	1.40	54.5	2.55	79.5	3.66	
5.0	0.22	30.0	1.42	55.0	2.57	80.0	3.68	
5.5	0.25	30.5	1.44	55.5	2.60	80.5	3.70	
6.0	0.27	31.0	1.47	56.0	2.62	81.0	3.73	
6.5	0.29	31.5	1.49	56.5	2.64	81.5	3.75	
7.0	0.32	32.0	1.51	57.0	2.66	82.0	3.77	
7.5	0.34	32.5	1.54	57.5	2.69	82.5	3.79	
8.0	0.37	33.0	1.56	58.0	2.71	83.0	3.81	
8.5	0.39	33.5	1.58	58.5	2.73	83.5	3.83	
9.0	0.42	34.0	1.61	59.0	2.75	84.0	3.86	
9.5	0.44	34.5	1.63	59.5	2.78	84.5	3.88	
10.0	0.46	35.0	1.65	60.0	2.80	85.0	3.90	
10.5	0.49	35.5	1.68	60.5	2.82	85.5	3.92	
11.0	0.51	36.0	1.70	61.0	2.84	86.0	3.94	
11.5	0.54	36.5	1.72	61.5	2.87	86.5	3.96	
12.0	0.56	37.0	1.75	62.0	2.89	87.0	3.99	
12.5	0.59	37.5	1.77	62.5	2.91	87.5	4.01	
13.0	0.61	38.0	1.79	63.0	2.93	88.0	4.03	
13.5	0.63	38.5	1.82	63.5	2.96	88.5	4.05	
14.0	0.66	39.0	1.84	64.0	2.98	89.0	4.07	
14.5	0.68	39.5	1.86	64.5	3.00	89.5	4.09	
15.0	0.71	40.0	1.89	65.0	3.02	90.0	4.11	
15.5	0.73	40.5	1.91	65.5	3.04	90.5	4.14	
16.0	0.75	41.0	1.93	66.0	3.07	91.0	4.16	
16.5	0.78	41.5	1.96	66.5	3.09	91.5	4.18	
17.0	0.80	42.0	1.98	67.0	3.11	92.0	4.20	
17.5	0.83	42.5	2.00	67.5	3.13	92.5	4.22	
18.0	0.85	43.0	2.03	68.0	3.16	93.0	4.24	
18.5	0.87	43.5	2.05	68.5	3.18	93.5	4.26	
19.0	0.90	44.0	2.07	69.0	3.20	94.0	4.28	
19.5	0.92	44.5	2.09	69.5	3.22	94.5	4.31	
20.0	0.95	45.0	2.12	70.0	3.24	95.0	4.33	
20.5	0.97	45.5	2.14	70.5	3.27	95.5	4.35	
21.0	0.99	46.0	2.16	71.0	3.29	96.0	4.37	
21.5	1.02	46.5	2.19	71.5	3.31	96.5	4.39	
22.0	1.04	47.0	2.21	72.0	3.33	97.0	4.41	
22.5	1.07	47.5	2.23	72.5	3.35	97.5	4.43	
23.0	1.09	48.0	2.26	73.0	3.38	98.0	4.45	
23.5	1.11	48.5	2.28	73.5	3.40	98.5	4.47	
24.0	1.14	49.0	2.30	74.0	3.42	99.0	4.50	
24.5	1.16	49.5	2.32	74.5	3.44	99.5	4.52	
25.0	1.18	50.0	2.35	75.0	3.46	100.0	4.54	

Temperature, °F

12 • 2

- 11.0

Temperature, °C								
atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.56	125.5	5.59	150.5	6.58	175.5	7.53	
101.0	4.58	126.0	5.61	151.0	6.60	176.0	7.55	
101.5	4.60	126.5	5.63	151.5	6.62	176.5	7.57	
102.0	4.62	127.0	5.65	152.0	6.64	177.0	7.58	
102.5	4.64	127.5	5.67	152.5	6.66	177.5	7.60	
103.0	4.66	128.0	5.69	153.0	6.68	178.0	7.62	
103.5	4.69	128.5	5.71	153.5	6.69	178.5	7.64	
104.0	4.71	129.0	5.73	154.0	6.71	179.0	7.66	
104.5	4.73	129.5	5.75	154.5	6.73	179.5	7.68	
105.0	4.75	130.0	5.77	155.0	6.75	180.0	7.69	
105.5	4.77	130.5	5.79	155.5	6.77	180.5	7.71	
106.0	4.79	131.0	5.81	156.0	6.79	181.0	7.73	
106.5	4.81	131.5	5.83	156.5	6.81	181.5	7.75	
107.0	4.83	132.0	5.85	157.0	6.83	182.0	7.77	
107.5	4.85	132.5	5.87	157.5	6.85	182.5	7.79	
108.0	4.87	133.0	5.89	158.0	6.87	183.0	7.80	
108.5	4.89	133.5	5.91	158.5	6.89	183.5	7.82	
109.0	4.91	134.0	5.93	159.0	6.91	184.0	7.84	
109.5	4.93	134.5	5.95	159.5	6.93	184.5	7.86	
110.0	4.96	135.0	5.97	160.0	6.94	185.0	7.88	
110.5	4.98	135.5	5.99	160.5	6.96	185.5	7.90	
111.0	5.00	136.0	6.01	161.0	6.98	186.0	7.91	
111.5	5.02	136.5	6.03	161.5	7.00	186.5	7.93	
112.0	5.04	137.0	6.05	162.0	7.02	187.0	7.95	
112.5	5.06	137.5	6.07	162.5	7.04	187.5	7.97	
113.0	5.08	138.0	6.09	163.0	7.06	188.0	7.99	
113.5	5.10	138.5	6.11	163.5	7.08	188.5	8.01	
114.0	5.12	139.0	6.13	164.0	7.10	189.0	8.02	
114.5	5.14	139.5	6.15	164.5	7.12	189.5	8.04	
115.0	5.16	140.0	6.17	165.0	7.13	190.0	8.06	
115.5	5.18	140.5	6.19	165.5	7.15	190.5	8.08	
116.0	5.20	141.0	6.21	166.0	7.17	191.0	8.10	
116.5	5.22	141.5	6.23	166.5	7.19	191.5	8.11	
117.0	5.24	142.0	6.25	167.0	7.21	192.0	8.13	
117.5	5.26	142.5	6.27	167.5	7.23	192.5	8.15	
118.0	5.28	143.0	6.29	168.0	7.25	193.0	8.17	
118.5	5.31	143.5	6.31	168.5	7.27	193.5	8.19	
119.0	5.33	144.0	6.33	169.0	7.28	194.0	8.21	
119.5	5.35	144.5	6.35	169.5	7.30	194.5	8.22	
120.0	5.37	145.0	6.36	170.0	7.32	195.0	8.24	
120.5	5.39	145.5	6.38	170.5	7.34	195.5	8.26	
121.0	5.41	146.0	6.40	171.0	7.36	196.0	8.28	
121.5	5.43	146.5	6.42	171.5	7.38	196.5	8.29	
122.0	5.45	147.0	6.44	172.0	7.40	197.0	8.31	
122.5	5.47	147.5	6.46	172.5	7.42	197.5	8.33	
123.0	5.49	148.0	6.48	173.0	7.43	198.0	8.35	
123.5	5.51	148.5	6.50	173.5	7.45	198.5	8.37	
124.0	5.53	149.0	6.52	174.0	7.47	199.0	8.38	
124.5	5.55	149.5	6.54	174.5	7.49	199.5	8.40	
125.0	5.57	150.0	6.56	175.0	7.51	200.0	8.42	

Temperature, °F

12.2

← 10.0

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.20	50.5	2.36	75.5	3.47
1.0	0.02	26.0	1.23	51.0	2.38	76.0	3.49
1.5	0.05	26.5	1.25	51.5	2.41	76.5	3.52
2.0	0.07	27.0	1.27	52.0	2.43	77.0	3.54
2.5	0.10	27.5	1.30	52.5	2.45	77.5	3.56
3.0	0.12	28.0	1.32	53.0	2.47	78.0	3.58
3.5	0.15	28.5	1.34	53.5	2.50	78.5	3.60
4.0	0.17	29.0	1.37	54.0	2.52	79.0	3.62
4.5	0.20	29.5	1.39	54.5	2.54	79.5	3.65
5.0	0.22	30.0	1.41	55.0	2.56	80.0	3.67
5.5	0.24	30.5	1.44	55.5	2.59	80.5	3.69
6.0	0.27	31.0	1.46	56.0	2.61	81.0	3.71
6.5	0.29	31.5	1.48	56.5	2.63	81.5	3.73
7.0	0.32	32.0	1.51	57.0	2.65	82.0	3.75
7.5	0.34	32.5	1.53	57.5	2.68	82.5	3.78
8.0	0.37	33.0	1.55	58.0	2.70	83.0	3.80
8.5	0.39	33.5	1.58	58.5	2.72	83.5	3.82
9.0	0.41	34.0	1.60	59.0	2.74	84.0	3.84
9.5	0.44	34.5	1.62	59.5	2.77	84.5	3.86
10.0	0.46	35.0	1.65	60.0	2.79	85.0	3.88
10.5	0.49	35.5	1.67	60.5	2.81	85.5	3.91
11.0	0.51	36.0	1.69	61.0	2.83	86.0	3.93
11.5	0.54	36.5	1.72	61.5	2.86	86.5	3.95
12.0	0.56	37.0	1.74	62.0	2.88	87.0	3.97
12.5	0.58	37.5	1.76	62.5	2.90	87.5	3.99
13.0	0.61	38.0	1.79	63.0	2.92	88.0	4.01
13.5	0.63	38.5	1.81	63.5	2.94	88.5	4.03
14.0	0.66	39.0	1.83	64.0	2.97	89.0	4.06
14.5	0.68	39.5	1.86	64.5	2.99	89.5	4.08
15.0	0.70	40.0	1.88	65.0	3.01	90.0	4.10
15.5	0.73	40.5	1.90	65.5	3.03	90.5	4.12
16.0	0.75	41.0	1.93	66.0	3.06	91.0	4.14
16.5	0.78	41.5	1.95	66.5	3.08	91.5	4.16
17.0	0.80	42.0	1.97	67.0	3.10	92.0	4.18
17.5	0.82	42.5	1.99	67.5	3.12	92.5	4.20
18.0	0.85	43.0	2.02	68.0	3.14	93.0	4.23
18.5	0.87	43.5	2.04	68.5	3.17	93.5	4.25
19.0	0.89	44.0	2.06	69.0	3.19	94.0	4.27
19.5	0.92	44.5	2.09	69.5	3.21	94.5	4.29
20.0	0.94	45.0	2.11	70.0	3.23	95.0	4.31
20.5	0.97	45.5	2.13	70.5	3.25	95.5	4.33
21.0	0.99	46.0	2.16	71.0	3.28	96.0	4.35
21.5	1.01	46.5	2.18	71.5	3.30	96.5	4.37
22.0	1.04	47.0	2.20	72.0	3.32	97.0	4.39
22.5	1.06	47.5	2.22	72.5	3.34	97.5	4.42
23.0	1.08	48.0	2.25	73.0	3.36	98.0	4.44
23.5	1.11	48.5	2.27	73.5	3.39	98.5	4.46
24.0	1.13	49.0	2.29	74.0	3.41	99.0	4.48
24.5	1.16	49.5	2.31	74.5	3.43	99.5	4.50
25.0	1.18	50.0	2.34	75.0	3.45	100.0	4.52

Temperature, °F

14.0

						Temperature, °C		- 10.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
100.5	4.54	125.5	5.57	150.5	6.55	175.5	7.50	
101.0	4.56	126.0	5.59	151.0	6.57	176.0	7.52	
101.5	4.58	126.5	5.61	151.5	6.59	176.5	7.54	
102.0	4.60	127.0	5.63	152.0	6.61	177.0	7.56	
102.5	4.63	127.5	5.65	152.5	6.63	177.5	7.57	
103.0	4.65	128.0	5.67	153.0	6.65	178.0	7.59	
103.5	4.67	128.5	5.69	153.5	6.67	178.5	7.61	
104.0	4.69	129.0	5.71	154.0	6.69	179.0	7.63	
104.5	4.71	129.5	5.73	154.5	6.71	179.5	7.65	
105.0	4.73	130.0	5.75	155.0	6.73	180.0	7.67	
105.5	4.75	130.5	5.77	155.5	6.75	180.5	7.68	
106.0	4.77	131.0	5.79	156.0	6.77	181.0	7.70	
106.5	4.79	131.5	5.81	156.5	6.78	181.5	7.72	
107.0	4.81	132.0	5.83	157.0	6.80	182.0	7.74	
107.5	4.83	132.5	5.85	157.5	6.82	182.5	7.76	
108.0	4.85	133.0	5.87	158.0	6.84	183.0	7.78	
108.5	4.87	133.5	5.89	158.5	6.86	183.5	7.79	
109.0	4.90	134.0	5.91	159.0	6.88	184.0	7.81	
109.5	4.92	134.5	5.93	159.5	6.90	184.5	7.83	
110.0	4.94	135.0	5.95	160.0	6.92	185.0	7.85	
110.5	4.96	135.5	5.97	160.5	6.94	185.5	7.87	
111.0	4.98	136.0	5.99	161.0	6.96	186.0	7.89	
111.5	5.00	136.5	6.01	161.5	6.97	186.5	7.90	
112.0	5.02	137.0	6.03	162.0	6.99	187.0	7.92	
112.5	5.04	137.5	6.05	162.5	7.01	187.5	7.94	
113.0	5.06	138.0	6.07	163.0	7.03	188.0	7.96	
113.5	5.08	138.5	6.09	163.5	7.05	188.5	7.98	
114.0	5.10	139.0	6.11	164.0	7.07	189.0	7.99	
114.5	5.12	139.5	6.13	164.5	7.09	189.5	8.01	
115.0	5.14	140.0	6.14	165.0	7.11	190.0	8.03	
115.5	5.16	140.5	6.16	165.5	7.13	190.5	8.05	
116.0	5.18	141.0	6.18	166.0	7.14	191.0	8.07	
116.5	5.20	141.5	6.20	166.5	7.16	191.5	8.08	
117.0	5.22	142.0	6.22	167.0	7.18	192.0	8.10	
117.5	5.24	142.5	6.24	167.5	7.20	192.5	8.12	
118.0	5.26	143.0	6.26	168.0	7.22	193.0	8.14	
118.5	5.29	143.5	6.28	168.5	7.24	193.5	8.16	
119.0	5.31	144.0	6.30	169.0	7.26	194.0	8.17	
119.5	5.33	144.5	6.32	169.5	7.28	194.5	8.19	
120.0	5.35	145.0	6.34	170.0	7.30	195.0	8.21	
120.5	5.37	145.5	6.36	170.5	7.31	195.5	8.23	
121.0	5.39	146.0	6.38	171.0	7.33	196.0	8.25	
121.5	5.41	146.5	6.40	171.5	7.35	196.5	8.26	
122.0	5.43	147.0	6.42	172.0	7.37	197.0	8.28	
122.5	5.45	147.5	6.44	172.5	7.39	197.5	8.30	
123.0	5.47	148.0	6.46	173.0	7.41	198.0	8.32	
123.5	5.49	148.5	6.48	173.5	7.43	198.5	8.34	
124.0	5.51	149.0	6.50	174.0	7.44	199.0	8.35	
124.5	5.53	149.5	6.52	174.5	7.46	199.5	8.37	
125.0	5.55	150.0	6.53	175.0	7.48	200.0	8.39	

Temperature, °F

14.0

				Temperature, °C				- 960
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.20	50.5	2.35	75.5	3.46	
1.0	0.02	26.0	1.22	51.0	2.37	76.0	3.48	
1.5	0.05	26.5	1.25	51.5	2.40	76.5	3.50	
2.0	0.07	27.0	1.27	52.0	2.42	77.0	3.52	
2.5	0.10	27.5	1.29	52.5	2.44	77.5	3.55	
3.0	0.12	28.0	1.32	53.0	2.46	78.0	3.57	
3.5	0.15	28.5	1.34	53.5	2.49	78.5	3.59	
4.0	0.17	29.0	1.36	54.0	2.51	79.0	3.61	
4.5	0.19	29.5	1.39	54.5	2.53	79.5	3.63	
5.0	0.22	30.0	1.41	55.0	2.55	80.0	3.65	
5.5	0.24	30.5	1.43	55.5	2.58	80.5	3.68	
6.0	0.27	31.0	1.46	56.0	2.60	81.0	3.70	
6.5	0.29	31.5	1.48	56.5	2.62	81.5	3.72	
7.0	0.32	32.0	1.50	57.0	2.64	82.0	3.74	
7.5	0.34	32.5	1.53	57.5	2.67	82.5	3.76	
8.0	0.36	33.0	1.55	58.0	2.69	83.0	3.78	
8.5	0.39	33.5	1.57	58.5	2.71	83.5	3.80	
9.0	0.41	34.0	1.60	59.0	2.73	84.0	3.83	
9.5	0.44	34.5	1.62	59.5	2.76	84.5	3.85	
10.0	0.46	35.0	1.64	60.0	2.78	85.0	3.87	
10.5	0.48	35.5	1.66	60.5	2.80	85.5	3.89	
11.0	0.51	36.0	1.69	61.0	2.82	86.0	3.91	
11.5	0.53	36.5	1.71	61.5	2.84	86.5	3.93	
12.0	0.56	37.0	1.73	62.0	2.87	87.0	3.95	
12.5	0.58	37.5	1.76	62.5	2.89	87.5	3.98	
13.0	0.60	38.0	1.78	63.0	2.91	88.0	4.00	
13.5	0.63	38.5	1.80	63.5	2.93	88.5	4.02	
14.0	0.65	39.0	1.83	64.0	2.96	89.0	4.04	
14.5	0.68	39.5	1.85	64.5	2.98	89.5	4.06	
15.0	0.70	40.0	1.87	65.0	3.00	90.0	4.08	
15.5	0.72	40.5	1.90	65.5	3.02	90.5	4.10	
16.0	0.75	41.0	1.92	66.0	3.04	91.0	4.12	
16.5	0.77	41.5	1.94	66.5	3.07	91.5	4.15	
17.0	0.80	42.0	1.96	67.0	3.09	92.0	4.17	
17.5	0.82	42.5	1.99	67.5	3.11	92.5	4.19	
18.0	0.84	43.0	2.01	68.0	3.13	93.0	4.21	
18.5	0.87	43.5	2.03	68.5	3.15	93.5	4.23	
19.0	0.89	44.0	2.06	69.0	3.18	94.0	4.25	
19.5	0.91	44.5	2.08	69.5	3.20	94.5	4.27	
20.0	0.94	45.0	2.10	70.0	3.22	95.0	4.29	
20.5	0.96	45.5	2.12	70.5	3.24	95.5	4.31	
21.0	0.99	46.0	2.15	71.0	3.26	96.0	4.34	
21.5	1.01	46.5	2.17	71.5	3.28	96.5	4.36	
22.0	1.03	47.0	2.19	72.0	3.31	97.0	4.38	
22.5	1.06	47.5	2.22	72.5	3.33	97.5	4.40	
23.0	1.08	48.0	2.24	73.0	3.35	98.0	4.42	
23.5	1.10	48.5	2.26	73.5	3.37	98.5	4.44	
24.0	1.13	49.0	2.28	74.0	3.39	99.0	4.46	
24.5	1.15	49.5	2.31	74.5	3.42	99.5	4.48	
25.0	1.17	50.0	2.33	75.0	3.44	100.0	4.50	

Temperature, °F

15.8

Temperature, °C								- 9.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.52	125.5	5.55	150.5	6.53	175.5	7.47				
101.0	4.55	126.0	5.57	151.0	6.55	176.0	7.49				
101.5	4.57	126.5	5.59	151.5	6.57	176.5	7.51				
102.0	4.59	127.0	5.61	152.0	6.59	177.0	7.53				
102.5	4.61	127.5	5.63	152.5	6.61	177.5	7.55				
103.0	4.63	128.0	5.65	153.0	6.63	178.0	7.56				
103.5	4.65	128.5	5.67	153.5	6.64	178.5	7.58				
104.0	4.67	129.0	5.69	154.0	6.66	179.0	7.60				
104.5	4.69	129.5	5.71	154.5	6.68	179.5	7.62				
105.0	4.71	130.0	5.73	155.0	6.70	180.0	7.64				
105.5	4.73	130.5	5.75	155.5	6.72	180.5	7.66				
106.0	4.75	131.0	5.77	156.0	6.74	181.0	7.67				
106.5	4.77	131.5	5.79	156.5	6.76	181.5	7.69				
107.0	4.79	132.0	5.81	157.0	6.78	182.0	7.71				
107.5	4.81	132.5	5.83	157.5	6.80	182.5	7.73				
108.0	4.84	133.0	5.85	158.0	6.82	183.0	7.75				
108.5	4.86	133.5	5.87	158.5	6.84	183.5	7.77				
109.0	4.88	134.0	5.89	159.0	6.85	184.0	7.78				
109.5	4.90	134.5	5.91	159.5	6.87	184.5	7.80				
110.0	4.92	135.0	5.93	160.0	6.89	185.0	7.82				
110.5	4.94	135.5	5.94	160.5	6.91	185.5	7.84				
111.0	4.96	136.0	5.96	161.0	6.93	186.0	7.86				
111.5	4.98	136.5	5.98	161.5	6.95	186.5	7.87				
112.0	5.00	137.0	6.00	162.0	6.97	187.0	7.89				
112.5	5.02	137.5	6.02	162.5	6.99	187.5	7.91				
113.0	5.04	138.0	6.04	163.0	7.01	188.0	7.93				
113.5	5.06	138.5	6.06	163.5	7.02	188.5	7.95				
114.0	5.08	139.0	6.08	164.0	7.04	189.0	7.96				
114.5	5.10	139.5	6.10	164.5	7.06	189.5	7.98				
115.0	5.12	140.0	6.12	165.0	7.08	190.0	8.00				
115.5	5.14	140.5	6.14	165.5	7.10	190.5	8.02				
116.0	5.16	141.0	6.16	166.0	7.12	191.0	8.04				
116.5	5.18	141.5	6.18	166.5	7.14	191.5	8.05				
117.0	5.20	142.0	6.20	167.0	7.16	192.0	8.07				
117.5	5.22	142.5	6.22	167.5	7.17	192.5	8.09				
118.0	5.24	143.0	6.24	168.0	7.19	193.0	8.11				
118.5	5.27	143.5	6.26	168.5	7.21	193.5	8.13				
119.0	5.29	144.0	6.28	169.0	7.23	194.0	8.14				
119.5	5.31	144.5	6.30	169.5	7.25	194.5	8.16				
120.0	5.33	145.0	6.32	170.0	7.27	195.0	8.18				
120.5	5.35	145.5	6.34	170.5	7.29	195.5	8.20				
121.0	5.37	146.0	6.36	171.0	7.30	196.0	8.22				
121.5	5.39	146.5	6.37	171.5	7.32	196.5	8.23				
122.0	5.41	147.0	6.39	172.0	7.34	197.0	8.25				
122.5	5.43	147.5	6.41	172.5	7.36	197.5	8.27				
123.0	5.45	148.0	6.43	173.0	7.38	198.0	8.29				
123.5	5.47	148.5	6.45	173.5	7.40	198.5	8.30				
124.0	5.49	149.0	6.47	174.0	7.42	199.0	8.32				
124.5	5.51	149.5	6.49	174.5	7.43	199.5	8.34				
125.0	5.53	150.0	6.51	175.0	7.45	200.0	8.36				

Temperature, °F

15.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								- 8.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.19	50.5	2.34	75.5	3.45	
1.0	0.02	26.0	1.22	51.0	2.36	76.0	3.47	
1.5	0.05	26.5	1.24	51.5	2.39	76.5	3.49	
2.0	0.07	27.0	1.26	52.0	2.41	77.0	3.51	
2.5	0.10	27.5	1.29	52.5	2.43	77.5	3.53	
3.0	0.12	28.0	1.31	53.0	2.45	78.0	3.55	
3.5	0.15	28.5	1.33	53.5	2.48	78.5	3.58	
4.0	0.17	29.0	1.36	54.0	2.50	79.0	3.60	
4.5	0.19	29.5	1.38	54.5	2.52	79.5	3.62	
5.0	0.22	30.0	1.40	55.0	2.54	80.0	3.64	
5.5	0.24	30.5	1.43	55.5	2.57	80.5	3.66	
6.0	0.27	31.0	1.45	56.0	2.59	81.0	3.68	
6.5	0.29	31.5	1.47	56.5	2.61	81.5	3.70	
7.0	0.31	32.0	1.50	57.0	2.63	82.0	3.73	
7.5	0.34	32.5	1.52	57.5	2.66	82.5	3.75	
8.0	0.36	33.0	1.54	58.0	2.68	83.0	3.77	
8.5	0.39	33.5	1.57	58.5	2.70	83.5	3.79	
9.0	0.41	34.0	1.59	59.0	2.72	84.0	3.81	
9.5	0.44	34.5	1.61	59.5	2.74	84.5	3.83	
10.0	0.46	35.0	1.64	60.0	2.77	85.0	3.85	
10.5	0.48	35.5	1.66	60.5	2.79	85.5	3.88	
11.0	0.51	36.0	1.68	61.0	2.81	86.0	3.90	
11.5	0.53	36.5	1.70	61.5	2.83	86.5	3.92	
12.0	0.55	37.0	1.73	62.0	2.86	87.0	3.94	
12.5	0.58	37.5	1.75	62.5	2.88	87.5	3.96	
13.0	0.60	38.0	1.77	63.0	2.90	88.0	3.98	
13.5	0.63	38.5	1.80	63.5	2.92	88.5	4.00	
14.0	0.65	39.0	1.82	64.0	2.94	89.0	4.02	
14.5	0.67	39.5	1.84	64.5	2.97	89.5	4.05	
15.0	0.70	40.0	1.87	65.0	2.99	90.0	4.07	
15.5	0.72	40.5	1.89	65.5	3.01	90.5	4.09	
16.0	0.75	41.0	1.91	66.0	3.03	91.0	4.11	
16.5	0.77	41.5	1.93	66.5	3.05	91.5	4.13	
17.0	0.79	42.0	1.96	67.0	3.08	92.0	4.15	
17.5	0.82	42.5	1.98	67.5	3.10	92.5	4.17	
18.0	0.84	43.0	2.00	68.0	3.12	93.0	4.19	
18.5	0.86	43.5	2.03	68.5	3.14	93.5	4.21	
19.0	0.89	44.0	2.05	69.0	3.16	94.0	4.24	
19.5	0.91	44.5	2.07	69.5	3.19	94.5	4.26	
20.0	0.94	45.0	2.09	70.0	3.21	95.0	4.28	
20.5	0.96	45.5	2.12	70.5	3.23	95.5	4.30	
21.0	0.98	46.0	2.14	71.0	3.25	96.0	4.32	
21.5	1.01	46.5	2.16	71.5	3.27	96.5	4.34	
22.0	1.03	47.0	2.18	72.0	3.29	97.0	4.36	
22.5	1.05	47.5	2.21	72.5	3.32	97.5	4.38	
23.0	1.08	48.0	2.23	73.0	3.34	98.0	4.40	
23.5	1.10	48.5	2.25	73.5	3.36	98.5	4.42	
24.0	1.12	49.0	2.27	74.0	3.38	99.0	4.44	
24.5	1.15	49.5	2.30	74.5	3.40	99.5	4.47	
25.0	1.17	50.0	2.32	75.0	3.42	100.0	4.49	

Temperature, °F

17.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		- 8.0	
atü	-	kg		atü	-	kg	
100.5	4.51	125.5	5.53	150.5	6.50	175.5	7.44
101.0	4.53	126.0	5.55	151.0	6.52	176.0	7.46
101.5	4.55	126.5	5.57	151.5	6.54	176.5	7.48
102.0	4.57	127.0	5.59	152.0	6.56	177.0	7.50
102.5	4.59	127.5	5.61	152.5	6.58	177.5	7.52
103.0	4.61	128.0	5.63	153.0	6.60	178.0	7.54
103.5	4.63	128.5	5.65	153.5	6.62	178.5	7.55
104.0	4.65	129.0	5.67	154.0	6.64	179.0	7.57
104.5	4.67	129.5	5.69	154.5	6.66	179.5	7.59
105.0	4.69	130.0	5.71	155.0	6.68	180.0	7.61
105.5	4.71	130.5	5.73	155.5	6.70	180.5	7.63
106.0	4.73	131.0	5.75	156.0	6.71	181.0	7.65
106.5	4.76	131.5	5.76	156.5	6.73	181.5	7.66
107.0	4.78	132.0	5.78	157.0	6.75	182.0	7.68
107.5	4.80	132.5	5.80	157.5	6.77	182.5	7.70
108.0	4.82	133.0	5.82	158.0	6.79	183.0	7.72
108.5	4.84	133.5	5.84	158.5	6.81	183.5	7.74
109.0	4.86	134.0	5.86	159.0	6.83	184.0	7.75
109.5	4.88	134.5	5.88	159.5	6.85	184.5	7.77
110.0	4.90	135.0	5.90	160.0	6.87	185.0	7.79
110.5	4.92	135.5	5.92	160.5	6.89	185.5	7.81
111.0	4.94	136.0	5.94	161.0	6.90	186.0	7.83
111.5	4.96	136.5	5.96	161.5	6.92	186.5	7.84
112.0	4.98	137.0	5.98	162.0	6.94	187.0	7.86
112.5	5.00	137.5	6.00	162.5	6.96	187.5	7.88
113.0	5.02	138.0	6.02	163.0	6.98	188.0	7.90
113.5	5.04	138.5	6.04	163.5	7.00	188.5	7.92
114.0	5.06	139.0	6.06	164.0	7.02	189.0	7.93
114.5	5.08	139.5	6.08	164.5	7.04	189.5	7.95
115.0	5.10	140.0	6.10	165.0	7.05	190.0	7.97
115.5	5.12	140.5	6.12	165.5	7.07	190.5	7.99
116.0	5.14	141.0	6.14	166.0	7.09	191.0	8.01
116.5	5.16	141.5	6.16	166.5	7.11	191.5	8.02
117.0	5.18	142.0	6.18	167.0	7.13	192.0	8.04
117.5	5.20	142.5	6.20	167.5	7.15	192.5	8.06
118.0	5.22	143.0	6.22	168.0	7.17	193.0	8.08
118.5	5.25	143.5	6.23	168.5	7.18	193.5	8.10
119.0	5.27	144.0	6.25	169.0	7.20	194.0	8.11
119.5	5.29	144.5	6.27	169.5	7.22	194.5	8.13
120.0	5.31	145.0	6.29	170.0	7.24	195.0	8.15
120.5	5.33	145.5	6.31	170.5	7.26	195.5	8.17
121.0	5.35	146.0	6.33	171.0	7.28	196.0	8.19
121.5	5.37	146.5	6.35	171.5	7.30	196.5	8.20
122.0	5.39	147.0	6.37	172.0	7.31	197.0	8.22
122.5	5.41	147.5	6.39	172.5	7.33	197.5	8.24
123.0	5.43	148.0	6.41	173.0	7.35	198.0	8.26
123.5	5.45	148.5	6.43	173.5	7.37	198.5	8.27
124.0	5.47	149.0	6.45	174.0	7.39	199.0	8.29
124.5	5.49	149.5	6.47	174.5	7.41	199.5	8.31
125.0	5.51	150.0	6.49	175.0	7.43	200.0	8.33

Temperature, °F

17.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.19	50.5	2.33	75.5	3.43
1.0	0.02	26.0	1.21	51.0	2.36	76.0	3.45
1.5	0.05	26.5	1.24	51.5	2.38	76.5	3.48
2.0	0.07	27.0	1.26	52.0	2.40	77.0	3.50
2.5	0.10	27.5	1.28	52.5	2.42	77.5	3.52
3.0	0.12	28.0	1.31	53.0	2.45	78.0	3.54
3.5	0.15	28.5	1.33	53.5	2.47	78.5	3.56
4.0	0.17	29.0	1.35	54.0	2.49	79.0	3.58
4.5	0.19	29.5	1.38	54.5	2.51	79.5	3.60
5.0	0.22	30.0	1.40	55.0	2.53	80.0	3.63
5.5	0.24	30.5	1.42	55.5	2.56	80.5	3.65
6.0	0.27	31.0	1.44	56.0	2.58	81.0	3.67
6.5	0.29	31.5	1.47	56.5	2.60	81.5	3.69
7.0	0.31	32.0	1.49	57.0	2.62	82.0	3.71
7.5	0.34	32.5	1.51	57.5	2.65	82.5	3.73
8.0	0.36	33.0	1.54	58.0	2.67	83.0	3.75
8.5	0.39	33.5	1.56	58.5	2.69	83.5	3.78
9.0	0.41	34.0	1.58	59.0	2.71	84.0	3.80
9.5	0.43	34.5	1.61	59.5	2.73	84.5	3.82
10.0	0.46	35.0	1.63	60.0	2.76	85.0	3.84
10.5	0.48	35.5	1.65	60.5	2.78	85.5	3.86
11.0	0.51	36.0	1.68	61.0	2.80	86.0	3.88
11.5	0.53	36.5	1.70	61.5	2.82	86.5	3.90
12.0	0.55	37.0	1.72	62.0	2.84	87.0	3.92
12.5	0.58	37.5	1.74	62.5	2.87	87.5	3.95
13.0	0.60	38.0	1.77	63.0	2.89	88.0	3.97
13.5	0.62	38.5	1.79	63.5	2.91	88.5	3.99
14.0	0.65	39.0	1.81	64.0	2.93	89.0	4.01
14.5	0.67	39.5	1.84	64.5	2.95	89.5	4.03
15.0	0.70	40.0	1.86	65.0	2.98	90.0	4.05
15.5	0.72	40.5	1.88	65.5	3.00	90.5	4.07
16.0	0.74	41.0	1.90	66.0	3.02	91.0	4.09
16.5	0.77	41.5	1.93	66.5	3.04	91.5	4.11
17.0	0.79	42.0	1.95	67.0	3.06	92.0	4.14
17.5	0.81	42.5	1.97	67.5	3.09	92.5	4.16
18.0	0.84	43.0	1.99	68.0	3.11	93.0	4.18
18.5	0.86	43.5	2.02	68.5	3.13	93.5	4.20
19.0	0.88	44.0	2.04	69.0	3.15	94.0	4.22
19.5	0.91	44.5	2.06	69.5	3.17	94.5	4.24
20.0	0.93	45.0	2.09	70.0	3.19	95.0	4.26
20.5	0.95	45.5	2.11	70.5	3.22	95.5	4.28
21.0	0.98	46.0	2.13	71.0	3.24	96.0	4.30
21.5	1.00	46.5	2.15	71.5	3.26	96.5	4.32
22.0	1.03	47.0	2.18	72.0	3.28	97.0	4.34
22.5	1.05	47.5	2.20	72.5	3.30	97.5	4.37
23.0	1.07	48.0	2.22	73.0	3.32	98.0	4.39
23.5	1.10	48.5	2.24	73.5	3.35	98.5	4.41
24.0	1.12	49.0	2.27	74.0	3.37	99.0	4.43
24.5	1.14	49.5	2.29	74.5	3.39	99.5	4.45
25.0	1.17	50.0	2.31	75.0	3.41	100.0	4.47

Temperature, °F

19.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C	- 7.0
atü	- kg								
100.5	4.49	125.5	5.51	150.5	6.48	175.5	7.42		
101.0	4.51	126.0	5.53	151.0	6.50	176.0	7.43		
101.5	4.53	126.5	5.55	151.5	6.52	176.5	7.45		
102.0	4.55	127.0	5.57	152.0	6.54	177.0	7.47		
102.5	4.57	127.5	5.58	152.5	6.56	177.5	7.49		
103.0	4.59	128.0	5.60	153.0	6.58	178.0	7.51		
103.5	4.61	128.5	5.62	153.5	6.59	178.5	7.53		
104.0	4.63	129.0	5.64	154.0	6.61	179.0	7.54		
104.5	4.66	129.5	5.66	154.5	6.63	179.5	7.56		
105.0	4.68	130.0	5.68	155.0	6.65	180.0	7.58		
105.5	4.70	130.5	5.70	155.5	6.67	180.5	7.60		
106.0	4.72	131.0	5.72	156.0	6.69	181.0	7.62		
106.5	4.74	131.5	5.74	156.5	6.71	181.5	7.64		
107.0	4.76	132.0	5.76	157.0	6.73	182.0	7.65		
107.5	4.78	132.5	5.78	157.5	6.75	182.5	7.67		
108.0	4.80	133.0	5.80	158.0	6.77	183.0	7.69		
108.5	4.82	133.5	5.82	158.5	6.78	183.5	7.71		
109.0	4.84	134.0	5.84	159.0	6.80	184.0	7.73		
109.5	4.86	134.5	5.86	159.5	6.82	184.5	7.74		
110.0	4.88	135.0	5.88	160.0	6.84	185.0	7.76		
110.5	4.90	135.5	5.90	160.5	6.86	185.5	7.78		
111.0	4.92	136.0	5.92	161.0	6.88	186.0	7.80		
111.5	4.94	136.5	5.94	161.5	6.90	186.5	7.82		
112.0	4.96	137.0	5.96	162.0	6.92	187.0	7.83		
112.5	4.98	137.5	5.98	162.5	6.93	187.5	7.85		
113.0	5.00	138.0	6.00	163.0	6.95	188.0	7.87		
113.5	5.02	138.5	6.02	163.5	6.97	188.5	7.89		
114.0	5.04	139.0	6.04	164.0	6.99	189.0	7.91		
114.5	5.06	139.5	6.06	164.5	7.01	189.5	7.92		
115.0	5.08	140.0	6.08	165.0	7.03	190.0	7.94		
115.5	5.10	140.5	6.10	165.5	7.05	190.5	7.96		
116.0	5.12	141.0	6.11	166.0	7.07	191.0	7.98		
116.5	5.14	141.5	6.13	166.5	7.08	191.5	8.00		
117.0	5.16	142.0	6.15	167.0	7.10	192.0	8.01		
117.5	5.18	142.5	6.17	167.5	7.12	192.5	8.03		
118.0	5.21	143.0	6.19	168.0	7.14	193.0	8.05		
118.5	5.23	143.5	6.21	168.5	7.16	193.5	8.07		
119.0	5.25	144.0	6.23	169.0	7.18	194.0	8.08		
119.5	5.27	144.5	6.25	169.5	7.20	194.5	8.10		
120.0	5.29	145.0	6.27	170.0	7.21	195.0	8.12		
120.5	5.31	145.5	6.29	170.5	7.23	195.5	8.14		
121.0	5.33	146.0	6.31	171.0	7.25	196.0	8.16		
121.5	5.35	146.5	6.33	171.5	7.27	196.5	8.17		
122.0	5.37	147.0	6.35	172.0	7.29	197.0	8.19		
122.5	5.39	147.5	6.37	172.5	7.31	197.5	8.21		
123.0	5.41	148.0	6.38	173.0	7.32	198.0	8.23		
123.5	5.43	148.5	6.40	173.5	7.34	198.5	8.24		
124.0	5.45	149.0	6.42	174.0	7.36	199.0	8.26		
124.5	5.47	149.5	6.44	174.5	7.38	199.5	8.28		
125.0	5.49	150.0	6.46	175.0	7.40	200.0	8.30		

Temperature, °F

19.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 6.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.18	50.5	2.32	75.5	3.42
1.0	0.02	26.0	1.21	51.0	2.35	76.0	3.44
1.5	0.05	26.5	1.23	51.5	2.37	76.5	3.46
2.0	0.07	27.0	1.25	52.0	2.39	77.0	3.48
2.5	0.10	27.5	1.28	52.5	2.41	77.5	3.51
3.0	0.12	28.0	1.30	53.0	2.44	78.0	3.53
3.5	0.14	28.5	1.32	53.5	2.46	78.5	3.55
4.0	0.17	29.0	1.35	54.0	2.48	79.0	3.57
4.5	0.19	29.5	1.37	54.5	2.50	79.5	3.59
5.0	0.22	30.0	1.39	55.0	2.52	80.0	3.61
5.5	0.24	30.5	1.42	55.5	2.55	80.5	3.63
6.0	0.26	31.0	1.44	56.0	2.57	81.0	3.66
6.5	0.29	31.5	1.46	56.5	2.59	81.5	3.68
7.0	0.31	32.0	1.49	57.0	2.61	82.0	3.70
7.5	0.34	32.5	1.51	57.5	2.64	82.5	3.72
8.0	0.36	33.0	1.53	58.0	2.66	83.0	3.74
8.5	0.38	33.5	1.55	58.5	2.68	83.5	3.76
9.0	0.41	34.0	1.58	59.0	2.70	84.0	3.78
9.5	0.43	34.5	1.60	59.5	2.72	84.5	3.80
10.0	0.46	35.0	1.62	60.0	2.75	85.0	3.83
10.5	0.48	35.5	1.65	60.5	2.77	85.5	3.85
11.0	0.50	36.0	1.67	61.0	2.79	86.0	3.87
11.5	0.53	36.5	1.69	61.5	2.81	86.5	3.89
12.0	0.55	37.0	1.71	62.0	2.83	87.0	3.91
12.5	0.57	37.5	1.74	62.5	2.86	87.5	3.93
13.0	0.60	38.0	1.76	63.0	2.88	88.0	3.95
13.5	0.62	38.5	1.78	63.5	2.90	88.5	3.97
14.0	0.65	39.0	1.81	64.0	2.92	89.0	3.99
14.5	0.67	39.5	1.83	64.5	2.94	89.5	4.01
15.0	0.69	40.0	1.85	65.0	2.96	90.0	4.04
15.5	0.72	40.5	1.87	65.5	2.99	90.5	4.06
16.0	0.74	41.0	1.90	66.0	3.01	91.0	4.08
16.5	0.76	41.5	1.92	66.5	3.03	91.5	4.10
17.0	0.79	42.0	1.94	67.0	3.05	92.0	4.12
17.5	0.81	42.5	1.96	67.5	3.07	92.5	4.14
18.0	0.83	43.0	1.99	68.0	3.10	93.0	4.16
18.5	0.86	43.5	2.01	68.5	3.12	93.5	4.18
19.0	0.88	44.0	2.03	69.0	3.14	94.0	4.20
19.5	0.90	44.5	2.05	69.5	3.16	94.5	4.22
20.0	0.93	45.0	2.08	70.0	3.18	95.0	4.24
20.5	0.95	45.5	2.10	70.5	3.20	95.5	4.27
21.0	0.97	46.0	2.12	71.0	3.23	96.0	4.29
21.5	1.00	46.5	2.14	71.5	3.25	96.5	4.31
22.0	1.02	47.0	2.17	72.0	3.27	97.0	4.33
22.5	1.04	47.5	2.19	72.5	3.29	97.5	4.35
23.0	1.07	48.0	2.21	73.0	3.31	98.0	4.37
23.5	1.09	48.5	2.23	73.5	3.33	98.5	4.39
24.0	1.11	49.0	2.26	74.0	3.36	99.0	4.41
24.5	1.14	49.5	2.28	74.5	3.38	99.5	4.43
25.0	1.16	50.0	2.30	75.0	3.40	100.0	4.45

Temperature, °F

21.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				- 6.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	4.47	125.5	5.48	150.5	6.46	175.5	7.39
101.0	4.49	126.0	5.50	151.0	6.48	176.0	7.41
101.5	4.51	126.5	5.52	151.5	6.49	176.5	7.43
102.0	4.53	127.0	5.54	152.0	6.51	177.0	7.44
102.5	4.56	127.5	5.56	152.5	6.53	177.5	7.46
103.0	4.58	128.0	5.58	153.0	6.55	178.0	7.48
103.5	4.60	128.5	5.60	153.5	6.57	178.5	7.50
104.0	4.62	129.0	5.62	154.0	6.59	179.0	7.52
104.5	4.64	129.5	5.64	154.5	6.61	179.5	7.53
105.0	4.66	130.0	5.66	155.0	6.63	180.0	7.55
105.5	4.68	130.5	5.68	155.5	6.65	180.5	7.57
106.0	4.70	131.0	5.70	156.0	6.66	181.0	7.59
106.5	4.72	131.5	5.72	156.5	6.68	181.5	7.61
107.0	4.74	132.0	5.74	157.0	6.70	182.0	7.62
107.5	4.76	132.5	5.76	157.5	6.72	182.5	7.64
108.0	4.78	133.0	5.78	158.0	6.74	183.0	7.66
108.5	4.80	133.5	5.80	158.5	6.76	183.5	7.68
109.0	4.82	134.0	5.82	159.0	6.78	184.0	7.70
109.5	4.84	134.5	5.84	159.5	6.80	184.5	7.72
110.0	4.86	135.0	5.86	160.0	6.82	185.0	7.73
110.5	4.88	135.5	5.88	160.5	6.83	185.5	7.75
111.0	4.90	136.0	5.90	161.0	6.85	186.0	7.77
111.5	4.92	136.5	5.92	161.5	6.87	186.5	7.79
112.0	4.94	137.0	5.94	162.0	6.89	187.0	7.80
112.5	4.96	137.5	5.96	162.5	6.91	187.5	7.82
113.0	4.98	138.0	5.98	163.0	6.93	188.0	7.84
113.5	5.00	138.5	5.99	163.5	6.95	188.5	7.86
114.0	5.02	139.0	6.01	164.0	6.96	189.0	7.88
114.5	5.04	139.5	6.03	164.5	6.98	189.5	7.89
115.0	5.06	140.0	6.05	165.0	7.00	190.0	7.91
115.5	5.08	140.5	6.07	165.5	7.02	190.5	7.93
116.0	5.11	141.0	6.09	166.0	7.04	191.0	7.95
116.5	5.13	141.5	6.11	166.5	7.06	191.5	7.97
117.0	5.15	142.0	6.13	167.0	7.08	192.0	7.98
117.5	5.17	142.5	6.15	167.5	7.09	192.5	8.00
118.0	5.19	143.0	6.17	168.0	7.11	193.0	8.02
118.5	5.21	143.5	6.19	168.5	7.13	193.5	8.04
119.0	5.23	144.0	6.21	169.0	7.15	194.0	8.05
119.5	5.25	144.5	6.23	169.5	7.17	194.5	8.07
120.0	5.27	145.0	6.25	170.0	7.19	195.0	8.09
120.5	5.29	145.5	6.27	170.5	7.21	195.5	8.11
121.0	5.31	146.0	6.28	171.0	7.22	196.0	8.13
121.5	5.33	146.5	6.30	171.5	7.24	196.5	8.14
122.0	5.35	147.0	6.32	172.0	7.26	197.0	8.16
122.5	5.37	147.5	6.34	172.5	7.28	197.5	8.18
123.0	5.39	148.0	6.36	173.0	7.30	198.0	8.20
123.5	5.41	148.5	6.38	173.5	7.32	198.5	8.21
124.0	5.43	149.0	6.40	174.0	7.33	199.0	8.23
124.5	5.45	149.5	6.42	174.5	7.35	199.5	8.25
125.0	5.46	150.0	6.44	175.0	7.37	200.0	8.27

Temperature, °F

21.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				- 5 • 0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•18	50•5	2•32	75•5	3•41
1•0	0•02	26•0	1•20	51•0	2•34	76•0	3•43
1•5	0•05	26•5	1•23	51•5	2•36	76•5	3•45
2•0	0•07	27•0	1•25	52•0	2•38	77•0	3•47
2•5	0•10	27•5	1•27	52•5	2•40	77•5	3•49
3•0	0•12	28•0	1•30	53•0	2•43	78•0	3•51
3•5	0•14	28•5	1•32	53•5	2•45	78•5	3•54
4•0	0•17	29•0	1•34	54•0	2•47	79•0	3•56
4•5	0•19	29•5	1•36	54•5	2•49	79•5	3•58
5•0	0•22	30•0	1•39	55•0	2•52	80•0	3•60
5•5	0•24	30•5	1•41	55•5	2•54	80•5	3•62
6•0	0•26	31•0	1•43	56•0	2•56	81•0	3•64
6•5	0•29	31•5	1•46	56•5	2•58	81•5	3•66
7•0	0•31	32•0	1•48	57•0	2•60	82•0	3•68
7•5	0•34	32•5	1•50	57•5	2•63	82•5	3•70
8•0	0•36	33•0	1•53	58•0	2•65	83•0	3•73
8•5	0•38	33•5	1•55	58•5	2•67	83•5	3•75
9•0	0•41	34•0	1•57	59•0	2•69	84•0	3•77
9•5	0•43	34•5	1•59	59•5	2•71	84•5	3•79
10•0	0•45	35•0	1•62	60•0	2•74	85•0	3•81
10•5	0•48	35•5	1•64	60•5	2•76	85•5	3•83
11•0	0•50	36•0	1•66	61•0	2•78	86•0	3•85
11•5	0•52	36•5	1•69	61•5	2•80	86•5	3•87
12•0	0•55	37•0	1•71	62•0	2•82	87•0	3•89
12•5	0•57	37•5	1•73	62•5	2•84	87•5	3•92
13•0	0•60	38•0	1•75	63•0	2•87	88•0	3•94
13•5	0•62	38•5	1•78	63•5	2•89	88•5	3•96
14•0	0•64	39•0	1•80	64•0	2•91	89•0	3•98
14•5	0•67	39•5	1•82	64•5	2•93	89•5	4•00
15•0	0•69	40•0	1•84	65•0	2•95	90•0	4•02
15•5	0•71	40•5	1•87	65•5	2•98	90•5	4•04
16•0	0•74	41•0	1•89	66•0	3•00	91•0	4•06
16•5	0•76	41•5	1•91	66•5	3•02	91•5	4•08
17•0	0•78	42•0	1•93	67•0	3•04	92•0	4•10
17•5	0•81	42•5	1•96	67•5	3•06	92•5	4•12
18•0	0•83	43•0	1•98	68•0	3•08	93•0	4•15
18•5	0•85	43•5	2•00	68•5	3•11	93•5	4•17
19•0	0•88	44•0	2•02	69•0	3•13	94•0	4•19
19•5	0•90	44•5	2•05	69•5	3•15	94•5	4•21
20•0	0•92	45•0	2•07	70•0	3•17	95•0	4•23
20•5	0•95	45•5	2•09	70•5	3•19	95•5	4•25
21•0	0•97	46•0	2•11	71•0	3•21	96•0	4•27
21•5	0•99	46•5	2•14	71•5	3•24	96•5	4•29
22•0	1•02	47•0	2•16	72•0	3•26	97•0	4•31
22•5	1•04	47•5	2•18	72•5	3•28	97•5	4•33
23•0	1•06	48•0	2•20	73•0	3•30	98•0	4•35
23•5	1•09	48•5	2•23	73•5	3•32	98•5	4•37
24•0	1•11	49•0	2•25	74•0	3•34	99•0	4•39
24•5	1•13	49•5	2•27	74•5	3•36	99•5	4•41
25•0	1•16	50•0	2•29	75•0	3•39	100•0	4•44

Temperature, °F

23•0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

- 5•0

Temperature, °C

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•46	125•5	5•46	150•5	6•43	175•5	7•36				
101•0	4•48	126•0	5•48	151•0	6•45	176•0	7•38				
101•5	4•50	126•5	5•50	151•5	6•47	176•5	7•40				
102•0	4•52	127•0	5•52	152•0	6•49	177•0	7•42				
102•5	4•54	127•5	5•54	152•5	6•51	177•5	7•43				
103•0	4•56	128•0	5•56	153•0	6•53	178•0	7•45				
103•5	4•58	128•5	5•58	153•5	6•55	178•5	7•47				
104•0	4•60	129•0	5•60	154•0	6•56	179•0	7•49				
104•5	4•62	129•5	5•62	154•5	6•58	179•5	7•51				
105•0	4•64	130•0	5•64	155•0	6•60	180•0	7•52				
105•5	4•66	130•5	5•66	155•5	6•62	180•5	7•54				
106•0	4•68	131•0	5•68	156•0	6•64	181•0	7•56				
106•5	4•70	131•5	5•70	156•5	6•66	181•5	7•58				
107•0	4•72	132•0	5•72	157•0	6•68	182•0	7•60				
107•5	4•74	132•5	5•74	157•5	6•70	182•5	7•61				
108•0	4•76	133•0	5•76	158•0	6•71	183•0	7•63				
108•5	4•78	133•5	5•78	158•5	6•73	183•5	7•65				
109•0	4•80	134•0	5•80	159•0	6•75	184•0	7•67				
109•5	4•82	134•5	5•82	159•5	6•77	184•5	7•69				
110•0	4•84	135•0	5•84	160•0	6•79	185•0	7•70				
110•5	4•86	135•5	5•86	160•5	6•81	185•5	7•72				
111•0	4•88	136•0	5•88	161•0	6•83	186•0	7•74				
111•5	4•90	136•5	5•89	161•5	6•85	186•5	7•76				
112•0	4•92	137•0	5•91	162•0	6•86	187•0	7•78				
112•5	4•95	137•5	5•93	162•5	6•88	187•5	7•79				
113•0	4•97	138•0	5•95	163•0	6•90	188•0	7•81				
113•5	4•99	138•5	5•97	163•5	6•92	188•5	7•83				
114•0	5•01	139•0	5•99	164•0	6•94	189•0	7•85				
114•5	5•03	139•5	6•01	164•5	6•96	189•5	7•87				
115•0	5•05	140•0	6•03	165•0	6•98	190•0	7•88				
115•5	5•07	140•5	6•05	165•5	6•99	190•5	7•90				
116•0	5•09	141•0	6•07	166•0	7•01	191•0	7•92				
116•5	5•11	141•5	6•09	166•5	7•03	191•5	7•94				
117•0	5•13	142•0	6•11	167•0	7•05	192•0	7•95				
117•5	5•15	142•5	6•13	167•5	7•07	192•5	7•97				
118•0	5•17	143•0	6•15	168•0	7•09	193•0	7•99				
118•5	5•19	143•5	6•17	168•5	7•10	193•5	8•01				
119•0	5•21	144•0	6•18	169•0	7•12	194•0	8•02				
119•5	5•23	144•5	6•20	169•5	7•14	194•5	8•04				
120•0	5•25	145•0	6•22	170•0	7•16	195•0	8•06				
120•5	5•27	145•5	6•24	170•5	7•18	195•5	8•08				
121•0	5•29	146•0	6•26	171•0	7•20	196•0	8•10				
121•5	5•31	146•5	6•28	171•5	7•22	196•5	8•11				
122•0	5•33	147•0	6•30	172•0	7•23	197•0	8•13				
122•5	5•35	147•5	6•32	172•5	7•25	197•5	8•15				
123•0	5•37	148•0	6•34	173•0	7•27	198•0	8•17				
123•5	5•38	148•5	6•36	173•5	7•29	198•5	8•18				
124•0	5•40	149•0	6•38	174•0	7•31	199•0	8•20				
124•5	5•42	149•5	6•39	174•5	7•32	199•5	8•22				
125•0	5•44	150•0	6•41	175•0	7•34	200•0	8•24				

Temperature, °F

23•0

- 4.0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.18	50.5	2.31	75.5	3.39
1.0	0.02	26.0	1.20	51.0	2.33	76.0	3.42
1.5	0.05	26.5	1.22	51.5	2.35	76.5	3.44
2.0	0.07	27.0	1.24	52.0	2.37	77.0	3.46
2.5	0.10	27.5	1.27	52.5	2.40	77.5	3.48
3.0	0.12	28.0	1.29	53.0	2.42	78.0	3.50
3.5	0.14	28.5	1.31	53.5	2.44	78.5	3.52
4.0	0.17	29.0	1.34	54.0	2.46	79.0	3.54
4.5	0.19	29.5	1.36	54.5	2.48	79.5	3.56
5.0	0.21	30.0	1.38	55.0	2.51	80.0	3.59
5.5	0.24	30.5	1.41	55.5	2.53	80.5	3.61
6.0	0.26	31.0	1.43	56.0	2.55	81.0	3.63
6.5	0.29	31.5	1.45	56.5	2.57	81.5	3.65
7.0	0.31	32.0	1.47	57.0	2.59	82.0	3.67
7.5	0.33	32.5	1.50	57.5	2.62	82.5	3.69
8.0	0.36	33.0	1.52	58.0	2.64	83.0	3.71
8.5	0.38	33.5	1.54	58.5	2.66	83.5	3.73
9.0	0.40	34.0	1.57	59.0	2.68	84.0	3.75
9.5	0.43	34.5	1.59	59.5	2.70	84.5	3.78
10.0	0.45	35.0	1.61	60.0	2.72	85.0	3.80
10.5	0.48	35.5	1.63	60.5	2.75	85.5	3.82
11.0	0.50	36.0	1.66	61.0	2.77	86.0	3.84
11.5	0.52	36.5	1.68	61.5	2.79	86.5	3.86
12.0	0.55	37.0	1.70	62.0	2.81	87.0	3.88
12.5	0.57	37.5	1.72	62.5	2.83	87.5	3.90
13.0	0.59	38.0	1.75	63.0	2.86	88.0	3.92
13.5	0.62	38.5	1.77	63.5	2.88	88.5	3.94
14.0	0.64	39.0	1.79	64.0	2.90	89.0	3.96
14.5	0.66	39.5	1.81	64.5	2.92	89.5	3.98
15.0	0.69	40.0	1.84	65.0	2.94	90.0	4.01
15.5	0.71	40.5	1.86	65.5	2.96	90.5	4.03
16.0	0.73	41.0	1.88	66.0	2.99	91.0	4.05
16.5	0.76	41.5	1.90	66.5	3.01	91.5	4.07
17.0	0.78	42.0	1.93	67.0	3.03	92.0	4.09
17.5	0.80	42.5	1.95	67.5	3.05	92.5	4.11
18.0	0.83	43.0	1.97	68.0	3.07	93.0	4.13
18.5	0.85	43.5	1.99	68.5	3.09	93.5	4.15
19.0	0.87	44.0	2.02	69.0	3.12	94.0	4.17
19.5	0.90	44.5	2.04	69.5	3.14	94.5	4.19
20.0	0.92	45.0	2.06	70.0	3.16	95.0	4.21
20.5	0.94	45.5	2.08	70.5	3.18	95.5	4.23
21.0	0.97	46.0	2.11	71.0	3.20	96.0	4.25
21.5	0.99	46.5	2.13	71.5	3.22	96.5	4.27
22.0	1.01	47.0	2.15	72.0	3.24	97.0	4.30
22.5	1.04	47.5	2.17	72.5	3.27	97.5	4.32
23.0	1.06	48.0	2.20	73.0	3.29	98.0	4.34
23.5	1.08	48.5	2.22	73.5	3.31	98.5	4.36
24.0	1.11	49.0	2.24	74.0	3.33	99.0	4.38
24.5	1.13	49.5	2.26	74.5	3.35	99.5	4.40
25.0	1.15	50.0	2.28	75.0	3.37	100.0	4.42

Temperature, °F

24.8

Temperature, °C

- 4.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.44	125.5	5.44	150.5	6.41	175.5	7.33				
101.0	4.46	126.0	5.46	151.0	6.43	176.0	7.35				
101.5	4.48	126.5	5.48	151.5	6.45	176.5	7.37				
102.0	4.50	127.0	5.50	152.0	6.46	177.0	7.39				
102.5	4.52	127.5	5.52	152.5	6.48	177.5	7.41				
103.0	4.54	128.0	5.54	153.0	6.50	178.0	7.42				
103.5	4.56	128.5	5.56	153.5	6.52	178.5	7.44				
104.0	4.58	129.0	5.58	154.0	6.54	179.0	7.46				
104.5	4.60	129.5	5.60	154.5	6.56	179.5	7.48				
105.0	4.62	130.0	5.62	155.0	6.58	180.0	7.50				
105.5	4.64	130.5	5.64	155.5	6.60	180.5	7.51				
106.0	4.66	131.0	5.66	156.0	6.62	181.0	7.53				
106.5	4.68	131.5	5.68	156.5	6.63	181.5	7.55				
107.0	4.70	132.0	5.70	157.0	6.65	182.0	7.57				
107.5	4.72	132.5	5.72	157.5	6.67	182.5	7.59				
108.0	4.74	133.0	5.74	158.0	6.69	183.0	7.60				
108.5	4.77	133.5	5.76	158.5	6.71	183.5	7.62				
109.0	4.79	134.0	5.78	159.0	6.73	184.0	7.64				
109.5	4.81	134.5	5.80	159.5	6.75	184.5	7.66				
110.0	4.83	135.0	5.81	160.0	6.76	185.0	7.68				
110.5	4.85	135.5	5.83	160.5	6.78	185.5	7.69				
111.0	4.87	136.0	5.85	161.0	6.80	186.0	7.71				
111.5	4.89	136.5	5.87	161.5	6.82	186.5	7.73				
112.0	4.91	137.0	5.89	162.0	6.84	187.0	7.75				
112.5	4.93	137.5	5.91	162.5	6.86	187.5	7.77				
113.0	4.95	138.0	5.93	163.0	6.88	188.0	7.78				
113.5	4.97	138.5	5.95	163.5	6.89	188.5	7.80				
114.0	4.99	139.0	5.97	164.0	6.91	189.0	7.82				
114.5	5.01	139.5	5.99	164.5	6.93	189.5	7.84				
115.0	5.03	140.0	6.01	165.0	6.95	190.0	7.85				
115.5	5.05	140.5	6.03	165.5	6.97	190.5	7.87				
116.0	5.07	141.0	6.05	166.0	6.99	191.0	7.89				
116.5	5.09	141.5	6.07	166.5	7.01	191.5	7.91				
117.0	5.11	142.0	6.08	167.0	7.02	192.0	7.92				
117.5	5.13	142.5	6.10	167.5	7.04	192.5	7.94				
118.0	5.15	143.0	6.12	168.0	7.06	193.0	7.96				
118.5	5.17	143.5	6.14	168.5	7.08	193.5	7.98				
119.0	5.19	144.0	6.16	169.0	7.10	194.0	8.00				
119.5	5.21	144.5	6.18	169.5	7.12	194.5	8.01				
120.0	5.23	145.0	6.20	170.0	7.13	195.0	8.03				
120.5	5.25	145.5	6.22	170.5	7.15	195.5	8.05				
121.0	5.27	146.0	6.24	171.0	7.17	196.0	8.07				
121.5	5.29	146.5	6.26	171.5	7.19	196.5	8.08				
122.0	5.31	147.0	6.28	172.0	7.21	197.0	8.10				
122.5	5.33	147.5	6.29	172.5	7.23	197.5	8.12				
123.0	5.35	148.0	6.31	173.0	7.24	198.0	8.14				
123.5	5.36	148.5	6.33	173.5	7.26	198.5	8.15				
124.0	5.38	149.0	6.35	174.0	7.28	199.0	8.17				
124.5	5.40	149.5	6.37	174.5	7.30	199.5	8.19				
125.0	5.42	150.0	6.39	175.0	7.32	200.0	8.21				

Temperature, °F

24.8

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.17	50.5	2.30	75.5	3.38
1.0	0.02	26.0	1.19	51.0	2.32	76.0	3.40
1.5	0.05	26.5	1.22	51.5	2.34	76.5	3.42
2.0	0.07	27.0	1.24	52.0	2.36	77.0	3.44
2.5	0.10	27.5	1.26	52.5	2.39	77.5	3.47
3.0	0.12	28.0	1.29	53.0	2.41	78.0	3.49
3.5	0.14	28.5	1.31	53.5	2.43	78.5	3.51
4.0	0.17	29.0	1.33	54.0	2.45	79.0	3.53
4.5	0.19	29.5	1.35	54.5	2.47	79.5	3.55
5.0	0.21	30.0	1.38	55.0	2.50	80.0	3.57
5.5	0.24	30.5	1.40	55.5	2.52	80.5	3.59
6.0	0.26	31.0	1.42	56.0	2.54	81.0	3.61
6.5	0.29	31.5	1.45	56.5	2.56	81.5	3.63
7.0	0.31	32.0	1.47	57.0	2.58	82.0	3.66
7.5	0.33	32.5	1.49	57.5	2.61	82.5	3.68
8.0	0.36	33.0	1.51	58.0	2.63	83.0	3.70
8.5	0.38	33.5	1.54	58.5	2.65	83.5	3.72
9.0	0.40	34.0	1.56	59.0	2.67	84.0	3.74
9.5	0.43	34.5	1.58	59.5	2.69	84.5	3.76
10.0	0.45	35.0	1.60	60.0	2.71	85.0	3.78
10.5	0.47	35.5	1.63	60.5	2.74	85.5	3.80
11.0	0.50	36.0	1.65	61.0	2.76	86.0	3.82
11.5	0.52	36.5	1.67	61.5	2.78	86.5	3.84
12.0	0.54	37.0	1.69	62.0	2.80	87.0	3.87
12.5	0.57	37.5	1.72	62.5	2.82	87.5	3.89
13.0	0.59	38.0	1.74	63.0	2.84	88.0	3.91
13.5	0.61	38.5	1.76	63.5	2.87	88.5	3.93
14.0	0.64	39.0	1.78	64.0	2.89	89.0	3.95
14.5	0.66	39.5	1.81	64.5	2.91	89.5	3.97
15.0	0.68	40.0	1.83	65.0	2.93	90.0	3.99
15.5	0.71	40.5	1.85	65.5	2.95	90.5	4.01
16.0	0.73	41.0	1.87	66.0	2.97	91.0	4.03
16.5	0.75	41.5	1.90	66.5	3.00	91.5	4.05
17.0	0.78	42.0	1.92	67.0	3.02	92.0	4.07
17.5	0.80	42.5	1.94	67.5	3.04	92.5	4.09
18.0	0.82	43.0	1.96	68.0	3.06	93.0	4.11
18.5	0.85	43.5	1.99	68.5	3.08	93.5	4.14
19.0	0.87	44.0	2.01	69.0	3.10	94.0	4.16
19.5	0.89	44.5	2.03	69.5	3.13	94.5	4.18
20.0	0.92	45.0	2.05	70.0	3.15	95.0	4.20
20.5	0.94	45.5	2.08	70.5	3.17	95.5	4.22
21.0	0.96	46.0	2.10	71.0	3.19	96.0	4.24
21.5	0.99	46.5	2.12	71.5	3.21	96.5	4.26
22.0	1.01	47.0	2.14	72.0	3.23	97.0	4.28
22.5	1.03	47.5	2.16	72.5	3.25	97.5	4.30
23.0	1.06	48.0	2.19	73.0	3.27	98.0	4.32
23.5	1.08	48.5	2.21	73.5	3.30	98.5	4.34
24.0	1.10	49.0	2.23	74.0	3.32	99.0	4.36
24.5	1.13	49.5	2.25	74.5	3.34	99.5	4.38
25.0	1.15	50.0	2.28	75.0	3.36	100.0	4.40

Temperature, °F

26.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C = 3.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.42	125.5	5.42	150.5	6.38	175.5	7.31				
101.0	4.44	126.0	5.44	151.0	6.40	176.0	7.33				
101.5	4.46	126.5	5.46	151.5	6.42	176.5	7.34				
102.0	4.48	127.0	5.48	152.0	6.44	177.0	7.36				
102.5	4.50	127.5	5.50	152.5	6.46	177.5	7.38				
103.0	4.52	128.0	5.52	153.0	6.48	178.0	7.40				
103.5	4.54	128.5	5.54	153.5	6.50	178.5	7.42				
104.0	4.57	129.0	5.56	154.0	6.52	179.0	7.43				
104.5	4.59	129.5	5.58	154.5	6.53	179.5	7.45				
105.0	4.61	130.0	5.60	155.0	6.55	180.0	7.47				
105.5	4.63	130.5	5.62	155.5	6.57	180.5	7.49				
106.0	4.65	131.0	5.64	156.0	6.59	181.0	7.51				
106.5	4.67	131.5	5.66	156.5	6.61	181.5	7.52				
107.0	4.69	132.0	5.68	157.0	6.63	182.0	7.54				
107.5	4.71	132.5	5.70	157.5	6.65	182.5	7.56				
108.0	4.73	133.0	5.72	158.0	6.67	183.0	7.58				
108.5	4.75	133.5	5.74	158.5	6.68	183.5	7.59				
109.0	4.77	134.0	5.75	159.0	6.70	184.0	7.61				
109.5	4.79	134.5	5.77	159.5	6.72	184.5	7.63				
110.0	4.81	135.0	5.79	160.0	6.74	185.0	7.65				
110.5	4.83	135.5	5.81	160.5	6.76	185.5	7.67				
111.0	4.85	136.0	5.83	161.0	6.78	186.0	7.68				
111.5	4.87	136.5	5.85	161.5	6.80	186.5	7.70				
112.0	4.89	137.0	5.87	162.0	6.81	187.0	7.72				
112.5	4.91	137.5	5.89	162.5	6.83	187.5	7.74				
113.0	4.93	138.0	5.91	163.0	6.85	188.0	7.75				
113.5	4.95	138.5	5.93	163.5	6.87	188.5	7.77				
114.0	4.97	139.0	5.95	164.0	6.89	189.0	7.79				
114.5	4.99	139.5	5.97	164.5	6.91	189.5	7.81				
115.0	5.01	140.0	5.99	165.0	6.92	190.0	7.83				
115.5	5.03	140.5	6.00	165.5	6.94	190.5	7.84				
116.0	5.05	141.0	6.02	166.0	6.96	191.0	7.86				
116.5	5.07	141.5	6.04	166.5	6.98	191.5	7.88				
117.0	5.09	142.0	6.06	167.0	7.00	192.0	7.90				
117.5	5.11	142.5	6.08	167.5	7.02	192.5	7.91				
118.0	5.13	143.0	6.10	168.0	7.03	193.0	7.93				
118.5	5.15	143.5	6.12	168.5	7.05	193.5	7.95				
119.0	5.17	144.0	6.14	169.0	7.07	194.0	7.97				
119.5	5.19	144.5	6.16	169.5	7.09	194.5	7.98				
120.0	5.21	145.0	6.18	170.0	7.11	195.0	8.00				
120.5	5.23	145.5	6.20	170.5	7.13	195.5	8.02				
121.0	5.25	146.0	6.21	171.0	7.14	196.0	8.04				
121.5	5.27	146.5	6.23	171.5	7.16	196.5	8.05				
122.0	5.29	147.0	6.25	172.0	7.18	197.0	8.07				
122.5	5.31	147.5	6.27	172.5	7.20	197.5	8.09				
123.0	5.33	148.0	6.29	173.0	7.22	198.0	8.11				
123.5	5.34	148.5	6.31	173.5	7.23	198.5	8.12				
124.0	5.36	149.0	6.33	174.0	7.25	199.0	8.14				
124.5	5.38	149.5	6.35	174.5	7.27	199.5	8.16				
125.0	5.40	150.0	6.37	175.0	7.29	200.0	8.18				

Temperature, °F

26.6

- 20

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.17	50.5	2.29	75.5	3.37
1.0	0.02	26.0	1.19	51.0	2.31	76.0	3.39
1.5	0.05	26.5	1.21	51.5	2.33	76.5	3.41
2.0	0.07	27.0	1.24	52.0	2.36	77.0	3.43
2.5	0.09	27.5	1.26	52.5	2.38	77.5	3.45
3.0	0.12	28.0	1.28	53.0	2.40	78.0	3.47
3.5	0.14	28.5	1.30	53.5	2.42	78.5	3.50
4.0	0.17	29.0	1.33	54.0	2.44	79.0	3.52
4.5	0.19	29.5	1.35	54.5	2.46	79.5	3.54
5.0	0.21	30.0	1.37	55.0	2.49	80.0	3.56
5.5	0.24	30.5	1.39	55.5	2.51	80.5	3.58
6.0	0.26	31.0	1.42	56.0	2.53	81.0	3.60
6.5	0.28	31.5	1.44	56.5	2.55	81.5	3.62
7.0	0.31	32.0	1.46	57.0	2.57	82.0	3.64
7.5	0.33	32.5	1.49	57.5	2.60	82.5	3.66
8.0	0.35	33.0	1.51	58.0	2.62	83.0	3.68
8.5	0.38	33.5	1.53	58.5	2.64	83.5	3.70
9.0	0.40	34.0	1.55	59.0	2.66	84.0	3.73
9.5	0.43	34.5	1.58	59.5	2.68	84.5	3.75
10.0	0.45	35.0	1.60	60.0	2.70	85.0	3.77
10.5	0.47	35.5	1.62	60.5	2.73	85.5	3.79
11.0	0.50	36.0	1.64	61.0	2.75	86.0	3.81
11.5	0.52	36.5	1.67	61.5	2.77	86.5	3.83
12.0	0.54	37.0	1.69	62.0	2.79	87.0	3.85
12.5	0.57	37.5	1.71	62.5	2.81	87.5	3.87
13.0	0.59	38.0	1.73	63.0	2.83	88.0	3.89
13.5	0.61	38.5	1.76	63.5	2.86	88.5	3.91
14.0	0.64	39.0	1.78	64.0	2.88	89.0	3.93
14.5	0.66	39.5	1.80	64.5	2.90	89.5	3.95
15.0	0.68	40.0	1.82	65.0	2.92	90.0	3.98
15.5	0.71	40.5	1.85	65.5	2.94	90.5	4.00
16.0	0.73	41.0	1.87	66.0	2.96	91.0	4.02
16.5	0.75	41.5	1.89	66.5	2.98	91.5	4.04
17.0	0.78	42.0	1.91	67.0	3.01	92.0	4.06
17.5	0.80	42.5	1.93	67.5	3.03	92.5	4.08
18.0	0.82	43.0	1.96	68.0	3.05	93.0	4.10
18.5	0.84	43.5	1.98	68.5	3.07	93.5	4.12
19.0	0.87	44.0	2.00	69.0	3.09	94.0	4.14
19.5	0.89	44.5	2.02	69.5	3.11	94.5	4.16
20.0	0.91	45.0	2.05	70.0	3.13	95.0	4.18
20.5	0.94	45.5	2.07	70.5	3.16	95.5	4.20
21.0	0.96	46.0	2.09	71.0	3.18	96.0	4.22
21.5	0.98	46.5	2.11	71.5	3.20	96.5	4.24
22.0	1.01	47.0	2.13	72.0	3.22	97.0	4.26
22.5	1.03	47.5	2.16	72.5	3.24	97.5	4.28
23.0	1.05	48.0	2.18	73.0	3.26	98.0	4.30
23.5	1.08	48.5	2.20	73.5	3.28	98.5	4.32
24.0	1.10	49.0	2.22	74.0	3.30	99.0	4.34
24.5	1.12	49.5	2.25	74.5	3.33	99.5	4.37
25.0	1.14	50.0	2.27	75.0	3.35	100.0	4.39

Temperature, °F

28.4

Temperature, °C = 2.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.41	125.5	5.40	150.5	6.36	175.5	7.28				
101.0	4.43	126.0	5.42	151.0	6.38	176.0	7.30				
101.5	4.45	126.5	5.44	151.5	6.40	176.5	7.32				
102.0	4.47	127.0	5.46	152.0	6.42	177.0	7.33				
102.5	4.49	127.5	5.48	152.5	6.44	177.5	7.35				
103.0	4.51	128.0	5.50	153.0	6.45	178.0	7.37				
103.5	4.53	128.5	5.52	153.5	6.47	178.5	7.39				
104.0	4.55	129.0	5.54	154.0	6.49	179.0	7.41				
104.5	4.57	129.5	5.56	154.5	6.51	179.5	7.42				
105.0	4.59	130.0	5.58	155.0	6.53	180.0	7.44				
105.5	4.61	130.5	5.60	155.5	6.55	180.5	7.46				
106.0	4.63	131.0	5.62	156.0	6.57	181.0	7.48				
106.5	4.65	131.5	5.64	156.5	6.58	181.5	7.50				
107.0	4.67	132.0	5.66	157.0	6.60	182.0	7.51				
107.5	4.69	132.5	5.68	157.5	6.62	182.5	7.53				
108.0	4.71	133.0	5.69	158.0	6.64	183.0	7.55				
108.5	4.73	133.5	5.71	158.5	6.66	183.5	7.57				
109.0	4.75	134.0	5.73	159.0	6.68	184.0	7.58				
109.5	4.77	134.5	5.75	159.5	6.70	184.5	7.60				
110.0	4.79	135.0	5.77	160.0	6.71	185.0	7.62				
110.5	4.81	135.5	5.79	160.5	6.73	185.5	7.64				
111.0	4.83	136.0	5.81	161.0	6.75	186.0	7.66				
111.5	4.85	136.5	5.83	161.5	6.77	186.5	7.67				
112.0	4.87	137.0	5.85	162.0	6.79	187.0	7.69				
112.5	4.89	137.5	5.87	162.5	6.81	187.5	7.71				
113.0	4.91	138.0	5.89	163.0	6.83	188.0	7.73				
113.5	4.93	138.5	5.91	163.5	6.84	188.5	7.74				
114.0	4.95	139.0	5.92	164.0	6.86	189.0	7.76				
114.5	4.97	139.5	5.94	164.5	6.88	189.5	7.78				
115.0	4.99	140.0	5.96	165.0	6.90	190.0	7.80				
115.5	5.01	140.5	5.98	165.5	6.92	190.5	7.81				
116.0	5.03	141.0	6.00	166.0	6.94	191.0	7.83				
116.5	5.05	141.5	6.02	166.5	6.95	191.5	7.85				
117.0	5.07	142.0	6.04	167.0	6.97	192.0	7.87				
117.5	5.09	142.5	6.06	167.5	6.99	192.5	7.88				
118.0	5.11	143.0	6.08	168.0	7.01	193.0	7.90				
118.5	5.13	143.5	6.10	168.5	7.03	193.5	7.92				
119.0	5.15	144.0	6.12	169.0	7.04	194.0	7.94				
119.5	5.17	144.5	6.13	169.5	7.06	194.5	7.95				
120.0	5.19	145.0	6.15	170.0	7.08	195.0	7.97				
120.5	5.21	145.5	6.17	170.5	7.10	195.5	7.99				
121.0	5.23	146.0	6.19	171.0	7.12	196.0	8.01				
121.5	5.25	146.5	6.21	171.5	7.14	196.5	8.02				
122.0	5.27	147.0	6.23	172.0	7.15	197.0	8.04				
122.5	5.29	147.5	6.25	172.5	7.17	197.5	8.06				
123.0	5.31	148.0	6.27	173.0	7.19	198.0	8.08				
123.5	5.32	148.5	6.29	173.5	7.21	198.5	8.09				
124.0	5.34	149.0	6.30	174.0	7.23	199.0	8.11				
124.5	5.36	149.5	6.32	174.5	7.24	199.5	8.13				
125.0	5.38	150.0	6.34	175.0	7.26	200.0	8.15				

Temperature, °F

28.4

Temperature, °C								- 1.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.16	50.5	2.28	75.5	3.36	
1.0	0.02	26.0	1.19	51.0	2.30	76.0	3.38	
1.5	0.05	26.5	1.21	51.5	2.32	76.5	3.40	
2.0	0.07	27.0	1.23	52.0	2.35	77.0	3.42	
2.5	0.09	27.5	1.25	52.5	2.37	77.5	3.44	
3.0	0.12	28.0	1.28	53.0	2.39	78.0	3.46	
3.5	0.14	28.5	1.30	53.5	2.41	78.5	3.48	
4.0	0.17	29.0	1.32	54.0	2.43	79.0	3.50	
4.5	0.19	29.5	1.34	54.5	2.46	79.5	3.52	
5.0	0.21	30.0	1.37	55.0	2.48	80.0	3.54	
5.5	0.24	30.5	1.39	55.5	2.50	80.5	3.57	
6.0	0.26	31.0	1.41	56.0	2.52	81.0	3.59	
6.5	0.28	31.5	1.43	56.5	2.54	81.5	3.61	
7.0	0.31	32.0	1.46	57.0	2.56	82.0	3.63	
7.5	0.33	32.5	1.48	57.5	2.59	82.5	3.65	
8.0	0.35	33.0	1.50	58.0	2.61	83.0	3.67	
8.5	0.38	33.5	1.52	58.5	2.63	83.5	3.69	
9.0	0.40	34.0	1.55	59.0	2.65	84.0	3.71	
9.5	0.42	34.5	1.57	59.5	2.67	84.5	3.73	
10.0	0.45	35.0	1.59	60.0	2.69	85.0	3.75	
10.5	0.47	35.5	1.61	60.5	2.72	85.5	3.77	
11.0	0.49	36.0	1.64	61.0	2.74	86.0	3.79	
11.5	0.52	36.5	1.66	61.5	2.76	86.5	3.82	
12.0	0.54	37.0	1.68	62.0	2.78	87.0	3.84	
12.5	0.56	37.5	1.70	62.5	2.80	87.5	3.86	
13.0	0.59	38.0	1.73	63.0	2.82	88.0	3.88	
13.5	0.61	38.5	1.75	63.5	2.84	88.5	3.90	
14.0	0.63	39.0	1.77	64.0	2.87	89.0	3.92	
14.5	0.66	39.5	1.79	64.5	2.89	89.5	3.94	
15.0	0.68	40.0	1.82	65.0	2.91	90.0	3.96	
15.5	0.70	40.5	1.84	65.5	2.93	90.5	3.98	
16.0	0.73	41.0	1.86	66.0	2.95	91.0	4.00	
16.5	0.75	41.5	1.88	66.5	2.97	91.5	4.02	
17.0	0.77	42.0	1.91	67.0	2.99	92.0	4.04	
17.5	0.80	42.5	1.93	67.5	3.02	92.5	4.06	
18.0	0.82	43.0	1.95	68.0	3.04	93.0	4.08	
18.5	0.84	43.5	1.97	68.5	3.06	93.5	4.10	
19.0	0.86	44.0	1.99	69.0	3.08	94.0	4.12	
19.5	0.89	44.5	2.02	69.5	3.10	94.5	4.15	
20.0	0.91	45.0	2.04	70.0	3.12	95.0	4.17	
20.5	0.93	45.5	2.06	70.5	3.14	95.5	4.19	
21.0	0.96	46.0	2.08	71.0	3.17	96.0	4.21	
21.5	0.98	46.5	2.10	71.5	3.19	96.5	4.23	
22.0	1.00	47.0	2.13	72.0	3.21	97.0	4.25	
22.5	1.03	47.5	2.15	72.5	3.23	97.5	4.27	
23.0	1.05	48.0	2.17	73.0	3.25	98.0	4.29	
23.5	1.07	48.5	2.19	73.5	3.27	98.5	4.31	
24.0	1.09	49.0	2.21	74.0	3.29	99.0	4.33	
24.5	1.12	49.5	2.24	74.5	3.31	99.5	4.35	
25.0	1.14	50.0	2.26	75.0	3.33	100.0	4.37	

Temperature, °F

30.2

		Temperature, °C				1.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	4.39	125.5	5.38	150.5	6.34	175.5	7.25
101.0	4.41	126.0	5.40	151.0	6.36	176.0	7.27
101.5	4.43	126.5	5.42	151.5	6.37	176.5	7.29
102.0	4.45	127.0	5.44	152.0	6.39	177.0	7.31
102.5	4.47	127.5	5.46	152.5	6.41	177.5	7.33
103.0	4.49	128.0	5.48	153.0	6.43	178.0	7.34
103.5	4.51	128.5	5.50	153.5	6.45	178.5	7.36
104.0	4.53	129.0	5.52	154.0	6.47	179.0	7.38
104.5	4.55	129.5	5.54	154.5	6.49	179.5	7.40
105.0	4.57	130.0	5.56	155.0	6.50	180.0	7.41
105.5	4.59	130.5	5.58	155.5	6.52	180.5	7.43
106.0	4.61	131.0	5.60	156.0	6.54	181.0	7.45
106.5	4.63	131.5	5.62	156.5	6.56	181.5	7.47
107.0	4.65	132.0	5.63	157.0	6.58	182.0	7.49
107.5	4.67	132.5	5.65	157.5	6.60	182.5	7.50
108.0	4.69	133.0	5.67	158.0	6.62	183.0	7.52
108.5	4.71	133.5	5.69	158.5	6.63	183.5	7.54
109.0	4.73	134.0	5.71	159.0	6.65	184.0	7.56
109.5	4.75	134.5	5.73	159.5	6.67	184.5	7.57
110.0	4.77	135.0	5.75	160.0	6.69	185.0	7.59
110.5	4.79	135.5	5.77	160.5	6.71	185.5	7.61
111.0	4.81	136.0	5.79	161.0	6.73	186.0	7.63
111.5	4.83	136.5	5.81	161.5	6.74	186.5	7.64
112.0	4.85	137.0	5.83	162.0	6.76	187.0	7.66
112.5	4.87	137.5	5.85	162.5	6.78	187.5	7.68
113.0	4.89	138.0	5.86	163.0	6.80	188.0	7.70
113.5	4.91	138.5	5.88	163.5	6.82	188.5	7.72
114.0	4.93	139.0	5.90	164.0	6.84	189.0	7.73
114.5	4.95	139.5	5.92	164.5	6.85	189.5	7.75
115.0	4.97	140.0	5.94	165.0	6.87	190.0	7.77
115.5	4.99	140.5	5.96	165.5	6.89	190.5	7.79
116.0	5.01	141.0	5.98	166.0	6.91	191.0	7.80
116.5	5.03	141.5	6.00	166.5	6.93	191.5	7.82
117.0	5.05	142.0	6.02	167.0	6.95	192.0	7.84
117.5	5.07	142.5	6.04	167.5	6.96	192.5	7.86
118.0	5.09	143.0	6.05	168.0	6.98	193.0	7.87
118.5	5.11	143.5	6.07	168.5	7.00	193.5	7.89
119.0	5.13	144.0	6.09	169.0	7.02	194.0	7.91
119.5	5.15	144.5	6.11	169.5	7.04	194.5	7.93
120.0	5.17	145.0	6.13	170.0	7.06	195.0	7.94
120.5	5.19	145.5	6.15	170.5	7.07	195.5	7.96
121.0	5.21	146.0	6.17	171.0	7.09	196.0	7.98
121.5	5.23	146.5	6.19	171.5	7.11	196.5	7.99
122.0	5.25	147.0	6.21	172.0	7.13	197.0	8.01
122.5	5.27	147.5	6.22	172.5	7.15	197.5	8.03
123.0	5.29	148.0	6.24	173.0	7.16	198.0	8.05
123.5	5.30	148.5	6.26	173.5	7.18	198.5	8.06
124.0	5.32	149.0	6.28	174.0	7.20	199.0	8.08
124.5	5.34	149.5	6.30	174.5	7.22	199.5	8.10
125.0	5.36	150.0	6.32	175.0	7.24	200.0	8.12

Temperature, °F

30.2

0.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.16	50.5	2.27	75.5	3.34
1.0	0.02	26.0	1.18	51.0	2.29	76.0	3.36
1.5	0.05	26.5	1.20	51.5	2.32	76.5	3.39
2.0	0.07	27.0	1.23	52.0	2.34	77.0	3.41
2.5	0.09	27.5	1.25	52.5	2.36	77.5	3.43
3.0	0.12	28.0	1.27	53.0	2.38	78.0	3.45
3.5	0.14	28.5	1.29	53.5	2.40	78.5	3.47
4.0	0.16	29.0	1.32	54.0	2.42	79.0	3.49
4.5	0.19	29.5	1.34	54.5	2.45	79.5	3.51
5.0	0.21	30.0	1.36	55.0	2.47	80.0	3.53
5.5	0.24	30.5	1.38	55.5	2.49	80.5	3.55
6.0	0.26	31.0	1.41	56.0	2.51	81.0	3.57
6.5	0.28	31.5	1.43	56.5	2.53	81.5	3.59
7.0	0.31	32.0	1.45	57.0	2.55	82.0	3.61
7.5	0.33	32.5	1.47	57.5	2.58	82.5	3.64
8.0	0.35	33.0	1.50	58.0	2.60	83.0	3.66
8.5	0.38	33.5	1.52	58.5	2.62	83.5	3.68
9.0	0.40	34.0	1.54	59.0	2.64	84.0	3.70
9.5	0.42	34.5	1.56	59.5	2.66	84.5	3.72
10.0	0.45	35.0	1.59	60.0	2.68	85.0	3.74
10.5	0.47	35.5	1.61	60.5	2.71	85.5	3.76
11.0	0.49	36.0	1.63	61.0	2.73	86.0	3.78
11.5	0.51	36.5	1.65	61.5	2.75	86.5	3.80
12.0	0.54	37.0	1.68	62.0	2.77	87.0	3.82
12.5	0.56	37.5	1.70	62.5	2.79	87.5	3.84
13.0	0.58	38.0	1.72	63.0	2.81	88.0	3.86
13.5	0.61	38.5	1.74	63.5	2.83	88.5	3.88
14.0	0.63	39.0	1.76	64.0	2.86	89.0	3.90
14.5	0.65	39.5	1.79	64.5	2.88	89.5	3.92
15.0	0.68	40.0	1.81	65.0	2.90	90.0	3.95
15.5	0.70	40.5	1.83	65.5	2.92	90.5	3.97
16.0	0.72	41.0	1.85	66.0	2.94	91.0	3.99
16.5	0.75	41.5	1.88	66.5	2.96	91.5	4.01
17.0	0.77	42.0	1.90	67.0	2.98	92.0	4.03
17.5	0.79	42.5	1.92	67.5	3.00	92.5	4.05
18.0	0.82	43.0	1.94	68.0	3.03	93.0	4.07
18.5	0.84	43.5	1.96	68.5	3.05	93.5	4.09
19.0	0.86	44.0	1.99	69.0	3.07	94.0	4.11
19.5	0.88	44.5	2.01	69.5	3.09	94.5	4.13
20.0	0.91	45.0	2.03	70.0	3.11	95.0	4.15
20.5	0.93	45.5	2.05	70.5	3.13	95.5	4.17
21.0	0.95	46.0	2.07	71.0	3.15	96.0	4.19
21.5	0.98	46.5	2.10	71.5	3.17	96.5	4.21
22.0	1.00	47.0	2.12	72.0	3.20	97.0	4.23
22.5	1.02	47.5	2.14	72.5	3.22	97.5	4.25
23.0	1.04	48.0	2.16	73.0	3.24	98.0	4.27
23.5	1.07	48.5	2.18	73.5	3.26	98.5	4.29
24.0	1.09	49.0	2.21	74.0	3.28	99.0	4.31
24.5	1.11	49.5	2.23	74.5	3.30	99.5	4.33
25.0	1.14	50.0	2.25	75.0	3.32	100.0	4.35

Temperature, °F

32.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 0.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.37	125.5	5.36	150.5	6.31	175.5	7.23				
101.0	4.39	126.0	5.38	151.0	6.33	176.0	7.24				
101.5	4.41	126.5	5.40	151.5	6.35	176.5	7.26				
102.0	4.43	127.0	5.42	152.0	6.37	177.0	7.28				
102.5	4.45	127.5	5.44	152.5	6.39	177.5	7.30				
103.0	4.47	128.0	5.46	153.0	6.41	178.0	7.32				
103.5	4.49	128.5	5.48	153.5	6.43	178.5	7.33				
104.0	4.51	129.0	5.50	154.0	6.44	179.0	7.35				
104.5	4.53	129.5	5.52	154.5	6.46	179.5	7.37				
105.0	4.55	130.0	5.54	155.0	6.48	180.0	7.39				
105.5	4.57	130.5	5.56	155.5	6.50	180.5	7.41				
106.0	4.59	131.0	5.58	156.0	6.52	181.0	7.42				
106.5	4.61	131.5	5.59	156.5	6.54	181.5	7.44				
107.0	4.63	132.0	5.61	157.0	6.55	182.0	7.46				
107.5	4.65	132.5	5.63	157.5	6.57	182.5	7.48				
108.0	4.67	133.0	5.65	158.0	6.59	183.0	7.49				
108.5	4.69	133.5	5.67	158.5	6.61	183.5	7.51				
109.0	4.71	134.0	5.69	159.0	6.63	184.0	7.53				
109.5	4.73	134.5	5.71	159.5	6.65	184.5	7.55				
110.0	4.75	135.0	5.73	160.0	6.67	185.0	7.56				
110.5	4.77	135.5	5.75	160.5	6.68	185.5	7.58				
111.0	4.79	136.0	5.77	161.0	6.70	186.0	7.60				
111.5	4.81	136.5	5.79	161.5	6.72	186.5	7.62				
112.0	4.83	137.0	5.81	162.0	6.74	187.0	7.63				
112.5	4.85	137.5	5.82	162.5	6.76	187.5	7.65				
113.0	4.87	138.0	5.84	163.0	6.77	188.0	7.67				
113.5	4.89	138.5	5.86	163.5	6.79	188.5	7.69				
114.0	4.91	139.0	5.88	164.0	6.81	189.0	7.70				
114.5	4.93	139.5	5.90	164.5	6.83	189.5	7.72				
115.0	4.95	140.0	5.92	165.0	6.85	190.0	7.74				
115.5	4.97	140.5	5.94	165.5	6.87	190.5	7.76				
116.0	4.99	141.0	5.96	166.0	6.88	191.0	7.77				
116.5	5.01	141.5	5.98	166.5	6.90	191.5	7.79				
117.0	5.03	142.0	6.00	167.0	6.92	192.0	7.81				
117.5	5.05	142.5	6.01	167.5	6.94	192.5	7.83				
118.0	5.07	143.0	6.03	168.0	6.96	193.0	7.84				
118.5	5.09	143.5	6.05	168.5	6.97	193.5	7.86				
119.0	5.11	144.0	6.07	169.0	6.99	194.0	7.88				
119.5	5.13	144.5	6.09	169.5	7.01	194.5	7.90				
120.0	5.15	145.0	6.11	170.0	7.03	195.0	7.91				
120.5	5.17	145.5	6.13	170.5	7.05	195.5	7.93				
121.0	5.19	146.0	6.15	171.0	7.07	196.0	7.95				
121.5	5.21	146.5	6.16	171.5	7.08	196.5	7.97				
122.0	5.23	147.0	6.18	172.0	7.10	197.0	7.98				
122.5	5.25	147.5	6.20	172.5	7.12	197.5	8.00				
123.0	5.27	148.0	6.22	173.0	7.14	198.0	8.02				
123.5	5.29	148.5	6.24	173.5	7.16	198.5	8.03				
124.0	5.30	149.0	6.26	174.0	7.17	199.0	8.05				
124.5	5.32	149.5	6.28	174.5	7.19	199.5	8.07				
125.0	5.34	150.0	6.30	175.0	7.21	200.0	8.09				

Temperature, °F

32.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				1.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.15	50.5	2.26	75.5	3.33
1.0	0.02	26.0	1.18	51.0	2.29	76.0	3.35
1.5	0.05	26.5	1.20	51.5	2.31	76.5	3.37
2.0	0.07	27.0	1.22	52.0	2.33	77.0	3.39
2.5	0.09	27.5	1.24	52.5	2.35	77.5	3.41
3.0	0.12	28.0	1.27	53.0	2.37	78.0	3.44
3.5	0.14	28.5	1.29	53.5	2.39	78.5	3.46
4.0	0.16	29.0	1.31	54.0	2.42	79.0	3.48
4.5	0.19	29.5	1.33	54.5	2.44	79.5	3.50
5.0	0.21	30.0	1.36	55.0	2.46	80.0	3.52
5.5	0.23	30.5	1.38	55.5	2.48	80.5	3.54
6.0	0.26	31.0	1.40	56.0	2.50	81.0	3.56
6.5	0.28	31.5	1.42	56.5	2.52	81.5	3.58
7.0	0.30	32.0	1.45	57.0	2.54	82.0	3.60
7.5	0.33	32.5	1.47	57.5	2.57	82.5	3.62
8.0	0.35	33.0	1.49	58.0	2.59	83.0	3.64
8.5	0.37	33.5	1.51	58.5	2.61	83.5	3.66
9.0	0.40	34.0	1.54	59.0	2.63	84.0	3.68
9.5	0.42	34.5	1.56	59.5	2.65	84.5	3.70
10.0	0.44	35.0	1.58	60.0	2.67	85.0	3.73
10.5	0.47	35.5	1.60	60.5	2.70	85.5	3.75
11.0	0.49	36.0	1.62	61.0	2.72	86.0	3.77
11.5	0.51	36.5	1.65	61.5	2.74	86.5	3.79
12.0	0.54	37.0	1.67	62.0	2.76	87.0	3.81
12.5	0.56	37.5	1.69	62.5	2.78	87.5	3.83
13.0	0.58	38.0	1.71	63.0	2.80	88.0	3.85
13.5	0.61	38.5	1.74	63.5	2.82	88.5	3.87
14.0	0.63	39.0	1.76	64.0	2.84	89.0	3.89
14.5	0.65	39.5	1.78	64.5	2.87	89.5	3.91
15.0	0.67	40.0	1.80	65.0	2.89	90.0	3.93
15.5	0.70	40.5	1.82	65.5	2.91	90.5	3.95
16.0	0.72	41.0	1.85	66.0	2.93	91.0	3.97
16.5	0.74	41.5	1.87	66.5	2.95	91.5	3.99
17.0	0.77	42.0	1.89	67.0	2.97	92.0	4.01
17.5	0.79	42.5	1.91	67.5	2.99	92.5	4.03
18.0	0.81	43.0	1.93	68.0	3.01	93.0	4.05
18.5	0.83	43.5	1.96	68.5	3.04	93.5	4.07
19.0	0.86	44.0	1.98	69.0	3.06	94.0	4.09
19.5	0.88	44.5	2.00	69.5	3.08	94.5	4.11
20.0	0.90	45.0	2.02	70.0	3.10	95.0	4.13
20.5	0.93	45.5	2.04	70.5	3.12	95.5	4.15
21.0	0.95	46.0	2.07	71.0	3.14	96.0	4.18
21.5	0.97	46.5	2.09	71.5	3.16	96.5	4.20
22.0	0.99	47.0	2.11	72.0	3.18	97.0	4.22
22.5	1.02	47.5	2.13	72.5	3.20	97.5	4.24
23.0	1.04	48.0	2.15	73.0	3.23	98.0	4.26
23.5	1.06	48.5	2.18	73.5	3.25	98.5	4.28
24.0	1.09	49.0	2.20	74.0	3.27	99.0	4.30
24.5	1.11	49.5	2.22	74.5	3.29	99.5	4.32
25.0	1.13	50.0	2.24	75.0	3.31	100.0	4.34

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				1•0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100•5	4•36	125•5	5•34	150•5	6•29	175•5	7•20
101•0	4•38	126•0	5•36	151•0	6•31	176•0	7•22
101•5	4•40	126•5	5•38	151•5	6•33	176•5	7•24
102•0	4•42	127•0	5•40	152•0	6•35	177•0	7•25
102•5	4•44	127•5	5•42	152•5	6•36	177•5	7•27
103•0	4•46	128•0	5•44	153•0	6•38	178•0	7•29
103•5	4•48	128•5	5•46	153•5	6•40	178•5	7•31
104•0	4•50	129•0	5•48	154•0	6•42	179•0	7•32
104•5	4•52	129•5	5•50	154•5	6•44	179•5	7•34
105•0	4•54	130•0	5•52	155•0	6•46	180•0	7•36
105•5	4•56	130•5	5•54	155•5	6•48	180•5	7•38
106•0	4•58	131•0	5•55	156•0	6•49	181•0	7•40
106•5	4•60	131•5	5•57	156•5	6•51	181•5	7•41
107•0	4•62	132•0	5•59	157•0	6•53	182•0	7•43
107•5	4•64	132•5	5•61	157•5	6•55	182•5	7•45
108•0	4•66	133•0	5•63	158•0	6•57	183•0	7•47
108•5	4•68	133•5	5•65	158•5	6•59	183•5	7•48
109•0	4•70	134•0	5•67	159•0	6•60	184•0	7•50
109•5	4•72	134•5	5•69	159•5	6•62	184•5	7•52
110•0	4•74	135•0	5•71	160•0	6•64	185•0	7•54
110•5	4•76	135•5	5•73	160•5	6•66	185•5	7•55
111•0	4•78	136•0	5•75	161•0	6•68	186•0	7•57
111•5	4•80	136•5	5•76	161•5	6•70	186•5	7•59
112•0	4•82	137•0	5•78	162•0	6•71	187•0	7•61
112•5	4•84	137•5	5•80	162•5	6•73	187•5	7•62
113•0	4•85	138•0	5•82	163•0	6•75	188•0	7•64
113•5	4•87	138•5	5•84	163•5	6•77	188•5	7•66
114•0	4•89	139•0	5•86	164•0	6•79	189•0	7•68
114•5	4•91	139•5	5•88	164•5	6•80	189•5	7•69
115•0	4•93	140•0	5•90	165•0	6•82	190•0	7•71
115•5	4•95	140•5	5•92	165•5	6•84	190•5	7•73
116•0	4•97	141•0	5•93	166•0	6•86	191•0	7•75
116•5	4•99	141•5	5•95	166•5	6•88	191•5	7•76
117•0	5•01	142•0	5•97	167•0	6•90	192•0	7•78
117•5	5•03	142•5	5•99	167•5	6•91	192•5	7•80
118•0	5•05	143•0	6•01	168•0	6•93	193•0	7•82
118•5	5•07	143•5	6•03	168•5	6•95	193•5	7•83
119•0	5•09	144•0	6•05	169•0	6•97	194•0	7•85
119•5	5•11	144•5	6•07	169•5	6•99	194•5	7•87
120•0	5•13	145•0	6•09	170•0	7•00	195•0	7•88
120•5	5•15	145•5	6•10	170•5	7•02	195•5	7•90
121•0	5•17	146•0	6•12	171•0	7•04	196•0	7•92
121•5	5•19	146•5	6•14	171•5	7•06	196•5	7•94
122•0	5•21	147•0	6•16	172•0	7•08	197•0	7•95
122•5	5•23	147•5	6•18	172•5	7•09	197•5	7•97
123•0	5•25	148•0	6•20	173•0	7•11	198•0	7•99
123•5	5•27	148•5	6•22	173•5	7•13	198•5	8•01
124•0	5•28	149•0	6•23	174•0	7•15	199•0	8•02
124•5	5•30	149•5	6•25	174•5	7•16	199•5	8•04
125•0	5•32	150•0	6•27	175•0	7•18	200•0	8•06

Temperature, °F

33•8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

2.0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.15	50.5	2.25	75.5	3.32
1.0	0.02	26.0	1.17	51.0	2.28	76.0	3.34
1.5	0.05	26.5	1.19	51.5	2.30	76.5	3.36
2.0	0.07	27.0	1.22	52.0	2.32	77.0	3.38
2.5	0.09	27.5	1.24	52.5	2.34	77.5	3.40
3.0	0.12	28.0	1.26	53.0	2.36	78.0	3.42
3.5	0.14	28.5	1.28	53.5	2.38	78.5	3.44
4.0	0.16	29.0	1.31	54.0	2.41	79.0	3.46
4.5	0.19	29.5	1.33	54.5	2.43	79.5	3.48
5.0	0.21	30.0	1.35	55.0	2.45	80.0	3.51
5.5	0.23	30.5	1.37	55.5	2.47	80.5	3.53
6.0	0.26	31.0	1.40	56.0	2.49	81.0	3.55
6.5	0.28	31.5	1.42	56.5	2.51	81.5	3.57
7.0	0.30	32.0	1.44	57.0	2.54	82.0	3.59
7.5	0.33	32.5	1.46	57.5	2.56	82.5	3.61
8.0	0.35	33.0	1.49	58.0	2.58	83.0	3.63
8.5	0.37	33.5	1.51	58.5	2.60	83.5	3.65
9.0	0.40	34.0	1.53	59.0	2.62	84.0	3.67
9.5	0.42	34.5	1.55	59.5	2.64	84.5	3.69
10.0	0.44	35.0	1.57	60.0	2.66	85.0	3.71
10.5	0.46	35.5	1.60	60.5	2.69	85.5	3.73
11.0	0.49	36.0	1.62	61.0	2.71	86.0	3.75
11.5	0.51	36.5	1.64	61.5	2.73	86.5	3.77
12.0	0.53	37.0	1.66	62.0	2.75	87.0	3.79
12.5	0.56	37.5	1.69	62.5	2.77	87.5	3.81
13.0	0.58	38.0	1.71	63.0	2.79	88.0	3.83
13.5	0.60	38.5	1.73	63.5	2.81	88.5	3.85
14.0	0.63	39.0	1.75	64.0	2.83	89.0	3.88
14.5	0.65	39.5	1.77	64.5	2.86	89.5	3.90
15.0	0.67	40.0	1.80	65.0	2.88	90.0	3.92
15.5	0.69	40.5	1.82	65.5	2.90	90.5	3.94
16.0	0.72	41.0	1.84	66.0	2.92	91.0	3.96
16.5	0.74	41.5	1.86	66.5	2.94	91.5	3.98
17.0	0.76	42.0	1.88	67.0	2.96	92.0	4.00
17.5	0.79	42.5	1.91	67.5	2.98	92.5	4.02
18.0	0.81	43.0	1.93	68.0	3.00	93.0	4.04
18.5	0.83	43.5	1.95	68.5	3.02	93.5	4.06
19.0	0.85	44.0	1.97	69.0	3.05	94.0	4.08
19.5	0.88	44.5	1.99	69.5	3.07	94.5	4.10
20.0	0.90	45.0	2.02	70.0	3.09	95.0	4.12
20.5	0.92	45.5	2.04	70.5	3.11	95.5	4.14
21.0	0.95	46.0	2.06	71.0	3.13	96.0	4.16
21.5	0.97	46.5	2.08	71.5	3.15	96.5	4.18
22.0	0.99	47.0	2.10	72.0	3.17	97.0	4.20
22.5	1.01	47.5	2.12	72.5	3.19	97.5	4.22
23.0	1.04	48.0	2.15	73.0	3.21	98.0	4.24
23.5	1.06	48.5	2.17	73.5	3.23	98.5	4.26
24.0	1.08	49.0	2.19	74.0	3.26	99.0	4.28
24.5	1.10	49.5	2.21	74.5	3.28	99.5	4.30
25.0	1.13	50.0	2.23	75.0	3.30	100.0	4.32

Temperature, °F

35.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

2•0

		Temperature, °C						
atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•34	125•5	5•32	150•5	6•27	175•5	7•17	
101•0	4•36	126•0	5•34	151•0	6•29	176•0	7•19	
101•5	4•38	126•5	5•36	151•5	6•30	176•5	7•21	
102•0	4•40	127•0	5•38	152•0	6•32	177•0	7•23	
102•5	4•42	127•5	5•40	152•5	6•34	177•5	7•25	
103•0	4•44	128•0	5•42	153•0	6•36	178•0	7•26	
103•5	4•46	128•5	5•44	153•5	6•38	178•5	7•28	
104•0	4•48	129•0	5•46	154•0	6•40	179•0	7•30	
104•5	4•50	129•5	5•48	154•5	6•41	179•5	7•32	
105•0	4•52	130•0	5•50	155•0	6•43	180•0	7•33	
105•5	4•54	130•5	5•51	155•5	6•45	180•5	7•35	
106•0	4•56	131•0	5•53	156•0	6•47	181•0	7•37	
106•5	4•58	131•5	5•55	156•5	6•49	181•5	7•39	
107•0	4•60	132•0	5•57	157•0	6•51	182•0	7•40	
107•5	4•62	132•5	5•59	157•5	6•52	182•5	7•42	
108•0	4•64	133•0	5•61	158•0	6•54	183•0	7•44	
108•5	4•66	133•5	5•63	158•5	6•56	183•5	7•46	
109•0	4•68	134•0	5•65	159•0	6•58	184•0	7•47	
109•5	4•70	134•5	5•67	159•5	6•60	184•5	7•49	
110•0	4•72	135•0	5•69	160•0	6•62	185•0	7•51	
110•5	4•74	135•5	5•71	160•5	6•63	185•5	7•53	
111•0	4•76	136•0	5•72	161•0	6•65	186•0	7•54	
111•5	4•78	136•5	5•74	161•5	6•67	186•5	7•56	
112•0	4•80	137•0	5•76	162•0	6•69	187•0	7•58	
112•5	4•82	137•5	5•78	162•5	6•71	187•5	7•60	
113•0	4•84	138•0	5•80	163•0	6•73	188•0	7•61	
113•5	4•86	138•5	5•82	163•5	6•74	188•5	7•63	
114•0	4•88	139•0	5•84	164•0	6•76	189•0	7•65	
114•5	4•90	139•5	5•86	164•5	6•78	189•5	7•67	
115•0	4•92	140•0	5•88	165•0	6•80	190•0	7•68	
115•5	4•93	140•5	5•89	165•5	6•82	190•5	7•70	
116•0	4•95	141•0	5•91	166•0	6•83	191•0	7•72	
116•5	4•97	141•5	5•93	166•5	6•85	191•5	7•74	
117•0	4•99	142•0	5•95	167•0	6•87	192•0	7•75	
117•5	5•01	142•5	5•97	167•5	6•89	192•5	7•77	
118•0	5•03	143•0	5•99	168•0	6•91	193•0	7•79	
118•5	5•05	143•5	6•01	168•5	6•92	193•5	7•80	
119•0	5•07	144•0	6•03	169•0	6•94	194•0	7•82	
119•5	5•09	144•5	6•04	169•5	6•96	194•5	7•84	
120•0	5•11	145•0	6•06	170•0	6•98	195•0	7•86	
120•5	5•13	145•5	6•08	170•5	7•00	195•5	7•87	
121•0	5•15	146•0	6•10	171•0	7•01	196•0	7•89	
121•5	5•17	146•5	6•12	171•5	7•03	196•5	7•91	
122•0	5•19	147•0	6•14	172•0	7•05	197•0	7•93	
122•5	5•21	147•5	6•16	172•5	7•07	197•5	7•94	
123•0	5•23	148•0	6•17	173•0	7•08	198•0	7•96	
123•5	5•25	148•5	6•19	173•5	7•10	198•5	7•98	
124•0	5•27	149•0	6•21	174•0	7•12	199•0	7•99	
124•5	5•28	149•5	6•23	174•5	7•14	199•5	8•01	
125•0	5•30	150•0	6•25	175•0	7•16	200•0	8•03	

Temperature, °F

35•6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		3.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.14	50.5	2.25	75.5	3.31
1.0	0.02	26.0	1.17	51.0	2.27	76.0	3.33
1.5	0.05	26.5	1.19	51.5	2.29	76.5	3.35
2.0	0.07	27.0	1.21	52.0	2.31	77.0	3.37
2.5	0.09	27.5	1.23	52.5	2.33	77.5	3.39
3.0	0.12	28.0	1.26	53.0	2.35	78.0	3.41
3.5	0.14	28.5	1.28	53.5	2.38	78.5	3.43
4.0	0.16	29.0	1.30	54.0	2.40	79.0	3.45
4.5	0.19	29.5	1.32	54.5	2.42	79.5	3.47
5.0	0.21	30.0	1.35	55.0	2.44	80.0	3.49
5.5	0.23	30.5	1.37	55.5	2.46	80.5	3.51
6.0	0.26	31.0	1.39	56.0	2.48	81.0	3.53
6.5	0.28	31.5	1.41	56.5	2.50	81.5	3.55
7.0	0.30	32.0	1.44	57.0	2.53	82.0	3.57
7.5	0.32	32.5	1.46	57.5	2.55	82.5	3.60
8.0	0.35	33.0	1.48	58.0	2.57	83.0	3.62
8.5	0.37	33.5	1.50	58.5	2.59	83.5	3.64
9.0	0.39	34.0	1.52	59.0	2.61	84.0	3.66
9.5	0.42	34.5	1.55	59.5	2.63	84.5	3.68
10.0	0.44	35.0	1.57	60.0	2.65	85.0	3.70
10.5	0.46	35.5	1.59	60.5	2.68	85.5	3.72
11.0	0.49	36.0	1.61	61.0	2.70	86.0	3.74
11.5	0.51	36.5	1.63	61.5	2.72	86.5	3.76
12.0	0.53	37.0	1.66	62.0	2.74	87.0	3.78
12.5	0.56	37.5	1.68	62.5	2.76	87.5	3.80
13.0	0.58	38.0	1.70	63.0	2.78	88.0	3.82
13.5	0.60	38.5	1.72	63.5	2.80	88.5	3.84
14.0	0.62	39.0	1.74	64.0	2.82	89.0	3.86
14.5	0.65	39.5	1.77	64.5	2.84	89.5	3.88
15.0	0.67	40.0	1.79	65.0	2.87	90.0	3.90
15.5	0.69	40.5	1.81	65.5	2.89	90.5	3.92
16.0	0.71	41.0	1.83	66.0	2.91	91.0	3.94
16.5	0.74	41.5	1.85	66.5	2.93	91.5	3.96
17.0	0.76	42.0	1.88	67.0	2.95	92.0	3.98
17.5	0.78	42.5	1.90	67.5	2.97	92.5	4.00
18.0	0.81	43.0	1.92	68.0	2.99	93.0	4.02
18.5	0.83	43.5	1.94	68.5	3.01	93.5	4.04
19.0	0.85	44.0	1.96	69.0	3.03	94.0	4.06
19.5	0.87	44.5	1.99	69.5	3.06	94.5	4.08
20.0	0.90	45.0	2.01	70.0	3.08	95.0	4.10
20.5	0.92	45.5	2.03	70.5	3.10	95.5	4.12
21.0	0.94	46.0	2.05	71.0	3.12	96.0	4.14
21.5	0.96	46.5	2.07	71.5	3.14	96.5	4.16
22.0	0.99	47.0	2.09	72.0	3.16	97.0	4.18
22.5	1.01	47.5	2.12	72.5	3.18	97.5	4.20
23.0	1.03	48.0	2.14	73.0	3.20	98.0	4.22
23.5	1.05	48.5	2.16	73.5	3.22	98.5	4.24
24.0	1.08	49.0	2.18	74.0	3.24	99.0	4.26
24.5	1.10	49.5	2.20	74.5	3.26	99.5	4.28
25.0	1.12	50.0	2.22	75.0	3.28	100.0	4.30

Temperature, °F

37.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				3•0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•32	125•5	5•30	150•5	6•24	175•5	7•15				
101•0	4•34	126•0	5•32	151•0	6•26	176•0	7•17				
101•5	4•36	126•5	5•34	151•5	6•28	176•5	7•18				
102•0	4•38	127•0	5•36	152•0	6•30	177•0	7•20				
102•5	4•40	127•5	5•38	152•5	6•32	177•5	7•22				
103•0	4•42	128•0	5•40	153•0	6•34	178•0	7•24				
103•5	4•44	128•5	5•42	153•5	6•35	178•5	7•25				
104•0	4•46	129•0	5•44	154•0	6•37	179•0	7•27				
104•5	4•48	129•5	5•46	154•5	6•39	179•5	7•29				
105•0	4•50	130•0	5•48	155•0	6•41	180•0	7•31				
105•5	4•52	130•5	5•49	155•5	6•43	180•5	7•32				
106•0	4•54	131•0	5•51	156•0	6•45	181•0	7•34				
106•5	4•56	131•5	5•53	156•5	6•46	181•5	7•36				
107•0	4•58	132•0	5•55	157•0	6•48	182•0	7•38				
107•5	4•60	132•5	5•57	157•5	6•50	182•5	7•39				
108•0	4•62	133•0	5•59	158•0	6•52	183•0	7•41				
108•5	4•64	133•5	5•61	158•5	6•54	183•5	7•43				
109•0	4•66	134•0	5•63	159•0	6•56	184•0	7•45				
109•5	4•68	134•5	5•65	159•5	6•57	184•5	7•46				
110•0	4•70	135•0	5•67	160•0	6•59	185•0	7•48				
110•5	4•72	135•5	5•68	160•5	6•61	185•5	7•50				
111•0	4•74	136•0	5•70	161•0	6•63	186•0	7•52				
111•5	4•76	136•5	5•72	161•5	6•65	186•5	7•53				
112•0	4•78	137•0	5•74	162•0	6•66	187•0	7•55				
112•5	4•80	137•5	5•76	162•5	6•68	187•5	7•57				
113•0	4•82	138•0	5•78	163•0	6•70	188•0	7•59				
113•5	4•84	138•5	5•80	163•5	6•72	188•5	7•60				
114•0	4•86	139•0	5•82	164•0	6•74	189•0	7•62				
114•5	4•88	139•5	5•83	164•5	6•75	189•5	7•64				
115•0	4•90	140•0	5•85	165•0	6•77	190•0	7•66				
115•5	4•92	140•5	5•87	165•5	6•79	190•5	7•67				
116•0	4•94	141•0	5•89	166•0	6•81	191•0	7•69				
116•5	4•96	141•5	5•91	166•5	6•83	191•5	7•71				
117•0	4•97	142•0	5•93	167•0	6•84	192•0	7•72				
117•5	4•99	142•5	5•95	167•5	6•86	192•5	7•74				
118•0	5•01	143•0	5•97	168•0	6•88	193•0	7•76				
118•5	5•03	143•5	5•98	168•5	6•90	193•5	7•78				
119•0	5•05	144•0	6•00	169•0	6•92	194•0	7•79				
119•5	5•07	144•5	6•02	169•5	6•93	194•5	7•81				
120•0	5•09	145•0	6•04	170•0	6•95	195•0	7•83				
120•5	5•11	145•5	6•06	170•5	6•97	195•5	7•84				
121•0	5•13	146•0	6•08	171•0	6•99	196•0	7•86				
121•5	5•15	146•5	6•10	171•5	7•01	196•5	7•88				
122•0	5•17	147•0	6•11	172•0	7•02	197•0	7•90				
122•5	5•19	147•5	6•13	172•5	7•04	197•5	7•91				
123•0	5•21	148•0	6•15	173•0	7•06	198•0	7•93				
123•5	5•23	148•5	6•17	173•5	7•08	198•5	7•95				
124•0	5•25	149•0	6•19	174•0	7•09	199•0	7•96				
124•5	5•26	149•5	6•21	174•5	7•11	199•5	7•98				
125•0	5•28	150•0	6•23	175•0	7•13	200•0	8•00				

4•0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.14	50.5	2.24	75.5	3.29
1.0	0.02	26.0	1.16	51.0	2.26	76.0	3.31
1.5	0.05	26.5	1.19	51.5	2.28	76.5	3.33
2.0	0.07	27.0	1.21	52.0	2.30	77.0	3.36
2.5	0.09	27.5	1.23	52.5	2.32	77.5	3.38
3.0	0.12	28.0	1.25	53.0	2.35	78.0	3.40
3.5	0.14	28.5	1.27	53.5	2.37	78.5	3.42
4.0	0.16	29.0	1.30	54.0	2.39	79.0	3.44
4.5	0.19	29.5	1.32	54.5	2.41	79.5	3.46
5.0	0.21	30.0	1.34	55.0	2.43	80.0	3.48
5.5	0.23	30.5	1.36	55.5	2.45	80.5	3.50
6.0	0.25	31.0	1.39	56.0	2.47	81.0	3.52
6.5	0.28	31.5	1.41	56.5	2.50	81.5	3.54
7.0	0.30	32.0	1.43	57.0	2.52	82.0	3.56
7.5	0.32	32.5	1.45	57.5	2.54	82.5	3.58
8.0	0.35	33.0	1.47	58.0	2.56	83.0	3.60
8.5	0.37	33.5	1.50	58.5	2.58	83.5	3.62
9.0	0.39	34.0	1.52	59.0	2.60	84.0	3.64
9.5	0.42	34.5	1.54	59.5	2.62	84.5	3.66
10.0	0.44	35.0	1.56	60.0	2.64	85.0	3.68
10.5	0.46	35.5	1.58	60.5	2.67	85.5	3.70
11.0	0.48	36.0	1.61	61.0	2.69	86.0	3.72
11.5	0.51	36.5	1.63	61.5	2.71	86.5	3.74
12.0	0.53	37.0	1.65	62.0	2.73	87.0	3.77
12.5	0.55	37.5	1.67	62.5	2.75	87.5	3.79
13.0	0.58	38.0	1.69	63.0	2.77	88.0	3.81
13.5	0.60	38.5	1.72	63.5	2.79	88.5	3.83
14.0	0.62	39.0	1.74	64.0	2.81	89.0	3.85
14.5	0.64	39.5	1.76	64.5	2.83	89.5	3.87
15.0	0.67	40.0	1.78	65.0	2.86	90.0	3.89
15.5	0.69	40.5	1.80	65.5	2.88	90.5	3.91
16.0	0.71	41.0	1.83	66.0	2.90	91.0	3.93
16.5	0.73	41.5	1.85	66.5	2.92	91.5	3.95
17.0	0.76	42.0	1.87	67.0	2.94	92.0	3.97
17.5	0.78	42.5	1.89	67.5	2.96	92.5	3.99
18.0	0.80	43.0	1.91	68.0	2.98	93.0	4.01
18.5	0.83	43.5	1.93	68.5	3.00	93.5	4.03
19.0	0.85	44.0	1.96	69.0	3.02	94.0	4.05
19.5	0.87	44.5	1.98	69.5	3.04	94.5	4.07
20.0	0.89	45.0	2.00	70.0	3.06	95.0	4.09
20.5	0.92	45.5	2.02	70.5	3.09	95.5	4.11
21.0	0.94	46.0	2.04	71.0	3.11	96.0	4.13
21.5	0.96	46.5	2.07	71.5	3.13	96.5	4.15
22.0	0.98	47.0	2.09	72.0	3.15	97.0	4.17
22.5	1.01	47.5	2.11	72.5	3.17	97.5	4.19
23.0	1.03	48.0	2.13	73.0	3.19	98.0	4.21
23.5	1.05	48.5	2.15	73.5	3.21	98.5	4.23
24.0	1.07	49.0	2.17	74.0	3.23	99.0	4.25
24.5	1.10	49.5	2.19	74.5	3.25	99.5	4.27
25.0	1.12	50.0	2.22	75.0	3.27	100.0	4.29

Temperature, °F

39•2

4•0

Temperature, °C

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•31	125•5	5•28	150•5	6•22	175•5	7•12				
101•0	4•33	126•0	5•30	151•0	6•24	176•0	7•14				
101•5	4•35	126•5	5•32	151•5	6•26	176•5	7•16				
102•0	4•37	127•0	5•34	152•0	6•28	177•0	7•17				
102•5	4•39	127•5	5•36	152•5	6•29	177•5	7•19				
103•0	4•41	128•0	5•38	153•0	6•31	178•0	7•21				
103•5	4•43	128•5	5•40	153•5	6•33	178•5	7•23				
104•0	4•45	129•0	5•42	154•0	6•35	179•0	7•24				
104•5	4•47	129•5	5•44	154•5	6•37	179•5	7•26				
105•0	4•49	130•0	5•46	155•0	6•39	180•0	7•28				
105•5	4•51	130•5	5•47	155•5	6•40	180•5	7•30				
106•0	4•53	131•0	5•49	156•0	6•42	181•0	7•32				
106•5	4•55	131•5	5•51	156•5	6•44	181•5	7•33				
107•0	4•57	132•0	5•53	157•0	6•46	182•0	7•35				
107•5	4•59	132•5	5•55	157•5	6•48	182•5	7•37				
108•0	4•60	133•0	5•57	158•0	6•50	183•0	7•38				
108•5	4•62	133•5	5•59	158•5	6•51	183•5	7•40				
109•0	4•64	134•0	5•61	159•0	6•53	184•0	7•42				
109•5	4•66	134•5	5•63	159•5	6•55	184•5	7•44				
110•0	4•68	135•0	5•64	160•0	6•57	185•0	7•45				
110•5	4•70	135•5	5•66	160•5	6•59	185•5	7•47				
111•0	4•72	136•0	5•68	161•0	6•60	186•0	7•49				
111•5	4•74	136•5	5•70	161•5	6•62	186•5	7•51				
112•0	4•76	137•0	5•72	162•0	6•64	187•0	7•52				
112•5	4•78	137•5	5•74	162•5	6•66	187•5	7•54				
113•0	4•80	138•0	5•76	163•0	6•68	188•0	7•56				
113•5	4•82	138•5	5•78	163•5	6•69	188•5	7•58				
114•0	4•84	139•0	5•79	164•0	6•71	189•0	7•59				
114•5	4•86	139•5	5•81	164•5	6•73	189•5	7•61				
115•0	4•88	140•0	5•83	165•0	6•75	190•0	7•63				
115•5	4•90	140•5	5•85	165•5	6•77	190•5	7•64				
116•0	4•92	141•0	5•87	166•0	6•78	191•0	7•66				
116•5	4•94	141•5	5•89	166•5	6•80	191•5	7•68				
117•0	4•96	142•0	5•91	167•0	6•82	192•0	7•70				
117•5	4•98	142•5	5•93	167•5	6•84	192•5	7•71				
118•0	5•00	143•0	5•94	168•0	6•86	193•0	7•73				
118•5	5•01	143•5	5•96	168•5	6•87	193•5	7•75				
119•0	5•03	144•0	5•98	169•0	6•89	194•0	7•77				
119•5	5•05	144•5	6•00	169•5	6•91	194•5	7•78				
120•0	5•07	145•0	6•02	170•0	6•93	195•0	7•80				
120•5	5•09	145•5	6•04	170•5	6•94	195•5	7•82				
121•0	5•11	146•0	6•06	171•0	6•96	196•0	7•83				
121•5	5•13	146•5	6•07	171•5	6•98	196•5	7•85				
122•0	5•15	147•0	6•09	172•0	7•00	197•0	7•87				
122•5	5•17	147•5	6•11	172•5	7•02	197•5	7•88				
123•0	5•19	148•0	6•13	173•0	7•03	198•0	7•90				
123•5	5•21	148•5	6•15	173•5	7•05	198•5	7•92				
124•0	5•23	149•0	6•17	174•0	7•07	199•0	7•94				
124•5	5•25	149•5	6•18	174•5	7•09	199•5	7•95				
125•0	5•26	150•0	6•20	175•0	7•10	200•0	7•97				

Temperature, °F

39•2

5•0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•14	50•5	2•23	75•5	3•28
1•0	0•02	26•0	1•16	51•0	2•25	76•0	3•30
1•5	0•05	26•5	1•18	51•5	2•27	76•5	3•32
2•0	0•07	27•0	1•20	52•0	2•29	77•0	3•34
2•5	0•09	27•5	1•23	52•5	2•32	77•5	3•36
3•0	0•12	28•0	1•25	53•0	2•34	78•0	3•38
3•5	0•14	28•5	1•27	53•5	2•36	78•5	3•40
4•0	0•16	29•0	1•29	54•0	2•38	79•0	3•43
4•5	0•18	29•5	1•31	54•5	2•40	79•5	3•45
5•0	0•21	30•0	1•34	55•0	2•42	80•0	3•47
5•5	0•23	30•5	1•36	55•5	2•44	80•5	3•49
6•0	0•25	31•0	1•38	56•0	2•46	81•0	3•51
6•5	0•28	31•5	1•40	56•5	2•49	81•5	3•53
7•0	0•30	32•0	1•42	57•0	2•51	82•0	3•55
7•5	0•32	32•5	1•45	57•5	2•53	82•5	3•57
8•0	0•35	33•0	1•47	58•0	2•55	83•0	3•59
8•5	0•37	33•5	1•49	58•5	2•57	83•5	3•61
9•0	0•39	34•0	1•51	59•0	2•59	84•0	3•63
9•5	0•41	34•5	1•53	59•5	2•61	84•5	3•65
10•0	0•44	35•0	1•56	60•0	2•63	85•0	3•67
10•5	0•46	35•5	1•58	60•5	2•66	85•5	3•69
11•0	0•48	36•0	1•60	61•0	2•68	86•0	3•71
11•5	0•51	36•5	1•62	61•5	2•70	86•5	3•73
12•0	0•53	37•0	1•64	62•0	2•72	87•0	3•75
12•5	0•55	37•5	1•67	62•5	2•74	87•5	3•77
13•0	0•57	38•0	1•69	63•0	2•76	88•0	3•79
13•5	0•60	38•5	1•71	63•5	2•78	88•5	3•81
14•0	0•62	39•0	1•73	64•0	2•80	89•0	3•83
14•5	0•64	39•5	1•75	64•5	2•82	89•5	3•85
15•0	0•66	40•0	1•78	65•0	2•84	90•0	3•87
15•5	0•69	40•5	1•80	65•5	2•87	90•5	3•89
16•0	0•71	41•0	1•82	66•0	2•89	91•0	3•91
16•5	0•73	41•5	1•84	66•5	2•91	91•5	3•93
17•0	0•75	42•0	1•86	67•0	2•93	92•0	3•95
17•5	0•78	42•5	1•88	67•5	2•95	92•5	3•97
18•0	0•80	43•0	1•91	68•0	2•97	93•0	3•99
18•5	0•82	43•5	1•93	68•5	2•99	93•5	4•01
19•0	0•85	44•0	1•95	69•0	3•01	94•0	4•03
19•5	0•87	44•5	1•97	69•5	3•03	94•5	4•05
20•0	0•89	45•0	1•99	70•0	3•05	95•0	4•07
20•5	0•91	45•5	2•01	70•5	3•07	95•5	4•09
21•0	0•93	46•0	2•04	71•0	3•09	96•0	4•11
21•5	0•96	46•5	2•06	71•5	3•12	96•5	4•13
22•0	0•98	47•0	2•08	72•0	3•14	97•0	4•15
22•5	1•00	47•5	2•10	72•5	3•16	97•5	4•17
23•0	1•02	48•0	2•12	73•0	3•18	98•0	4•19
23•5	1•05	48•5	2•14	73•5	3•20	98•5	4•21
24•0	1•07	49•0	2•17	74•0	3•22	99•0	4•23
24•5	1•09	49•5	2•19	74•5	3•24	99•5	4•25
25•0	1•11	50•0	2•21	75•0	3•26	100•0	4•27

Temperature, °F

41•0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								5•0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•29	125•5	5•26	150•5	6•20	175•5	7•10				
101•0	4•31	126•0	5•28	151•0	6•22	176•0	7•11				
101•5	4•33	126•5	5•30	151•5	6•23	176•5	7•13				
102•0	4•35	127•0	5•32	152•0	6•25	177•0	7•15				
102•5	4•37	127•5	5•34	152•5	6•27	177•5	7•17				
103•0	4•39	128•0	5•36	153•0	6•29	178•0	7•18				
103•5	4•41	128•5	5•38	153•5	6•31	178•5	7•20				
104•0	4•43	129•0	5•40	154•0	6•33	179•0	7•22				
104•5	4•45	129•5	5•42	154•5	6•34	179•5	7•24				
105•0	4•47	130•0	5•44	155•0	6•36	180•0	7•25				
105•5	4•49	130•5	5•45	155•5	6•38	180•5	7•27				
106•0	4•51	131•0	5•47	156•0	6•40	181•0	7•29				
106•5	4•53	131•5	5•49	156•5	6•42	181•5	7•31				
107•0	4•55	132•0	5•51	157•0	6•44	182•0	7•32				
107•5	4•57	132•5	5•53	157•5	6•45	182•5	7•34				
108•0	4•59	133•0	5•55	158•0	6•47	183•0	7•36				
108•5	4•61	133•5	5•57	158•5	6•49	183•5	7•38				
109•0	4•63	134•0	5•59	159•0	6•51	184•0	7•39				
109•5	4•65	134•5	5•60	159•5	6•53	184•5	7•41				
110•0	4•67	135•0	5•62	160•0	6•54	185•0	7•43				
110•5	4•69	135•5	5•64	160•5	6•56	185•5	7•44				
111•0	4•71	136•0	5•66	161•0	6•58	186•0	7•46				
111•5	4•72	136•5	5•68	161•5	6•60	186•5	7•48				
112•0	4•74	137•0	5•70	162•0	6•62	187•0	7•50				
112•5	4•76	137•5	5•72	162•5	6•63	187•5	7•51				
113•0	4•78	138•0	5•74	163•0	6•65	188•0	7•53				
113•5	4•80	138•5	5•75	163•5	6•67	188•5	7•55				
114•0	4•82	139•0	5•77	164•0	6•69	189•0	7•57				
114•5	4•84	139•5	5•79	164•5	6•71	189•5	7•58				
115•0	4•86	140•0	5•81	165•0	6•72	190•0	7•60				
115•5	4•88	140•5	5•83	165•5	6•74	190•5	7•62				
116•0	4•90	141•0	5•85	166•0	6•76	191•0	7•63				
116•5	4•92	141•5	5•87	166•5	6•78	191•5	7•65				
117•0	4•94	142•0	5•88	167•0	6•79	192•0	7•67				
117•5	4•96	142•5	5•90	167•5	6•81	192•5	7•69				
118•0	4•98	143•0	5•92	168•0	6•83	193•0	7•70				
118•5	5•00	143•5	5•94	168•5	6•85	193•5	7•72				
119•0	5•02	144•0	5•96	169•0	6•87	194•0	7•74				
119•5	5•03	144•5	5•98	169•5	6•88	194•5	7•75				
120•0	5•05	145•0	6•00	170•0	6•90	195•0	7•77				
120•5	5•07	145•5	6•01	170•5	6•92	195•5	7•79				
121•0	5•09	146•0	6•03	171•0	6•94	196•0	7•81				
121•5	5•11	146•5	6•05	171•5	6•95	196•5	7•82				
122•0	5•13	147•0	6•07	172•0	6•97	197•0	7•84				
122•5	5•15	147•5	6•09	172•5	6•99	197•5	7•86				
123•0	5•17	148•0	6•11	173•0	7•01	198•0	7•87				
123•5	5•19	148•5	6•12	173•5	7•03	198•5	7•89				
124•0	5•21	149•0	6•14	174•0	7•04	199•0	7•91				
124•5	5•23	149•5	6•16	174•5	7•06	199•5	7•92				
125•0	5•25	150•0	6•18	175•0	7•08	200•0	7•94				

Temperature, °F

41•0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				6.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
0.5	0.00	25.5	1.13	50.5	2.22	75.5	3.27				
1.0	0.02	26.0	1.15	51.0	2.24	76.0	3.29				
1.5	0.05	26.5	1.18	51.5	2.26	76.5	3.31				
2.0	0.07	27.0	1.20	52.0	2.29	77.0	3.33				
2.5	0.09	27.5	1.22	52.5	2.31	77.5	3.35				
3.0	0.12	28.0	1.24	53.0	2.33	78.0	3.37				
3.5	0.14	28.5	1.26	53.5	2.35	78.5	3.39				
4.0	0.16	29.0	1.29	54.0	2.37	79.0	3.41				
4.5	0.18	29.5	1.31	54.5	2.39	79.5	3.43				
5.0	0.21	30.0	1.33	55.0	2.41	80.0	3.45				
5.5	0.23	30.5	1.35	55.5	2.43	80.5	3.47				
6.0	0.25	31.0	1.38	56.0	2.46	81.0	3.49				
6.5	0.28	31.5	1.40	56.5	2.48	81.5	3.51				
7.0	0.30	32.0	1.42	57.0	2.50	82.0	3.53				
7.5	0.32	32.5	1.44	57.5	2.52	82.5	3.55				
8.0	0.34	33.0	1.46	58.0	2.54	83.0	3.58				
8.5	0.37	33.5	1.49	58.5	2.56	83.5	3.60				
9.0	0.39	34.0	1.51	59.0	2.58	84.0	3.62				
9.5	0.41	34.5	1.53	59.5	2.60	84.5	3.64				
10.0	0.44	35.0	1.55	60.0	2.62	85.0	3.66				
10.5	0.46	35.5	1.57	60.5	2.65	85.5	3.68				
11.0	0.48	36.0	1.59	61.0	2.67	86.0	3.70				
11.5	0.50	36.5	1.62	61.5	2.69	86.5	3.72				
12.0	0.53	37.0	1.64	62.0	2.71	87.0	3.74				
12.5	0.55	37.5	1.66	62.5	2.73	87.5	3.76				
13.0	0.57	38.0	1.68	63.0	2.75	88.0	3.78				
13.5	0.59	38.5	1.70	63.5	2.77	88.5	3.80				
14.0	0.62	39.0	1.73	64.0	2.79	89.0	3.82				
14.5	0.64	39.5	1.75	64.5	2.81	89.5	3.84				
15.0	0.66	40.0	1.77	65.0	2.83	90.0	3.86				
15.5	0.68	40.5	1.79	65.5	2.85	90.5	3.88				
16.0	0.71	41.0	1.81	66.0	2.88	91.0	3.90				
16.5	0.73	41.5	1.83	66.5	2.90	91.5	3.92				
17.0	0.75	42.0	1.86	67.0	2.92	92.0	3.94				
17.5	0.77	42.5	1.88	67.5	2.94	92.5	3.96				
18.0	0.80	43.0	1.90	68.0	2.96	93.0	3.98				
18.5	0.82	43.5	1.92	68.5	2.98	93.5	4.00				
19.0	0.84	44.0	1.94	69.0	3.00	94.0	4.02				
19.5	0.86	44.5	1.96	69.5	3.02	94.5	4.04				
20.0	0.89	45.0	1.99	70.0	3.04	95.0	4.06				
20.5	0.91	45.5	2.01	70.5	3.06	95.5	4.08				
21.0	0.93	46.0	2.03	71.0	3.08	96.0	4.10				
21.5	0.95	46.5	2.05	71.5	3.10	96.5	4.12				
22.0	0.98	47.0	2.07	72.0	3.12	97.0	4.14				
22.5	1.00	47.5	2.09	72.5	3.15	97.5	4.16				
23.0	1.02	48.0	2.11	73.0	3.17	98.0	4.18				
23.5	1.04	48.5	2.14	73.5	3.19	98.5	4.20				
24.0	1.07	49.0	2.16	74.0	3.21	99.0	4.22				
24.5	1.09	49.5	2.18	74.5	3.23	99.5	4.24				
25.0	1.11	50.0	2.20	75.0	3.25	100.0	4.26				

Temperature, °F

42.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C
6•0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•28	125•5	5•24	150•5	6•18	175•5	7•07				
101•0	4•30	126•0	5•26	151•0	6•19	176•0	7•09				
101•5	4•32	126•5	5•28	151•5	6•21	176•5	7•10				
102•0	4•34	127•0	5•30	152•0	6•23	177•0	7•12				
102•5	4•36	127•5	5•32	152•5	6•25	177•5	7•14				
103•0	4•37	128•0	5•34	153•0	6•27	178•0	7•16				
103•5	4•39	128•5	5•36	153•5	6•28	178•5	7•17				
104•0	4•41	129•0	5•38	154•0	6•30	179•0	7•19				
104•5	4•43	129•5	5•40	154•5	6•32	179•5	7•21				
105•0	4•45	130•0	5•42	155•0	6•34	180•0	7•23				
105•5	4•47	130•5	5•43	155•5	6•36	180•5	7•24				
106•0	4•49	131•0	5•45	156•0	6•38	181•0	7•26				
106•5	4•51	131•5	5•47	156•5	6•39	181•5	7•28				
107•0	4•53	132•0	5•49	157•0	6•41	182•0	7•30				
107•5	4•55	132•5	5•51	157•5	6•43	182•5	7•31				
108•0	4•57	133•0	5•53	158•0	6•45	183•0	7•33				
108•5	4•59	133•5	5•55	158•5	6•47	183•5	7•35				
109•0	4•61	134•0	5•57	159•0	6•48	184•0	7•37				
109•5	4•63	134•5	5•58	159•5	6•50	184•5	7•38				
110•0	4•65	135•0	5•60	160•0	6•52	185•0	7•40				
110•5	4•67	135•5	5•62	160•5	6•54	185•5	7•42				
111•0	4•69	136•0	5•64	161•0	6•56	186•0	7•43				
111•5	4•71	136•5	5•66	161•5	6•57	186•5	7•45				
112•0	4•73	137•0	5•68	162•0	6•59	187•0	7•47				
112•5	4•75	137•5	5•70	162•5	6•61	187•5	7•49				
113•0	4•77	138•0	5•71	163•0	6•63	188•0	7•50				
113•5	4•78	138•5	5•73	163•5	6•65	188•5	7•52				
114•0	4•80	139•0	5•75	164•0	6•66	189•0	7•54				
114•5	4•82	139•5	5•77	164•5	6•68	189•5	7•56				
115•0	4•84	140•0	5•79	165•0	6•70	190•0	7•57				
115•5	4•86	140•5	5•81	165•5	6•72	190•5	7•59				
116•0	4•88	141•0	5•83	166•0	6•73	191•0	7•61				
116•5	4•90	141•5	5•84	166•5	6•75	191•5	7•62				
117•0	4•92	142•0	5•86	167•0	6•77	192•0	7•64				
117•5	4•94	142•5	5•88	167•5	6•79	192•5	7•66				
118•0	4•96	143•0	5•90	168•0	6•81	193•0	7•67				
118•5	4•98	143•5	5•92	168•5	6•82	193•5	7•69				
119•0	5•00	144•0	5•94	169•0	6•84	194•0	7•71				
119•5	5•02	144•5	5•96	169•5	6•86	194•5	7•73				
120•0	5•04	145•0	5•97	170•0	6•88	195•0	7•74				
120•5	5•05	145•5	5•99	170•5	6•89	195•5	7•76				
121•0	5•07	146•0	6•01	171•0	6•91	196•0	7•78				
121•5	5•09	146•5	6•03	171•5	6•93	196•5	7•79				
122•0	5•11	147•0	6•05	172•0	6•95	197•0	7•81				
122•5	5•13	147•5	6•07	172•5	6•96	197•5	7•83				
123•0	5•15	148•0	6•08	173•0	6•98	198•0	7•84				
123•5	5•17	148•5	6•10	173•5	7•00	198•5	7•86				
124•0	5•19	149•0	6•12	174•0	7•02	199•0	7•88				
124•5	5•21	149•5	6•14	174•5	7•03	199•5	7•90				
125•0	5•23	150•0	6•16	175•0	7•05	200•0	7•91				

Temperature, °F

42•8

7•0

		Temperature, °C			
atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•13	50•5	2•21
1•0	0•02	26•0	1•15	51•0	2•23
1•5	0•05	26•5	1•17	51•5	2•26
2•0	0•07	27•0	1•19	52•0	2•28
2•5	0•09	27•5	1•22	52•5	2•30
3•0	0•11	28•0	1•24	53•0	2•32
3•5	0•14	28•5	1•26	53•5	2•34
4•0	0•16	29•0	1•28	54•0	2•36
4•5	0•18	29•5	1•30	54•5	2•38
5•0	0•21	30•0	1•33	55•0	2•40
5•5	0•23	30•5	1•35	55•5	2•42
6•0	0•25	31•0	1•37	56•0	2•45
6•5	0•27	31•5	1•39	56•5	2•47
7•0	0•30	32•0	1•41	57•0	2•49
7•5	0•32	32•5	1•44	57•5	2•51
8•0	0•34	33•0	1•46	58•0	2•53
8•5	0•37	33•5	1•48	58•5	2•55
9•0	0•39	34•0	1•50	59•0	2•57
9•5	0•41	34•5	1•52	59•5	2•59
10•0	0•43	35•0	1•55	60•0	2•61
10•5	0•46	35•5	1•57	60•5	2•64
11•0	0•48	36•0	1•59	61•0	2•66
11•5	0•50	36•5	1•61	61•5	2•68
12•0	0•52	37•0	1•63	62•0	2•70
12•5	0•55	37•5	1•65	62•5	2•72
13•0	0•57	38•0	1•68	63•0	2•74
13•5	0•59	38•5	1•70	63•5	2•76
14•0	0•61	39•0	1•72	64•0	2•78
14•5	0•64	39•5	1•74	64•5	2•80
15•0	0•66	40•0	1•76	65•0	2•82
15•5	0•68	40•5	1•78	65•5	2•84
16•0	0•70	41•0	1•81	66•0	2•86
16•5	0•73	41•5	1•83	66•5	2•89
17•0	0•75	42•0	1•85	67•0	2•91
17•5	0•77	42•5	1•87	67•5	2•93
18•0	0•79	43•0	1•89	68•0	2•95
18•5	0•82	43•5	1•91	68•5	2•97
19•0	0•84	44•0	1•93	69•0	2•99
19•5	0•86	44•5	1•96	69•5	3•01
20•0	0•88	45•0	1•98	70•0	3•03
20•5	0•91	45•5	2•00	70•5	3•05
21•0	0•93	46•0	2•02	71•0	3•07
21•5	0•95	46•5	2•04	71•5	3•09
22•0	0•97	47•0	2•06	72•0	3•11
22•5	0•99	47•5	2•08	72•5	3•13
23•0	1•02	48•0	2•11	73•0	3•15
23•5	1•04	48•5	2•13	73•5	3•17
24•0	1•06	49•0	2•15	74•0	3•20
24•5	1•08	49•5	2•17	74•5	3•22
25•0	1•11	50•0	2•19	75•0	3•24

Temperature, °F

44•6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		7.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
100.5	4.26	125.5	5.23	150.5	6.15	175.5	7.04	
101.0	4.28	126.0	5.24	151.0	6.17	176.0	7.06	
101.5	4.30	126.5	5.26	151.5	6.19	176.5	7.08	
102.0	4.32	127.0	5.28	152.0	6.21	177.0	7.10	
102.5	4.34	127.5	5.30	152.5	6.23	177.5	7.11	
103.0	4.36	128.0	5.32	153.0	6.24	178.0	7.13	
103.5	4.38	128.5	5.34	153.5	6.26	178.5	7.15	
104.0	4.40	129.0	5.36	154.0	6.28	179.0	7.17	
104.5	4.42	129.5	5.38	154.5	6.30	179.5	7.18	
105.0	4.44	130.0	5.40	155.0	6.32	180.0	7.20	
105.5	4.46	130.5	5.41	155.5	6.33	180.5	7.22	
106.0	4.48	131.0	5.43	156.0	6.35	181.0	7.24	
106.5	4.50	131.5	5.45	156.5	6.37	181.5	7.25	
107.0	4.52	132.0	5.47	157.0	6.39	182.0	7.27	
107.5	4.53	132.5	5.49	157.5	6.41	182.5	7.29	
108.0	4.55	133.0	5.51	158.0	6.42	183.0	7.30	
108.5	4.57	133.5	5.53	158.5	6.44	183.5	7.32	
109.0	4.59	134.0	5.54	159.0	6.46	184.0	7.34	
109.5	4.61	134.5	5.56	159.5	6.48	184.5	7.36	
110.0	4.63	135.0	5.58	160.0	6.50	185.0	7.37	
110.5	4.65	135.5	5.60	160.5	6.51	185.5	7.39	
111.0	4.67	136.0	5.62	161.0	6.53	186.0	7.41	
111.5	4.69	136.5	5.64	161.5	6.55	186.5	7.43	
112.0	4.71	137.0	5.66	162.0	6.57	187.0	7.44	
112.5	4.73	137.5	5.68	162.5	6.59	187.5	7.46	
113.0	4.75	138.0	5.69	163.0	6.60	188.0	7.48	
113.5	4.77	138.5	5.71	163.5	6.62	188.5	7.49	
114.0	4.79	139.0	5.73	164.0	6.64	189.0	7.51	
114.5	4.81	139.5	5.75	164.5	6.66	189.5	7.53	
115.0	4.82	140.0	5.77	165.0	6.67	190.0	7.54	
115.5	4.84	140.5	5.79	165.5	6.69	190.5	7.56	
116.0	4.86	141.0	5.80	166.0	6.71	191.0	7.58	
116.5	4.88	141.5	5.82	166.5	6.73	191.5	7.60	
117.0	4.90	142.0	5.84	167.0	6.75	192.0	7.61	
117.5	4.92	142.5	5.86	167.5	6.76	192.5	7.63	
118.0	4.94	143.0	5.88	168.0	6.78	193.0	7.65	
118.5	4.96	143.5	5.90	168.5	6.80	193.5	7.66	
119.0	4.98	144.0	5.92	169.0	6.82	194.0	7.68	
119.5	5.00	144.5	5.93	169.5	6.83	194.5	7.70	
120.0	5.02	145.0	5.95	170.0	6.85	195.0	7.71	
120.5	5.04	145.5	5.97	170.5	6.87	195.5	7.73	
121.0	5.05	146.0	5.99	171.0	6.89	196.0	7.75	
121.5	5.07	146.5	6.01	171.5	6.90	196.5	7.77	
122.0	5.09	147.0	6.03	172.0	6.92	197.0	7.78	
122.5	5.11	147.5	6.04	172.5	6.94	197.5	7.80	
123.0	5.13	148.0	6.06	173.0	6.96	198.0	7.82	
123.5	5.15	148.5	6.08	173.5	6.97	198.5	7.83	
124.0	5.17	149.0	6.10	174.0	6.99	199.0	7.85	
124.5	5.19	149.5	6.12	174.5	7.01	199.5	7.87	
125.0	5.21	150.0	6.13	175.0	7.03	200.0	7.88	

Temperature, °F

44.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

8•0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•12	50•5	2•20	75•5	3•24
1•0	0•02	26•0	1•15	51•0	2•23	76•0	3•26
1•5	0•05	26•5	1•17	51•5	2•25	76•5	3•29
2•0	0•07	27•0	1•19	52•0	2•27	77•0	3•31
2•5	0•09	27•5	1•21	52•5	2•29	77•5	3•33
3•0	0•11	28•0	1•23	53•0	2•31	78•0	3•35
3•5	0•14	28•5	1•26	53•5	2•33	78•5	3•37
4•0	0•16	29•0	1•28	54•0	2•35	79•0	3•39
4•5	0•18	29•5	1•30	54•5	2•37	79•5	3•41
5•0	0•21	30•0	1•32	55•0	2•39	80•0	3•43
5•5	0•23	30•5	1•34	55•5	2•42	80•5	3•45
6•0	0•25	31•0	1•37	56•0	2•44	81•0	3•47
6•5	0•27	31•5	1•39	56•5	2•46	81•5	3•49
7•0	0•30	32•0	1•41	57•0	2•48	82•0	3•51
7•5	0•32	32•5	1•43	57•5	2•50	82•5	3•53
8•0	0•34	33•0	1•45	58•0	2•52	83•0	3•55
8•5	0•36	33•5	1•47	58•5	2•54	83•5	3•57
9•0	0•39	34•0	1•50	59•0	2•56	84•0	3•59
9•5	0•41	34•5	1•52	59•5	2•58	84•5	3•61
10•0	0•43	35•0	1•54	60•0	2•60	85•0	3•63
10•5	0•45	35•5	1•56	60•5	2•63	85•5	3•65
11•0	0•48	36•0	1•58	61•0	2•65	86•0	3•67
11•5	0•50	36•5	1•60	61•5	2•67	86•5	3•69
12•0	0•52	37•0	1•63	62•0	2•69	87•0	3•71
12•5	0•54	37•5	1•65	62•5	2•71	87•5	3•73
13•0	0•57	38•0	1•67	63•0	2•73	88•0	3•75
13•5	0•59	38•5	1•69	63•5	2•75	88•5	3•77
14•0	0•61	39•0	1•71	64•0	2•77	89•0	3•79
14•5	0•63	39•5	1•73	64•5	2•79	89•5	3•81
15•0	0•66	40•0	1•76	65•0	2•81	90•0	3•83
15•5	0•68	40•5	1•78	65•5	2•83	90•5	3•85
16•0	0•70	41•0	1•80	66•0	2•85	91•0	3•87
16•5	0•72	41•5	1•82	66•5	2•87	91•5	3•89
17•0	0•75	42•0	1•84	67•0	2•90	92•0	3•91
17•5	0•77	42•5	1•86	67•5	2•92	92•5	3•93
18•0	0•79	43•0	1•88	68•0	2•94	93•0	3•95
18•5	0•81	43•5	1•91	68•5	2•96	93•5	3•97
19•0	0•84	44•0	1•93	69•0	2•98	94•0	3•99
19•5	0•86	44•5	1•95	69•5	3•00	94•5	4•01
20•0	0•88	45•0	1•97	70•0	3•02	95•0	4•03
20•5	0•90	45•5	1•99	70•5	3•04	95•5	4•05
21•0	0•92	46•0	2•01	71•0	3•06	96•0	4•07
21•5	0•95	46•5	2•03	71•5	3•08	96•5	4•09
22•0	0•97	47•0	2•06	72•0	3•10	97•0	4•11
22•5	0•99	47•5	2•08	72•5	3•12	97•5	4•13
23•0	1•01	48•0	2•10	73•0	3•14	98•0	4•15
23•5	1•04	48•5	2•12	73•5	3•16	98•5	4•17
24•0	1•06	49•0	2•14	74•0	3•18	99•0	4•19
24•5	1•08	49•5	2•16	74•5	3•20	99•5	4•21
25•0	1•10	50•0	2•18	75•0	3•22	100•0	4•23

Temperature, °F

46•4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 8•0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•24	125•5	5•21	150•5	6•13	175•5	7•02				
101•0	4•26	126•0	5•23	151•0	6•15	176•0	7•04				
101•5	4•28	126•5	5•24	151•5	6•17	176•5	7•05				
102•0	4•30	127•0	5•26	152•0	6•18	177•0	7•07				
102•5	4•32	127•5	5•28	152•5	6•20	177•5	7•09				
103•0	4•34	128•0	5•30	153•0	6•22	178•0	7•11				
103•5	4•36	128•5	5•32	153•5	6•24	178•5	7•12				
104•0	4•38	129•0	5•34	154•0	6•26	179•0	7•14				
104•5	4•40	129•5	5•36	154•5	6•27	179•5	7•16				
105•0	4•42	130•0	5•38	155•0	6•29	180•0	7•17				
105•5	4•44	130•5	5•39	155•5	6•31	180•5	7•19				
106•0	4•46	131•0	5•41	156•0	6•33	181•0	7•21				
106•5	4•48	131•5	5•43	156•5	6•35	181•5	7•23				
107•0	4•50	132•0	5•45	157•0	6•36	182•0	7•24				
107•5	4•52	132•5	5•47	157•5	6•38	182•5	7•26				
108•0	4•54	133•0	5•49	158•0	6•40	183•0	7•28				
108•5	4•56	133•5	5•51	158•5	6•42	183•5	7•30				
109•0	4•58	134•0	5•52	159•0	6•44	184•0	7•31				
109•5	4•60	134•5	5•54	159•5	6•45	184•5	7•33				
110•0	4•61	135•0	5•56	160•0	6•47	185•0	7•35				
110•5	4•63	135•5	5•58	160•5	6•49	185•5	7•36				
111•0	4•65	136•0	5•60	161•0	6•51	186•0	7•38				
111•5	4•67	136•5	5•62	161•5	6•53	186•5	7•40				
112•0	4•69	137•0	5•64	162•0	6•54	187•0	7•42				
112•5	4•71	137•5	5•65	162•5	6•56	187•5	7•43				
113•0	4•73	138•0	5•67	163•0	6•58	188•0	7•45				
113•5	4•75	138•5	5•69	163•5	6•60	188•5	7•47				
114•0	4•77	139•0	5•71	164•0	6•61	189•0	7•48				
114•5	4•79	139•5	5•73	164•5	6•63	189•5	7•50				
115•0	4•81	140•0	5•75	165•0	6•65	190•0	7•52				
115•5	4•83	140•5	5•77	165•5	6•67	190•5	7•53				
116•0	4•85	141•0	5•78	166•0	6•69	191•0	7•55				
116•5	4•86	141•5	5•80	166•5	6•70	191•5	7•57				
117•0	4•88	142•0	5•82	167•0	6•72	192•0	7•59				
117•5	4•90	142•5	5•84	167•5	6•74	192•5	7•60				
118•0	4•92	143•0	5•86	168•0	6•76	193•0	7•62				
118•5	4•94	143•5	5•88	168•5	6•77	193•5	7•64				
119•0	4•96	144•0	5•89	169•0	6•79	194•0	7•65				
119•5	4•98	144•5	5•91	169•5	6•81	194•5	7•67				
120•0	5•00	145•0	5•93	170•0	6•83	195•0	7•69				
120•5	5•02	145•5	5•95	170•5	6•84	195•5	7•70				
121•0	5•04	146•0	5•97	171•0	6•86	196•0	7•72				
121•5	5•05	146•5	5•98	171•5	6•88	196•5	7•74				
122•0	5•07	147•0	6•00	172•0	6•90	197•0	7•75				
122•5	5•09	147•5	6•02	172•5	6•91	197•5	7•77				
123•0	5•11	148•0	6•04	173•0	6•93	198•0	7•79				
123•5	5•13	148•5	6•06	173•5	6•95	198•5	7•80				
124•0	5•15	149•0	6•08	174•0	6•97	199•0	7•82				
124•5	5•17	149•5	6•09	174•5	6•98	199•5	7•84				
125•0	5•19	150•0	6•11	175•0	7•00	200•0	7•85				

Temperature, °F

46•4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		9•0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•12	50•5	2•20	75•5	3•23
1•0	0•02	26•0	1•14	51•0	2•22	76•0	3•25
1•5	0•05	26•5	1•16	51•5	2•24	76•5	3•27
2•0	0•07	27•0	1•19	52•0	2•26	77•0	3•29
2•5	0•09	27•5	1•21	52•5	2•28	77•5	3•31
3•0	0•11	28•0	1•23	53•0	2•30	78•0	3•33
3•5	0•14	28•5	1•25	53•5	2•32	78•5	3•35
4•0	0•16	29•0	1•27	54•0	2•34	79•0	3•37
4•5	0•18	29•5	1•29	54•5	2•36	79•5	3•39
5•0	0•20	30•0	1•32	55•0	2•39	80•0	3•41
5•5	0•23	30•5	1•34	55•5	2•41	80•5	3•43
6•0	0•25	31•0	1•36	56•0	2•43	81•0	3•46
6•5	0•27	31•5	1•38	56•5	2•45	81•5	3•48
7•0	0•30	32•0	1•40	57•0	2•47	82•0	3•50
7•5	0•32	32•5	1•43	57•5	2•49	82•5	3•52
8•0	0•34	33•0	1•45	58•0	2•51	83•0	3•54
8•5	0•36	33•5	1•47	58•5	2•53	83•5	3•56
9•0	0•39	34•0	1•49	59•0	2•55	84•0	3•58
9•5	0•41	34•5	1•51	59•5	2•57	84•5	3•60
10•0	0•43	35•0	1•53	60•0	2•59	85•0	3•62
10•5	0•45	35•5	1•56	60•5	2•62	85•5	3•64
11•0	0•48	36•0	1•58	61•0	2•64	86•0	3•66
11•5	0•50	36•5	1•60	61•5	2•66	86•5	3•68
12•0	0•52	37•0	1•62	62•0	2•68	87•0	3•70
12•5	0•54	37•5	1•64	62•5	2•70	87•5	3•72
13•0	0•57	38•0	1•66	63•0	2•72	88•0	3•74
13•5	0•59	38•5	1•68	63•5	2•74	88•5	3•76
14•0	0•61	39•0	1•71	64•0	2•76	89•0	3•78
14•5	0•63	39•5	1•73	64•5	2•78	89•5	3•80
15•0	0•65	40•0	1•75	65•0	2•80	90•0	3•82
15•5	0•68	40•5	1•77	65•5	2•82	90•5	3•84
16•0	0•70	41•0	1•79	66•0	2•84	91•0	3•85
16•5	0•72	41•5	1•81	66•5	2•86	91•5	3•87
17•0	0•74	42•0	1•83	67•0	2•88	92•0	3•89
17•5	0•77	42•5	1•86	67•5	2•91	92•5	3•91
18•0	0•79	43•0	1•88	68•0	2•93	93•0	3•93
18•5	0•81	43•5	1•90	68•5	2•95	93•5	3•95
19•0	0•83	44•0	1•92	69•0	2•97	94•0	3•97
19•5	0•85	44•5	1•94	69•5	2•99	94•5	3•99
20•0	0•88	45•0	1•96	70•0	3•01	95•0	4•01
20•5	0•90	45•5	1•98	70•5	3•03	95•5	4•03
21•0	0•92	46•0	2•01	71•0	3•05	96•0	4•05
21•5	0•94	46•5	2•03	71•5	3•07	96•5	4•07
22•0	0•97	47•0	2•05	72•0	3•09	97•0	4•09
22•5	0•99	47•5	2•07	72•5	3•11	97•5	4•11
23•0	1•01	48•0	2•09	73•0	3•13	98•0	4•13
23•5	1•03	48•5	2•11	73•5	3•15	98•5	4•15
24•0	1•05	49•0	2•13	74•0	3•17	99•0	4•17
24•5	1•08	49•5	2•15	74•5	3•19	99•5	4•19
25•0	1•10	50•0	2•18	75•0	3•21	100•0	4•21

Temperature, °F

48•2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 9•0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•23	125•5	5•19	150•5	6•11	175•5	6•99				
101•0	4•25	126•0	5•21	151•0	6•13	176•0	7•01				
101•5	4•27	126•5	5•22	151•5	6•14	176•5	7•03				
102•0	4•29	127•0	5•24	152•0	6•16	177•0	7•04				
102•5	4•31	127•5	5•26	152•5	6•18	177•5	7•06				
103•0	4•33	128•0	5•28	153•0	6•20	178•0	7•08				
103•5	4•35	128•5	5•30	153•5	6•22	178•5	7•10				
104•0	4•37	129•0	5•32	154•0	6•23	179•0	7•11				
104•5	4•38	129•5	5•34	154•5	6•25	179•5	7•13				
105•0	4•40	130•0	5•36	155•0	6•27	180•0	7•15				
105•5	4•42	130•5	5•37	155•5	6•29	180•5	7•17				
106•0	4•44	131•0	5•39	156•0	6•31	181•0	7•18				
106•5	4•46	131•5	5•41	156•5	6•32	181•5	7•20				
107•0	4•48	132•0	5•43	157•0	6•34	182•0	7•22				
107•5	4•50	132•5	5•45	157•5	6•36	182•5	7•23				
108•0	4•52	133•0	5•47	158•0	6•38	183•0	7•25				
108•5	4•54	133•5	5•49	158•5	6•39	183•5	7•27				
109•0	4•56	134•0	5•50	159•0	6•41	184•0	7•29				
109•5	4•58	134•5	5•52	159•5	6•43	184•5	7•30				
110•0	4•60	135•0	5•54	160•0	6•45	185•0	7•32				
110•5	4•62	135•5	5•56	160•5	6•47	185•5	7•34				
111•0	4•64	136•0	5•58	161•0	6•48	186•0	7•35				
111•5	4•66	136•5	5•60	161•5	6•50	186•5	7•37				
112•0	4•67	137•0	5•62	162•0	6•52	187•0	7•39				
112•5	4•69	137•5	5•63	162•5	6•54	187•5	7•41				
113•0	4•71	138•0	5•65	163•0	6•55	188•0	7•42				
113•5	4•73	138•5	5•67	163•5	6•57	188•5	7•44				
114•0	4•75	139•0	5•69	164•0	6•59	189•0	7•46				
114•5	4•77	139•5	5•71	164•5	6•61	189•5	7•47				
115•0	4•79	140•0	5•73	165•0	6•63	190•0	7•49				
115•5	4•81	140•5	5•74	165•5	6•64	190•5	7•51				
116•0	4•83	141•0	5•76	166•0	6•66	191•0	7•52				
116•5	4•85	141•5	5•78	166•5	6•68	191•5	7•54				
117•0	4•87	142•0	5•80	167•0	6•70	192•0	7•56				
117•5	4•88	142•5	5•82	167•5	6•71	192•5	7•57				
118•0	4•90	143•0	5•84	168•0	6•73	193•0	7•59				
118•5	4•92	143•5	5•85	168•5	6•75	193•5	7•61				
119•0	4•94	144•0	5•87	169•0	6•77	194•0	7•63				
119•5	4•96	144•5	5•89	169•5	6•78	194•5	7•64				
120•0	4•98	145•0	5•91	170•0	6•80	195•0	7•66				
120•5	5•00	145•5	5•93	170•5	6•82	195•5	7•68				
121•0	5•02	146•0	5•94	171•0	6•84	196•0	7•69				
121•5	5•04	146•5	5•96	171•5	6•85	196•5	7•71				
122•0	5•06	147•0	5•98	172•0	6•87	197•0	7•73				
122•5	5•07	147•5	6•00	172•5	6•89	197•5	7•74				
123•0	5•09	148•0	6•02	173•0	6•91	198•0	7•76				
123•5	5•11	148•5	6•04	173•5	6•92	198•5	7•78				
124•0	5•13	149•0	6•05	174•0	6•94	199•0	7•79				
124•5	5•15	149•5	6•07	174•5	6•96	199•5	7•81				
125•0	5•17	150•0	6•09	175•0	6•98	200•0	7•83				

Temperature, °F

48•2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

10.0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.12	50.5	2.19	75.5	3.22
1.0	0.02	26.0	1.14	51.0	2.21	76.0	3.24
1.5	0.05	26.5	1.16	51.5	2.23	76.5	3.26
2.0	0.07	27.0	1.18	52.0	2.25	77.0	3.28
2.5	0.09	27.5	1.20	52.5	2.27	77.5	3.30
3.0	0.11	28.0	1.22	53.0	2.29	78.0	3.32
3.5	0.14	28.5	1.25	53.5	2.31	78.5	3.34
4.0	0.16	29.0	1.27	54.0	2.34	79.0	3.36
4.5	0.18	29.5	1.29	54.5	2.36	79.5	3.38
5.0	0.20	30.0	1.31	55.0	2.38	80.0	3.40
5.5	0.23	30.5	1.33	55.5	2.40	80.5	3.42
6.0	0.25	31.0	1.35	56.0	2.42	81.0	3.44
6.5	0.27	31.5	1.38	56.5	2.44	81.5	3.46
7.0	0.29	32.0	1.40	57.0	2.46	82.0	3.48
7.5	0.32	32.5	1.42	57.5	2.48	82.5	3.50
8.0	0.34	33.0	1.44	58.0	2.50	83.0	3.52
8.5	0.36	33.5	1.46	58.5	2.52	83.5	3.54
9.0	0.38	34.0	1.48	59.0	2.54	84.0	3.56
9.5	0.41	34.5	1.51	59.5	2.56	84.5	3.58
10.0	0.43	35.0	1.53	60.0	2.59	85.0	3.60
10.5	0.45	35.5	1.55	60.5	2.61	85.5	3.62
11.0	0.47	36.0	1.57	61.0	2.63	86.0	3.64
11.5	0.50	36.5	1.59	61.5	2.65	86.5	3.66
12.0	0.52	37.0	1.61	62.0	2.67	87.0	3.68
12.5	0.54	37.5	1.64	62.5	2.69	87.5	3.70
13.0	0.56	38.0	1.66	63.0	2.71	88.0	3.72
13.5	0.59	38.5	1.68	63.5	2.73	88.5	3.74
14.0	0.61	39.0	1.70	64.0	2.75	89.0	3.76
14.5	0.63	39.5	1.72	64.5	2.77	89.5	3.78
15.0	0.65	40.0	1.74	65.0	2.79	90.0	3.80
15.5	0.67	40.5	1.76	65.5	2.81	90.5	3.82
16.0	0.70	41.0	1.79	66.0	2.83	91.0	3.84
16.5	0.72	41.5	1.81	66.5	2.85	91.5	3.86
17.0	0.74	42.0	1.83	67.0	2.87	92.0	3.88
17.5	0.76	42.5	1.85	67.5	2.89	92.5	3.90
18.0	0.79	43.0	1.87	68.0	2.92	93.0	3.92
18.5	0.81	43.5	1.89	68.5	2.94	93.5	3.94
19.0	0.83	44.0	1.91	69.0	2.96	94.0	3.96
19.5	0.85	44.5	1.93	69.5	2.98	94.5	3.98
20.0	0.87	45.0	1.96	70.0	3.00	95.0	4.00
20.5	0.90	45.5	1.98	70.5	3.02	95.5	4.02
21.0	0.92	46.0	2.00	71.0	3.04	96.0	4.04
21.5	0.94	46.5	2.02	71.5	3.06	96.5	4.06
22.0	0.96	47.0	2.04	72.0	3.08	97.0	4.08
22.5	0.98	47.5	2.06	72.5	3.10	97.5	4.10
23.0	1.01	48.0	2.08	73.0	3.12	98.0	4.12
23.5	1.03	48.5	2.10	73.5	3.14	98.5	4.14
24.0	1.05	49.0	2.13	74.0	3.16	99.0	4.15
24.5	1.07	49.5	2.15	74.5	3.18	99.5	4.17
25.0	1.09	50.0	2.17	75.0	3.20	100.0	4.19

Temperature, °F

50.0

								Temperature, °C		10•0	
atü	- kg										
100•5	4•21	125•5	5•17	150•5	6•09	175•5	6•97				
101•0	4•23	126•0	5•19	151•0	6•10	176•0	6•98				
101•5	4•25	126•5	5•21	151•5	6•12	176•5	7•00				
102•0	4•27	127•0	5•22	152•0	6•14	177•0	7•02				
102•5	4•29	127•5	5•24	152•5	6•16	177•5	7•04				
103•0	4•31	128•0	5•26	153•0	6•18	178•0	7•05				
103•5	4•33	128•5	5•28	153•5	6•19	178•5	7•07				
104•0	4•35	129•0	5•30	154•0	6•21	179•0	7•09				
104•5	4•37	129•5	5•32	154•5	6•23	179•5	7•11				
105•0	4•39	130•0	5•34	155•0	6•25	180•0	7•12				
105•5	4•41	130•5	5•35	155•5	6•26	180•5	7•14				
106•0	4•43	131•0	5•37	156•0	6•28	181•0	7•16				
106•5	4•45	131•5	5•39	156•5	6•30	181•5	7•17				
107•0	4•47	132•0	5•41	157•0	6•32	182•0	7•19				
107•5	4•48	132•5	5•43	157•5	6•34	182•5	7•21				
108•0	4•50	133•0	5•45	158•0	6•35	183•0	7•23				
108•5	4•52	133•5	5•47	158•5	6•37	183•5	7•24				
109•0	4•54	134•0	5•48	159•0	6•39	184•0	7•26				
109•5	4•56	134•5	5•50	159•5	6•41	184•5	7•28				
110•0	4•58	135•0	5•52	160•0	6•42	185•0	7•29				
110•5	4•60	135•5	5•54	160•5	6•44	185•5	7•31				
111•0	4•62	136•0	5•56	161•0	6•46	186•0	7•33				
111•5	4•64	136•5	5•58	161•5	6•48	186•5	7•34				
112•0	4•66	137•0	5•59	162•0	6•50	187•0	7•36				
112•5	4•68	137•5	5•61	162•5	6•51	187•5	7•38				
113•0	4•70	138•0	5•63	163•0	6•53	188•0	7•40				
113•5	4•71	138•5	5•65	163•5	6•55	188•5	7•41				
114•0	4•73	139•0	5•67	164•0	6•57	189•0	7•43				
114•5	4•75	139•5	5•69	164•5	6•58	189•5	7•45				
115•0	4•77	140•0	5•70	165•0	6•60	190•0	7•46				
115•5	4•79	140•5	5•72	165•5	6•62	190•5	7•48				
116•0	4•81	141•0	5•74	166•0	6•64	191•0	7•50				
116•5	4•83	141•5	5•76	166•5	6•65	191•5	7•51				
117•0	4•85	142•0	5•78	167•0	6•67	192•0	7•53				
117•5	4•87	142•5	5•80	167•5	6•69	192•5	7•55				
118•0	4•89	143•0	5•81	168•0	6•71	193•0	7•56				
118•5	4•90	143•5	5•83	168•5	6•72	193•5	7•58				
119•0	4•92	144•0	5•85	169•0	6•74	194•0	7•60				
119•5	4•94	144•5	5•87	169•5	6•76	194•5	7•61				
120•0	4•96	145•0	5•89	170•0	6•78	195•0	7•63				
120•5	4•98	145•5	5•90	170•5	6•79	195•5	7•65				
121•0	5•00	146•0	5•92	171•0	6•81	196•0	7•66				
121•5	5•02	146•5	5•94	171•5	6•83	196•5	7•68				
122•0	5•04	147•0	5•96	172•0	6•85	197•0	7•70				
122•5	5•06	147•5	5•98	172•5	6•86	197•5	7•71				
123•0	5•07	148•0	6•00	173•0	6•88	198•0	7•73				
123•5	5•09	148•5	6•01	173•5	6•90	198•5	7•74				
124•0	5•11	149•0	6•03	174•0	6•92	199•0	7•77				
124•5	5•13	149•5	6•05	174•5	6•93	199•5	7•78				
125•0	5•15	150•0	6•07	175•0	6•95	200•0	7•80				

Temperature, °F

50•0

Temperature, °C								11.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.11	50.5	2.18	75.5	3.21	
1.0	0.02	26.0	1.13	51.0	2.20	76.0	3.23	
1.5	0.05	26.5	1.15	51.5	2.22	76.5	3.25	
2.0	0.07	27.0	1.18	52.0	2.24	77.0	3.27	
2.5	0.09	27.5	1.20	52.5	2.26	77.5	3.29	
3.0	0.11	28.0	1.22	53.0	2.28	78.0	3.31	
3.5	0.14	28.5	1.24	53.5	2.31	78.5	3.33	
4.0	0.16	29.0	1.26	54.0	2.33	79.0	3.35	
4.5	0.18	29.5	1.28	54.5	2.35	79.5	3.37	
5.0	0.20	30.0	1.31	55.0	2.37	80.0	3.39	
5.5	0.23	30.5	1.33	55.5	2.39	80.5	3.41	
6.0	0.25	31.0	1.35	56.0	2.41	81.0	3.43	
6.5	0.27	31.5	1.37	56.5	2.43	81.5	3.45	
7.0	0.29	32.0	1.39	57.0	2.45	82.0	3.47	
7.5	0.32	32.5	1.41	57.5	2.47	82.5	3.49	
8.0	0.34	33.0	1.44	58.0	2.49	83.0	3.51	
8.5	0.36	33.5	1.46	58.5	2.51	83.5	3.53	
9.0	0.38	34.0	1.48	59.0	2.53	84.0	3.55	
9.5	0.40	34.5	1.50	59.5	2.55	84.5	3.57	
10.0	0.43	35.0	1.52	60.0	2.58	85.0	3.59	
10.5	0.45	35.5	1.54	60.5	2.60	85.5	3.61	
11.0	0.47	36.0	1.57	61.0	2.62	86.0	3.63	
11.5	0.49	36.5	1.59	61.5	2.64	86.5	3.65	
12.0	0.52	37.0	1.61	62.0	2.66	87.0	3.67	
12.5	0.54	37.5	1.63	62.5	2.68	87.5	3.69	
13.0	0.56	38.0	1.65	63.0	2.70	88.0	3.71	
13.5	0.58	38.5	1.67	63.5	2.72	88.5	3.73	
14.0	0.61	39.0	1.69	64.0	2.74	89.0	3.75	
14.5	0.63	39.5	1.71	64.5	2.76	89.5	3.77	
15.0	0.65	40.0	1.74	65.0	2.78	90.0	3.79	
15.5	0.67	40.5	1.76	65.5	2.80	90.5	3.81	
16.0	0.69	41.0	1.78	66.0	2.82	91.0	3.83	
16.5	0.72	41.5	1.80	66.5	2.84	91.5	3.85	
17.0	0.74	42.0	1.82	67.0	2.86	92.0	3.87	
17.5	0.76	42.5	1.84	67.5	2.88	92.5	3.89	
18.0	0.78	43.0	1.86	68.0	2.90	93.0	3.90	
18.5	0.80	43.5	1.88	68.5	2.92	93.5	3.92	
19.0	0.83	44.0	1.91	69.0	2.94	94.0	3.94	
19.5	0.85	44.5	1.93	69.5	2.97	94.5	3.96	
20.0	0.87	45.0	1.95	70.0	2.99	95.0	3.98	
20.5	0.89	45.5	1.97	70.5	3.01	95.5	4.00	
21.0	0.91	46.0	1.99	71.0	3.03	96.0	4.02	
21.5	0.94	46.5	2.01	71.5	3.05	96.5	4.04	
22.0	0.96	47.0	2.03	72.0	3.07	97.0	4.06	
22.5	0.98	47.5	2.05	72.5	3.09	97.5	4.08	
23.0	1.00	48.0	2.08	73.0	3.11	98.0	4.10	
23.5	1.02	48.5	2.10	73.5	3.13	98.5	4.12	
24.0	1.05	49.0	2.12	74.0	3.15	99.0	4.14	
24.5	1.07	49.5	2.14	74.5	3.17	99.5	4.16	
25.0	1.09	50.0	2.16	75.0	3.19	100.0	4.18	

Temperature, °F

51.8

				Temperature, °C				11.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.20	125.5	5.15	150.5	6.06	175.5	6.94				
101.0	4.22	126.0	5.17	151.0	6.08	176.0	6.96				
101.5	4.24	126.5	5.19	151.5	6.10	176.5	6.98				
102.0	4.26	127.0	5.20	152.0	6.12	177.0	6.99				
102.5	4.28	127.5	5.22	152.5	6.13	177.5	7.01				
103.0	4.29	128.0	5.24	153.0	6.15	178.0	7.03				
103.5	4.31	128.5	5.26	153.5	6.17	178.5	7.05				
104.0	4.33	129.0	5.28	154.0	6.19	179.0	7.06				
104.5	4.35	129.5	5.30	154.5	6.21	179.5	7.08				
105.0	4.37	130.0	5.32	155.0	6.22	180.0	7.10				
105.5	4.39	130.5	5.33	155.5	6.24	180.5	7.11				
106.0	4.41	131.0	5.35	156.0	6.26	181.0	7.13				
106.5	4.43	131.5	5.37	156.5	6.28	181.5	7.15				
107.0	4.45	132.0	5.39	157.0	6.30	182.0	7.16				
107.5	4.47	132.5	5.41	157.5	6.31	182.5	7.18				
108.0	4.49	133.0	5.43	158.0	6.33	183.0	7.20				
108.5	4.51	133.5	5.45	158.5	6.35	183.5	7.22				
109.0	4.53	134.0	5.46	159.0	6.37	184.0	7.23				
109.5	4.54	134.5	5.48	159.5	6.38	184.5	7.25				
110.0	4.56	135.0	5.50	160.0	6.40	185.0	7.27				
110.5	4.58	135.5	5.52	160.5	6.42	185.5	7.28				
111.0	4.60	136.0	5.54	161.0	6.44	186.0	7.30				
111.5	4.62	136.5	5.56	161.5	6.45	186.5	7.32				
112.0	4.64	137.0	5.57	162.0	6.47	187.0	7.33				
112.5	4.66	137.5	5.59	162.5	6.49	187.5	7.35				
113.0	4.68	138.0	5.61	163.0	6.51	188.0	7.37				
113.5	4.70	138.5	5.63	163.5	6.52	188.5	7.39				
114.0	4.72	139.0	5.65	164.0	6.54	189.0	7.40				
114.5	4.73	139.5	5.67	164.5	6.56	189.5	7.42				
115.0	4.75	140.0	5.68	165.0	6.58	190.0	7.44				
115.5	4.77	140.5	5.70	165.5	6.59	190.5	7.45				
116.0	4.79	141.0	5.72	166.0	6.61	191.0	7.47				
116.5	4.81	141.5	5.74	166.5	6.63	191.5	7.49				
117.0	4.83	142.0	5.76	167.0	6.65	192.0	7.50				
117.5	4.85	142.5	5.77	167.5	6.66	192.5	7.52				
118.0	4.87	143.0	5.79	168.0	6.68	193.0	7.54				
118.5	4.89	143.5	5.81	168.5	6.70	193.5	7.55				
119.0	4.91	144.0	5.83	169.0	6.72	194.0	7.57				
119.5	4.92	144.5	5.85	169.5	6.73	194.5	7.59				
120.0	4.94	145.0	5.87	170.0	6.75	195.0	7.60				
120.5	4.96	145.5	5.88	170.5	6.77	195.5	7.62				
121.0	4.98	146.0	5.90	171.0	6.79	196.0	7.64				
121.5	5.00	146.5	5.92	171.5	6.80	196.5	7.65				
122.0	5.02	147.0	5.94	172.0	6.82	197.0	7.67				
122.5	5.04	147.5	5.96	172.5	6.84	197.5	7.69				
123.0	5.06	148.0	5.97	173.0	6.86	198.0	7.70				
123.5	5.07	148.5	5.99	173.5	6.87	198.5	7.72				
124.0	5.09	149.0	6.01	174.0	6.89	199.0	7.74				
124.5	5.11	149.5	6.03	174.5	6.91	199.5	7.75				
125.0	5.13	150.0	6.05	175.0	6.92	200.0	7.77				

Temperature, °F

51.8

		Temperature, °C				12.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.11	50.5	2.17	75.5	3.20
1.0	0.02	26.0	1.13	51.0	2.19	76.0	3.22
1.5	0.05	26.5	1.15	51.5	2.21	76.5	3.24
2.0	0.07	27.0	1.17	52.0	2.23	77.0	3.26
2.5	0.09	27.5	1.19	52.5	2.26	77.5	3.28
3.0	0.11	28.0	1.22	53.0	2.28	78.0	3.30
3.5	0.14	28.5	1.24	53.5	2.30	78.5	3.32
4.0	0.16	29.0	1.26	54.0	2.32	79.0	3.34
4.5	0.18	29.5	1.28	54.5	2.34	79.5	3.36
5.0	0.20	30.0	1.30	55.0	2.36	80.0	3.38
5.5	0.22	30.5	1.32	55.5	2.38	80.5	3.40
6.0	0.25	31.0	1.34	56.0	2.40	81.0	3.42
6.5	0.27	31.5	1.37	56.5	2.42	81.5	3.44
7.0	0.29	32.0	1.39	57.0	2.44	82.0	3.46
7.5	0.31	32.5	1.41	57.5	2.46	82.5	3.48
8.0	0.34	33.0	1.43	58.0	2.48	83.0	3.50
8.5	0.36	33.5	1.45	58.5	2.50	83.5	3.52
9.0	0.38	34.0	1.47	59.0	2.52	84.0	3.54
9.5	0.40	34.5	1.50	59.5	2.55	84.5	3.56
10.0	0.43	35.0	1.52	60.0	2.57	85.0	3.58
10.5	0.45	35.5	1.54	60.5	2.59	85.5	3.60
11.0	0.47	36.0	1.56	61.0	2.61	86.0	3.62
11.5	0.49	36.5	1.58	61.5	2.63	86.5	3.63
12.0	0.51	37.0	1.60	62.0	2.65	87.0	3.65
12.5	0.54	37.5	1.62	62.5	2.67	87.5	3.67
13.0	0.56	38.0	1.64	63.0	2.69	88.0	3.69
13.5	0.58	38.5	1.67	63.5	2.71	88.5	3.71
14.0	0.60	39.0	1.69	64.0	2.73	89.0	3.73
14.5	0.63	39.5	1.71	64.5	2.75	89.5	3.75
15.0	0.65	40.0	1.73	65.0	2.77	90.0	3.77
15.5	0.67	40.5	1.75	65.5	2.79	90.5	3.79
16.0	0.69	41.0	1.77	66.0	2.81	91.0	3.81
16.5	0.71	41.5	1.79	66.5	2.83	91.5	3.83
17.0	0.74	42.0	1.81	67.0	2.85	92.0	3.85
17.5	0.76	42.5	1.84	67.5	2.87	92.5	3.87
18.0	0.78	43.0	1.86	68.0	2.89	93.0	3.89
18.5	0.80	43.5	1.88	68.5	2.91	93.5	3.91
19.0	0.82	44.0	1.90	69.0	2.93	94.0	3.93
19.5	0.85	44.5	1.92	69.5	2.95	94.5	3.95
20.0	0.87	45.0	1.94	70.0	2.97	95.0	3.97
20.5	0.89	45.5	1.96	70.5	2.99	95.5	3.99
21.0	0.91	46.0	1.98	71.0	3.02	96.0	4.01
21.5	0.93	46.5	2.00	71.5	3.04	96.5	4.03
22.0	0.95	47.0	2.03	72.0	3.06	97.0	4.05
22.5	0.98	47.5	2.05	72.5	3.08	97.5	4.07
23.0	1.00	48.0	2.07	73.0	3.10	98.0	4.09
23.5	1.02	48.5	2.09	73.5	3.12	98.5	4.10
24.0	1.04	49.0	2.11	74.0	3.14	99.0	4.12
24.5	1.06	49.5	2.13	74.5	3.16	99.5	4.14
25.0	1.09	50.0	2.15	75.0	3.18	100.0	4.16

Temperature, °F

53.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C		12.0	
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.18	125.5	5.13	150.5	6.04	175.5	6.92				
101.0	4.20	126.0	5.15	151.0	6.06	176.0	6.93				
101.5	4.22	126.5	5.17	151.5	6.08	176.5	6.95				
102.0	4.24	127.0	5.19	152.0	6.09	177.0	6.97				
102.5	4.26	127.5	5.20	152.5	6.11	177.5	6.99				
103.0	4.28	128.0	5.22	153.0	6.13	178.0	7.00				
103.5	4.30	128.5	5.24	153.5	6.15	178.5	7.02				
104.0	4.32	129.0	5.26	154.0	6.17	179.0	7.04				
104.5	4.34	129.5	5.28	154.5	6.18	179.5	7.05				
105.0	4.36	130.0	5.30	155.0	6.20	180.0	7.07				
105.5	4.37	130.5	5.31	155.5	6.22	180.5	7.09				
106.0	4.39	131.0	5.33	156.0	6.24	181.0	7.10				
106.5	4.41	131.5	5.35	156.5	6.25	181.5	7.12				
107.0	4.43	132.0	5.37	157.0	6.27	182.0	7.14				
107.5	4.45	132.5	5.39	157.5	6.29	182.5	7.16				
108.0	4.47	133.0	5.41	158.0	6.31	183.0	7.17				
108.5	4.49	133.5	5.43	158.5	6.32	183.5	7.19				
109.0	4.51	134.0	5.44	159.0	6.34	184.0	7.21				
109.5	4.53	134.5	5.46	159.5	6.36	184.5	7.22				
110.0	4.55	135.0	5.48	160.0	6.38	185.0	7.24				
110.5	4.57	135.5	5.50	160.5	6.40	185.5	7.26				
111.0	4.58	136.0	5.52	161.0	6.41	186.0	7.27				
111.5	4.60	136.5	5.54	161.5	6.43	186.5	7.29				
112.0	4.62	137.0	5.55	162.0	6.45	187.0	7.31				
112.5	4.64	137.5	5.57	162.5	6.47	187.5	7.32				
113.0	4.66	138.0	5.59	163.0	6.48	188.0	7.34				
113.5	4.68	138.5	5.61	163.5	6.50	188.5	7.36				
114.0	4.70	139.0	5.63	164.0	6.52	189.0	7.38				
114.5	4.72	139.5	5.64	164.5	6.54	189.5	7.39				
115.0	4.74	140.0	5.66	165.0	6.55	190.0	7.41				
115.5	4.76	140.5	5.68	165.5	6.57	190.5	7.43				
116.0	4.77	141.0	5.70	166.0	6.59	191.0	7.44				
116.5	4.79	141.5	5.72	166.5	6.61	191.5	7.46				
117.0	4.81	142.0	5.74	167.0	6.62	192.0	7.48				
117.5	4.83	142.5	5.75	167.5	6.64	192.5	7.49				
118.0	4.85	143.0	5.77	168.0	6.66	193.0	7.51				
118.5	4.87	143.5	5.79	168.5	6.67	193.5	7.53				
119.0	4.89	144.0	5.81	169.0	6.69	194.0	7.54				
119.5	4.91	144.5	5.83	169.5	6.71	194.5	7.56				
120.0	4.92	145.0	5.84	170.0	6.73	195.0	7.58				
120.5	4.94	145.5	5.86	170.5	6.74	195.5	7.59				
121.0	4.96	146.0	5.88	171.0	6.76	196.0	7.61				
121.5	4.98	146.5	5.90	171.5	6.78	196.5	7.63				
122.0	5.00	147.0	5.92	172.0	6.80	197.0	7.64				
122.5	5.02	147.5	5.93	172.5	6.81	197.5	7.66				
123.0	5.04	148.0	5.95	173.0	6.83	198.0	7.68				
123.5	5.06	148.5	5.97	173.5	6.85	198.5	7.69				
124.0	5.07	149.0	5.99	174.0	6.87	199.0	7.71				
124.5	5.09	149.5	6.01	174.5	6.88	199.5	7.73				
125.0	5.11	150.0	6.02	175.0	6.90	200.0	7.74				

Temperature, °F

53.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		13•0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0•5	0•00	25•5	1•10	50•5	2•16	75•5	3•18	
1•0	0•02	26•0	1•12	51•0	2•18	76•0	3•20	
1•5	0•04	26•5	1•15	51•5	2•21	76•5	3•22	
2•0	0•07	27•0	1•17	52•0	2•23	77•0	3•24	
2•5	0•09	27•5	1•19	52•5	2•25	77•5	3•26	
3•0	0•11	28•0	1•21	53•0	2•27	78•0	3•28	
3•5	0•13	28•5	1•23	53•5	2•29	78•5	3•30	
4•0	0•16	29•0	1•25	54•0	2•31	79•0	3•32	
4•5	0•18	29•5	1•28	54•5	2•33	79•5	3•34	
5•0	0•20	30•0	1•30	55•0	2•35	80•0	3•36	
5•5	0•22	30•5	1•32	55•5	2•37	80•5	3•38	
6•0	0•25	31•0	1•34	56•0	2•39	81•0	3•40	
6•5	0•27	31•5	1•36	56•5	2•41	81•5	3•42	
7•0	0•29	32•0	1•38	57•0	2•43	82•0	3•44	
7•5	0•31	32•5	1•40	57•5	2•45	82•5	3•46	
8•0	0•34	33•0	1•43	58•0	2•47	83•0	3•48	
8•5	0•36	33•5	1•45	58•5	2•49	83•5	3•50	
9•0	0•38	34•0	1•47	59•0	2•52	84•0	3•52	
9•5	0•40	34•5	1•49	59•5	2•54	84•5	3•54	
10•0	0•42	35•0	1•51	60•0	2•56	85•0	3•56	
10•5	0•45	35•5	1•53	60•5	2•58	85•5	3•58	
11•0	0•47	36•0	1•55	61•0	2•60	86•0	3•60	
11•5	0•49	36•5	1•57	61•5	2•62	86•5	3•62	
12•0	0•51	37•0	1•60	62•0	2•64	87•0	3•64	
12•5	0•53	37•5	1•62	62•5	2•66	87•5	3•66	
13•0	0•56	38•0	1•64	63•0	2•68	88•0	3•68	
13•5	0•58	38•5	1•66	63•5	2•70	88•5	3•70	
14•0	0•60	39•0	1•68	64•0	2•72	89•0	3•72	
14•5	0•62	39•5	1•70	64•5	2•74	89•5	3•74	
15•0	0•64	40•0	1•72	65•0	2•76	90•0	3•76	
15•5	0•67	40•5	1•74	65•5	2•78	90•5	3•78	
16•0	0•69	41•0	1•77	66•0	2•80	91•0	3•80	
16•5	0•71	41•5	1•79	66•5	2•82	91•5	3•82	
17•0	0•73	42•0	1•81	67•0	2•84	92•0	3•84	
17•5	0•75	42•5	1•83	67•5	2•86	92•5	3•86	
18•0	0•78	43•0	1•85	68•0	2•88	93•0	3•88	
18•5	0•80	43•5	1•87	68•5	2•90	93•5	3•90	
19•0	0•82	44•0	1•89	69•0	2•92	94•0	3•91	
19•5	0•84	44•5	1•91	69•5	2•94	94•5	3•93	
20•0	0•86	45•0	1•93	70•0	2•96	95•0	3•95	
20•5	0•89	45•5	1•95	70•5	2•98	95•5	3•97	
21•0	0•91	46•0	1•98	71•0	3•00	96•0	4•00	
21•5	0•93	46•5	2•00	71•5	3•02	96•5	4•01	
22•0	0•95	47•0	2•02	72•0	3•04	97•0	4•03	
22•5	0•97	47•5	2•04	72•5	3•06	97•5	4•05	
23•0	0•99	48•0	2•06	73•0	3•08	98•0	4•07	
23•5	1•02	48•5	2•08	73•5	3•10	98•5	4•09	
24•0	1•04	49•0	2•10	74•0	3•12	99•0	4•11	
24•5	1•06	49•5	2•12	74•5	3•14	99•5	4•13	
25•0	1•08	50•0	2•14	75•0	3•16	100•0	4•15	

Temperature, °F

55•4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				13.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	4.17	125.5	5.11	150.5	6.02	175.5	6.89
101.0	4.19	126.0	5.13	151.0	6.04	176.0	6.91
101.5	4.21	126.5	5.15	151.5	6.05	176.5	6.93
102.0	4.22	127.0	5.17	152.0	6.07	177.0	6.94
102.5	4.24	127.5	5.18	152.5	6.09	177.5	6.96
103.0	4.26	128.0	5.20	153.0	6.11	178.0	6.98
103.5	4.28	128.5	5.22	153.5	6.13	178.5	6.99
104.0	4.30	129.0	5.24	154.0	6.14	179.0	7.01
104.5	4.32	129.5	5.26	154.5	6.16	179.5	7.03
105.0	4.34	130.0	5.28	155.0	6.18	180.0	7.04
105.5	4.36	130.5	5.30	155.5	6.20	180.5	7.06
106.0	4.38	131.0	5.31	156.0	6.21	181.0	7.08
106.5	4.40	131.5	5.33	156.5	6.23	181.5	7.10
107.0	4.42	132.0	5.35	157.0	6.25	182.0	7.11
107.5	4.43	132.5	5.37	157.5	6.27	182.5	7.13
108.0	4.45	133.0	5.39	158.0	6.28	183.0	7.15
108.5	4.47	133.5	5.41	158.5	6.30	183.5	7.16
109.0	4.49	134.0	5.42	159.0	6.32	184.0	7.18
109.5	4.51	134.5	5.44	159.5	6.34	184.5	7.20
110.0	4.53	135.0	5.46	160.0	6.35	185.0	7.21
110.5	4.55	135.5	5.48	160.5	6.37	185.5	7.23
111.0	4.57	136.0	5.50	161.0	6.39	186.0	7.25
111.5	4.59	136.5	5.51	161.5	6.41	186.5	7.26
112.0	4.61	137.0	5.53	162.0	6.42	187.0	7.28
112.5	4.62	137.5	5.55	162.5	6.44	187.5	7.30
113.0	4.64	138.0	5.57	163.0	6.46	188.0	7.32
113.5	4.66	138.5	5.59	163.5	6.48	188.5	7.33
114.0	4.68	139.0	5.61	164.0	6.49	189.0	7.35
114.5	4.70	139.5	5.62	164.5	6.51	189.5	7.37
115.0	4.72	140.0	5.64	165.0	6.53	190.0	7.38
115.5	4.74	140.5	5.66	165.5	6.55	190.5	7.40
116.0	4.76	141.0	5.68	166.0	6.56	191.0	7.42
116.5	4.78	141.5	5.70	166.5	6.58	191.5	7.43
117.0	4.79	142.0	5.71	167.0	6.60	192.0	7.45
117.5	4.81	142.5	5.73	167.5	6.62	192.5	7.47
118.0	4.83	143.0	5.75	168.0	6.63	193.0	7.48
118.5	4.85	143.5	5.77	168.5	6.65	193.5	7.50
119.0	4.87	144.0	5.79	169.0	6.67	194.0	7.52
119.5	4.89	144.5	5.80	169.5	6.69	194.5	7.53
120.0	4.91	145.0	5.82	170.0	6.70	195.0	7.55
120.5	4.92	145.5	5.84	170.5	6.72	195.5	7.57
121.0	4.94	146.0	5.86	171.0	6.74	196.0	7.58
121.5	4.96	146.5	5.88	171.5	6.75	196.5	7.60
122.0	4.98	147.0	5.89	172.0	6.77	197.0	7.61
122.5	5.00	147.5	5.91	172.5	6.79	197.5	7.63
123.0	5.02	148.0	5.93	173.0	6.81	198.0	7.65
123.5	5.04	148.5	5.95	173.5	6.82	198.5	7.66
124.0	5.06	149.0	5.97	174.0	6.84	199.0	7.68
124.5	5.07	149.5	5.98	174.5	6.86	199.5	7.70
125.0	5.09	150.0	6.00	175.0	6.87	200.0	7.71

Temperature, °F

55.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

1400

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.10	50.5	2.16	75.5	3.17
1.0	0.02	26.0	1.12	51.0	2.18	76.0	3.19
1.5	0.04	26.5	1.14	51.5	2.20	76.5	3.21
2.0	0.07	27.0	1.16	52.0	2.22	77.0	3.23
2.5	0.09	27.5	1.18	52.5	2.24	77.5	3.25
3.0	0.11	28.0	1.21	53.0	2.26	78.0	3.27
3.5	0.13	28.5	1.23	53.5	2.28	78.5	3.29
4.0	0.16	29.0	1.25	54.0	2.30	79.0	3.31
4.5	0.18	29.5	1.27	54.5	2.32	79.5	3.33
5.0	0.20	30.0	1.29	55.0	2.34	80.0	3.35
5.5	0.22	30.5	1.31	55.5	2.36	80.5	3.37
6.0	0.25	31.0	1.33	56.0	2.38	81.0	3.39
6.5	0.27	31.5	1.36	56.5	2.40	81.5	3.41
7.0	0.29	32.0	1.38	57.0	2.42	82.0	3.43
7.5	0.31	32.5	1.40	57.5	2.44	82.5	3.45
8.0	0.33	33.0	1.42	58.0	2.47	83.0	3.47
8.5	0.36	33.5	1.44	58.5	2.49	83.5	3.49
9.0	0.38	34.0	1.46	59.0	2.51	84.0	3.51
9.5	0.40	34.5	1.48	59.5	2.53	84.5	3.53
10.0	0.42	35.0	1.51	60.0	2.55	85.0	3.55
10.5	0.44	35.5	1.53	60.5	2.57	85.5	3.57
11.0	0.47	36.0	1.55	61.0	2.59	86.0	3.59
11.5	0.49	36.5	1.57	61.5	2.61	86.5	3.61
12.0	0.51	37.0	1.59	62.0	2.63	87.0	3.63
12.5	0.53	37.5	1.61	62.5	2.65	87.5	3.65
13.0	0.55	38.0	1.63	63.0	2.67	88.0	3.67
13.5	0.58	38.5	1.65	63.5	2.69	88.5	3.69
14.0	0.60	39.0	1.67	64.0	2.71	89.0	3.71
14.5	0.62	39.5	1.70	64.5	2.73	89.5	3.73
15.0	0.64	40.0	1.72	65.0	2.75	90.0	3.74
15.5	0.66	40.5	1.74	65.5	2.77	90.5	3.76
16.0	0.69	41.0	1.76	66.0	2.79	91.0	3.78
16.5	0.71	41.5	1.78	66.5	2.81	91.5	3.80
17.0	0.73	42.0	1.80	67.0	2.83	92.0	3.82
17.5	0.75	42.5	1.82	67.5	2.85	92.5	3.84
18.0	0.77	43.0	1.84	68.0	2.87	93.0	3.86
18.5	0.80	43.5	1.86	68.5	2.89	93.5	3.88
19.0	0.82	44.0	1.88	69.0	2.91	94.0	3.90
19.5	0.84	44.5	1.91	69.5	2.93	94.5	3.92
20.0	0.86	45.0	1.93	70.0	2.95	95.0	3.94
20.5	0.88	45.5	1.95	70.5	2.97	95.5	3.96
21.0	0.90	46.0	1.97	71.0	2.99	96.0	3.98
21.5	0.93	46.5	1.99	71.5	3.01	96.5	4.00
22.0	0.95	47.0	2.01	72.0	3.03	97.0	4.02
22.5	0.97	47.5	2.03	72.5	3.05	97.5	4.04
23.0	0.99	48.0	2.05	73.0	3.07	98.0	4.05
23.5	1.01	48.5	2.07	73.5	3.09	98.5	4.07
24.0	1.03	49.0	2.09	74.0	3.11	99.0	4.09
24.5	1.06	49.5	2.11	74.5	3.13	99.5	4.11
25.0	1.08	50.0	2.13	75.0	3.15	100.0	4.13

Temperature, °F

57.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 14.0

atü	- kg						
100.5	4.15	125.5	5.09	150.5	6.00	175.5	6.87
101.0	4.17	126.0	5.11	151.0	6.01	176.0	6.88
101.5	4.19	126.5	5.13	151.5	6.03	176.5	6.90
102.0	4.21	127.0	5.15	152.0	6.05	177.0	6.92
102.5	4.23	127.5	5.17	152.5	6.07	177.5	6.93
103.0	4.25	128.0	5.18	153.0	6.09	178.0	6.95
103.5	4.27	128.5	5.20	153.5	6.10	178.5	6.97
104.0	4.29	129.0	5.22	154.0	6.12	179.0	6.99
104.5	4.30	129.5	5.24	154.5	6.14	179.5	7.00
105.0	4.32	130.0	5.26	155.0	6.16	180.0	7.02
105.5	4.34	130.5	5.28	155.5	6.17	180.5	7.04
106.0	4.36	131.0	5.29	156.0	6.19	181.0	7.05
106.5	4.38	131.5	5.31	156.5	6.21	181.5	7.07
107.0	4.40	132.0	5.33	157.0	6.23	182.0	7.09
107.5	4.42	132.5	5.35	157.5	6.24	182.5	7.10
108.0	4.44	133.0	5.37	158.0	6.26	183.0	7.12
108.5	4.46	133.5	5.39	158.5	6.28	183.5	7.14
109.0	4.48	134.0	5.40	159.0	6.30	184.0	7.15
109.5	4.49	134.5	5.42	159.5	6.31	184.5	7.17
110.0	4.51	135.0	5.44	160.0	6.33	185.0	7.19
110.5	4.53	135.5	5.46	160.5	6.35	185.5	7.20
111.0	4.55	136.0	5.48	161.0	6.37	186.0	7.22
111.5	4.57	136.5	5.49	161.5	6.38	186.5	7.24
112.0	4.59	137.0	5.51	162.0	6.40	187.0	7.25
112.5	4.61	137.5	5.53	162.5	6.42	187.5	7.27
113.0	4.63	138.0	5.55	163.0	6.44	188.0	7.29
113.5	4.64	138.5	5.57	163.5	6.45	188.5	7.31
114.0	4.66	139.0	5.58	164.0	6.47	189.0	7.32
114.5	4.68	139.5	5.60	164.5	6.49	189.5	7.34
115.0	4.70	140.0	5.62	165.0	6.51	190.0	7.36
115.5	4.72	140.5	5.64	165.5	6.52	190.5	7.37
116.0	4.74	141.0	5.66	166.0	6.54	191.0	7.39
116.5	4.76	141.5	5.68	166.5	6.56	191.5	7.41
117.0	4.78	142.0	5.69	167.0	6.57	192.0	7.42
117.5	4.79	142.5	5.71	167.5	6.59	192.5	7.44
118.0	4.81	143.0	5.73	168.0	6.61	193.0	7.45
118.5	4.83	143.5	5.75	168.5	6.63	193.5	7.47
119.0	4.85	144.0	5.76	169.0	6.64	194.0	7.49
119.5	4.87	144.5	5.78	169.5	6.66	194.5	7.50
120.0	4.89	145.0	5.80	170.0	6.68	195.0	7.52
120.5	4.91	145.5	5.82	170.5	6.70	195.5	7.54
121.0	4.93	146.0	5.84	171.0	6.71	196.0	7.55
121.5	4.94	146.5	5.85	171.5	6.73	196.5	7.57
122.0	4.96	147.0	5.87	172.0	6.75	197.0	7.59
122.5	4.98	147.5	5.89	172.5	6.76	197.5	7.60
123.0	5.00	148.0	5.91	173.0	6.78	198.0	7.62
123.5	5.02	148.5	5.93	173.5	6.80	198.5	7.64
124.0	5.04	149.0	5.94	174.0	6.82	199.0	7.65
124.5	5.06	149.5	5.96	174.5	6.83	199.5	7.67
125.0	5.07	150.0	5.98	175.0	6.85	200.0	7.69

Temperature, °F

57.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		15.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.09	50.5	2.15	75.5	3.16	
1.0	0.02	26.0	1.12	51.0	2.17	76.0	3.18	
1.5	0.04	26.5	1.14	51.5	2.19	76.5	3.20	
2.0	0.07	27.0	1.16	52.0	2.21	77.0	3.22	
2.5	0.09	27.5	1.18	52.5	2.23	77.5	3.24	
3.0	0.11	28.0	1.20	53.0	2.25	78.0	3.26	
3.5	0.13	28.5	1.22	53.5	2.27	78.5	3.28	
4.0	0.16	29.0	1.24	54.0	2.29	79.0	3.30	
4.5	0.18	29.5	1.27	54.5	2.31	79.5	3.32	
5.0	0.20	30.0	1.29	55.0	2.33	80.0	3.34	
5.5	0.22	30.5	1.31	55.5	2.35	80.5	3.36	
6.0	0.24	31.0	1.33	56.0	2.37	81.0	3.38	
6.5	0.27	31.5	1.35	56.5	2.39	81.5	3.40	
7.0	0.29	32.0	1.37	57.0	2.41	82.0	3.42	
7.5	0.31	32.5	1.39	57.5	2.44	82.5	3.44	
8.0	0.33	33.0	1.41	58.0	2.46	83.0	3.46	
8.5	0.35	33.5	1.44	58.5	2.48	83.5	3.48	
9.0	0.38	34.0	1.46	59.0	2.50	84.0	3.50	
9.5	0.40	34.5	1.48	59.5	2.52	84.5	3.52	
10.0	0.42	35.0	1.50	60.0	2.54	85.0	3.54	
10.5	0.44	35.5	1.52	60.5	2.56	85.5	3.56	
11.0	0.46	36.0	1.54	61.0	2.58	86.0	3.57	
11.5	0.49	36.5	1.56	61.5	2.60	86.5	3.59	
12.0	0.51	37.0	1.58	62.0	2.62	87.0	3.61	
12.5	0.53	37.5	1.61	62.5	2.64	87.5	3.63	
13.0	0.55	38.0	1.63	63.0	2.66	88.0	3.65	
13.5	0.57	38.5	1.65	63.5	2.68	88.5	3.67	
14.0	0.60	39.0	1.67	64.0	2.70	89.0	3.69	
14.5	0.62	39.5	1.69	64.5	2.72	89.5	3.71	
15.0	0.64	40.0	1.71	65.0	2.74	90.0	3.73	
15.5	0.66	40.5	1.73	65.5	2.76	90.5	3.75	
16.0	0.68	41.0	1.75	66.0	2.78	91.0	3.77	
16.5	0.71	41.5	1.77	66.5	2.80	91.5	3.79	
17.0	0.73	42.0	1.79	67.0	2.82	92.0	3.81	
17.5	0.75	42.5	1.82	67.5	2.84	92.5	3.83	
18.0	0.77	43.0	1.84	68.0	2.86	93.0	3.85	
18.5	0.79	43.5	1.86	68.5	2.88	93.5	3.87	
19.0	0.81	44.0	1.88	69.0	2.90	94.0	3.89	
19.5	0.84	44.5	1.90	69.5	2.92	94.5	3.91	
20.0	0.86	45.0	1.92	70.0	2.94	95.0	3.92	
20.5	0.88	45.5	1.94	70.5	2.96	95.5	3.94	
21.0	0.90	46.0	1.96	71.0	2.98	96.0	3.96	
21.5	0.92	46.5	1.98	71.5	3.00	96.5	3.98	
22.0	0.94	47.0	2.00	72.0	3.02	97.0	4.00	
22.5	0.97	47.5	2.02	72.5	3.04	97.5	4.02	
23.0	0.99	48.0	2.04	73.0	3.06	98.0	4.04	
23.5	1.01	48.5	2.06	73.5	3.08	98.5	4.06	
24.0	1.03	49.0	2.09	74.0	3.10	99.0	4.08	
24.5	1.05	49.5	2.11	74.5	3.12	99.5	4.10	
25.0	1.07	50.0	2.13	75.0	3.14	100.0	4.12	

Temperature, °F

59.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				15.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.14	125.5	5.07	150.5	5.97	175.5	6.84				
101.0	4.15	126.0	5.09	151.0	5.99	176.0	6.86				
101.5	4.17	126.5	5.11	151.5	6.01	176.5	6.88				
102.0	4.19	127.0	5.13	152.0	6.03	177.0	6.89				
102.5	4.21	127.5	5.15	152.5	6.05	177.5	6.91				
103.0	4.23	128.0	5.16	153.0	6.06	178.0	6.93				
103.5	4.25	128.5	5.18	153.5	6.08	178.5	6.94				
104.0	4.27	129.0	5.20	154.0	6.10	179.0	6.96				
104.5	4.29	129.5	5.22	154.5	6.12	179.5	6.98				
105.0	4.31	130.0	5.24	155.0	6.13	180.0	6.99				
105.5	4.33	130.5	5.26	155.5	6.15	180.5	7.01				
106.0	4.35	131.0	5.27	156.0	6.17	181.0	7.03				
106.5	4.36	131.5	5.29	156.5	6.19	181.5	7.04				
107.0	4.38	132.0	5.31	157.0	6.20	182.0	7.06				
107.5	4.40	132.5	5.33	157.5	6.22	182.5	7.08				
108.0	4.42	133.0	5.35	158.0	6.24	183.0	7.09				
108.5	4.44	133.5	5.37	158.5	6.26	183.5	7.11				
109.0	4.46	134.0	5.38	159.0	6.27	184.0	7.13				
109.5	4.48	134.5	5.40	159.5	6.29	184.5	7.14				
110.0	4.50	135.0	5.42	160.0	6.31	185.0	7.16				
110.5	4.52	135.5	5.44	160.5	6.33	185.5	7.18				
111.0	4.53	136.0	5.46	161.0	6.34	186.0	7.20				
111.5	4.55	136.5	5.47	161.5	6.36	186.5	7.21				
112.0	4.57	137.0	5.49	162.0	6.38	187.0	7.23				
112.5	4.59	137.5	5.51	162.5	6.39	187.5	7.25				
113.0	4.61	138.0	5.53	163.0	6.41	188.0	7.26				
113.5	4.63	138.5	5.55	163.5	6.43	188.5	7.28				
114.0	4.65	139.0	5.56	164.0	6.45	189.0	7.30				
114.5	4.67	139.5	5.58	164.5	6.46	189.5	7.31				
115.0	4.68	140.0	5.60	165.0	6.48	190.0	7.33				
115.5	4.70	140.5	5.62	165.5	6.50	190.5	7.35				
116.0	4.72	141.0	5.64	166.0	6.52	191.0	7.36				
116.5	4.74	141.5	5.65	166.5	6.53	191.5	7.38				
117.0	4.76	142.0	5.67	167.0	6.55	192.0	7.39				
117.5	4.78	142.5	5.69	167.5	6.57	192.5	7.41				
118.0	4.80	143.0	5.71	168.0	6.58	193.0	7.43				
118.5	4.81	143.5	5.73	168.5	6.60	193.5	7.44				
119.0	4.83	144.0	5.74	169.0	6.62	194.0	7.46				
119.5	4.85	144.5	5.76	169.5	6.64	194.5	7.48				
120.0	4.87	145.0	5.78	170.0	6.65	195.0	7.49				
120.5	4.89	145.5	5.80	170.5	6.67	195.5	7.51				
121.0	4.91	146.0	5.81	171.0	6.69	196.0	7.53				
121.5	4.93	146.5	5.83	171.5	6.70	196.5	7.54				
122.0	4.94	147.0	5.85	172.0	6.72	197.0	7.56				
122.5	4.96	147.5	5.87	172.5	6.74	197.5	7.58				
123.0	4.98	148.0	5.89	173.0	6.76	198.0	7.59				
123.5	5.00	148.5	5.90	173.5	6.77	198.5	7.61				
124.0	5.02	149.0	5.92	174.0	6.79	199.0	7.63				
124.5	5.04	149.5	5.94	174.5	6.81	199.5	7.64				
125.0	5.05	150.0	5.96	175.0	6.82	200.0	7.66				

Temperature, °F 59.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								16.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.09	50.5	2.14	75.5	3.15	
1.0	0.02	26.0	1.11	51.0	2.16	76.0	3.17	
1.5	0.04	26.5	1.13	51.5	2.18	76.5	3.19	
2.0	0.07	27.0	1.15	52.0	2.20	77.0	3.21	
2.5	0.09	27.5	1.18	52.5	2.22	77.5	3.23	
3.0	0.11	28.0	1.20	53.0	2.24	78.0	3.25	
3.5	0.13	28.5	1.22	53.5	2.26	78.5	3.27	
4.0	0.16	29.0	1.24	54.0	2.28	79.0	3.29	
4.5	0.18	29.5	1.26	54.5	2.30	79.5	3.31	
5.0	0.20	30.0	1.28	55.0	2.32	80.0	3.33	
5.5	0.22	30.5	1.30	55.5	2.34	80.5	3.35	
6.0	0.24	31.0	1.32	56.0	2.37	81.0	3.37	
6.5	0.27	31.5	1.35	56.5	2.39	81.5	3.39	
7.0	0.29	32.0	1.37	57.0	2.41	82.0	3.41	
7.5	0.31	32.5	1.39	57.5	2.43	82.5	3.42	
8.0	0.33	33.0	1.41	58.0	2.45	83.0	3.44	
8.5	0.35	33.5	1.43	58.5	2.47	83.5	3.46	
9.0	0.38	34.0	1.45	59.0	2.49	84.0	3.48	
9.5	0.40	34.5	1.47	59.5	2.51	84.5	3.50	
10.0	0.42	35.0	1.49	60.0	2.53	85.0	3.52	
10.5	0.44	35.5	1.51	60.5	2.55	85.5	3.54	
11.0	0.46	36.0	1.54	61.0	2.57	86.0	3.56	
11.5	0.48	36.5	1.56	61.5	2.59	86.5	3.58	
12.0	0.51	37.0	1.58	62.0	2.61	87.0	3.60	
12.5	0.53	37.5	1.60	62.5	2.63	87.5	3.62	
13.0	0.55	38.0	1.62	63.0	2.65	88.0	3.64	
13.5	0.57	38.5	1.64	63.5	2.67	88.5	3.66	
14.0	0.59	39.0	1.66	64.0	2.69	89.0	3.68	
14.5	0.62	39.5	1.68	64.5	2.71	89.5	3.70	
15.0	0.64	40.0	1.70	65.0	2.73	90.0	3.72	
15.5	0.66	40.5	1.72	65.5	2.75	90.5	3.74	
16.0	0.68	41.0	1.75	66.0	2.77	91.0	3.76	
16.5	0.70	41.5	1.77	66.5	2.79	91.5	3.78	
17.0	0.72	42.0	1.79	67.0	2.81	92.0	3.79	
17.5	0.75	42.5	1.81	67.5	2.83	92.5	3.81	
18.0	0.77	43.0	1.83	68.0	2.85	93.0	3.83	
18.5	0.79	43.5	1.85	68.5	2.87	93.5	3.85	
19.0	0.81	44.0	1.87	69.0	2.89	94.0	3.87	
19.5	0.83	44.5	1.89	69.5	2.91	94.5	3.89	
20.0	0.85	45.0	1.91	70.0	2.93	95.0	3.91	
20.5	0.88	45.5	1.93	70.5	2.95	95.5	3.93	
21.0	0.90	46.0	1.95	71.0	2.97	96.0	3.95	
21.5	0.92	46.5	1.97	71.5	2.99	96.5	3.97	
22.0	0.94	47.0	2.00	72.0	3.01	97.0	3.99	
22.5	0.96	47.5	2.02	72.5	3.03	97.5	4.01	
23.0	0.98	48.0	2.04	73.0	3.05	98.0	4.02	
23.5	1.00	48.5	2.06	73.5	3.07	98.5	4.04	
24.0	1.03	49.0	2.08	74.0	3.09	99.0	4.06	
24.5	1.05	49.5	2.10	74.5	3.11	99.5	4.08	
25.0	1.07	50.0	2.12	75.0	3.13	100.0	4.10	

Temperature, °F

60.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

16•0

atü	- kg						
100•5	4•12	125•5	5•05	150•5	5•95	175•5	6•82
101•0	4•14	126•0	5•07	151•0	5•97	176•0	6•83
101•5	4•16	126•5	5•09	151•5	5•99	176•5	6•85
102•0	4•18	127•0	5•11	152•0	6•01	177•0	6•87
102•5	4•20	127•5	5•13	152•5	6•02	177•5	6•88
103•0	4•22	128•0	5•15	153•0	6•04	178•0	6•90
103•5	4•23	128•5	5•16	153•5	6•06	178•5	6•92
104•0	4•25	129•0	5•18	154•0	6•08	179•0	6•93
104•5	4•27	129•5	5•20	154•5	6•09	179•5	6•95
105•0	4•29	130•0	5•22	155•0	6•11	180•0	6•97
105•5	4•31	130•5	5•24	155•5	6•13	180•5	6•98
106•0	4•33	131•0	5•25	156•0	6•15	181•0	7•00
106•5	4•35	131•5	5•27	156•5	6•16	181•5	7•02
107•0	4•37	132•0	5•29	157•0	6•18	182•0	7•04
107•5	4•39	132•5	5•31	157•5	6•20	182•5	7•05
108•0	4•40	133•0	5•33	158•0	6•22	183•0	7•07
108•5	4•42	133•5	5•35	158•5	6•23	183•5	7•09
109•0	4•44	134•0	5•36	159•0	6•25	184•0	7•10
109•5	4•46	134•5	5•38	159•5	6•27	184•5	7•12
110•0	4•48	135•0	5•40	160•0	6•28	185•0	7•14
110•5	4•50	135•5	5•42	160•5	6•30	185•5	7•15
111•0	4•52	136•0	5•44	161•0	6•32	186•0	7•17
111•5	4•54	136•5	5•45	161•5	6•34	186•5	7•19
112•0	4•55	137•0	5•47	162•0	6•35	187•0	7•20
112•5	4•57	137•5	5•49	162•5	6•37	187•5	7•22
113•0	4•59	138•0	5•51	163•0	6•39	188•0	7•24
113•5	4•61	138•5	5•53	163•5	6•41	188•5	7•25
114•0	4•63	139•0	5•54	164•0	6•42	189•0	7•27
114•5	4•65	139•5	5•56	164•5	6•44	189•5	7•29
115•0	4•67	140•0	5•58	165•0	6•46	190•0	7•30
115•5	4•69	140•5	5•60	165•5	6•47	190•5	7•32
116•0	4•70	141•0	5•62	166•0	6•49	191•0	7•33
116•5	4•72	141•5	5•63	166•5	6•51	191•5	7•35
117•0	4•74	142•0	5•65	167•0	6•53	192•0	7•37
117•5	4•76	142•5	5•67	167•5	6•54	192•5	7•38
118•0	4•78	143•0	5•69	168•0	6•56	193•0	7•40
118•5	4•80	143•5	5•70	168•5	6•58	193•5	7•42
119•0	4•81	144•0	5•72	169•0	6•59	194•0	7•43
119•5	4•83	144•5	5•74	169•5	6•61	194•5	7•45
120•0	4•85	145•0	5•76	170•0	6•63	195•0	7•47
120•5	4•87	145•5	5•78	170•5	6•65	195•5	7•48
121•0	4•89	146•0	5•79	171•0	6•66	196•0	7•50
121•5	4•91	146•5	5•81	171•5	6•68	196•5	7•52
122•0	4•93	147•0	5•83	172•0	6•70	197•0	7•53
122•5	4•94	147•5	5•85	172•5	6•71	197•5	7•55
123•0	4•96	148•0	5•86	173•0	6•73	198•0	7•56
123•5	4•98	148•5	5•88	173•5	6•75	198•5	7•58
124•0	5•00	149•0	5•90	174•0	6•77	199•0	7•60
124•5	5•02	149•5	5•92	174•5	6•78	199•5	7•61
125•0	5•04	150•0	5•93	175•0	6•80	200•0	7•63

Temperature, °F

60•8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

17.0
Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.09	50.5	2.13	75.5	3.14
1.0	0.02	26.0	1.11	51.0	2.15	76.0	3.16
1.5	0.04	26.5	1.13	51.5	2.17	76.5	3.18
2.0	0.07	27.0	1.15	52.0	2.19	77.0	3.20
2.5	0.09	27.5	1.17	52.5	2.21	77.5	3.22
3.0	0.11	28.0	1.19	53.0	2.23	78.0	3.24
3.5	0.13	28.5	1.21	53.5	2.25	78.5	3.26
4.0	0.15	29.0	1.24	54.0	2.27	79.0	3.28
4.5	0.18	29.5	1.26	54.5	2.30	79.5	3.29
5.0	0.20	30.0	1.28	55.0	2.32	80.0	3.31
5.5	0.22	30.5	1.30	55.5	2.34	80.5	3.33
6.0	0.24	31.0	1.32	56.0	2.36	81.0	3.35
6.5	0.26	31.5	1.34	56.5	2.38	81.5	3.37
7.0	0.29	32.0	1.36	57.0	2.40	82.0	3.39
7.5	0.31	32.5	1.38	57.5	2.42	82.5	3.41
8.0	0.33	33.0	1.40	58.0	2.44	83.0	3.43
8.5	0.35	33.5	1.43	58.5	2.46	83.5	3.45
9.0	0.37	34.0	1.45	59.0	2.48	84.0	3.47
9.5	0.40	34.5	1.47	59.5	2.50	84.5	3.49
10.0	0.42	35.0	1.49	60.0	2.52	85.0	3.51
10.5	0.44	35.5	1.51	60.5	2.54	85.5	3.53
11.0	0.46	36.0	1.53	61.0	2.56	86.0	3.55
11.5	0.48	36.5	1.55	61.5	2.58	86.5	3.57
12.0	0.50	37.0	1.57	62.0	2.60	87.0	3.59
12.5	0.53	37.5	1.59	62.5	2.62	87.5	3.61
13.0	0.55	38.0	1.61	63.0	2.64	88.0	3.63
13.5	0.57	38.5	1.63	63.5	2.66	88.5	3.65
14.0	0.59	39.0	1.66	64.0	2.68	89.0	3.66
14.5	0.61	39.5	1.68	64.5	2.70	89.5	3.68
15.0	0.64	40.0	1.70	65.0	2.72	90.0	3.70
15.5	0.66	40.5	1.72	65.5	2.74	90.5	3.72
16.0	0.68	41.0	1.74	66.0	2.76	91.0	3.74
16.5	0.70	41.5	1.76	66.5	2.78	91.5	3.76
17.0	0.72	42.0	1.78	67.0	2.80	92.0	3.78
17.5	0.74	42.5	1.80	67.5	2.82	92.5	3.80
18.0	0.76	43.0	1.82	68.0	2.84	93.0	3.82
18.5	0.79	43.5	1.84	68.5	2.86	93.5	3.84
19.0	0.81	44.0	1.86	69.0	2.88	94.0	3.86
19.5	0.83	44.5	1.88	69.5	2.90	94.5	3.88
20.0	0.85	45.0	1.91	70.0	2.92	95.0	3.90
20.5	0.87	45.5	1.93	70.5	2.94	95.5	3.91
21.0	0.89	46.0	1.95	71.0	2.96	96.0	3.93
21.5	0.92	46.5	1.97	71.5	2.98	96.5	3.95
22.0	0.94	47.0	1.99	72.0	3.00	97.0	3.97
22.5	0.96	47.5	2.01	72.5	3.02	97.5	3.99
23.0	0.98	48.0	2.03	73.0	3.04	98.0	4.01
23.5	1.00	48.5	2.05	73.5	3.06	98.5	4.03
24.0	1.02	49.0	2.07	74.0	3.08	99.0	4.05
24.5	1.04	49.5	2.09	74.5	3.10	99.5	4.07
25.0	1.06	50.0	2.11	75.0	3.12	100.0	4.09

Temperature, °F 62.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 17.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.10	125.5	5.04	150.5	5.93	175.5	6.79				
101.0	4.12	126.0	5.05	151.0	5.95	176.0	6.81				
101.5	4.14	126.5	5.07	151.5	5.97	176.5	6.82				
102.0	4.16	127.0	5.09	152.0	5.98	177.0	6.84				
102.5	4.18	127.5	5.11	152.5	6.00	177.5	6.86				
103.0	4.20	128.0	5.13	153.0	6.02	178.0	6.88				
103.5	4.22	128.5	5.14	153.5	6.04	178.5	6.89				
104.0	4.24	129.0	5.16	154.0	6.05	179.0	6.91				
104.5	4.26	129.5	5.18	154.5	6.07	179.5	6.93				
105.0	4.28	130.0	5.20	155.0	6.09	180.0	6.94				
105.5	4.29	130.5	5.22	155.5	6.11	180.5	6.96				
106.0	4.31	131.0	5.24	156.0	6.12	181.0	6.98				
106.5	4.33	131.5	5.25	156.5	6.14	181.5	6.99				
107.0	4.35	132.0	5.27	157.0	6.16	182.0	7.01				
107.5	4.37	132.5	5.29	157.5	6.17	182.5	7.03				
108.0	4.39	133.0	5.31	158.0	6.19	183.0	7.04				
108.5	4.41	133.5	5.33	158.5	6.21	183.5	7.06				
109.0	4.43	134.0	5.34	159.0	6.23	184.0	7.08				
109.5	4.44	134.5	5.36	159.5	6.24	184.5	7.09				
110.0	4.46	135.0	5.38	160.0	6.26	185.0	7.11				
110.5	4.48	135.5	5.40	160.5	6.28	185.5	7.13				
111.0	4.50	136.0	5.42	161.0	6.30	186.0	7.14				
111.5	4.52	136.5	5.43	161.5	6.31	186.5	7.16				
112.0	4.54	137.0	5.45	162.0	6.33	187.0	7.18				
112.5	4.56	137.5	5.47	162.5	6.35	187.5	7.19				
113.0	4.57	138.0	5.49	163.0	6.37	188.0	7.21				
113.5	4.59	138.5	5.51	163.5	6.38	188.5	7.23				
114.0	4.61	139.0	5.52	164.0	6.40	189.0	7.24				
114.5	4.63	139.5	5.54	164.5	6.42	189.5	7.26				
115.0	4.65	140.0	5.56	165.0	6.43	190.0	7.27				
115.5	4.67	140.5	5.58	165.5	6.45	190.5	7.29				
116.0	4.69	141.0	5.59	166.0	6.47	191.0	7.31				
116.5	4.70	141.5	5.61	166.5	6.49	191.5	7.32				
117.0	4.72	142.0	5.63	167.0	6.50	192.0	7.34				
117.5	4.74	142.5	5.65	167.5	6.52	192.5	7.36				
118.0	4.76	143.0	5.67	168.0	6.54	193.0	7.37				
118.5	4.78	143.5	5.68	168.5	6.55	193.5	7.39				
119.0	4.80	144.0	5.70	169.0	6.57	194.0	7.41				
119.5	4.82	144.5	5.72	169.5	6.59	194.5	7.42				
120.0	4.83	145.0	5.74	170.0	6.60	195.0	7.44				
120.5	4.85	145.5	5.75	170.5	6.62	195.5	7.46				
121.0	4.87	146.0	5.77	171.0	6.64	196.0	7.47				
121.5	4.89	146.5	5.79	171.5	6.66	196.5	7.49				
122.0	4.91	147.0	5.81	172.0	6.67	197.0	7.50				
122.5	4.93	147.5	5.82	172.5	6.69	197.5	7.52				
123.0	4.94	148.0	5.84	173.0	6.71	198.0	7.54				
123.5	4.96	148.5	5.86	173.5	6.72	198.5	7.55				
124.0	4.98	149.0	5.88	174.0	6.74	199.0	7.57				
124.5	5.00	149.5	5.90	174.5	6.76	199.5	7.59				
125.0	5.02	150.0	5.91	175.0	6.77	200.0	7.60				

Temperature, °F

62.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

18.0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.08	50.5	2.12	75.5	3.13
1.0	0.02	26.0	1.10	51.0	2.14	76.0	3.15
1.5	0.04	26.5	1.12	51.5	2.16	76.5	3.16
2.0	0.07	27.0	1.15	52.0	2.18	77.0	3.18
2.5	0.09	27.5	1.17	52.5	2.21	77.5	3.20
3.0	0.11	28.0	1.19	53.0	2.23	78.0	3.22
3.5	0.13	28.5	1.21	53.5	2.25	78.5	3.24
4.0	0.15	29.0	1.23	54.0	2.27	79.0	3.26
4.5	0.18	29.5	1.25	54.5	2.29	79.5	3.28
5.0	0.20	30.0	1.27	55.0	2.31	80.0	3.30
5.5	0.22	30.5	1.29	55.5	2.33	80.5	3.32
6.0	0.24	31.0	1.31	56.0	2.35	81.0	3.34
6.5	0.26	31.5	1.34	56.5	2.37	81.5	3.36
7.0	0.29	32.0	1.36	57.0	2.39	82.0	3.38
7.5	0.31	32.5	1.38	57.5	2.41	82.5	3.40
8.0	0.33	33.0	1.40	58.0	2.43	83.0	3.42
8.5	0.35	33.5	1.42	58.5	2.45	83.5	3.44
9.0	0.37	34.0	1.44	59.0	2.47	84.0	3.46
9.5	0.39	34.5	1.46	59.5	2.49	84.5	3.48
10.0	0.42	35.0	1.48	60.0	2.51	85.0	3.50
10.5	0.44	35.5	1.50	60.5	2.53	85.5	3.52
11.0	0.46	36.0	1.52	61.0	2.55	86.0	3.54
11.5	0.48	36.5	1.55	61.5	2.57	86.5	3.55
12.0	0.50	37.0	1.57	62.0	2.59	87.0	3.57
12.5	0.52	37.5	1.59	62.5	2.61	87.5	3.59
13.0	0.55	38.0	1.61	63.0	2.63	88.0	3.61
13.5	0.57	38.5	1.63	63.5	2.65	88.5	3.63
14.0	0.59	39.0	1.65	64.0	2.67	89.0	3.65
14.5	0.61	39.5	1.67	64.5	2.69	89.5	3.67
15.0	0.63	40.0	1.69	65.0	2.71	90.0	3.69
15.5	0.65	40.5	1.71	65.5	2.73	90.5	3.71
16.0	0.68	41.0	1.73	66.0	2.75	91.0	3.73
16.5	0.70	41.5	1.75	66.5	2.77	91.5	3.75
17.0	0.72	42.0	1.77	67.0	2.79	92.0	3.77
17.5	0.74	42.5	1.79	67.5	2.81	92.5	3.79
18.0	0.76	43.0	1.82	68.0	2.83	93.0	3.80
18.5	0.78	43.5	1.84	68.5	2.85	93.5	3.82
19.0	0.80	44.0	1.86	69.0	2.87	94.0	3.84
19.5	0.83	44.5	1.88	69.5	2.89	94.5	3.86
20.0	0.85	45.0	1.90	70.0	2.91	95.0	3.88
20.5	0.87	45.5	1.92	70.5	2.93	95.5	3.90
21.0	0.89	46.0	1.94	71.0	2.95	96.0	3.92
21.5	0.91	46.5	1.96	71.5	2.97	96.5	3.94
22.0	0.93	47.0	1.98	72.0	2.99	97.0	3.96
22.5	0.95	47.5	2.00	72.5	3.01	97.5	3.98
23.0	0.98	48.0	2.02	73.0	3.03	98.0	3.99
23.5	1.00	48.5	2.04	73.5	3.05	98.5	4.01
24.0	1.02	49.0	2.06	74.0	3.07	99.0	4.03
24.5	1.04	49.5	2.08	74.5	3.09	99.5	4.05
25.0	1.06	50.0	2.10	75.0	3.11	100.0	4.07

Temperature, °F

64.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C

18.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.09	125.5	5.02	150.5	5.91	175.5	6.77				
101.0	4.11	126.0	5.03	151.0	5.93	176.0	6.78				
101.5	4.13	126.5	5.05	151.5	5.94	176.5	6.80				
102.0	4.15	127.0	5.07	152.0	5.96	177.0	6.82				
102.5	4.17	127.5	5.09	152.5	5.98	177.5	6.83				
103.0	4.18	128.0	5.11	153.0	6.00	178.0	6.85				
103.5	4.20	128.5	5.13	153.5	6.01	178.5	6.87				
104.0	4.22	129.0	5.14	154.0	6.03	179.0	6.88				
104.5	4.24	129.5	5.16	154.5	6.05	179.5	6.90				
105.0	4.26	130.0	5.18	155.0	6.07	180.0	6.92				
105.5	4.28	130.5	5.20	155.5	6.08	180.5	6.93				
106.0	4.30	131.0	5.22	156.0	6.10	181.0	6.95				
106.5	4.32	131.5	5.23	156.5	6.12	181.5	6.97				
107.0	4.33	132.0	5.25	157.0	6.13	182.0	6.98				
107.5	4.35	132.5	5.27	157.5	6.15	182.5	7.00				
108.0	4.37	133.0	5.29	158.0	6.17	183.0	7.02				
108.5	4.39	133.5	5.31	158.5	6.19	183.5	7.03				
109.0	4.41	134.0	5.32	159.0	6.20	184.0	7.05				
109.5	4.43	134.5	5.34	159.5	6.22	184.5	7.07				
110.0	4.45	135.0	5.36	160.0	6.24	185.0	7.08				
110.5	4.46	135.5	5.38	160.5	6.26	185.5	7.10				
111.0	4.48	136.0	5.40	161.0	6.27	186.0	7.12				
111.5	4.50	136.5	5.41	161.5	6.29	186.5	7.13				
112.0	4.52	137.0	5.43	162.0	6.31	187.0	7.15				
112.5	4.54	137.5	5.45	162.5	6.32	187.5	7.17				
113.0	4.56	138.0	5.47	163.0	6.34	188.0	7.18				
113.5	4.58	138.5	5.48	163.5	6.36	188.5	7.20				
114.0	4.59	139.0	5.50	164.0	6.38	189.0	7.22				
114.5	4.61	139.5	5.52	164.5	6.39	189.5	7.23				
115.0	4.63	140.0	5.54	165.0	6.41	190.0	7.25				
115.5	4.65	140.5	5.56	165.5	6.43	190.5	7.26				
116.0	4.67	141.0	5.57	166.0	6.44	191.0	7.28				
116.5	4.69	141.5	5.59	166.5	6.46	191.5	7.30				
117.0	4.71	142.0	5.61	167.0	6.48	192.0	7.31				
117.5	4.72	142.5	5.63	167.5	6.50	192.5	7.33				
118.0	4.74	143.0	5.64	168.0	6.51	193.0	7.35				
118.5	4.76	143.5	5.66	168.5	6.53	193.5	7.36				
119.0	4.78	144.0	5.68	169.0	6.55	194.0	7.38				
119.5	4.80	144.5	5.70	169.5	6.56	194.5	7.40				
120.0	4.82	145.0	5.72	170.0	6.58	195.0	7.41				
120.5	4.83	145.5	5.73	170.5	6.60	195.5	7.43				
121.0	4.85	146.0	5.75	171.0	6.61	196.0	7.44				
121.5	4.87	146.5	5.77	171.5	6.63	196.5	7.46				
122.0	4.89	147.0	5.79	172.0	6.65	197.0	7.48				
122.5	4.91	147.5	5.80	172.5	6.67	197.5	7.49				
123.0	4.93	148.0	5.82	173.0	6.68	198.0	7.51				
123.5	4.94	148.5	5.84	173.5	6.70	198.5	7.53				
124.0	4.96	149.0	5.86	174.0	6.72	199.0	7.54				
124.5	4.98	149.5	5.87	174.5	6.73	199.5	7.56				
125.0	5.00	150.0	5.89	175.0	6.75	200.0	7.57				

Temperature, °F

64.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 19.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.08	50.5	2.12	75.5	3.11
1.0	0.02	26.0	1.10	51.0	2.14	76.0	3.13
1.5	0.04	26.5	1.12	51.5	2.16	76.5	3.15
2.0	0.07	27.0	1.14	52.0	2.18	77.0	3.17
2.5	0.09	27.5	1.16	52.5	2.20	77.5	3.19
3.0	0.11	28.0	1.18	53.0	2.22	78.0	3.21
3.5	0.13	28.5	1.20	53.5	2.24	78.5	3.23
4.0	0.15	29.0	1.23	54.0	2.26	79.0	3.25
4.5	0.18	29.5	1.25	54.5	2.28	79.5	3.27
5.0	0.20	30.0	1.27	55.0	2.30	80.0	3.29
5.5	0.22	30.5	1.29	55.5	2.32	80.5	3.31
6.0	0.24	31.0	1.31	56.0	2.34	81.0	3.33
6.5	0.26	31.5	1.33	56.5	2.36	81.5	3.35
7.0	0.28	32.0	1.35	57.0	2.38	82.0	3.37
7.5	0.31	32.5	1.37	57.5	2.40	82.5	3.39
8.0	0.33	33.0	1.39	58.0	2.42	83.0	3.41
8.5	0.35	33.5	1.41	58.5	2.44	83.5	3.43
9.0	0.37	34.0	1.44	59.0	2.46	84.0	3.44
9.5	0.39	34.5	1.46	59.5	2.48	84.5	3.46
10.0	0.41	35.0	1.48	60.0	2.50	85.0	3.48
10.5	0.44	35.5	1.50	60.5	2.52	85.5	3.50
11.0	0.46	36.0	1.52	61.0	2.54	86.0	3.52
11.5	0.48	36.5	1.54	61.5	2.56	86.5	3.54
12.0	0.50	37.0	1.56	62.0	2.58	87.0	3.56
12.5	0.52	37.5	1.58	62.5	2.60	87.5	3.58
13.0	0.54	38.0	1.60	63.0	2.62	88.0	3.60
13.5	0.57	38.5	1.62	63.5	2.64	88.5	3.62
14.0	0.59	39.0	1.64	64.0	2.66	89.0	3.64
14.5	0.61	39.5	1.66	64.5	2.68	89.5	3.66
15.0	0.63	40.0	1.68	65.0	2.70	90.0	3.68
15.5	0.65	40.5	1.71	65.5	2.72	90.5	3.69
16.0	0.67	41.0	1.73	66.0	2.74	91.0	3.71
16.5	0.69	41.5	1.75	66.5	2.76	91.5	3.73
17.0	0.72	42.0	1.77	67.0	2.78	92.0	3.75
17.5	0.74	42.5	1.79	67.5	2.80	92.5	3.77
18.0	0.76	43.0	1.81	68.0	2.82	93.0	3.79
18.5	0.78	43.5	1.83	68.5	2.84	93.5	3.81
19.0	0.80	44.0	1.85	69.0	2.86	94.0	3.83
19.5	0.82	44.5	1.87	69.5	2.88	94.5	3.85
20.0	0.84	45.0	1.89	70.0	2.90	95.0	3.87
20.5	0.87	45.5	1.91	70.5	2.92	95.5	3.89
21.0	0.89	46.0	1.93	71.0	2.94	96.0	3.90
21.5	0.91	46.5	1.95	71.5	2.96	96.5	3.92
22.0	0.93	47.0	1.97	72.0	2.98	97.0	3.94
22.5	0.95	47.5	1.99	72.5	3.00	97.5	3.96
23.0	0.97	48.0	2.01	73.0	3.02	98.0	3.98
23.5	0.99	48.5	2.03	73.5	3.04	98.5	4.00
24.0	1.01	49.0	2.05	74.0	3.06	99.0	4.02
24.5	1.04	49.5	2.07	74.5	3.07	99.5	4.04
25.0	1.06	50.0	2.10	75.0	3.09	100.0	4.06

Temperature, °F

66.2

				Temperature, °C				19•0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100•5	4•07	125•5	5•00	150•5	5•89	175•5	6•74				
101•0	4•09	126•0	5•02	151•0	5•90	176•0	6•76				
101•5	4•11	126•5	5•03	151•5	5•92	176•5	6•77				
102•0	4•13	127•0	5•05	152•0	5•94	177•0	6•79				
102•5	4•15	127•5	5•07	152•5	5•96	177•5	6•81				
103•0	4•17	128•0	5•09	153•0	5•97	178•0	6•82				
103•5	4•19	128•5	5•11	153•5	5•99	178•5	6•84				
104•0	4•21	129•0	5•12	154•0	6•01	179•0	6•86				
104•5	4•22	129•5	5•14	154•5	6•03	179•5	6•87				
105•0	4•24	130•0	5•16	155•0	6•04	180•0	6•89				
105•5	4•26	130•5	5•18	155•5	6•06	180•5	6•91				
106•0	4•28	131•0	5•20	156•0	6•08	181•0	6•92				
106•5	4•30	131•5	5•21	156•5	6•09	181•5	6•94				
107•0	4•32	132•0	5•23	157•0	6•11	182•0	6•96				
107•5	4•34	132•5	5•25	157•5	6•13	182•5	6•97				
108•0	4•36	133•0	5•27	158•0	6•15	183•0	6•99				
108•5	4•37	133•5	5•29	158•5	6•16	183•5	7•01				
109•0	4•39	134•0	5•30	159•0	6•18	184•0	7•02				
109•5	4•41	134•5	5•32	159•5	6•20	184•5	7•04				
110•0	4•43	135•0	5•34	160•0	6•22	185•0	7•06				
110•5	4•45	135•5	5•36	160•5	6•23	185•5	7•07				
111•0	4•47	136•0	5•38	161•0	6•25	186•0	7•09				
111•5	4•49	136•5	5•39	161•5	6•27	186•5	7•11				
112•0	4•50	137•0	5•41	162•0	6•28	187•0	7•12				
112•5	4•52	137•5	5•43	162•5	6•30	187•5	7•14				
113•0	4•54	138•0	5•45	163•0	6•32	188•0	7•16				
113•5	4•56	138•5	5•46	163•5	6•34	188•5	7•17				
114•0	4•58	139•0	5•48	164•0	6•35	189•0	7•19				
114•5	4•60	139•5	5•50	164•5	6•37	189•5	7•21				
115•0	4•61	140•0	5•52	165•0	6•39	190•0	7•22				
115•5	4•63	140•5	5•54	165•5	6•40	190•5	7•24				
116•0	4•65	141•0	5•55	166•0	6•42	191•0	7•25				
116•5	4•67	141•5	5•57	166•5	6•44	191•5	7•27				
117•0	4•69	142•0	5•59	167•0	6•45	192•0	7•29				
117•5	4•71	142•5	5•61	167•5	6•47	192•5	7•30				
118•0	4•72	143•0	5•62	168•0	6•49	193•0	7•32				
118•5	4•74	143•5	5•64	168•5	6•51	193•5	7•34				
119•0	4•76	144•0	5•66	169•0	6•52	194•0	7•35				
119•5	4•78	144•5	5•68	169•5	6•54	194•5	7•37				
120•0	4•80	145•0	5•69	170•0	6•56	195•0	7•38				
120•5	4•82	145•5	5•71	170•5	6•57	195•5	7•40				
121•0	4•83	146•0	5•73	171•0	6•59	196•0	7•42				
121•5	4•85	146•5	5•75	171•5	6•61	196•5	7•43				
122•0	4•87	147•0	5•76	172•0	6•62	197•0	7•45				
122•5	4•89	147•5	5•78	172•5	6•64	197•5	7•47				
123•0	4•91	148•0	5•80	173•0	6•66	198•0	7•48				
123•5	4•93	148•5	5•82	173•5	6•67	198•5	7•50				
124•0	4•94	149•0	5•83	174•0	6•69	199•0	7•51				
124•5	4•96	149•5	5•85	174•5	6•71	199•5	7•53				
125•0	4•98	150•0	5•87	175•0	6•72	200•0	7•55				

Temperature, °F

66•2

						Temperature, °C		200
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.07	50.5	2.11	75.5	3.10	
1.0	0.02	26.0	1.10	51.0	2.13	76.0	3.12	
1.5	0.04	26.5	1.12	51.5	2.15	76.5	3.14	
2.0	0.07	27.0	1.14	52.0	2.17	77.0	3.16	
2.5	0.09	27.5	1.16	52.5	2.19	77.5	3.18	
3.0	0.11	28.0	1.18	53.0	2.21	78.0	3.20	
3.5	0.13	28.5	1.20	53.5	2.23	78.5	3.22	
4.0	0.15	29.0	1.22	54.0	2.25	79.0	3.24	
4.5	0.17	29.5	1.24	54.5	2.27	79.5	3.26	
5.0	0.20	30.0	1.26	55.0	2.29	80.0	3.28	
5.5	0.22	30.5	1.28	55.5	2.31	80.5	3.30	
6.0	0.24	31.0	1.30	56.0	2.33	81.0	3.32	
6.5	0.26	31.5	1.33	56.5	2.35	81.5	3.34	
7.0	0.28	32.0	1.35	57.0	2.37	82.0	3.35	
7.5	0.30	32.5	1.37	57.5	2.39	82.5	3.37	
8.0	0.33	33.0	1.39	58.0	2.41	83.0	3.39	
8.5	0.35	33.5	1.41	58.5	2.43	83.5	3.41	
9.0	0.37	34.0	1.43	59.0	2.45	84.0	3.43	
9.5	0.39	34.5	1.45	59.5	2.47	84.5	3.45	
10.0	0.41	35.0	1.47	60.0	2.49	85.0	3.47	
10.5	0.43	35.5	1.49	60.5	2.51	85.5	3.49	
11.0	0.46	36.0	1.51	61.0	2.53	86.0	3.51	
11.5	0.48	36.5	1.53	61.5	2.55	86.5	3.53	
12.0	0.50	37.0	1.55	62.0	2.57	87.0	3.55	
12.5	0.52	37.5	1.58	62.5	2.59	87.5	3.57	
13.0	0.54	38.0	1.60	63.0	2.61	88.0	3.59	
13.5	0.56	38.5	1.62	63.5	2.63	88.5	3.60	
14.0	0.59	39.0	1.64	64.0	2.65	89.0	3.62	
14.5	0.61	39.5	1.66	64.5	2.67	89.5	3.64	
15.0	0.63	40.0	1.68	65.0	2.69	90.0	3.66	
15.5	0.65	40.5	1.70	65.5	2.71	90.5	3.68	
16.0	0.67	41.0	1.72	66.0	2.73	91.0	3.70	
16.5	0.69	41.5	1.74	66.5	2.75	91.5	3.72	
17.0	0.71	42.0	1.76	67.0	2.77	92.0	3.74	
17.5	0.73	42.5	1.78	67.5	2.79	92.5	3.76	
18.0	0.76	43.0	1.80	68.0	2.81	93.0	3.78	
18.5	0.78	43.5	1.82	68.5	2.83	93.5	3.79	
19.0	0.80	44.0	1.84	69.0	2.85	94.0	3.81	
19.5	0.82	44.5	1.86	69.5	2.87	94.5	3.83	
20.0	0.84	45.0	1.88	70.0	2.89	95.0	3.85	
20.5	0.86	45.5	1.90	70.5	2.91	95.5	3.87	
21.0	0.88	46.0	1.92	71.0	2.93	96.0	3.89	
21.5	0.90	46.5	1.94	71.5	2.95	96.5	3.91	
22.0	0.93	47.0	1.97	72.0	2.97	97.0	3.93	
22.5	0.95	47.5	1.99	72.5	2.98	97.5	3.95	
23.0	0.97	48.0	2.01	73.0	3.00	98.0	3.96	
23.5	0.99	48.5	2.03	73.5	3.02	98.5	3.98	
24.0	1.01	49.0	2.05	74.0	3.04	99.0	4.00	
24.5	1.03	49.5	2.07	74.5	3.06	99.5	4.02	
25.0	1.05	50.0	2.09	75.0	3.08	100.0	4.04	

Temperature, °F

68.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				20•0		
atü	-	kg		atü	-	kg		atü	-	kg
100•5	4•06	125•5	4•98	150•5	5•86	175•5	6•72			
101•0	4•08	126•0	5•00	151•0	5•88	176•0	6•73			
101•5	4•10	126•5	5•02	151•5	5•90	176•5	6•75			
102•0	4•12	127•0	5•03	152•0	5•92	177•0	6•77			
102•5	4•13	127•5	5•05	152•5	5•93	177•5	6•78			
103•0	4•15	128•0	5•07	153•0	5•95	178•0	6•80			
103•5	4•17	128•5	5•09	153•5	5•97	178•5	6•82			
104•0	4•19	129•0	5•11	154•0	5•99	179•0	6•83			
104•5	4•21	129•5	5•12	154•5	6•00	179•5	6•85			
105•0	4•23	130•0	5•14	155•0	6•02	180•0	6•87			
105•5	4•25	130•5	5•16	155•5	6•04	180•5	6•88			
106•0	4•26	131•0	5•18	156•0	6•05	181•0	6•90			
106•5	4•28	131•5	5•20	156•5	6•07	181•5	6•92			
107•0	4•30	132•0	5•21	157•0	6•09	182•0	6•93			
107•5	4•32	132•5	5•23	157•5	6•11	182•5	6•95			
108•0	4•34	133•0	5•25	158•0	6•12	183•0	6•97			
108•5	4•36	133•5	5•27	158•5	6•14	183•5	6•98			
109•0	4•38	134•0	5•28	159•0	6•16	184•0	7•00			
109•5	4•39	134•5	5•30	159•5	6•18	184•5	7•01			
110•0	4•41	135•0	5•32	160•0	6•19	185•0	7•03			
110•5	4•43	135•5	5•34	160•5	6•21	185•5	7•05			
111•0	4•45	136•0	5•36	161•0	6•23	186•0	7•06			
111•5	4•47	136•5	5•37	161•5	6•24	186•5	7•08			
112•0	4•49	137•0	5•39	162•0	6•26	187•0	7•10			
112•5	4•51	137•5	5•41	162•5	6•28	187•5	7•11			
113•0	4•52	138•0	5•43	163•0	6•29	188•0	7•13			
113•5	4•54	138•5	5•44	163•5	6•31	188•5	7•15			
114•0	4•56	139•0	5•46	164•0	6•33	189•0	7•16			
114•5	4•58	139•5	5•48	164•5	6•35	189•5	7•18			
115•0	4•60	140•0	5•50	165•0	6•36	190•0	7•20			
115•5	4•62	140•5	5•51	165•5	6•38	190•5	7•21			
116•0	4•63	141•0	5•53	166•0	6•40	191•0	7•23			
116•5	4•65	141•5	5•55	166•5	6•41	191•5	7•24			
117•0	4•67	142•0	5•57	167•0	6•43	192•0	7•26			
117•5	4•69	142•5	5•59	167•5	6•45	192•5	7•28			
118•0	4•71	143•0	5•60	168•0	6•46	193•0	7•29			
118•5	4•73	143•5	5•62	168•5	6•48	193•5	7•31			
119•0	4•74	144•0	5•64	169•0	6•50	194•0	7•33			
119•5	4•76	144•5	5•66	169•5	6•51	194•5	7•34			
120•0	4•78	145•0	5•67	170•0	6•53	195•0	7•36			
120•5	4•80	145•5	5•69	170•5	6•55	195•5	7•37			
121•0	4•82	146•0	5•71	171•0	6•57	196•0	7•39			
121•5	4•83	146•5	5•73	171•5	6•58	196•5	7•41			
122•0	4•85	147•0	5•74	172•0	6•60	197•0	7•42			
122•5	4•87	147•5	5•76	172•5	6•62	197•5	7•44			
123•0	4•89	148•0	5•78	173•0	6•63	198•0	7•45			
123•5	4•91	148•5	5•80	173•5	6•65	198•5	7•47			
124•0	4•93	149•0	5•81	174•0	6•67	199•0	7•49			
124•5	4•94	149•5	5•83	174•5	6•68	199•5	7•50			
125•0	4•96	150•0	5•85	175•0	6•70	200•0	7•52			

Temperature, °F

68•0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

21•0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0.00	25•5	1.07	50•5	2.10	75•5	3.09
1•0	0.02	26•0	1.09	51•0	2.12	76•0	3.11
1•5	0.04	26•5	1.11	51•5	2.14	76•5	3.13
2•0	0.07	27•0	1.13	52•0	2.16	77•0	3.15
2•5	0.09	27•5	1.15	52•5	2.18	77•5	3.17
3•0	0.11	28•0	1.17	53•0	2.20	78•0	3.19
3•5	0.13	28•5	1.20	53•5	2.22	78•5	3.21
4•0	0.15	29•0	1.22	54•0	2.24	79•0	3.23
4•5	0.17	29•5	1.24	54•5	2.26	79•5	3.25
5•0	0.20	30•0	1.26	55•0	2.28	80•0	3.26
5•5	0.22	30•5	1.28	55•5	2.30	80•5	3.28
6•0	0.24	31•0	1.30	56•0	2.32	81•0	3.30
6•5	0.26	31•5	1.32	56•5	2.34	81•5	3.32
7•0	0.28	32•0	1.34	57•0	2.36	82•0	3.34
7•5	0.30	32•5	1.36	57•5	2.38	82•5	3.36
8•0	0.33	33•0	1.38	58•0	2.40	83•0	3.38
8•5	0.35	33•5	1.40	58•5	2.42	83•5	3.40
9•0	0.37	34•0	1.42	59•0	2.44	84•0	3.42
9•5	0.39	34•5	1.45	59•5	2.46	84•5	3.44
10•0	0.41	35•0	1.47	60•0	2.48	85•0	3.46
10•5	0.43	35•5	1.49	60•5	2.50	85•5	3.48
11•0	0.45	36•0	1.51	61•0	2.52	86•0	3.50
11•5	0.48	36•5	1.53	61•5	2.54	86•5	3.51
12•0	0.50	37•0	1.55	62•0	2.56	87•0	3.53
12•5	0.52	37•5	1.57	62•5	2.58	87•5	3.55
13•0	0.54	38•0	1.59	63•0	2.60	88•0	3.57
13•5	0.56	38•5	1.61	63•5	2.62	88•5	3.59
14•0	0.58	39•0	1.63	64•0	2.64	89•0	3.61
14•5	0.60	39•5	1.65	64•5	2.66	89•5	3.63
15•0	0.63	40•0	1.67	65•0	2.68	90•0	3.65
15•5	0.65	40•5	1.69	65•5	2.70	90•5	3.67
16•0	0.67	41•0	1.71	66•0	2.72	91•0	3.69
16•5	0.69	41•5	1.73	66•5	2.74	91•5	3.70
17•0	0.71	42•0	1.75	67•0	2.76	92•0	3.72
17•5	0.73	42•5	1.77	67•5	2.78	92•5	3.74
18•0	0.75	43•0	1.79	68•0	2.80	93•0	3.76
18•5	0.77	43•5	1.82	68•5	2.82	93•5	3.78
19•0	0.80	44•0	1.84	69•0	2.84	94•0	3.80
19•5	0.82	44•5	1.86	69•5	2.86	94•5	3.82
20•0	0.84	45•0	1.88	70•0	2.88	95•0	3.84
20•5	0.86	45•5	1.90	70•5	2.90	95•5	3.86
21•0	0.88	46•0	1.92	71•0	2.91	96•0	3.87
21•5	0.90	46•5	1.94	71•5	2.93	96•5	3.89
22•0	0.92	47•0	1.96	72•0	2.95	97•0	3.91
22•5	0.94	47•5	1.98	72•5	2.97	97•5	3.93
23•0	0.96	48•0	2.00	73•0	2.99	98•0	3.95
23•5	0.99	48•5	2.02	73•5	3.01	98•5	3.97
24•0	1.01	49•0	2.04	74•0	3.03	99•0	3.99
24•5	1.03	49•5	2.06	74•5	3.05	99•5	4.01
25•0	1.05	50•0	2.08	75•0	3.07	100•0	4.03

Temperature, °F

69•8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

21.0

Temperature, °C

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.04	125.5	4.96	150.5	5.84	175.5	6.69				
101.0	4.06	126.0	4.98	151.0	5.86	176.0	6.71				
101.5	4.08	126.5	5.00	151.5	5.88	176.5	6.72				
102.0	4.10	127.0	5.01	152.0	5.89	177.0	6.74				
102.5	4.12	127.5	5.03	152.5	5.91	177.5	6.76				
103.0	4.14	128.0	5.05	153.0	5.93	178.0	6.77				
103.5	4.16	128.5	5.07	153.5	5.95	178.5	6.79				
104.0	4.17	129.0	5.09	154.0	5.96	179.0	6.81				
104.5	4.19	129.5	5.10	154.5	5.98	179.5	6.82				
105.0	4.21	130.0	5.12	155.0	6.00	180.0	6.84				
105.5	4.23	130.5	5.14	155.5	6.02	180.5	6.86				
106.0	4.25	131.0	5.16	156.0	6.03	181.0	6.87				
106.5	4.27	131.5	5.18	156.5	6.05	181.5	6.89				
107.0	4.29	132.0	5.19	157.0	6.07	182.0	6.91				
107.5	4.30	132.5	5.21	157.5	6.08	182.5	6.92				
108.0	4.32	133.0	5.23	158.0	6.10	183.0	6.94				
108.5	4.34	133.5	5.25	158.5	6.12	183.5	6.96				
109.0	4.36	134.0	5.26	159.0	6.14	184.0	6.97				
109.5	4.38	134.5	5.28	159.5	6.15	184.5	6.99				
110.0	4.40	135.0	5.30	160.0	6.17	185.0	7.01				
110.5	4.41	135.5	5.32	160.5	6.19	185.5	7.02				
111.0	4.43	136.0	5.34	161.0	6.20	186.0	7.04				
111.5	4.45	136.5	5.35	161.5	6.22	186.5	7.05				
112.0	4.47	137.0	5.37	162.0	6.24	187.0	7.07				
112.5	4.49	137.5	5.39	162.5	6.25	187.5	7.09				
113.0	4.51	138.0	5.41	163.0	6.27	188.0	7.10				
113.5	4.53	138.5	5.42	163.5	6.29	188.5	7.12				
114.0	4.54	139.0	5.44	164.0	6.31	189.0	7.14				
114.5	4.56	139.5	5.46	164.5	6.32	189.5	7.15				
115.0	4.58	140.0	5.48	165.0	6.34	190.0	7.17				
115.5	4.60	140.5	5.49	165.5	6.36	190.5	7.18				
116.0	4.62	141.0	5.51	166.0	6.37	191.0	7.20				
116.5	4.63	141.5	5.53	166.5	6.39	191.5	7.22				
117.0	4.65	142.0	5.55	167.0	6.41	192.0	7.23				
117.5	4.67	142.5	5.56	167.5	6.42	192.5	7.25				
118.0	4.69	143.0	5.58	168.0	6.44	193.0	7.27				
118.5	4.71	143.5	5.60	168.5	6.46	193.5	7.28				
119.0	4.73	144.0	5.62	169.0	6.47	194.0	7.30				
119.5	4.74	144.5	5.63	169.5	6.49	194.5	7.31				
120.0	4.76	145.0	5.65	170.0	6.51	195.0	7.33				
120.5	4.78	145.5	5.67	170.5	6.52	195.5	7.35				
121.0	4.80	146.0	5.69	171.0	6.54	196.0	7.36				
121.5	4.82	146.5	5.70	171.5	6.56	196.5	7.38				
122.0	4.83	147.0	5.72	172.0	6.57	197.0	7.40				
122.5	4.85	147.5	5.74	172.5	6.59	197.5	7.41				
123.0	4.87	148.0	5.76	173.0	6.61	198.0	7.43				
123.5	4.89	148.5	5.77	173.5	6.62	198.5	7.44				
124.0	4.91	149.0	5.79	174.0	6.64	199.0	7.46				
124.5	4.92	149.5	5.81	174.5	6.66	199.5	7.48				
125.0	4.94	150.0	5.83	175.0	6.67	200.0	7.49				

Temperature, °F

69.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

22.0

Temperature, °C							
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.07	50.5	2.09	75.5	3.08
1.0	0.02	26.0	1.09	51.0	2.11	76.0	3.10
1.5	0.04	26.5	1.11	51.5	2.13	76.5	3.12
2.0	0.07	27.0	1.13	52.0	2.15	77.0	3.14
2.5	0.09	27.5	1.15	52.5	2.17	77.5	3.16
3.0	0.11	28.0	1.17	53.0	2.19	78.0	3.18
3.5	0.13	28.5	1.19	53.5	2.21	78.5	3.19
4.0	0.15	29.0	1.21	54.0	2.23	79.0	3.21
4.5	0.17	29.5	1.23	54.5	2.25	79.5	3.23
5.0	0.19	30.0	1.25	55.0	2.27	80.0	3.25
5.5	0.22	30.5	1.27	55.5	2.29	80.5	3.27
6.0	0.24	31.0	1.29	56.0	2.31	81.0	3.29
6.5	0.26	31.5	1.32	56.5	2.33	81.5	3.31
7.0	0.28	32.0	1.34	57.0	2.35	82.0	3.33
7.5	0.30	32.5	1.36	57.5	2.37	82.5	3.35
8.0	0.32	33.0	1.38	58.0	2.39	83.0	3.37
8.5	0.35	33.5	1.40	58.5	2.41	83.5	3.39
9.0	0.37	34.0	1.42	59.0	2.43	84.0	3.41
9.5	0.39	34.5	1.44	59.5	2.45	84.5	3.42
10.0	0.41	35.0	1.46	60.0	2.47	85.0	3.44
10.5	0.43	35.5	1.48	60.5	2.49	85.5	3.46
11.0	0.45	36.0	1.50	61.0	2.51	86.0	3.48
11.5	0.47	36.5	1.52	61.5	2.53	86.5	3.50
12.0	0.50	37.0	1.54	62.0	2.55	87.0	3.52
12.5	0.52	37.5	1.56	62.5	2.57	87.5	3.54
13.0	0.54	38.0	1.58	63.0	2.59	88.0	3.56
13.5	0.56	38.5	1.60	63.5	2.61	88.5	3.58
14.0	0.58	39.0	1.62	64.0	2.63	89.0	3.60
14.5	0.60	39.5	1.65	64.5	2.65	89.5	3.62
15.0	0.62	40.0	1.67	65.0	2.67	90.0	3.63
15.5	0.64	40.5	1.69	65.5	2.69	90.5	3.65
16.0	0.67	41.0	1.71	66.0	2.71	91.0	3.67
16.5	0.69	41.5	1.73	66.5	2.73	91.5	3.69
17.0	0.71	42.0	1.75	67.0	2.75	92.0	3.71
17.5	0.73	42.5	1.77	67.5	2.77	92.5	3.73
18.0	0.75	43.0	1.79	68.0	2.79	93.0	3.75
18.5	0.77	43.5	1.81	68.5	2.81	93.5	3.77
19.0	0.79	44.0	1.83	69.0	2.83	94.0	3.79
19.5	0.81	44.5	1.85	69.5	2.85	94.5	3.80
20.0	0.83	45.0	1.87	70.0	2.86	95.0	3.82
20.5	0.86	45.5	1.89	70.5	2.88	95.5	3.84
21.0	0.88	46.0	1.91	71.0	2.90	96.0	3.86
21.5	0.90	46.5	1.93	71.5	2.92	96.5	3.88
22.0	0.92	47.0	1.95	72.0	2.94	97.0	3.90
22.5	0.94	47.5	1.97	72.5	2.96	97.5	3.92
23.0	0.96	48.0	1.99	73.0	2.98	98.0	3.94
23.5	0.98	48.5	2.01	73.5	3.00	98.5	3.95
24.0	1.00	49.0	2.03	74.0	3.02	99.0	3.97
24.5	1.02	49.5	2.05	74.5	3.04	99.5	3.99
25.0	1.04	50.0	2.07	75.0	3.06	100.0	4.01

Temperature, °F

71.6

Temperature, °C 22.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	4.03	125.5	4.94	150.5	5.82	175.5	6.67				
101.0	4.05	126.0	4.96	151.0	5.84	176.0	6.68				
101.5	4.07	126.5	4.98	151.5	5.86	176.5	6.70				
102.0	4.08	127.0	5.00	152.0	5.87	177.0	6.72				
102.5	4.10	127.5	5.01	152.5	5.89	177.5	6.73				
103.0	4.12	128.0	5.03	153.0	5.91	178.0	6.75				
103.5	4.14	128.5	5.05	153.5	5.92	178.5	6.77				
104.0	4.16	129.0	5.07	154.0	5.94	179.0	6.78				
104.5	4.18	129.5	5.09	154.5	5.96	179.5	6.80				
105.0	4.20	130.0	5.10	155.0	5.98	180.0	6.82				
105.5	4.21	130.5	5.12	155.5	5.99	180.5	6.83				
106.0	4.23	131.0	5.14	156.0	6.01	181.0	6.85				
106.5	4.25	131.5	5.16	156.5	6.03	181.5	6.86				
107.0	4.27	132.0	5.17	157.0	6.04	182.0	6.88				
107.5	4.29	132.5	5.19	157.5	6.06	182.5	6.90				
108.0	4.31	133.0	5.21	158.0	6.08	183.0	6.91				
108.5	4.32	133.5	5.23	158.5	6.10	183.5	6.93				
109.0	4.34	134.0	5.24	159.0	6.11	184.0	6.95				
109.5	4.36	134.5	5.26	159.5	6.13	184.5	6.96				
110.0	4.38	135.0	5.28	160.0	6.15	185.0	6.98				
110.5	4.40	135.5	5.30	160.5	6.16	185.5	7.00				
111.0	4.42	136.0	5.32	161.0	6.18	186.0	7.01				
111.5	4.43	136.5	5.33	161.5	6.20	186.5	7.03				
112.0	4.45	137.0	5.35	162.0	6.21	187.0	7.04				
112.5	4.47	137.5	5.37	162.5	6.23	187.5	7.06				
113.0	4.49	138.0	5.39	163.0	6.25	188.0	7.08				
113.5	4.51	138.5	5.40	163.5	6.26	188.5	7.09				
114.0	4.53	139.0	5.42	164.0	6.28	189.0	7.11				
114.5	4.54	139.5	5.44	164.5	6.30	189.5	7.13				
115.0	4.56	140.0	5.46	165.0	6.32	190.0	7.14				
115.5	4.58	140.5	5.47	165.5	6.33	190.5	7.16				
116.0	4.60	141.0	5.49	166.0	6.35	191.0	7.17				
116.5	4.62	141.5	5.51	166.5	6.37	191.5	7.19				
117.0	4.64	142.0	5.53	167.0	6.38	192.0	7.21				
117.5	4.65	142.5	5.54	167.5	6.40	192.5	7.22				
118.0	4.67	143.0	5.56	168.0	6.42	193.0	7.24				
118.5	4.69	143.5	5.58	168.5	6.43	193.5	7.26				
119.0	4.71	144.0	5.60	169.0	6.45	194.0	7.27				
119.5	4.73	144.5	5.61	169.5	6.47	194.5	7.29				
120.0	4.74	145.0	5.63	170.0	6.48	195.0	7.30				
120.5	4.76	145.5	5.65	170.5	6.50	195.5	7.32				
121.0	4.78	146.0	5.67	171.0	6.52	196.0	7.34				
121.5	4.80	146.5	5.68	171.5	6.53	196.5	7.35				
122.0	4.82	147.0	5.70	172.0	6.55	197.0	7.37				
122.5	4.83	147.5	5.72	172.5	6.57	197.5	7.38				
123.0	4.85	148.0	5.73	173.0	6.58	198.0	7.40				
123.5	4.87	148.5	5.75	173.5	6.60	198.5	7.42				
124.0	4.89	149.0	5.77	174.0	6.62	199.0	7.43				
124.5	4.91	149.5	5.79	174.5	6.63	199.5	7.45				
125.0	4.92	150.0	5.80	175.0	6.65	200.0	7.46				

Temperature, °F

71.6

23°0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.06	50.5	2.08	75.5	3.07
1.0	0.02	26.0	1.08	51.0	2.10	76.0	3.09
1.5	0.04	26.5	1.10	51.5	2.12	76.5	3.11
2.0	0.06	27.0	1.12	52.0	2.14	77.0	3.12
2.5	0.09	27.5	1.15	52.5	2.16	77.5	3.14
3.0	0.11	28.0	1.17	53.0	2.18	78.0	3.16
3.5	0.13	28.5	1.19	53.5	2.20	78.5	3.18
4.0	0.15	29.0	1.21	54.0	2.22	79.0	3.20
4.5	0.17	29.5	1.23	54.5	2.24	79.5	3.22
5.0	0.19	30.0	1.25	55.0	2.26	80.0	3.24
5.5	0.22	30.5	1.27	55.5	2.28	80.5	3.26
6.0	0.24	31.0	1.29	56.0	2.30	81.0	3.28
6.5	0.26	31.5	1.31	56.5	2.32	81.5	3.30
7.0	0.28	32.0	1.33	57.0	2.34	82.0	3.32
7.5	0.30	32.5	1.35	57.5	2.36	82.5	3.34
8.0	0.32	33.0	1.37	58.0	2.38	83.0	3.35
8.5	0.34	33.5	1.39	58.5	2.40	83.5	3.37
9.0	0.37	34.0	1.41	59.0	2.42	84.0	3.39
9.5	0.39	34.5	1.43	59.5	2.44	84.5	3.41
10.0	0.41	35.0	1.45	60.0	2.46	85.0	3.43
10.5	0.43	35.5	1.48	60.5	2.48	85.5	3.45
11.0	0.45	36.0	1.50	61.0	2.50	86.0	3.47
11.5	0.47	36.5	1.52	61.5	2.52	86.5	3.49
12.0	0.49	37.0	1.54	62.0	2.54	87.0	3.51
12.5	0.51	37.5	1.56	62.5	2.56	87.5	3.53
13.0	0.54	38.0	1.58	63.0	2.58	88.0	3.54
13.5	0.56	38.5	1.60	63.5	2.60	88.5	3.56
14.0	0.58	39.0	1.62	64.0	2.62	89.0	3.58
14.5	0.60	39.5	1.64	64.5	2.64	89.5	3.60
15.0	0.62	40.0	1.66	65.0	2.66	90.0	3.62
15.5	0.64	40.5	1.68	65.5	2.68	90.5	3.64
16.0	0.66	41.0	1.70	66.0	2.70	91.0	3.66
16.5	0.68	41.5	1.72	66.5	2.72	91.5	3.68
17.0	0.71	42.0	1.74	67.0	2.74	92.0	3.70
17.5	0.73	42.5	1.76	67.5	2.76	92.5	3.71
18.0	0.75	43.0	1.78	68.0	2.78	93.0	3.73
18.5	0.77	43.5	1.80	68.5	2.80	93.5	3.75
19.0	0.79	44.0	1.82	69.0	2.82	94.0	3.77
19.5	0.81	44.5	1.84	69.5	2.83	94.5	3.79
20.0	0.83	45.0	1.86	70.0	2.85	95.0	3.81
20.5	0.85	45.5	1.88	70.5	2.87	95.5	3.83
21.0	0.87	46.0	1.90	71.0	2.89	96.0	3.85
21.5	0.89	46.5	1.92	71.5	2.91	96.5	3.86
22.0	0.92	47.0	1.94	72.0	2.93	97.0	3.88
22.5	0.94	47.5	1.96	72.5	2.95	97.5	3.90
23.0	0.96	48.0	1.98	73.0	2.97	98.0	3.92
23.5	0.98	48.5	2.00	73.5	2.99	98.5	3.94
24.0	1.00	49.0	2.02	74.0	3.01	99.0	3.96
24.5	1.02	49.5	2.04	74.5	3.03	99.5	3.98
25.0	1.04	50.0	2.06	75.0	3.05	100.0	3.99

Temperature, °F

73°4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				23.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	4.01	125.5	4.92	150.5	5.80	175.5	6.64
101.0	4.03	126.0	4.94	151.0	5.82	176.0	6.66
101.5	4.05	126.5	4.96	151.5	5.83	176.5	6.67
102.0	4.07	127.0	4.98	152.0	5.85	177.0	6.69
102.5	4.09	127.5	4.99	152.5	5.87	177.5	6.71
103.0	4.11	128.0	5.01	153.0	5.88	178.0	6.72
103.5	4.12	128.5	5.03	153.5	5.90	178.5	6.74
104.0	4.14	129.0	5.05	154.0	5.92	179.0	6.76
104.5	4.16	129.5	5.07	154.5	5.94	179.5	6.77
105.0	4.18	130.0	5.08	155.0	5.95	180.0	6.79
105.5	4.20	130.5	5.10	155.5	5.97	180.5	6.81
106.0	4.22	131.0	5.12	156.0	5.99	181.0	6.82
106.5	4.23	131.5	5.14	156.5	6.00	181.5	6.84
107.0	4.25	132.0	5.15	157.0	6.02	182.0	6.86
107.5	4.27	132.5	5.17	157.5	6.04	182.5	6.87
108.0	4.29	133.0	5.19	158.0	6.06	183.0	6.89
108.5	4.31	133.5	5.21	158.5	6.07	183.5	6.90
109.0	4.33	134.0	5.23	159.0	6.09	184.0	6.92
109.5	4.34	134.5	5.24	159.5	6.11	184.5	6.94
110.0	4.36	135.0	5.26	160.0	6.12	185.0	6.95
110.5	4.38	135.5	5.28	160.5	6.14	185.5	6.97
111.0	4.40	136.0	5.30	161.0	6.16	186.0	6.99
111.5	4.42	136.5	5.31	161.5	6.17	186.5	7.00
112.0	4.44	137.0	5.33	162.0	6.19	187.0	7.02
112.5	4.45	137.5	5.35	162.5	6.21	187.5	7.03
113.0	4.47	138.0	5.37	163.0	6.22	188.0	7.05
113.5	4.49	138.5	5.38	163.5	6.24	188.5	7.07
114.0	4.51	139.0	5.40	164.0	6.26	189.0	7.08
114.5	4.53	139.5	5.42	164.5	6.27	189.5	7.10
115.0	4.55	140.0	5.44	165.0	6.29	190.0	7.12
115.5	4.56	140.5	5.45	165.5	6.31	190.5	7.13
116.0	4.58	141.0	5.47	166.0	6.33	191.0	7.15
116.5	4.60	141.5	5.49	166.5	6.34	191.5	7.16
117.0	4.62	142.0	5.51	167.0	6.36	192.0	7.18
117.5	4.64	142.5	5.52	167.5	6.38	192.5	7.20
118.0	4.65	143.0	5.54	168.0	6.39	193.0	7.21
118.5	4.67	143.5	5.56	168.5	6.41	193.5	7.23
119.0	4.69	144.0	5.57	169.0	6.43	194.0	7.24
119.5	4.71	144.5	5.59	169.5	6.44	194.5	7.26
120.0	4.73	145.0	5.61	170.0	6.46	195.0	7.28
120.5	4.74	145.5	5.63	170.5	6.48	195.5	7.29
121.0	4.76	146.0	5.64	171.0	6.49	196.0	7.31
121.5	4.78	146.5	5.66	171.5	6.51	196.5	7.32
122.0	4.80	147.0	5.68	172.0	6.53	197.0	7.34
122.5	4.82	147.5	5.70	172.5	6.54	197.5	7.36
123.0	4.83	148.0	5.71	173.0	6.56	198.0	7.37
123.5	4.85	148.5	5.73	173.5	6.58	198.5	7.39
124.0	4.87	149.0	5.75	174.0	6.59	199.0	7.40
124.5	4.89	149.5	5.76	174.5	6.61	199.5	7.42
125.0	4.91	150.0	5.78	175.0	6.63	200.0	7.44

Temperature, °F

73.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C								24.0
atü	- kg	atü	- kg	atü	- kg	atü	- kg	
0.5	0.00	25.5	1.06	50.5	2.08	75.5	3.06	
1.0	0.02	26.0	1.08	51.0	2.10	76.0	3.07	
1.5	0.04	26.5	1.10	51.5	2.12	76.5	3.09	
2.0	0.06	27.0	1.12	52.0	2.14	77.0	3.11	
2.5	0.09	27.5	1.14	52.5	2.16	77.5	3.13	
3.0	0.11	28.0	1.16	53.0	2.18	78.0	3.15	
3.5	0.13	28.5	1.18	53.5	2.20	78.5	3.17	
4.0	0.15	29.0	1.20	54.0	2.22	79.0	3.19	
4.5	0.17	29.5	1.22	54.5	2.24	79.5	3.21	
5.0	0.19	30.0	1.24	55.0	2.25	80.0	3.23	
5.5	0.21	30.5	1.26	55.5	2.27	80.5	3.25	
6.0	0.24	31.0	1.29	56.0	2.29	81.0	3.27	
6.5	0.26	31.5	1.31	56.5	2.31	81.5	3.28	
7.0	0.28	32.0	1.33	57.0	2.33	82.0	3.30	
7.5	0.30	32.5	1.35	57.5	2.35	82.5	3.32	
8.0	0.32	33.0	1.37	58.0	2.37	83.0	3.34	
8.5	0.34	33.5	1.39	58.5	2.39	83.5	3.36	
9.0	0.36	34.0	1.41	59.0	2.41	84.0	3.38	
9.5	0.39	34.5	1.43	59.5	2.43	84.5	3.40	
10.0	0.41	35.0	1.45	60.0	2.45	85.0	3.42	
10.5	0.43	35.5	1.47	60.5	2.47	85.5	3.44	
11.0	0.45	36.0	1.49	61.0	2.49	86.0	3.46	
11.5	0.47	36.5	1.51	61.5	2.51	86.5	3.47	
12.0	0.49	37.0	1.53	62.0	2.53	87.0	3.49	
12.5	0.51	37.5	1.55	62.5	2.55	87.5	3.51	
13.0	0.53	38.0	1.57	63.0	2.57	88.0	3.53	
13.5	0.56	38.5	1.59	63.5	2.59	88.5	3.55	
14.0	0.58	39.0	1.61	64.0	2.61	89.0	3.57	
14.5	0.60	39.5	1.63	64.5	2.63	89.5	3.59	
15.0	0.62	40.0	1.65	65.0	2.65	90.0	3.61	
15.5	0.64	40.5	1.67	65.5	2.67	90.5	3.63	
16.0	0.66	41.0	1.69	66.0	2.69	91.0	3.64	
16.5	0.68	41.5	1.71	66.5	2.71	91.5	3.66	
17.0	0.70	42.0	1.73	67.0	2.73	92.0	3.68	
17.5	0.72	42.5	1.75	67.5	2.75	92.5	3.70	
18.0	0.74	43.0	1.77	68.0	2.77	93.0	3.72	
18.5	0.77	43.5	1.79	68.5	2.78	93.5	3.74	
19.0	0.79	44.0	1.81	69.0	2.80	94.0	3.76	
19.5	0.81	44.5	1.83	69.5	2.82	94.5	3.77	
20.0	0.83	45.0	1.86	70.0	2.84	95.0	3.79	
20.5	0.85	45.5	1.88	70.5	2.86	95.5	3.81	
21.0	0.87	46.0	1.90	71.0	2.88	96.0	3.83	
21.5	0.89	46.5	1.92	71.5	2.90	96.5	3.85	
22.0	0.91	47.0	1.94	72.0	2.92	97.0	3.87	
22.5	0.93	47.5	1.96	72.5	2.94	97.5	3.89	
23.0	0.95	48.0	1.98	73.0	2.96	98.0	3.91	
23.5	0.97	48.5	2.00	73.5	2.98	98.5	3.92	
24.0	1.00	49.0	2.02	74.0	3.00	99.0	3.94	
24.5	1.02	49.5	2.04	74.5	3.02	99.5	3.96	
25.0	1.04	50.0	2.06	75.0	3.04	100.0	3.98	

Temperature, °F

75.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C		24.0	
atü	- kg										
100.5	4.00	125.5	4.90	150.5	5.78	175.5	6.62				
101.0	4.02	126.0	4.92	151.0	5.79	176.0	6.63				
101.5	4.03	126.5	4.94	151.5	5.81	176.5	6.65				
102.0	4.05	127.0	4.96	152.0	5.83	177.0	6.67				
102.5	4.07	127.5	4.98	152.5	5.85	177.5	6.68				
103.0	4.09	128.0	4.99	153.0	5.86	178.0	6.70				
103.5	4.11	128.5	5.01	153.5	5.88	178.5	6.72				
104.0	4.13	129.0	5.03	154.0	5.90	179.0	6.73				
104.5	4.15	129.5	5.05	154.5	5.91	179.5	6.75				
105.0	4.16	130.0	5.06	155.0	5.93	180.0	6.76				
105.5	4.18	130.5	5.08	155.5	5.95	180.5	6.78				
106.0	4.20	131.0	5.10	156.0	5.96	181.0	6.80				
106.5	4.22	131.5	5.12	156.5	5.98	181.5	6.81				
107.0	4.24	132.0	5.13	157.0	6.00	182.0	6.83				
107.5	4.26	132.5	5.15	157.5	6.02	182.5	6.85				
108.0	4.27	133.0	5.17	158.0	6.03	183.0	6.86				
108.5	4.29	133.5	5.19	158.5	6.05	183.5	6.88				
109.0	4.31	134.0	5.21	159.0	6.07	184.0	6.89				
109.5	4.33	134.5	5.22	159.5	6.08	184.5	6.91				
110.0	4.35	135.0	5.24	160.0	6.10	185.0	6.93				
110.5	4.36	135.5	5.26	160.5	6.12	185.5	6.94				
111.0	4.38	136.0	5.28	161.0	6.13	186.0	6.96				
111.5	4.40	136.5	5.29	161.5	6.15	186.5	6.98				
112.0	4.42	137.0	5.31	162.0	6.17	187.0	6.99				
112.5	4.44	137.5	5.33	162.5	6.18	187.5	7.01				
113.0	4.4	138.0	5.35	163.0	6.20	188.0	7.02				
113.5	4.47	138.5	5.36	163.5	6.22	188.5	7.04				
114.0	4.49	139.0	5.38	164.0	6.23	189.0	7.06				
114.5	4.51	139.5	5.40	164.5	6.25	189.5	7.07				
115.0	4.53	140.0	5.41	165.0	6.27	190.0	7.09				
115.5	4.55	140.5	5.43	165.5	6.28	190.5	7.10				
116.0	4.56	141.0	5.45	166.0	6.30	191.0	7.12				
116.5	4.58	141.5	5.47	166.5	6.32	191.5	7.14				
117.0	4.60	142.0	5.48	167.0	6.33	192.0	7.15				
117.5	4.62	142.5	5.50	167.5	6.35	192.5	7.17				
118.0	4.64	143.0	5.52	168.0	6.37	193.0	7.19				
118.5	4.65	143.5	5.54	168.5	6.38	193.5	7.20				
119.0	4.67	144.0	5.55	169.0	6.40	194.0	7.22				
119.5	4.69	144.5	5.57	169.5	6.42	194.5	7.23				
120.0	4.71	145.0	5.59	170.0	6.43	195.0	7.25				
120.5	4.73	145.5	5.61	170.5	6.45	195.5	7.27				
121.0	4.74	146.0	5.62	171.0	6.47	196.0	7.28				
121.5	4.76	146.5	5.64	171.5	6.48	196.5	7.30				
122.0	4.78	147.0	5.66	172.0	6.50	197.0	7.31				
122.5	4.80	147.5	5.67	172.5	6.52	197.5	7.33				
123.0	4.82	148.0	5.69	173.0	6.53	198.0	7.34				
123.5	4.83	148.5	5.71	173.5	6.55	198.5	7.36				
124.0	4.85	149.0	5.73	174.0	6.57	199.0	7.38				
124.5	4.87	149.5	5.74	174.5	6.58	199.5	7.39				
125.0	4.89	150.0	5.76	175.0	6.60	200.0	7.41				

Temperature, °F

75.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		25.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.05	50.5	2.07	75.5	3.04
1.0	0.02	26.0	1.07	51.0	2.09	76.0	3.06
1.5	0.04	26.5	1.10	51.5	2.11	76.5	3.08
2.0	0.06	27.0	1.12	52.0	2.13	77.0	3.10
2.5	0.09	27.5	1.14	52.5	2.15	77.5	3.12
3.0	0.11	28.0	1.16	53.0	2.17	78.0	3.14
3.5	0.13	28.5	1.18	53.5	2.19	78.5	3.16
4.0	0.15	29.0	1.20	54.0	2.21	79.0	3.18
4.5	0.17	29.5	1.22	54.5	2.23	79.5	3.20
5.0	0.19	30.0	1.24	55.0	2.25	80.0	3.22
5.5	0.21	30.5	1.26	55.5	2.27	80.5	3.23
6.0	0.24	31.0	1.28	56.0	2.29	81.0	3.25
6.5	0.26	31.5	1.30	56.5	2.31	81.5	3.27
7.0	0.28	32.0	1.32	57.0	2.33	82.0	3.29
7.5	0.30	32.5	1.34	57.5	2.34	82.5	3.31
8.0	0.32	33.0	1.36	58.0	2.36	83.0	3.33
8.5	0.34	33.5	1.38	58.5	2.38	83.5	3.35
9.0	0.36	34.0	1.40	59.0	2.40	84.0	3.37
9.5	0.38	34.5	1.42	59.5	2.42	84.5	3.39
10.0	0.41	35.0	1.44	60.0	2.44	85.0	3.40
10.5	0.43	35.5	1.46	60.5	2.46	85.5	3.42
11.0	0.45	36.0	1.48	61.0	2.48	86.0	3.44
11.5	0.47	36.5	1.50	61.5	2.50	86.5	3.46
12.0	0.49	37.0	1.53	62.0	2.52	87.0	3.48
12.5	0.51	37.5	1.55	62.5	2.54	87.5	3.50
13.0	0.53	38.0	1.57	63.0	2.56	88.0	3.52
13.5	0.55	38.5	1.59	63.5	2.58	88.5	3.54
14.0	0.57	39.0	1.61	64.0	2.60	89.0	3.56
14.5	0.60	39.5	1.63	64.5	2.62	89.5	3.57
15.0	0.62	40.0	1.65	65.0	2.64	90.0	3.59
15.5	0.64	40.5	1.67	65.5	2.66	90.5	3.61
16.0	0.66	41.0	1.69	66.0	2.68	91.0	3.63
16.5	0.68	41.5	1.71	66.5	2.70	91.5	3.65
17.0	0.70	42.0	1.73	67.0	2.72	92.0	3.67
17.5	0.72	42.5	1.75	67.5	2.74	92.5	3.69
18.0	0.74	43.0	1.77	68.0	2.75	93.0	3.70
18.5	0.76	43.5	1.79	68.5	2.77	93.5	3.72
19.0	0.78	44.0	1.81	69.0	2.79	94.0	3.74
19.5	0.80	44.5	1.83	69.5	2.81	94.5	3.76
20.0	0.83	45.0	1.85	70.0	2.83	95.0	3.78
20.5	0.85	45.5	1.87	70.5	2.85	95.5	3.80
21.0	0.87	46.0	1.89	71.0	2.87	96.0	3.82
21.5	0.89	46.5	1.91	71.5	2.89	96.5	3.83
22.0	0.91	47.0	1.93	72.0	2.91	97.0	3.85
22.5	0.93	47.5	1.95	72.5	2.93	97.5	3.87
23.0	0.95	48.0	1.97	73.0	2.95	98.0	3.89
23.5	0.97	48.5	1.99	73.5	2.97	98.5	3.91
24.0	0.99	49.0	2.01	74.0	2.99	99.0	3.93
24.5	1.01	49.5	2.03	74.5	3.01	99.5	3.95
25.0	1.03	50.0	2.05	75.0	3.02	100.0	3.96

Temperature, °F

77.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	3.98	125.5	4.89	150.5	5.76	175.5	6.59
101.0	4.00	126.0	4.90	151.0	5.77	176.0	6.61
101.5	4.02	126.5	4.92	151.5	5.79	176.5	6.62
102.0	4.04	127.0	4.94	152.0	5.81	177.0	6.64
102.5	4.06	127.5	4.96	152.5	5.82	177.5	6.66
103.0	4.07	128.0	4.97	153.0	5.84	178.0	6.67
103.5	4.09	128.5	4.99	153.5	5.86	178.5	6.69
104.0	4.11	129.0	5.01	154.0	5.87	179.0	6.71
104.5	4.13	129.5	5.03	154.5	5.89	179.5	6.72
105.0	4.15	130.0	5.05	155.0	5.91	180.0	6.74
105.5	4.17	130.5	5.06	155.5	5.93	180.5	6.76
106.0	4.18	131.0	5.08	156.0	5.94	181.0	6.77
106.5	4.20	131.5	5.10	156.5	5.96	181.5	6.79
107.0	4.22	132.0	5.12	157.0	5.98	182.0	6.80
107.5	4.24	132.5	5.13	157.5	5.99	182.5	6.82
108.0	4.26	133.0	5.15	158.0	6.01	183.0	6.84
108.5	4.28	133.5	5.17	158.5	6.03	183.5	6.85
109.0	4.29	134.0	5.19	159.0	6.04	184.0	6.87
109.5	4.31	134.5	5.20	159.5	6.06	184.5	6.88
110.0	4.33	135.0	5.22	160.0	6.08	185.0	6.90
110.5	4.35	135.5	5.24	160.5	6.09	185.5	6.92
111.0	4.37	136.0	5.26	161.0	6.11	186.0	6.93
111.5	4.38	136.5	5.27	161.5	6.13	186.5	6.95
112.0	4.40	137.0	5.29	162.0	6.14	187.0	6.97
112.5	4.42	137.5	5.31	162.5	6.16	187.5	6.98
113.0	4.44	138.0	5.32	163.0	6.18	188.0	7.00
113.5	4.46	138.5	5.34	163.5	6.19	188.5	7.01
114.0	4.47	139.0	5.36	164.0	6.21	189.0	7.03
114.5	4.49	139.5	5.38	164.5	6.23	189.5	7.05
115.0	4.51	140.0	5.39	165.0	6.24	190.0	7.06
115.5	4.53	140.5	5.41	165.5	6.26	190.5	7.08
116.0	4.55	141.0	5.43	166.0	6.28	191.0	7.09
116.5	4.56	141.5	5.45	166.5	6.29	191.5	7.11
117.0	4.58	142.0	5.46	167.0	6.31	192.0	7.13
117.5	4.60	142.5	5.48	167.5	6.33	192.5	7.14
118.0	4.62	143.0	5.50	168.0	6.34	193.0	7.16
118.5	4.64	143.5	5.52	168.5	6.36	193.5	7.17
119.0	4.65	144.0	5.53	169.0	6.38	194.0	7.19
119.5	4.67	144.5	5.55	169.5	6.39	194.5	7.21
120.0	4.69	145.0	5.57	170.0	6.41	195.0	7.22
120.5	4.71	145.5	5.58	170.5	6.43	195.5	7.24
121.0	4.73	146.0	5.60	171.0	6.44	196.0	7.25
121.5	4.74	146.5	5.62	171.5	6.46	196.5	7.27
122.0	4.76	147.0	5.64	172.0	6.48	197.0	7.29
122.5	4.78	147.5	5.65	172.5	6.49	197.5	7.30
123.0	4.80	148.0	5.67	173.0	6.51	198.0	7.32
123.5	4.82	148.5	5.69	173.5	6.53	198.5	7.33
124.0	4.83	149.0	5.70	174.0	6.54	199.0	7.35
124.5	4.85	149.5	5.72	174.5	6.56	199.5	7.36
125.0	4.87	150.0	5.74	175.0	6.58	200.0	7.38

Temperature, °F

77.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C							
						26.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.05	50.5	2.06	75.5	3.03
1.0	0.02	26.0	1.07	51.0	2.08	76.0	3.05
1.5	0.04	26.5	1.09	51.5	2.10	76.5	3.07
2.0	0.06	27.0	1.11	52.0	2.12	77.0	3.09
2.5	0.09	27.5	1.13	52.5	2.14	77.5	3.11
3.0	0.11	28.0	1.15	53.0	2.16	78.0	3.13
3.5	0.13	28.5	1.17	53.5	2.18	78.5	3.15
4.0	0.15	29.0	1.19	54.0	2.20	79.0	3.17
4.5	0.17	29.5	1.21	54.5	2.22	79.5	3.18
5.0	0.19	30.0	1.23	55.0	2.24	80.0	3.20
5.5	0.21	30.5	1.25	55.5	2.26	80.5	3.22
6.0	0.23	31.0	1.28	56.0	2.28	81.0	3.24
6.5	0.26	31.5	1.30	56.5	2.30	81.5	3.26
7.0	0.28	32.0	1.32	57.0	2.32	82.0	3.28
7.5	0.30	32.5	1.34	57.5	2.34	82.5	3.30
8.0	0.32	33.0	1.36	58.0	2.36	83.0	3.32
8.5	0.34	33.5	1.38	58.5	2.37	83.5	3.34
9.0	0.36	34.0	1.40	59.0	2.39	84.0	3.35
9.5	0.38	34.5	1.42	59.5	2.41	84.5	3.37
10.0	0.40	35.0	1.44	60.0	2.43	85.0	3.39
10.5	0.42	35.5	1.46	60.5	2.45	85.5	3.41
11.0	0.45	36.0	1.48	61.0	2.47	86.0	3.43
11.5	0.47	36.5	1.50	61.5	2.49	86.5	3.45
12.0	0.49	37.0	1.52	62.0	2.51	87.0	3.47
12.5	0.51	37.5	1.54	62.5	2.53	87.5	3.49
13.0	0.53	38.0	1.56	63.0	2.55	88.0	3.50
13.5	0.55	38.5	1.58	63.5	2.57	88.5	3.52
14.0	0.57	39.0	1.60	64.0	2.59	89.0	3.54
14.5	0.59	39.5	1.62	64.5	2.61	89.5	3.56
15.0	0.61	40.0	1.64	65.0	2.63	90.0	3.58
15.5	0.63	40.5	1.66	65.5	2.65	90.5	3.60
16.0	0.66	41.0	1.68	66.0	2.67	91.0	3.62
16.5	0.68	41.5	1.70	66.5	2.69	91.5	3.63
17.0	0.70	42.0	1.72	67.0	2.71	92.0	3.65
17.5	0.72	42.5	1.74	67.5	2.72	92.5	3.67
18.0	0.74	43.0	1.76	68.0	2.74	93.0	3.69
18.5	0.76	43.5	1.78	68.5	2.76	93.5	3.71
19.0	0.78	44.0	1.80	69.0	2.78	94.0	3.73
19.5	0.80	44.5	1.82	69.5	2.80	94.5	3.75
20.0	0.82	45.0	1.84	70.0	2.82	95.0	3.76
20.5	0.84	45.5	1.86	70.5	2.84	95.5	3.78
21.0	0.86	46.0	1.88	71.0	2.86	96.0	3.80
21.5	0.88	46.5	1.90	71.5	2.88	96.5	3.82
22.0	0.91	47.0	1.92	72.0	2.90	97.0	3.84
22.5	0.93	47.5	1.94	72.5	2.92	97.5	3.86
23.0	0.95	48.0	1.96	73.0	2.94	98.0	3.88
23.5	0.97	48.5	1.98	73.5	2.96	98.5	3.89
24.0	0.99	49.0	2.00	74.0	2.97	99.0	3.91
24.5	1.01	49.5	2.02	74.5	2.99	99.5	3.93
25.0	1.03	50.0	2.04	75.0	3.01	100.0	3.95

Temperature, °F

78.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	3.97	125.5	4.87	150.5	5.73	175.5	6.57
101.0	3.99	126.0	4.89	151.0	5.75	176.0	6.58
101.5	4.00	126.5	4.90	151.5	5.77	176.5	6.60
102.0	4.02	127.0	4.92	152.0	5.78	177.0	6.62
102.5	4.04	127.5	4.94	152.5	5.80	177.5	6.63
103.0	4.06	128.0	4.96	153.0	5.82	178.0	6.65
103.5	4.08	128.5	4.97	153.5	5.84	178.5	6.66
104.0	4.10	129.0	4.99	154.0	5.85	179.0	6.68
104.5	4.11	129.5	5.01	154.5	5.87	179.5	6.70
105.0	4.13	130.0	5.03	155.0	5.89	180.0	6.71
105.5	4.15	130.5	5.04	155.5	5.90	180.5	6.73
106.0	4.17	131.0	5.06	156.0	5.92	181.0	6.75
106.5	4.19	131.5	5.08	156.5	5.94	181.5	6.76
107.0	4.20	132.0	5.10	157.0	5.95	182.0	6.78
107.5	4.22	132.5	5.11	157.5	5.97	182.5	6.79
108.0	4.24	133.0	5.13	158.0	5.99	183.0	6.81
108.5	4.26	133.5	5.15	158.5	6.00	183.5	6.83
109.0	4.28	134.0	5.17	159.0	6.02	184.0	6.84
109.5	4.30	134.5	5.18	159.5	6.04	184.5	6.86
110.0	4.31	135.0	5.20	160.0	6.05	185.0	6.87
110.5	4.33	135.5	5.22	160.5	6.07	185.5	6.89
111.0	4.35	136.0	5.24	161.0	6.09	186.0	6.91
111.5	4.37	136.5	5.25	161.5	6.10	186.5	6.92
112.0	4.39	137.0	5.27	162.0	6.12	187.0	6.94
112.5	4.40	137.5	5.29	162.5	6.14	187.5	6.96
113.0	4.42	138.0	5.30	163.0	6.15	188.0	6.97
113.5	4.44	138.5	5.32	163.5	6.17	188.5	6.99
114.0	4.46	139.0	5.34	164.0	6.19	189.0	7.00
114.5	4.48	139.5	5.36	164.5	6.20	189.5	7.02
115.0	4.49	140.0	5.37	165.0	6.22	190.0	7.04
115.5	4.51	140.5	5.39	165.5	6.24	190.5	7.05
116.0	4.53	141.0	5.41	166.0	6.25	191.0	7.07
116.5	4.55	141.5	5.43	166.5	6.27	191.5	7.08
117.0	4.57	142.0	5.44	167.0	6.29	192.0	7.10
117.5	4.58	142.5	5.46	167.5	6.30	192.5	7.12
118.0	4.60	143.0	5.48	168.0	6.32	193.0	7.13
118.5	4.62	143.5	5.49	168.5	6.34	193.5	7.15
119.0	4.64	144.0	5.51	169.0	6.35	194.0	7.16
119.5	4.65	144.5	5.53	169.5	6.37	194.5	7.18
120.0	4.67	145.0	5.55	170.0	6.39	195.0	7.19
120.5	4.69	145.5	5.56	170.5	6.40	195.5	7.21
121.0	4.71	146.0	5.58	171.0	6.42	196.0	7.23
121.5	4.73	146.5	5.60	171.5	6.44	196.5	7.24
122.0	4.74	147.0	5.61	172.0	6.45	197.0	7.26
122.5	4.76	147.5	5.63	172.5	6.47	197.5	7.27
123.0	4.78	148.0	5.65	173.0	6.48	198.0	7.29
123.5	4.80	148.5	5.67	173.5	6.50	198.5	7.31
124.0	4.81	149.0	5.68	174.0	6.52	199.0	7.32
124.5	4.83	149.5	5.70	174.5	6.53	199.5	7.34
125.0	4.85	150.0	5.72	175.0	6.55	200.0	7.35

Temperature, °F

78.8

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				27.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.05	50.5	2.05	75.5	3.02
1.0	0.02	26.0	1.07	51.0	2.07	76.0	3.04
1.5	0.04	26.5	1.09	51.5	2.09	76.5	3.06
2.0	0.06	27.0	1.11	52.0	2.11	77.0	3.08
2.5	0.09	27.5	1.13	52.5	2.13	77.5	3.10
3.0	0.11	28.0	1.15	53.0	2.15	78.0	3.11
3.5	0.13	28.5	1.17	53.5	2.17	78.5	3.13
4.0	0.15	29.0	1.19	54.0	2.19	79.0	3.15
4.5	0.17	29.5	1.21	54.5	2.21	79.5	3.17
5.0	0.19	30.0	1.23	55.0	2.23	80.0	3.19
5.5	0.21	30.5	1.25	55.5	2.25	80.5	3.21
6.0	0.23	31.0	1.27	56.0	2.27	81.0	3.23
6.5	0.25	31.5	1.29	56.5	2.29	81.5	3.25
7.0	0.28	32.0	1.31	57.0	2.31	82.0	3.27
7.5	0.30	32.5	1.33	57.5	2.33	82.5	3.28
8.0	0.32	33.0	1.35	58.0	2.35	83.0	3.30
8.5	0.34	33.5	1.37	58.5	2.37	83.5	3.32
9.0	0.36	34.0	1.39	59.0	2.39	84.0	3.34
9.5	0.38	34.5	1.41	59.5	2.40	84.5	3.36
10.0	0.40	35.0	1.43	60.0	2.42	85.0	3.38
10.5	0.42	35.5	1.45	60.5	2.44	85.5	3.40
11.0	0.44	36.0	1.47	61.0	2.46	86.0	3.42
11.5	0.46	36.5	1.49	61.5	2.48	86.5	3.43
12.0	0.49	37.0	1.51	62.0	2.50	87.0	3.45
12.5	0.51	37.5	1.53	62.5	2.52	87.5	3.47
13.0	0.53	38.0	1.55	63.0	2.54	88.0	3.49
13.5	0.55	38.5	1.57	63.5	2.56	88.5	3.51
14.0	0.57	39.0	1.59	64.0	2.58	89.0	3.53
14.5	0.59	39.5	1.61	64.5	2.60	89.5	3.55
15.0	0.61	40.0	1.63	65.0	2.62	90.0	3.57
15.5	0.63	40.5	1.65	65.5	2.64	90.5	3.58
16.0	0.65	41.0	1.67	66.0	2.66	91.0	3.60
16.5	0.67	41.5	1.69	66.5	2.68	91.5	3.62
17.0	0.69	42.0	1.71	67.0	2.70	92.0	3.64
17.5	0.72	42.5	1.73	67.5	2.71	92.5	3.66
18.0	0.74	43.0	1.75	68.0	2.73	93.0	3.68
18.5	0.76	43.5	1.77	68.5	2.75	93.5	3.69
19.0	0.78	44.0	1.79	69.0	2.77	94.0	3.71
19.5	0.80	44.5	1.81	69.5	2.79	94.5	3.73
20.0	0.82	45.0	1.83	70.0	2.81	95.0	3.75
20.5	0.84	45.5	1.85	70.5	2.83	95.5	3.77
21.0	0.86	46.0	1.87	71.0	2.85	96.0	3.79
21.5	0.88	46.5	1.89	71.5	2.87	96.5	3.81
22.0	0.90	47.0	1.91	72.0	2.89	97.0	3.82
22.5	0.92	47.5	1.93	72.5	2.91	97.5	3.84
23.0	0.94	48.0	1.95	73.0	2.92	98.0	3.86
23.5	0.96	48.5	1.97	73.5	2.94	98.5	3.88
24.0	0.98	49.0	1.99	74.0	2.96	99.0	3.90
24.5	1.00	49.5	2.01	74.5	2.98	99.5	3.92
25.0	1.03	50.0	2.03	75.0	3.00	100.0	3.93

Temperature, °F

80.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C

27.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.95	125.5	4.85	150.5	5.71	175.5	6.54				
101.0	3.97	126.0	4.87	151.0	5.73	176.0	6.56				
101.5	3.99	126.5	4.88	151.5	5.75	176.5	6.57				
102.0	4.01	127.0	4.90	152.0	5.76	177.0	6.59				
102.5	4.03	127.5	4.92	152.5	5.78	177.5	6.61				
103.0	4.04	128.0	4.94	153.0	5.80	178.0	6.62				
103.5	4.06	128.5	4.95	153.5	5.81	178.5	6.64				
104.0	4.08	129.0	4.97	154.0	5.83	179.0	6.66				
104.5	4.10	129.5	4.99	154.5	5.85	179.5	6.67				
105.0	4.12	130.0	5.01	155.0	5.86	180.0	6.69				
105.5	4.13	130.5	5.02	155.5	5.88	180.5	6.70				
106.0	4.15	131.0	5.04	156.0	5.90	181.0	6.72				
106.5	4.17	131.5	5.06	156.5	5.91	181.5	6.74				
107.0	4.19	132.0	5.08	157.0	5.93	182.0	6.75				
107.5	4.21	132.5	5.09	157.5	5.95	182.5	6.77				
108.0	4.22	133.0	5.11	158.0	5.96	183.0	6.78				
108.5	4.24	133.5	5.13	158.5	5.98	183.5	6.80				
109.0	4.26	134.0	5.15	159.0	6.00	184.0	6.82				
109.5	4.28	134.5	5.16	159.5	6.01	184.5	6.83				
110.0	4.30	135.0	5.18	160.0	6.03	185.0	6.85				
110.5	4.31	135.5	5.20	160.5	6.05	185.5	6.86				
111.0	4.33	136.0	5.22	161.0	6.06	186.0	6.88				
111.5	4.35	136.5	5.23	161.5	6.08	186.5	6.90				
112.0	4.37	137.0	5.25	162.0	6.10	187.0	6.91				
112.5	4.39	137.5	5.27	162.5	6.11	187.5	6.93				
113.0	4.40	138.0	5.28	163.0	6.13	188.0	6.94				
113.5	4.42	138.5	5.30	163.5	6.15	188.5	6.96				
114.0	4.44	139.0	5.32	164.0	6.16	189.0	6.98				
114.5	4.46	139.5	5.34	164.5	6.18	189.5	6.99				
115.0	4.48	140.0	5.35	165.0	6.20	190.0	7.01				
115.5	4.49	140.5	5.37	165.5	6.21	190.5	7.02				
116.0	4.51	141.0	5.39	166.0	6.23	191.0	7.04				
116.5	4.53	141.5	5.40	166.5	6.25	191.5	7.06				
117.0	4.55	142.0	5.42	167.0	6.26	192.0	7.07				
117.5	4.57	142.5	5.44	167.5	6.28	192.5	7.09				
118.0	4.58	143.0	5.46	168.0	6.30	193.0	7.10				
118.5	4.60	143.5	5.47	168.5	6.31	193.5	7.12				
119.0	4.62	144.0	5.49	169.0	6.33	194.0	7.14				
119.5	4.64	144.5	5.51	169.5	6.35	194.5	7.15				
120.0	4.65	145.0	5.52	170.0	6.36	195.0	7.17				
120.5	4.67	145.5	5.54	170.5	6.38	195.5	7.18				
121.0	4.69	146.0	5.56	171.0	6.39	196.0	7.20				
121.5	4.71	146.5	5.58	171.5	6.41	196.5	7.21				
122.0	4.73	147.0	5.59	172.0	6.43	197.0	7.23				
122.5	4.74	147.5	5.61	172.5	6.44	197.5	7.25				
123.0	4.76	148.0	5.63	173.0	6.46	198.0	7.26				
123.5	4.78	148.5	5.64	173.5	6.48	198.5	7.28				
124.0	4.80	149.0	5.66	174.0	6.49	199.0	7.29				
124.5	4.81	149.5	5.68	174.5	6.51	199.5	7.31				
125.0	4.83	150.0	5.69	175.0	6.53	200.0	7.32				

Temperature, °F

80.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

28•0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•04	50•5	2•04	75•5	3•01
1•0	0•02	26•0	1•06	51•0	2•06	76•0	3•03
1•5	0•04	26•5	1•08	51•5	2•08	76•5	3•05
2•0	0•06	27•0	1•10	52•0	2•10	77•0	3•07
2•5	0•08	27•5	1•12	52•5	2•12	77•5	3•08
3•0	0•11	28•0	1•14	53•0	2•14	78•0	3•10
3•5	0•13	28•5	1•16	53•5	2•16	78•5	3•12
4•0	0•15	29•0	1•18	54•0	2•18	79•0	3•14
4•5	0•17	29•5	1•20	54•5	2•20	79•5	3•16
5•0	0•19	30•0	1•22	55•0	2•22	80•0	3•18
5•5	0•21	30•5	1•25	55•5	2•24	80•5	3•20
6•0	0•23	31•0	1•27	56•0	2•26	81•0	3•22
6•5	0•25	31•5	1•29	56•5	2•28	81•5	3•23
7•0	0•27	32•0	1•31	57•0	2•30	82•0	3•25
7•5	0•30	32•5	1•33	57•5	2•32	82•5	3•27
8•0	0•32	33•0	1•35	58•0	2•34	83•0	3•29
8•5	0•34	33•5	1•37	58•5	2•36	83•5	3•31
9•0	0•36	34•0	1•39	59•0	2•38	84•0	3•33
9•5	0•38	34•5	1•41	59•5	2•40	84•5	3•35
10•0	0•40	35•0	1•43	60•0	2•41	85•0	3•37
10•5	0•42	35•5	1•45	60•5	2•43	85•5	3•38
11•0	0•44	36•0	1•47	61•0	2•45	86•0	3•40
11•5	0•46	36•5	1•49	61•5	2•47	86•5	3•42
12•0	0•48	37•0	1•51	62•0	2•49	87•0	3•44
12•5	0•50	37•5	1•53	62•5	2•51	87•5	3•46
13•0	0•53	38•0	1•55	63•0	2•53	88•0	3•48
13•5	0•55	38•5	1•57	63•5	2•55	88•5	3•50
14•0	0•57	39•0	1•59	64•0	2•57	89•0	3•51
14•5	0•59	39•5	1•61	64•5	2•59	89•5	3•53
15•0	0•61	40•0	1•63	65•0	2•61	90•0	3•55
15•5	0•63	40•5	1•65	65•5	2•63	90•5	3•57
16•0	0•65	41•0	1•67	66•0	2•65	91•0	3•59
16•5	0•67	41•5	1•69	66•5	2•67	91•5	3•61
17•0	0•69	42•0	1•71	67•0	2•68	92•0	3•63
17•5	0•71	42•5	1•73	67•5	2•70	92•5	3•64
18•0	0•73	43•0	1•75	68•0	2•72	93•0	3•66
18•5	0•75	43•5	1•77	68•5	2•74	93•5	3•68
19•0	0•77	44•0	1•79	69•0	2•76	94•0	3•70
19•5	0•80	44•5	1•81	69•5	2•78	94•5	3•72
20•0	0•82	45•0	1•83	70•0	2•80	95•0	3•74
20•5	0•84	45•5	1•85	70•5	2•82	95•5	3•75
21•0	0•86	46•0	1•87	71•0	2•84	96•0	3•77
21•5	0•88	46•5	1•89	71•5	2•86	96•5	3•79
22•0	0•90	47•0	1•91	72•0	2•88	97•0	3•81
22•5	0•92	47•5	1•93	72•5	2•89	97•5	3•83
23•0	0•94	48•0	1•95	73•0	2•91	98•0	3•85
23•5	0•96	48•5	1•97	73•5	2•93	98•5	3•86
24•0	0•98	49•0	1•98	74•0	2•95	99•0	3•88
24•5	1•00	49•5	2•00	74•5	2•97	99•5	3•90
25•0	1•02	50•0	2•02	75•0	2•99	100•0	3•92

Temperature, °F

82•4

Temperature, °C 28.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.94	125.5	4.83	150.5	5.69	175.5	6.52				
101.0	3.95	126.0	4.85	151.0	5.71	176.0	6.53				
101.5	3.97	126.5	4.87	151.5	5.72	176.5	6.55				
102.0	3.99	127.0	4.88	152.0	5.74	177.0	6.57				
102.5	4.01	127.5	4.90	152.5	5.76	177.5	6.58				
103.0	4.03	128.0	4.92	153.0	5.77	178.0	6.60				
103.5	4.05	128.5	4.93	153.5	5.79	178.5	6.61				
104.0	4.06	129.0	4.95	154.0	5.81	179.0	6.63				
104.5	4.08	129.5	4.97	154.5	5.82	179.5	6.65				
105.0	4.10	130.0	4.99	155.0	5.84	180.0	6.66				
105.5	4.12	130.5	5.00	155.5	5.86	180.5	6.68				
106.0	4.14	131.0	5.02	156.0	5.87	181.0	6.69				
106.5	4.15	131.5	5.04	156.5	5.89	181.5	6.71				
107.0	4.17	132.0	5.06	157.0	5.91	182.0	6.73				
107.5	4.19	132.5	5.07	157.5	5.92	182.5	6.74				
108.0	4.21	133.0	5.09	158.0	5.94	183.0	6.76				
108.5	4.23	133.5	5.11	158.5	5.96	183.5	6.77				
109.0	4.24	134.0	5.13	159.0	5.97	184.0	6.79				
109.5	4.26	134.5	5.14	159.5	5.99	184.5	6.81				
110.0	4.28	135.0	5.16	160.0	6.01	185.0	6.82				
110.5	4.30	135.5	5.18	160.5	6.02	185.5	6.84				
111.0	4.32	136.0	5.20	161.0	6.04	186.0	6.85				
111.5	4.33	136.5	5.21	161.5	6.06	186.5	6.87				
112.0	4.35	137.0	5.23	162.0	6.07	187.0	6.89				
112.5	4.37	137.5	5.25	162.5	6.09	187.5	6.90				
113.0	4.39	138.0	5.26	163.0	6.11	188.0	6.92				
113.5	4.41	138.5	5.28	163.5	6.12	188.5	6.93				
114.0	4.42	139.0	5.30	164.0	6.14	189.0	6.95				
114.5	4.44	139.5	5.32	164.5	6.16	189.5	6.97				
115.0	4.46	140.0	5.33	165.0	6.17	190.0	6.98				
115.5	4.48	140.5	5.35	165.5	6.19	190.5	7.00				
116.0	4.49	141.0	5.37	166.0	6.21	191.0	7.01				
116.5	4.51	141.5	5.38	166.5	6.22	191.5	7.03				
117.0	4.53	142.0	5.40	167.0	6.24	192.0	7.05				
117.5	4.55	142.5	5.42	167.5	6.26	192.5	7.06				
118.0	4.57	143.0	5.44	168.0	6.27	193.0	7.08				
118.5	4.58	143.5	5.45	168.5	6.29	193.5	7.09				
119.0	4.60	144.0	5.47	169.0	6.30	194.0	7.11				
119.5	4.62	144.5	5.49	169.5	6.32	194.5	7.12				
120.0	4.64	145.0	5.50	170.0	6.34	195.0	7.14				
120.5	4.65	145.5	5.52	170.5	6.35	195.5	7.16				
121.0	4.67	146.0	5.54	171.0	6.37	196.0	7.17				
121.5	4.69	146.5	5.55	171.5	6.39	196.5	7.19				
122.0	4.71	147.0	5.57	172.0	6.40	197.0	7.20				
122.5	4.72	147.5	5.59	172.5	6.42	197.5	7.22				
123.0	4.74	148.0	5.61	173.0	6.44	198.0	7.23				
123.5	4.76	148.5	5.62	173.5	6.45	198.5	7.25				
124.0	4.78	149.0	5.64	174.0	6.47	199.0	7.27				
124.5	4.79	149.5	5.66	174.5	6.48	199.5	7.28				
125.0	4.81	150.0	5.67	175.0	6.50	200.0	7.30				

Temperature, °F

82.4

29•0

		Temperature, °C					
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•04	50•5	2•04	75•5	3•00
1•0	0•02	26•0	1•06	51•0	2•06	76•0	3•02
1•5	0•04	26•5	1•08	51•5	2•07	76•5	3•03
2•0	0•06	27•0	1•10	52•0	2•09	77•0	3•05
2•5	0•08	27•5	1•12	52•5	2•11	77•5	3•07
3•0	0•11	28•0	1•14	53•0	2•13	78•0	3•09
3•5	0•13	28•5	1•16	53•5	2•15	78•5	3•11
4•0	0•15	29•0	1•18	54•0	2•17	79•0	3•13
4•5	0•17	29•5	1•20	54•5	2•19	79•5	3•15
5•0	0•19	30•0	1•22	55•0	2•21	80•0	3•17
5•5	0•21	30•5	1•24	55•5	2•23	80•5	3•18
6•0	0•23	31•0	1•26	56•0	2•25	81•0	3•20
6•5	0•25	31•5	1•28	56•5	2•27	81•5	3•22
7•0	0•27	32•0	1•30	57•0	2•29	82•0	3•24
7•5	0•29	32•5	1•32	57•5	2•31	82•5	3•26
8•0	0•32	33•0	1•34	58•0	2•33	83•0	3•28
8•5	0•34	33•5	1•36	58•5	2•35	83•5	3•30
9•0	0•36	34•0	1•38	59•0	2•37	84•0	3•32
9•5	0•38	34•5	1•40	59•5	2•39	84•5	3•33
10•0	0•40	35•0	1•42	60•0	2•41	85•0	3•35
10•5	0•42	35•5	1•44	60•5	2•42	85•5	3•37
11•0	0•44	36•0	1•46	61•0	2•44	86•0	3•39
11•5	0•46	36•5	1•48	61•5	2•46	86•5	3•41
12•0	0•48	37•0	1•50	62•0	2•48	87•0	3•43
12•5	0•50	37•5	1•52	62•5	2•50	87•5	3•44
13•0	0•52	38•0	1•54	63•0	2•52	88•0	3•46
13•5	0•54	38•5	1•56	63•5	2•54	88•5	3•48
14•0	0•57	39•0	1•58	64•0	2•56	89•0	3•50
14•5	0•59	39•5	1•60	64•5	2•58	89•5	3•52
15•0	0•61	40•0	1•62	65•0	2•60	90•0	3•54
15•5	0•63	40•5	1•64	65•5	2•62	90•5	3•56
16•0	0•65	41•0	1•66	66•0	2•64	91•0	3•57
16•5	0•67	41•5	1•68	66•5	2•65	91•5	3•59
17•0	0•69	42•0	1•70	67•0	2•67	92•0	3•61
17•5	0•71	42•5	1•72	67•5	2•69	92•5	3•63
18•0	0•73	43•0	1•74	68•0	2•71	93•0	3•65
18•5	0•75	43•5	1•76	68•5	2•73	93•5	3•67
19•0	0•77	44•0	1•78	69•0	2•75	94•0	3•68
19•5	0•79	44•5	1•80	69•5	2•77	94•5	3•70
20•0	0•81	45•0	1•82	70•0	2•79	95•0	3•72
20•5	0•83	45•5	1•84	70•5	2•81	95•5	3•74
21•0	0•85	46•0	1•86	71•0	2•83	96•0	3•76
21•5	0•87	46•5	1•88	71•5	2•85	96•5	3•78
22•0	0•89	47•0	1•90	72•0	2•86	97•0	3•79
22•5	0•91	47•5	1•92	72•5	2•88	97•5	3•81
23•0	0•94	48•0	1•94	73•0	2•90	98•0	3•83
23•5	0•96	48•5	1•96	73•5	2•92	98•5	3•85
24•0	0•98	49•0	1•98	74•0	2•94	99•0	3•87
24•5	1•00	49•5	2•00	74•5	2•96	99•5	3•89
25•0	1•02	50•0	2•02	75•0	2•98	100•0	3•90

Temperature, °F

84•2

Temperature, °C 29.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.92	125.5	4.81	150.5	5.67	175.5	6.49				
101.0	3.94	126.0	4.83	151.0	5.68	176.0	6.51				
101.5	3.96	126.5	4.85	151.5	5.70	176.5	6.52				
102.0	3.98	127.0	4.86	152.0	5.72	177.0	6.54				
102.5	3.99	127.5	4.88	152.5	5.73	177.5	6.56				
103.0	4.01	128.0	4.90	153.0	5.75	178.0	6.57				
103.5	4.03	128.5	4.92	153.5	5.77	178.5	6.59				
104.0	4.05	129.0	4.93	154.0	5.78	179.0	6.60				
104.5	4.07	129.5	4.95	154.5	5.80	179.5	6.62				
105.0	4.08	130.0	4.97	155.0	5.82	180.0	6.64				
105.5	4.10	130.5	4.99	155.5	5.83	180.5	6.65				
106.0	4.12	131.0	5.00	156.0	5.85	181.0	6.67				
106.5	4.14	131.5	5.02	156.5	5.87	181.5	6.68				
107.0	4.16	132.0	5.04	157.0	5.88	182.0	6.70				
107.5	4.17	132.5	5.05	157.5	5.90	182.5	6.72				
108.0	4.19	133.0	5.07	158.0	5.92	183.0	6.73				
108.5	4.21	133.5	5.09	158.5	5.93	183.5	6.75				
109.0	4.23	134.0	5.11	159.0	5.95	184.0	6.76				
109.5	4.25	134.5	5.12	159.5	5.97	184.5	6.78				
110.0	4.26	135.0	5.14	160.0	5.98	185.0	6.80				
110.5	4.28	135.5	5.16	160.5	6.00	185.5	6.81				
111.0	4.30	136.0	5.17	161.0	6.02	186.0	6.83				
111.5	4.32	136.5	5.19	161.5	6.03	186.5	6.84				
112.0	4.33	137.0	5.21	162.0	6.05	187.0	6.86				
112.5	4.35	137.5	5.23	162.5	6.07	187.5	6.88				
113.0	4.37	138.0	5.24	163.0	6.08	188.0	6.89				
113.5	4.39	138.5	5.26	163.5	6.10	188.5	6.91				
114.0	4.41	139.0	5.28	164.0	6.12	189.0	6.92				
114.5	4.42	139.5	5.29	164.5	6.13	189.5	6.94				
115.0	4.44	140.0	5.31	165.0	6.15	190.0	6.96				
115.5	4.46	140.5	5.33	165.5	6.17	190.5	6.97				
116.0	4.48	141.0	5.35	166.0	6.18	191.0	6.99				
116.5	4.49	141.5	5.36	166.5	6.20	191.5	7.00				
117.0	4.51	142.0	5.38	167.0	6.21	192.0	7.02				
117.5	4.53	142.5	5.40	167.5	6.23	192.5	7.03				
118.0	4.55	143.0	5.41	168.0	6.25	193.0	7.05				
118.5	4.57	143.5	5.43	168.5	6.26	193.5	7.07				
119.0	4.58	144.0	5.45	169.0	6.28	194.0	7.08				
119.5	4.60	144.5	5.46	169.5	6.30	194.5	7.10				
120.0	4.62	145.0	5.48	170.0	6.31	195.0	7.11				
120.5	4.64	145.5	5.50	170.5	6.33	195.5	7.13				
121.0	4.65	146.0	5.52	171.0	6.35	196.0	7.14				
121.5	4.67	146.5	5.53	171.5	6.36	196.5	7.16				
122.0	4.69	147.0	5.55	172.0	6.38	197.0	7.18				
122.5	4.71	147.5	5.57	172.5	6.39	197.5	7.19				
123.0	4.72	148.0	5.58	173.0	6.41	198.0	7.21				
123.5	4.74	148.5	5.60	173.5	6.43	198.5	7.22				
124.0	4.76	149.0	5.62	174.0	6.44	199.0	7.24				
124.5	4.78	149.5	5.63	174.5	6.46	199.5	7.25				
125.0	4.79	150.0	5.65	175.0	6.48	200.0	7.27				

Temperature, °F

84.2

3000

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.03	50.5	2.03	75.5	2.98
1.0	0.02	26.0	1.05	51.0	2.05	76.0	3.00
1.5	0.04	26.5	1.07	51.5	2.07	76.5	3.02
2.0	0.06	27.0	1.09	52.0	2.09	77.0	3.04
2.5	0.08	27.5	1.11	52.5	2.11	77.5	3.06
3.0	0.11	28.0	1.13	53.0	2.13	78.0	3.08
3.5	0.13	28.5	1.15	53.5	2.14	78.5	3.10
4.0	0.15	29.0	1.17	54.0	2.16	79.0	3.12
4.5	0.17	29.5	1.19	54.5	2.18	79.5	3.13
5.0	0.19	30.0	1.22	55.0	2.20	80.0	3.15
5.5	0.21	30.5	1.24	55.5	2.22	80.5	3.17
6.0	0.23	31.0	1.26	56.0	2.24	81.0	3.19
6.5	0.25	31.5	1.28	56.5	2.26	81.5	3.21
7.0	0.27	32.0	1.30	57.0	2.28	82.0	3.23
7.5	0.29	32.5	1.32	57.5	2.30	82.5	3.25
8.0	0.31	33.0	1.34	58.0	2.32	83.0	3.26
8.5	0.33	33.5	1.36	58.5	2.34	83.5	3.28
9.0	0.36	34.0	1.38	59.0	2.36	84.0	3.30
9.5	0.38	34.5	1.40	59.5	2.38	84.5	3.32
10.0	0.40	35.0	1.42	60.0	2.40	85.0	3.34
10.5	0.42	35.5	1.44	60.5	2.41	85.5	3.36
11.0	0.44	36.0	1.46	61.0	2.43	86.0	3.38
11.5	0.46	36.5	1.48	61.5	2.45	86.5	3.39
12.0	0.48	37.0	1.50	62.0	2.47	87.0	3.41
12.5	0.50	37.5	1.52	62.5	2.49	87.5	3.43
13.0	0.52	38.0	1.54	63.0	2.51	88.0	3.45
13.5	0.54	38.5	1.56	63.5	2.53	88.5	3.47
14.0	0.56	39.0	1.58	64.0	2.55	89.0	3.49
14.5	0.58	39.5	1.59	64.5	2.57	89.5	3.50
15.0	0.60	40.0	1.61	65.0	2.59	90.0	3.52
15.5	0.62	40.5	1.63	65.5	2.61	90.5	3.54
16.0	0.65	41.0	1.65	66.0	2.63	91.0	3.56
16.5	0.67	41.5	1.67	66.5	2.64	91.5	3.58
17.0	0.69	42.0	1.69	67.0	2.66	92.0	3.60
17.5	0.71	42.5	1.71	67.5	2.68	92.5	3.62
18.0	0.73	43.0	1.73	68.0	2.70	93.0	3.63
18.5	0.75	43.5	1.75	68.5	2.72	93.5	3.65
19.0	0.77	44.0	1.77	69.0	2.74	94.0	3.67
19.5	0.79	44.5	1.79	69.5	2.76	94.5	3.69
20.0	0.81	45.0	1.81	70.0	2.78	95.0	3.71
20.5	0.83	45.5	1.83	70.5	2.80	95.5	3.72
21.0	0.85	46.0	1.85	71.0	2.82	96.0	3.74
21.5	0.87	46.5	1.87	71.5	2.83	96.5	3.76
22.0	0.89	47.0	1.89	72.0	2.85	97.0	3.78
22.5	0.91	47.5	1.91	72.5	2.87	97.5	3.80
23.0	0.93	48.0	1.93	73.0	2.89	98.0	3.82
23.5	0.95	48.5	1.95	73.5	2.91	98.5	3.83
24.0	0.97	49.0	1.97	74.0	2.93	99.0	3.85
24.5	0.99	49.5	1.99	74.5	2.95	99.5	3.87
25.0	1.01	50.0	2.01	75.0	2.97	100.0	3.89

Temperature, °C

86.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

		Temperature, °C				30.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
100.5	3.91	125.5	4.79	150.5	5.65	175.5	6.47
101.0	3.92	126.0	4.81	151.0	5.66	176.0	6.48
101.5	3.94	126.5	4.83	151.5	5.68	176.5	6.50
102.0	3.96	127.0	4.84	152.0	5.70	177.0	6.51
102.5	3.98	127.5	4.86	152.5	5.71	177.5	6.53
103.0	4.00	128.0	4.88	153.0	5.73	178.0	6.55
103.5	4.01	128.5	4.90	153.5	5.75	178.5	6.56
104.0	4.03	129.0	4.91	154.0	5.76	179.0	6.58
104.5	4.05	129.5	4.93	154.5	5.78	179.5	6.59
105.0	4.07	130.0	4.95	155.0	5.80	180.0	6.61
105.5	4.09	130.5	4.97	155.5	5.81	180.5	6.63
106.0	4.10	131.0	4.98	156.0	5.83	181.0	6.64
106.5	4.12	131.5	5.00	156.5	5.85	181.5	6.66
107.0	4.14	132.0	5.02	157.0	5.86	182.0	6.67
107.5	4.16	132.5	5.03	157.5	5.88	182.5	6.69
108.0	4.18	133.0	5.05	158.0	5.89	183.0	6.71
108.5	4.19	133.5	5.07	158.5	5.91	183.5	6.72
109.0	4.21	134.0	5.09	159.0	5.93	184.0	6.74
109.5	4.23	134.5	5.10	159.5	5.94	184.5	6.75
110.0	4.25	135.0	5.12	160.0	5.96	185.0	6.77
110.5	4.26	135.5	5.14	160.5	5.98	185.5	6.79
111.0	4.28	136.0	5.15	161.0	5.99	186.0	6.80
111.5	4.30	136.5	5.17	161.5	6.01	186.5	6.82
112.0	4.32	137.0	5.19	162.0	6.03	187.0	6.83
112.5	4.34	137.5	5.21	162.5	6.04	187.5	6.85
113.0	4.35	138.0	5.22	163.0	6.06	188.0	6.87
113.5	4.37	138.5	5.24	163.5	6.08	188.5	6.88
114.0	4.39	139.0	5.26	164.0	6.09	189.0	6.90
114.5	4.41	139.5	5.27	164.5	6.11	189.5	6.91
115.0	4.42	140.0	5.29	165.0	6.13	190.0	6.93
115.5	4.44	140.5	5.31	165.5	6.14	190.5	6.94
116.0	4.46	141.0	5.33	166.0	6.16	191.0	6.96
116.5	4.48	141.5	5.34	166.5	6.17	191.5	6.98
117.0	4.49	142.0	5.36	167.0	6.19	192.0	6.99
117.5	4.51	142.5	5.38	167.5	6.21	192.5	7.01
118.0	4.53	143.0	5.39	168.0	6.22	193.0	7.02
118.5	4.55	143.5	5.41	168.5	6.24	193.5	7.04
119.0	4.57	144.0	5.43	169.0	6.26	194.0	7.05
119.5	4.58	144.5	5.44	169.5	6.27	194.5	7.07
120.0	4.60	145.0	5.46	170.0	6.29	195.0	7.08
120.5	4.62	145.5	5.48	170.5	6.30	195.5	7.10
121.0	4.64	146.0	5.49	171.0	6.32	196.0	7.12
121.5	4.65	146.5	5.51	171.5	6.34	196.5	7.13
122.0	4.67	147.0	5.53	172.0	6.35	197.0	7.15
122.5	4.69	147.5	5.54	172.5	6.37	197.5	7.16
123.0	4.71	148.0	5.56	173.0	6.39	198.0	7.18
123.5	4.72	148.5	5.58	173.5	6.40	198.5	7.19
124.0	4.74	149.0	5.60	174.0	6.42	199.0	7.21
124.5	4.76	149.5	5.61	174.5	6.43	199.5	7.23
125.0	4.77	150.0	5.63	175.0	6.45	200.0	7.24

Temperature, °F

86.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C

31.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.03	50.5	2.02	75.5	2.97
1.0	0.02	26.0	1.05	51.0	2.04	76.0	2.99
1.5	0.04	26.5	1.07	51.5	2.06	76.5	3.01
2.0	0.06	27.0	1.09	52.0	2.08	77.0	3.03
2.5	0.08	27.5	1.11	52.5	2.10	77.5	3.05
3.0	0.10	28.0	1.13	53.0	2.12	78.0	3.07
3.5	0.13	28.5	1.15	53.5	2.14	78.5	3.08
4.0	0.15	29.0	1.17	54.0	2.16	79.0	3.10
4.5	0.17	29.5	1.19	54.5	2.17	79.5	3.12
5.0	0.19	30.0	1.21	55.0	2.19	80.0	3.14
5.5	0.21	30.5	1.23	55.5	2.21	80.5	3.16
6.0	0.23	31.0	1.25	56.0	2.23	81.0	3.18
6.5	0.25	31.5	1.27	56.5	2.25	81.5	3.20
7.0	0.27	32.0	1.29	57.0	2.27	82.0	3.21
7.5	0.29	32.5	1.31	57.5	2.29	82.5	3.23
8.0	0.31	33.0	1.33	58.0	2.31	83.0	3.25
8.5	0.33	33.5	1.35	58.5	2.33	83.5	3.27
9.0	0.35	34.0	1.37	59.0	2.35	84.0	3.29
9.5	0.38	34.5	1.39	59.5	2.37	84.5	3.31
10.0	0.40	35.0	1.41	60.0	2.39	85.0	3.33
10.5	0.42	35.5	1.43	60.5	2.41	85.5	3.34
11.0	0.44	36.0	1.45	61.0	2.42	86.0	3.36
11.5	0.46	36.5	1.47	61.5	2.44	86.5	3.38
12.0	0.48	37.0	1.49	62.0	2.46	87.0	3.40
12.5	0.50	37.5	1.51	62.5	2.48	87.5	3.42
13.0	0.52	38.0	1.53	63.0	2.50	88.0	3.44
13.5	0.54	38.5	1.55	63.5	2.52	88.5	3.45
14.0	0.56	39.0	1.57	64.0	2.54	89.0	3.47
14.5	0.58	39.5	1.59	64.5	2.56	89.5	3.49
15.0	0.60	40.0	1.61	65.0	2.58	90.0	3.51
15.5	0.62	40.5	1.63	65.5	2.60	90.5	3.53
16.0	0.64	41.0	1.65	66.0	2.62	91.0	3.55
16.5	0.66	41.5	1.67	66.5	2.63	91.5	3.56
17.0	0.68	42.0	1.69	67.0	2.65	92.0	3.58
17.5	0.70	42.5	1.71	67.5	2.67	92.5	3.60
18.0	0.72	43.0	1.73	68.0	2.69	93.0	3.62
18.5	0.74	43.5	1.75	68.5	2.71	93.5	3.64
19.0	0.77	44.0	1.77	69.0	2.73	94.0	3.66
19.5	0.79	44.5	1.79	69.5	2.75	94.5	3.67
20.0	0.81	45.0	1.81	70.0	2.77	95.0	3.69
20.5	0.83	45.5	1.82	70.5	2.79	95.5	3.71
21.0	0.85	46.0	1.84	71.0	2.80	96.0	3.73
21.5	0.87	46.5	1.86	71.5	2.82	96.5	3.75
22.0	0.89	47.0	1.88	72.0	2.84	97.0	3.76
22.5	0.91	47.5	1.90	72.5	2.86	97.5	3.78
23.0	0.93	48.0	1.92	73.0	2.88	98.0	3.80
23.5	0.95	48.5	1.94	73.5	2.90	98.5	3.82
24.0	0.97	49.0	1.96	74.0	2.92	99.0	3.84
24.5	0.99	49.5	1.98	74.5	2.94	99.5	3.85
25.0	1.01	50.0	2.00	75.0	2.95	100.0	3.87

Temperature, °F

87.8

				Temperature, °C				31.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.89	125.5	4.77	150.5	5.62	175.5	6.44				
101.0	3.91	126.0	4.79	151.0	5.64	176.0	6.46				
101.5	3.93	126.5	4.81	151.5	5.66	176.5	6.47				
102.0	3.94	127.0	4.83	152.0	5.67	177.0	6.49				
102.5	3.96	127.5	4.84	152.5	5.69	177.5	6.51				
103.0	3.98	128.0	4.86	153.0	5.71	178.0	6.52				
103.5	4.00	128.5	4.88	153.5	5.72	178.5	6.54				
104.0	4.02	129.0	4.89	154.0	5.74	179.0	6.55				
104.5	4.03	129.5	4.91	154.5	5.76	179.5	6.57				
105.0	4.05	130.0	4.93	155.0	5.77	180.0	6.58				
105.5	4.07	130.5	4.95	155.5	5.79	180.5	6.60				
106.0	4.09	131.0	4.96	156.0	5.81	181.0	6.62				
106.5	4.11	131.5	4.98	156.5	5.82	181.5	6.63				
107.0	4.12	132.0	5.00	157.0	5.84	182.0	6.65				
107.5	4.14	132.5	5.01	157.5	5.86	182.5	6.66				
108.0	4.16	133.0	5.03	158.0	5.87	183.0	6.68				
108.5	4.18	133.5	5.05	158.5	5.89	183.5	6.70				
109.0	4.19	134.0	5.07	159.0	5.90	184.0	6.71				
109.5	4.21	134.5	5.08	159.5	5.92	184.5	6.73				
110.0	4.23	135.0	5.10	160.0	5.94	185.0	6.74				
110.5	4.25	135.5	5.12	160.5	5.95	185.5	6.76				
111.0	4.27	136.0	5.13	161.0	5.97	186.0	6.78				
111.5	4.28	136.5	5.15	161.5	5.99	186.5	6.79				
112.0	4.30	137.0	5.17	162.0	6.00	187.0	6.81				
112.5	4.32	137.5	5.19	162.5	6.02	187.5	6.82				
113.0	4.34	138.0	5.20	163.0	6.04	188.0	6.84				
113.5	4.35	138.5	5.22	163.5	6.05	188.5	6.85				
114.0	4.37	139.0	5.24	164.0	6.07	189.0	6.87				
114.5	4.39	139.5	5.25	164.5	6.09	189.5	6.89				
115.0	4.41	140.0	5.27	165.0	6.10	190.0	6.90				
115.5	4.42	140.5	5.29	165.5	6.12	190.5	6.92				
116.0	4.44	141.0	5.30	166.0	6.13	191.0	6.93				
116.5	4.46	141.5	5.32	166.5	6.15	191.5	6.95				
117.0	4.48	142.0	5.34	167.0	6.17	192.0	6.96				
117.5	4.49	142.5	5.35	167.5	6.18	192.5	6.98				
118.0	4.51	143.0	5.37	168.0	6.20	193.0	7.00				
118.5	4.53	143.5	5.39	168.5	6.22	193.5	7.01				
119.0	4.55	144.0	5.41	169.0	6.23	194.0	7.03				
119.5	4.56	144.5	5.42	169.5	6.25	194.5	7.04				
120.0	4.58	145.0	5.44	170.0	6.26	195.0	7.06				
120.5	4.60	145.5	5.46	170.5	6.28	195.5	7.07				
121.0	4.62	146.0	5.47	171.0	6.30	196.0	7.09				
121.5	4.63	146.5	5.49	171.5	6.31	196.5	7.10				
122.0	4.65	147.0	5.51	172.0	6.33	197.0	7.12				
122.5	4.67	147.5	5.52	172.5	6.34	197.5	7.14				
123.0	4.69	148.0	5.54	173.0	6.36	198.0	7.15				
123.5	4.70	148.5	5.56	173.5	6.38	198.5	7.17				
124.0	4.72	149.0	5.57	174.0	6.39	199.0	7.18				
124.5	4.74	149.5	5.59	174.5	6.41	199.5	7.20				
125.0	4.76	150.0	5.61	175.0	6.42	200.0	7.21				

Temperature, °F

87.8

Temperature, °C

32.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.03	50.5	2.01	75.5	2.96
1.0	0.02	26.0	1.05	51.0	2.03	76.0	2.98
1.5	0.04	26.5	1.07	51.5	2.05	76.5	3.00
2.0	0.06	27.0	1.09	52.0	2.07	77.0	3.02
2.5	0.08	27.5	1.11	52.5	2.09	77.5	3.04
3.0	0.10	28.0	1.13	53.0	2.11	78.0	3.05
3.5	0.13	28.5	1.15	53.5	2.13	78.5	3.07
4.0	0.15	29.0	1.17	54.0	2.15	79.0	3.09
4.5	0.17	29.5	1.19	54.5	2.17	79.5	3.11
5.0	0.19	30.0	1.21	55.0	2.19	80.0	3.13
5.5	0.21	30.5	1.23	55.5	2.20	80.5	3.15
6.0	0.23	31.0	1.25	56.0	2.22	81.0	3.17
6.5	0.25	31.5	1.27	56.5	2.24	81.5	3.18
7.0	0.27	32.0	1.29	57.0	2.26	82.0	3.20
7.5	0.29	32.5	1.31	57.5	2.28	82.5	3.22
8.0	0.31	33.0	1.32	58.0	2.30	83.0	3.24
8.5	0.33	33.5	1.34	58.5	2.32	83.5	3.26
9.0	0.35	34.0	1.36	59.0	2.34	84.0	3.28
9.5	0.37	34.5	1.38	59.5	2.36	84.5	3.29
10.0	0.39	35.0	1.40	60.0	2.38	85.0	3.31
10.5	0.41	35.5	1.42	60.5	2.40	85.5	3.33
11.0	0.44	36.0	1.44	61.0	2.41	86.0	3.35
11.5	0.46	36.5	1.46	61.5	2.43	86.5	3.37
12.0	0.48	37.0	1.48	62.0	2.45	87.0	3.39
12.5	0.50	37.5	1.50	62.5	2.47	87.5	3.40
13.0	0.52	38.0	1.52	63.0	2.49	88.0	3.42
13.5	0.54	38.5	1.54	63.5	2.51	88.5	3.44
14.0	0.56	39.0	1.56	64.0	2.53	89.0	3.46
14.5	0.58	39.5	1.58	64.5	2.55	89.5	3.48
15.0	0.60	40.0	1.60	65.0	2.57	90.0	3.50
15.5	0.62	40.5	1.62	65.5	2.59	90.5	3.51
16.0	0.64	41.0	1.64	66.0	2.60	91.0	3.53
16.5	0.66	41.5	1.66	66.5	2.62	91.5	3.55
17.0	0.68	42.0	1.68	67.0	2.64	92.0	3.57
17.5	0.70	42.5	1.70	67.5	2.66	92.5	3.59
18.0	0.72	43.0	1.72	68.0	2.68	93.0	3.60
18.5	0.74	43.5	1.74	68.5	2.70	93.5	3.62
19.0	0.76	44.0	1.76	69.0	2.72	94.0	3.64
19.5	0.78	44.5	1.78	69.5	2.74	94.5	3.66
20.0	0.80	45.0	1.80	70.0	2.76	95.0	3.68
20.5	0.82	45.5	1.82	70.5	2.77	95.5	3.69
21.0	0.84	46.0	1.84	71.0	2.79	96.0	3.71
21.5	0.86	46.5	1.86	71.5	2.81	96.5	3.73
22.0	0.88	47.0	1.88	72.0	2.83	97.0	3.75
22.5	0.90	47.5	1.90	72.5	2.85	97.5	3.77
23.0	0.92	48.0	1.91	73.0	2.87	98.0	3.79
23.5	0.94	48.5	1.93	73.5	2.89	98.5	3.80
24.0	0.96	49.0	1.95	74.0	2.91	99.0	3.82
24.5	0.98	49.5	1.97	74.5	2.92	99.5	3.84
25.0	1.00	50.0	1.99	75.0	2.94	100.0	3.86

Temperature, °F

89.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 32.0

atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.87	125.5	4.75	150.5	5.60	175.5	6.42				
101.0	3.89	126.0	4.77	151.0	5.62	176.0	6.43				
101.5	3.91	126.5	4.79	151.5	5.63	176.5	6.45				
102.0	3.93	127.0	4.81	152.0	5.65	177.0	6.46				
102.5	3.95	127.5	4.82	152.5	5.67	177.5	6.48				
103.0	3.96	128.0	4.84	153.0	5.68	178.0	6.50				
103.5	3.98	128.5	4.86	153.5	5.70	178.5	6.51				
104.0	4.00	129.0	4.87	154.0	5.72	179.0	6.53				
104.5	4.02	129.5	4.89	154.5	5.73	179.5	6.54				
105.0	4.04	130.0	4.91	155.0	5.75	180.0	6.56				
105.5	4.05	130.5	4.93	155.5	5.77	180.5	6.57				
106.0	4.07	131.0	4.94	156.0	5.78	181.0	6.59				
106.5	4.09	131.5	4.96	156.5	5.80	181.5	6.61				
107.0	4.11	132.0	4.98	157.0	5.82	182.0	6.62				
107.5	4.12	132.5	4.99	157.5	5.83	182.5	6.64				
108.0	4.14	133.0	5.01	158.0	5.85	183.0	6.65				
108.5	4.16	133.5	5.03	158.5	5.87	183.5	6.67				
109.0	4.18	134.0	5.05	159.0	5.88	184.0	6.69				
109.5	4.20	134.5	5.06	159.5	5.90	184.5	6.70				
110.0	4.21	135.0	5.08	160.0	5.91	185.0	6.72				
110.5	4.23	135.5	5.10	160.5	5.93	185.5	6.73				
111.0	4.25	136.0	5.11	161.0	5.95	186.0	6.75				
111.5	4.27	136.5	5.13	161.5	5.96	186.5	6.76				
112.0	4.28	137.0	5.15	162.0	5.98	187.0	6.78				
112.5	4.30	137.5	5.16	162.5	6.00	187.5	6.80				
113.0	4.32	138.0	5.18	163.0	6.01	188.0	6.81				
113.5	4.34	138.5	5.20	163.5	6.03	188.5	6.83				
114.0	4.35	139.0	5.22	164.0	6.04	189.0	6.84				
114.5	4.37	139.5	5.23	164.5	6.06	189.5	6.86				
115.0	4.39	140.0	5.25	165.0	6.08	190.0	6.87				
115.5	4.41	140.5	5.27	165.5	6.09	190.5	6.89				
116.0	4.42	141.0	5.28	166.0	6.11	191.0	6.91				
116.5	4.44	141.5	5.30	166.5	6.13	191.5	6.92				
117.0	4.46	142.0	5.32	167.0	6.14	192.0	6.94				
117.5	4.48	142.5	5.33	167.5	6.16	192.5	6.95				
118.0	4.49	143.0	5.35	168.0	6.17	193.0	6.97				
118.5	4.51	143.5	5.37	168.5	6.19	193.5	6.98				
119.0	4.53	144.0	5.38	169.0	6.21	194.0	7.00				
119.5	4.55	144.5	5.40	169.5	6.22	194.5	7.01				
120.0	4.56	145.0	5.42	170.0	6.24	195.0	7.03				
120.5	4.58	145.5	5.43	170.5	6.26	195.5	7.05				
121.0	4.60	146.0	5.45	171.0	6.27	196.0	7.06				
121.5	4.62	146.5	5.47	171.5	6.29	196.5	7.08				
122.0	4.63	147.0	5.48	172.0	6.30	197.0	7.09				
122.5	4.65	147.5	5.50	172.5	6.32	197.5	7.11				
123.0	4.67	148.0	5.52	173.0	6.34	198.0	7.12				
123.5	4.69	148.5	5.53	173.5	6.35	198.5	7.14				
124.0	4.70	149.0	5.55	174.0	6.37	199.0	7.15				
124.5	4.72	149.5	5.57	174.5	6.38	199.5	7.17				
125.0	4.74	150.0	5.58	175.0	6.40	200.0	7.18				

Temperature, °F

89.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.02	50.5	2.00	75.5	2.95
1.0	0.02	26.0	1.04	51.0	2.02	76.0	2.97
1.5	0.04	26.5	1.06	51.5	2.04	76.5	2.99
2.0	0.06	27.0	1.08	52.0	2.06	77.0	3.00
2.5	0.08	27.5	1.10	52.5	2.08	77.5	3.02
3.0	0.10	28.0	1.12	53.0	2.10	78.0	3.04
3.5	0.12	28.5	1.14	53.5	2.12	78.5	3.06
4.0	0.15	29.0	1.16	54.0	2.14	79.0	3.08
4.5	0.17	29.5	1.18	54.5	2.16	79.5	3.10
5.0	0.19	30.0	1.20	55.0	2.18	80.0	3.12
5.5	0.21	30.5	1.22	55.5	2.20	80.5	3.13
6.0	0.23	31.0	1.24	56.0	2.21	81.0	3.15
6.5	0.25	31.5	1.26	56.5	2.23	81.5	3.17
7.0	0.27	32.0	1.28	57.0	2.25	82.0	3.19
7.5	0.29	32.5	1.30	57.5	2.27	82.5	3.21
8.0	0.31	33.0	1.32	58.0	2.29	83.0	3.23
8.5	0.33	33.5	1.34	58.5	2.31	83.5	3.24
9.0	0.35	34.0	1.36	59.0	2.33	84.0	3.26
9.5	0.37	34.5	1.38	59.5	2.35	84.5	3.28
10.0	0.39	35.0	1.40	60.0	2.37	85.0	3.30
10.5	0.41	35.5	1.42	60.5	2.39	85.5	3.32
11.0	0.43	36.0	1.44	61.0	2.41	86.0	3.34
11.5	0.45	36.5	1.46	61.5	2.42	86.5	3.35
12.0	0.47	37.0	1.48	62.0	2.44	87.0	3.37
12.5	0.49	37.5	1.50	62.5	2.46	87.5	3.39
13.0	0.52	38.0	1.52	63.0	2.48	88.0	3.41
13.5	0.54	38.5	1.54	63.5	2.50	88.5	3.43
14.0	0.56	39.0	1.56	64.0	2.52	89.0	3.45
14.5	0.58	39.5	1.58	64.5	2.54	89.5	3.46
15.0	0.60	40.0	1.60	65.0	2.56	90.0	3.48
15.5	0.62	40.5	1.61	65.5	2.58	90.5	3.50
16.0	0.64	41.0	1.63	66.0	2.59	91.0	3.52
16.5	0.66	41.5	1.65	66.5	2.61	91.5	3.54
17.0	0.68	42.0	1.67	67.0	2.63	92.0	3.55
17.5	0.70	42.5	1.69	67.5	2.65	92.5	3.57
18.0	0.72	43.0	1.71	68.0	2.67	93.0	3.59
18.5	0.74	43.5	1.73	68.5	2.69	93.5	3.61
19.0	0.76	44.0	1.75	69.0	2.71	94.0	3.63
19.5	0.78	44.5	1.77	69.5	2.73	94.5	3.64
20.0	0.80	45.0	1.79	70.0	2.74	95.0	3.66
20.5	0.82	45.5	1.81	70.5	2.76	95.5	3.68
21.0	0.84	46.0	1.83	71.0	2.78	96.0	3.70
21.5	0.86	46.5	1.85	71.5	2.80	96.5	3.72
22.0	0.88	47.0	1.87	72.0	2.82	97.0	3.73
22.5	0.90	47.5	1.89	72.5	2.84	97.5	3.75
23.0	0.92	48.0	1.91	73.0	2.86	98.0	3.77
23.5	0.94	48.5	1.93	73.5	2.87	98.5	3.78
24.0	0.96	49.0	1.95	74.0	2.89	99.0	3.81
24.5	0.98	49.5	1.96	74.5	2.91	99.5	3.82
25.0	1.00	50.0	1.98	75.0	2.93	100.0	3.84

Temperature, °F

91.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				33.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.86	125.5	4.74	150.5	5.58	175.5	6.39				
101.0	3.88	126.0	4.75	151.0	5.60	176.0	6.41				
101.5	3.90	126.5	4.77	151.5	5.61	176.5	6.42				
102.0	3.91	127.0	4.79	152.0	5.63	177.0	6.44				
102.5	3.93	127.5	4.80	152.5	5.64	177.5	6.45				
103.0	3.95	128.0	4.82	153.0	5.66	178.0	6.47				
103.5	3.97	128.5	4.84	153.5	5.68	178.5	6.49				
104.0	3.98	129.0	4.86	154.0	5.69	179.0	6.50				
104.5	4.00	129.5	4.87	154.5	5.71	179.5	6.52				
105.0	4.02	130.0	4.89	155.0	5.73	180.0	6.53				
105.5	4.04	130.5	4.91	155.5	5.74	180.5	6.55				
106.0	4.05	131.0	4.92	156.0	5.76	181.0	6.56				
106.5	4.07	131.5	4.94	156.5	5.78	181.5	6.58				
107.0	4.09	132.0	4.96	157.0	5.79	182.0	6.60				
107.5	4.11	132.5	4.97	157.5	5.81	182.5	6.61				
108.0	4.13	133.0	4.99	158.0	5.83	183.0	6.63				
108.5	4.14	133.5	5.01	158.5	5.84	183.5	6.64				
109.0	4.16	134.0	5.03	159.0	5.86	184.0	6.66				
109.5	4.18	134.5	5.04	159.5	5.87	184.5	6.67				
110.0	4.20	135.0	5.06	160.0	5.89	185.0	6.69				
110.5	4.21	135.5	5.08	160.5	5.91	185.5	6.71				
111.0	4.23	136.0	5.09	161.0	5.92	186.0	6.72				
111.5	4.25	136.5	5.11	161.5	5.94	186.5	6.74				
112.0	4.27	137.0	5.13	162.0	5.96	187.0	6.75				
112.5	4.28	137.5	5.14	162.5	5.97	187.5	6.77				
113.0	4.30	138.0	5.16	163.0	5.99	188.0	6.78				
113.5	4.32	138.5	5.18	163.5	6.00	188.5	6.80				
114.0	4.34	139.0	5.19	164.0	6.02	189.0	6.82				
114.5	4.35	139.5	5.21	164.5	6.04	189.5	6.83				
115.0	4.37	140.0	5.23	165.0	6.05	190.0	6.85				
115.5	4.39	140.5	5.25	165.5	6.07	190.5	6.86				
116.0	4.41	141.0	5.26	166.0	6.09	191.0	6.88				
116.5	4.42	141.5	5.28	166.5	6.10	191.5	6.89				
117.0	4.44	142.0	5.30	167.0	6.12	192.0	6.91				
117.5	4.46	142.5	5.31	167.5	6.13	192.5	6.92				
118.0	4.48	143.0	5.33	168.0	6.15	193.0	6.94				
118.5	4.49	143.5	5.35	168.5	6.17	193.5	6.96				
119.0	4.51	144.0	5.36	169.0	6.18	194.0	6.97				
119.5	4.53	144.5	5.38	169.5	6.20	194.5	6.99				
120.0	4.55	145.0	5.40	170.0	6.21	195.0	7.00				
120.5	4.56	145.5	5.41	170.5	6.23	195.5	7.02				
121.0	4.58	146.0	5.43	171.0	6.25	196.0	7.03				
121.5	4.60	146.5	5.45	171.5	6.26	196.5	7.05				
122.0	4.61	147.0	5.46	172.0	6.28	197.0	7.06				
122.5	4.63	147.5	5.48	172.5	6.29	197.5	7.08				
123.0	4.65	148.0	5.50	173.0	6.31	198.0	7.09				
123.5	4.67	148.5	5.51	173.5	6.33	198.5	7.11				
124.0	4.68	149.0	5.53	174.0	6.34	199.0	7.13				
124.5	4.70	149.5	5.55	174.5	6.36	199.5	7.14				
125.0	4.72	150.0	5.56	175.0	6.37	200.0	7.16				

Temperature, °F

91.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

34.0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.02	50.5	2.00	75.5	2.94
1.0	0.02	26.0	1.04	51.0	2.01	76.0	2.96
1.5	0.04	26.5	1.06	51.5	2.03	76.5	2.97
2.0	0.06	27.0	1.08	52.0	2.05	77.0	2.99
2.5	0.08	27.5	1.10	52.5	2.07	77.5	3.01
3.0	0.10	28.0	1.12	53.0	2.09	78.0	3.03
3.5	0.12	28.5	1.14	53.5	2.11	78.5	3.05
4.0	0.14	29.0	1.16	54.0	2.13	79.0	3.07
4.5	0.17	29.5	1.18	54.5	2.15	79.5	3.08
5.0	0.19	30.0	1.20	55.0	2.17	80.0	3.10
5.5	0.21	30.5	1.22	55.5	2.19	80.5	3.12
6.0	0.23	31.0	1.24	56.0	2.21	81.0	3.14
6.5	0.25	31.5	1.26	56.5	2.22	81.5	3.16
7.0	0.27	32.0	1.27	57.0	2.24	82.0	3.18
7.5	0.29	32.5	1.29	57.5	2.26	82.5	3.19
8.0	0.31	33.0	1.31	58.0	2.28	83.0	3.21
8.5	0.33	33.5	1.33	58.5	2.30	83.5	3.23
9.0	0.35	34.0	1.35	59.0	2.32	84.0	3.25
9.5	0.37	34.5	1.37	59.5	2.34	84.5	3.27
10.0	0.39	35.0	1.39	60.0	2.36	85.0	3.29
10.5	0.41	35.5	1.41	60.5	2.38	85.5	3.30
11.0	0.43	36.0	1.43	61.0	2.40	86.0	3.32
11.5	0.45	36.5	1.45	61.5	2.41	86.5	3.34
12.0	0.47	37.0	1.47	62.0	2.43	87.0	3.36
12.5	0.49	37.5	1.49	62.5	2.45	87.5	3.38
13.0	0.51	38.0	1.51	63.0	2.47	88.0	3.39
13.5	0.53	38.5	1.53	63.5	2.49	88.5	3.41
14.0	0.55	39.0	1.55	64.0	2.51	89.0	3.43
14.5	0.57	39.5	1.57	64.5	2.53	89.5	3.45
15.0	0.59	40.0	1.59	65.0	2.55	90.0	3.47
15.5	0.61	40.5	1.61	65.5	2.56	90.5	3.49
16.0	0.63	41.0	1.63	66.0	2.58	91.0	3.50
16.5	0.66	41.5	1.65	66.5	2.60	91.5	3.52
17.0	0.68	42.0	1.67	67.0	2.62	92.0	3.54
17.5	0.70	42.5	1.69	67.5	2.64	92.5	3.56
18.0	0.72	43.0	1.71	68.0	2.66	93.0	3.58
18.5	0.74	43.5	1.73	68.5	2.68	93.5	3.59
19.0	0.76	44.0	1.74	69.0	2.70	94.0	3.61
19.5	0.78	44.5	1.76	69.5	2.71	94.5	3.63
20.0	0.80	45.0	1.78	70.0	2.73	95.0	3.65
20.5	0.82	45.5	1.80	70.5	2.75	95.5	3.67
21.0	0.84	46.0	1.82	71.0	2.77	96.0	3.68
21.5	0.86	46.5	1.84	71.5	2.79	96.5	3.70
22.0	0.88	47.0	1.86	72.0	2.81	97.0	3.72
22.5	0.90	47.5	1.88	72.5	2.83	97.5	3.74
23.0	0.92	48.0	1.90	73.0	2.84	98.0	3.75
23.5	0.94	48.5	1.92	73.5	2.86	98.5	3.77
24.0	0.96	49.0	1.94	74.0	2.88	99.0	3.79
24.5	0.98	49.5	1.96	74.5	2.90	99.5	3.81
25.0	1.00	50.0	1.98	75.0	2.92	100.0	3.83

Temperature, °F

93.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				34.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.84	125.5	4.72	150.5	5.56	175.5	6.36				
101.0	3.86	126.0	4.73	151.0	5.57	176.0	6.38				
101.5	3.88	126.5	4.75	151.5	5.59	176.5	6.40				
102.0	3.90	127.0	4.77	152.0	5.61	177.0	6.41				
102.5	3.91	127.5	4.78	152.5	5.62	177.5	6.43				
103.0	3.93	128.0	4.80	153.0	5.64	178.0	6.44				
103.5	3.95	128.5	4.82	153.5	5.65	178.5	6.46				
104.0	3.97	129.0	4.84	154.0	5.67	179.0	6.48				
104.5	3.99	129.5	4.85	154.5	5.69	179.5	6.49				
105.0	4.00	130.0	4.87	155.0	5.70	180.0	6.51				
105.5	4.02	130.5	4.89	155.5	5.72	180.5	6.52				
106.0	4.04	131.0	4.90	156.0	5.74	181.0	6.54				
106.5	4.06	131.5	4.92	156.5	5.75	181.5	6.55				
107.0	4.07	132.0	4.94	157.0	5.77	182.0	6.57				
107.5	4.09	132.5	4.95	157.5	5.79	182.5	6.59				
108.0	4.11	133.0	4.97	158.0	5.80	183.0	6.60				
108.5	4.13	133.5	4.99	158.5	5.82	183.5	6.62				
109.0	4.14	134.0	5.01	159.0	5.83	184.0	6.63				
109.5	4.16	134.5	5.02	159.5	5.85	184.5	6.65				
110.0	4.18	135.0	5.04	160.0	5.87	185.0	6.66				
110.5	4.20	135.5	5.06	160.5	5.88	185.5	6.68				
111.0	4.21	136.0	5.07	161.0	5.90	186.0	6.69				
111.5	4.23	136.5	5.09	161.5	5.92	186.5	6.71				
112.0	4.25	137.0	5.11	162.0	5.93	187.0	6.73				
112.5	4.27	137.5	5.12	162.5	5.95	187.5	6.74				
113.0	4.28	138.0	5.14	163.0	5.96	188.0	6.76				
113.5	4.30	138.5	5.16	163.5	5.98	188.5	6.77				
114.0	4.32	139.0	5.17	164.0	6.00	189.0	6.79				
114.5	4.34	139.5	5.19	164.5	6.01	189.5	6.80				
115.0	4.35	140.0	5.21	165.0	6.03	190.0	6.82				
115.5	4.37	140.5	5.22	165.5	6.04	190.5	6.83				
116.0	4.39	141.0	5.24	166.0	6.06	191.0	6.85				
116.5	4.41	141.5	5.26	166.5	6.08	191.5	6.87				
117.0	4.42	142.0	5.27	167.0	6.09	192.0	6.88				
117.5	4.44	142.5	5.29	167.5	6.11	192.5	6.90				
118.0	4.46	143.0	5.31	168.0	6.13	193.0	6.91				
118.5	4.48	143.5	5.32	168.5	6.14	193.5	6.93				
119.0	4.49	144.0	5.34	169.0	6.16	194.0	6.94				
119.5	4.51	144.5	5.36	169.5	6.17	194.5	6.96				
120.0	4.53	145.0	5.37	170.0	6.19	195.0	6.97				
120.5	4.54	145.5	5.39	170.5	6.21	195.5	6.99				
121.0	4.56	146.0	5.41	171.0	6.22	196.0	7.00				
121.5	4.58	146.5	5.42	171.5	6.24	196.5	7.02				
122.0	4.60	147.0	5.44	172.0	6.25	197.0	7.04				
122.5	4.61	147.5	5.46	172.5	6.27	197.5	7.05				
123.0	4.63	148.0	5.47	173.0	6.28	198.0	7.07				
123.5	4.65	148.5	5.49	173.5	6.30	198.5	7.08				
124.0	4.66	149.0	5.51	174.0	6.32	199.0	7.10				
124.5	4.68	149.5	5.52	174.5	6.33	199.5	7.11				
125.0	4.70	150.0	5.54	175.0	6.35	200.0	7.13				

Temperature, °F

93.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C		35.0	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.01	50.5	1.99	75.5	2.93
1.0	0.02	26.0	1.03	51.0	2.01	76.0	2.94
1.5	0.04	26.5	1.05	51.5	2.03	76.5	2.96
2.0	0.06	27.0	1.07	52.0	2.04	77.0	2.98
2.5	0.08	27.5	1.09	52.5	2.06	77.5	3.00
3.0	0.10	28.0	1.11	53.0	2.08	78.0	3.02
3.5	0.12	28.5	1.13	53.5	2.10	78.5	3.04
4.0	0.14	29.0	1.15	54.0	2.12	79.0	3.05
4.5	0.16	29.5	1.17	54.5	2.14	79.5	3.07
5.0	0.19	30.0	1.19	55.0	2.16	80.0	3.09
5.5	0.21	30.5	1.21	55.5	2.18	80.5	3.11
6.0	0.23	31.0	1.23	56.0	2.20	81.0	3.13
6.5	0.25	31.5	1.25	56.5	2.22	81.5	3.14
7.0	0.27	32.0	1.27	57.0	2.23	82.0	3.16
7.5	0.29	32.5	1.29	57.5	2.25	82.5	3.18
8.0	0.31	33.0	1.31	58.0	2.27	83.0	3.20
8.5	0.33	33.5	1.33	58.5	2.29	83.5	3.22
9.0	0.35	34.0	1.35	59.0	2.31	84.0	3.24
9.5	0.37	34.5	1.37	59.5	2.33	84.5	3.25
10.0	0.39	35.0	1.39	60.0	2.35	85.0	3.27
10.5	0.41	35.5	1.41	60.5	2.37	85.5	3.29
11.0	0.43	36.0	1.43	61.0	2.39	86.0	3.31
11.5	0.45	36.5	1.45	61.5	2.40	86.5	3.33
12.0	0.47	37.0	1.47	62.0	2.42	87.0	3.34
12.5	0.49	37.5	1.48	62.5	2.44	87.5	3.36
13.0	0.51	38.0	1.50	63.0	2.46	88.0	3.38
13.5	0.53	38.5	1.52	63.5	2.48	88.5	3.40
14.0	0.55	39.0	1.54	64.0	2.50	89.0	3.42
14.5	0.57	39.5	1.56	64.5	2.52	89.5	3.43
15.0	0.59	40.0	1.58	65.0	2.54	90.0	3.45
15.5	0.61	40.5	1.60	65.5	2.55	90.5	3.47
16.0	0.63	41.0	1.62	66.0	2.57	91.0	3.49
16.5	0.65	41.5	1.64	66.5	2.59	91.5	3.51
17.0	0.67	42.0	1.66	67.0	2.61	92.0	3.52
17.5	0.69	42.5	1.68	67.5	2.63	92.5	3.54
18.0	0.71	43.0	1.70	68.0	2.65	93.0	3.56
18.5	0.73	43.5	1.72	68.5	2.67	93.5	3.58
19.0	0.75	44.0	1.74	69.0	2.68	94.0	3.60
19.5	0.77	44.5	1.76	69.5	2.70	94.5	3.61
20.0	0.79	45.0	1.78	70.0	2.72	95.0	3.63
20.5	0.81	45.5	1.80	70.5	2.74	95.5	3.65
21.0	0.83	46.0	1.81	71.0	2.76	96.0	3.67
21.5	0.85	46.5	1.83	71.5	2.78	96.5	3.69
22.0	0.87	47.0	1.85	72.0	2.80	97.0	3.70
22.5	0.89	47.5	1.87	72.5	2.81	97.5	3.72
23.0	0.91	48.0	1.89	73.0	2.83	98.0	3.74
23.5	0.93	48.5	1.91	73.5	2.85	98.5	3.76
24.0	0.95	49.0	1.93	74.0	2.87	99.0	3.77
24.5	0.97	49.5	1.95	74.5	2.89	99.5	3.79
25.0	0.99	50.0	1.97	75.0	2.91	100.0	3.81

Temperature, °F 95.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C						35.0					
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.83	125.5	4.70	150.5	5.53	175.5	6.34				
101.0	3.85	126.0	4.71	151.0	5.55	176.0	6.35				
101.5	3.86	126.5	4.73	151.5	5.57	176.5	6.37				
102.0	3.88	127.0	4.75	152.0	5.58	177.0	6.39				
102.5	3.90	127.5	4.77	152.5	5.60	177.5	6.40				
103.0	3.92	128.0	4.78	153.0	5.62	178.0	6.42				
103.5	3.93	128.5	4.80	153.5	5.63	178.5	6.43				
104.0	3.95	129.0	4.82	154.0	5.65	179.0	6.45				
104.5	3.97	129.5	4.83	154.5	5.66	179.5	6.46				
105.0	3.99	130.0	4.85	155.0	5.68	180.0	6.48				
105.5	4.00	130.5	4.87	155.5	5.70	180.5	6.50				
106.0	4.02	131.0	4.88	156.0	5.71	181.0	6.51				
106.5	4.04	131.5	4.90	156.5	5.73	181.5	6.53				
107.0	4.06	132.0	4.92	157.0	5.75	182.0	6.54				
107.5	4.07	132.5	4.93	157.5	5.76	182.5	6.56				
108.0	4.09	133.0	4.95	158.0	5.78	183.0	6.57				
108.5	4.11	133.5	4.97	158.5	5.79	183.5	6.59				
109.0	4.13	134.0	4.99	159.0	5.81	184.0	6.61				
109.5	4.14	134.5	5.00	159.5	5.83	184.5	6.62				
110.0	4.16	135.0	5.02	160.0	5.84	185.0	6.64				
110.5	4.18	135.5	5.04	160.5	5.86	185.5	6.65				
111.0	4.20	136.0	5.05	161.0	5.88	186.0	6.67				
111.5	4.21	136.5	5.07	161.5	5.89	186.5	6.68				
112.0	4.23	137.0	5.09	162.0	5.91	187.0	6.70				
112.5	4.25	137.5	5.10	162.5	5.92	187.5	6.71				
113.0	4.27	138.0	5.12	163.0	5.94	188.0	6.73				
113.5	4.28	138.5	5.14	163.5	5.96	188.5	6.75				
114.0	4.30	139.0	5.15	164.0	5.97	189.0	6.76				
114.5	4.32	139.5	5.17	164.5	5.99	189.5	6.78				
115.0	4.34	140.0	5.19	165.0	6.00	190.0	6.79				
115.5	4.35	140.5	5.20	165.5	6.02	190.5	6.81				
116.0	4.37	141.0	5.22	166.0	6.04	191.0	6.82				
116.5	4.39	141.5	5.24	166.5	6.05	191.5	6.84				
117.0	4.41	142.0	5.25	167.0	6.07	192.0	6.85				
117.5	4.42	142.5	5.27	167.5	6.08	192.5	6.87				
118.0	4.44	143.0	5.29	168.0	6.10	193.0	6.88				
118.5	4.46	143.5	5.30	168.5	6.12	193.5	6.90				
119.0	4.47	144.0	5.32	169.0	6.13	194.0	6.91				
119.5	4.49	144.5	5.34	169.5	6.15	194.5	6.93				
120.0	4.51	145.0	5.35	170.0	6.16	195.0	6.95				
120.5	4.53	145.5	5.37	170.5	6.18	195.5	6.96				
121.0	4.54	146.0	5.39	171.0	6.20	196.0	6.98				
121.5	4.56	146.5	5.40	171.5	6.21	196.5	6.99				
122.0	4.58	147.0	5.42	172.0	6.23	197.0	7.01				
122.5	4.59	147.5	5.43	172.5	6.24	197.5	7.02				
123.0	4.61	148.0	5.45	173.0	6.26	198.0	7.04				
123.5	4.63	148.5	5.47	173.5	6.28	198.5	7.05				
124.0	4.65	149.0	5.48	174.0	6.29	199.0	7.07				
124.5	4.66	149.5	5.50	174.5	6.31	199.5	7.08				
125.0	4.68	150.0	5.52	175.0	6.32	200.0	7.10				

Temperature, °F

95.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C 36.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.01	50.5	1.98	75.5	2.91
1.0	0.02	26.0	1.03	51.0	2.00	76.0	2.93
1.5	0.04	26.5	1.05	51.5	2.02	76.5	2.95
2.0	0.06	27.0	1.07	52.0	2.04	77.0	2.97
2.5	0.08	27.5	1.09	52.5	2.05	77.5	2.99
3.0	0.10	28.0	1.11	53.0	2.07	78.0	3.00
3.5	0.12	28.5	1.13	53.5	2.09	78.5	3.02
4.0	0.14	29.0	1.15	54.0	2.11	79.0	3.04
4.5	0.16	29.5	1.17	54.5	2.13	79.5	3.06
5.0	0.18	30.0	1.19	55.0	2.15	80.0	3.08
5.5	0.20	30.5	1.21	55.5	2.17	80.5	3.10
6.0	0.23	31.0	1.23	56.0	2.19	81.0	3.11
6.5	0.25	31.5	1.24	56.5	2.21	81.5	3.13
7.0	0.27	32.0	1.26	57.0	2.23	82.0	3.15
7.5	0.29	32.5	1.28	57.5	2.24	82.5	3.17
8.0	0.31	33.0	1.30	58.0	2.26	83.0	3.19
8.5	0.33	33.5	1.32	58.5	2.28	83.5	3.20
9.0	0.35	34.0	1.34	59.0	2.30	84.0	3.22
9.5	0.37	34.5	1.36	59.5	2.32	84.5	3.24
10.0	0.39	35.0	1.38	60.0	2.34	85.0	3.26
10.5	0.41	35.5	1.40	60.5	2.36	85.5	3.28
11.0	0.43	36.0	1.42	61.0	2.38	86.0	3.29
11.5	0.45	36.5	1.44	61.5	2.39	86.5	3.31
12.0	0.47	37.0	1.46	62.0	2.41	87.0	3.33
12.5	0.49	37.5	1.48	62.5	2.43	87.5	3.35
13.0	0.51	38.0	1.50	63.0	2.45	88.0	3.37
13.5	0.53	38.5	1.52	63.5	2.47	88.5	3.38
14.0	0.55	39.0	1.54	64.0	2.49	89.0	3.40
14.5	0.57	39.5	1.56	64.5	2.51	89.5	3.42
15.0	0.59	40.0	1.58	65.0	2.53	90.0	3.44
15.5	0.61	40.5	1.60	65.5	2.54	90.5	3.46
16.0	0.63	41.0	1.61	66.0	2.56	91.0	3.47
16.5	0.65	41.5	1.63	66.5	2.58	91.5	3.49
17.0	0.67	42.0	1.65	67.0	2.60	92.0	3.51
17.5	0.69	42.5	1.67	67.5	2.62	92.5	3.53
18.0	0.71	43.0	1.69	68.0	2.64	93.0	3.55
18.5	0.73	43.5	1.71	68.5	2.66	93.5	3.56
19.0	0.75	44.0	1.73	69.0	2.67	94.0	3.58
19.5	0.77	44.5	1.75	69.5	2.69	94.5	3.60
20.0	0.79	45.0	1.77	70.0	2.71	95.0	3.62
20.5	0.81	45.5	1.79	70.5	2.73	95.5	3.64
21.0	0.83	46.0	1.81	71.0	2.75	96.0	3.65
21.5	0.85	46.5	1.83	71.5	2.77	96.5	3.67
22.0	0.87	47.0	1.85	72.0	2.78	97.0	3.69
22.5	0.89	47.5	1.86	72.5	2.80	97.5	3.71
23.0	0.91	48.0	1.88	73.0	2.82	98.0	3.72
23.5	0.93	48.5	1.90	73.5	2.84	98.5	3.74
24.0	0.95	49.0	1.92	74.0	2.86	99.0	3.76
24.5	0.97	49.5	1.94	74.5	2.88	99.5	3.78
25.0	0.99	50.0	1.96	75.0	2.89	100.0	3.79

Temperature, °F

96.8

Temperature, °C 36.0

atü	-	kg									
100.5	3.81		125.5	4.68		150.5	5.51		175.5	6.31	
101.0	3.83		126.0	4.69		151.0	5.53		176.0	6.33	
101.5	3.85		126.5	4.71		151.5	5.54		176.5	6.34	
102.0	3.87		127.0	4.73		152.0	5.56		177.0	6.36	
102.5	3.88		127.5	4.75		152.5	5.58		177.5	6.38	
103.0	3.90		128.0	4.76		153.0	5.59		178.0	6.39	
103.5	3.92		128.5	4.78		153.5	5.61		178.5	6.41	
104.0	3.94		129.0	4.80		154.0	5.62		179.0	6.42	
104.5	3.95		129.5	4.81		154.5	5.64		179.5	6.44	
105.0	3.97		130.0	4.83		155.0	5.66		180.0	6.45	
105.5	3.99		130.5	4.85		155.5	5.67		180.5	6.47	
106.0	4.01		131.0	4.86		156.0	5.69		181.0	6.49	
106.5	4.02		131.5	4.88		156.5	5.71		181.5	6.50	
107.0	4.04		132.0	4.90		157.0	5.72		182.0	6.52	
107.5	4.06		132.5	4.91		157.5	5.74		182.5	6.53	
108.0	4.08		133.0	4.93		158.0	5.75		183.0	6.55	
108.5	4.09		133.5	4.95		158.5	5.77		183.5	6.56	
109.0	4.11		134.0	4.96		159.0	5.79		184.0	6.58	
109.5	4.13		134.5	4.98		159.5	5.80		184.5	6.59	
110.0	4.14		135.0	5.00		160.0	5.82		185.0	6.61	
110.5	4.16		135.5	5.01		160.5	5.84		185.5	6.63	
111.0	4.18		136.0	5.03		161.0	5.85		186.0	6.64	
111.5	4.20		136.5	5.05		161.5	5.87		186.5	6.66	
112.0	4.21		137.0	5.06		162.0	5.88		187.0	6.67	
112.5	4.23		137.5	5.08		162.5	5.90		187.5	6.69	
113.0	4.25		138.0	5.10		163.0	5.92		188.0	6.70	
113.5	4.27		138.5	5.11		163.5	5.93		188.5	6.72	
114.0	4.28		139.0	5.13		164.0	5.95		189.0	6.73	
114.5	4.30		139.5	5.15		164.5	5.96		189.5	6.75	
115.0	4.32		140.0	5.16		165.0	5.98		190.0	6.76	
115.5	4.34		140.5	5.18		165.5	6.00		190.5	6.78	
116.0	4.35		141.0	5.20		166.0	6.01		191.0	6.79	
116.5	4.37		141.5	5.21		166.5	6.03		191.5	6.81	
117.0	4.39		142.0	5.23		167.0	6.04		192.0	6.83	
117.5	4.40		142.5	5.25		167.5	6.06		192.5	6.84	
118.0	4.42		143.0	5.26		168.0	6.08		193.0	6.86	
118.5	4.44		143.5	5.28		168.5	6.09		193.5	6.87	
119.0	4.46		144.0	5.30		169.0	6.11		194.0	6.89	
119.5	4.47		144.5	5.31		169.5	6.12		194.5	6.90	
120.0	4.49		145.0	5.33		170.0	6.14		195.0	6.92	
120.5	4.51		145.5	5.35		170.5	6.15		195.5	6.93	
121.0	4.52		146.0	5.36		171.0	6.17		196.0	6.95	
121.5	4.54		146.5	5.38		171.5	6.19		196.5	6.96	
122.0	4.56		147.0	5.40		172.0	6.20		197.0	6.98	
122.5	4.58		147.5	5.41		172.5	6.22		197.5	6.99	
123.0	4.59		148.0	5.43		173.0	6.23		198.0	7.01	
123.5	4.61		148.5	5.45		173.5	6.25		198.5	7.02	
124.0	4.63		149.0	5.46		174.0	6.27		199.0	7.04	
124.5	4.64		149.5	5.48		174.5	6.28		199.5	7.05	
125.0	4.66		150.0	5.49		175.0	6.30		200.0	7.07	

Temperature, °F

96.8

Temperature, °C
37.0

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.00	50.5	1.97	75.5	2.90
1.0	0.02	26.0	1.02	51.0	1.99	76.0	2.92
1.5	0.04	26.5	1.04	51.5	2.01	76.5	2.94
2.0	0.06	27.0	1.06	52.0	2.03	77.0	2.96
2.5	0.08	27.5	1.08	52.5	2.05	77.5	2.97
3.0	0.10	28.0	1.10	53.0	2.07	78.0	2.99
3.5	0.12	28.5	1.12	53.5	2.08	78.5	3.01
4.0	0.14	29.0	1.14	54.0	2.10	79.0	3.03
4.5	0.16	29.5	1.16	54.5	2.12	79.5	3.05
5.0	0.18	30.0	1.18	55.0	2.14	80.0	3.06
5.5	0.20	30.5	1.20	55.5	2.16	80.5	3.08
6.0	0.22	31.0	1.22	56.0	2.18	81.0	3.10
6.5	0.24	31.5	1.24	56.5	2.20	81.5	3.12
7.0	0.26	32.0	1.26	57.0	2.22	82.0	3.14
7.5	0.29	32.5	1.28	57.5	2.23	82.5	3.16
8.0	0.31	33.0	1.30	58.0	2.25	83.0	3.17
8.5	0.33	33.5	1.32	58.5	2.27	83.5	3.19
9.0	0.35	34.0	1.34	59.0	2.29	84.0	3.21
9.5	0.37	34.5	1.36	59.5	2.31	84.5	3.23
10.0	0.39	35.0	1.38	60.0	2.33	85.0	3.25
10.5	0.41	35.5	1.40	60.5	2.35	85.5	3.26
11.0	0.43	36.0	1.41	61.0	2.37	86.0	3.28
11.5	0.45	36.5	1.43	61.5	2.38	86.5	3.30
12.0	0.47	37.0	1.45	62.0	2.40	87.0	3.32
12.5	0.49	37.5	1.47	62.5	2.42	87.5	3.33
13.0	0.51	38.0	1.49	63.0	2.44	88.0	3.35
13.5	0.53	38.5	1.51	63.5	2.46	88.5	3.37
14.0	0.55	39.0	1.53	64.0	2.48	89.0	3.39
14.5	0.57	39.5	1.55	64.5	2.50	89.5	3.41
15.0	0.59	40.0	1.57	65.0	2.51	90.0	3.42
15.5	0.61	40.5	1.59	65.5	2.53	90.5	3.44
16.0	0.63	41.0	1.61	66.0	2.55	91.0	3.46
16.5	0.65	41.5	1.63	66.5	2.57	91.5	3.48
17.0	0.67	42.0	1.65	67.0	2.59	92.0	3.50
17.5	0.69	42.5	1.67	67.5	2.61	92.5	3.51
18.0	0.71	43.0	1.68	68.0	2.63	93.0	3.53
18.5	0.73	43.5	1.70	68.5	2.64	93.5	3.55
19.0	0.75	44.0	1.72	69.0	2.66	94.0	3.57
19.5	0.77	44.5	1.74	69.5	2.68	94.5	3.58
20.0	0.79	45.0	1.76	70.0	2.70	95.0	3.60
20.5	0.81	45.5	1.78	70.5	2.72	95.5	3.62
21.0	0.83	46.0	1.80	71.0	2.74	96.0	3.64
21.5	0.85	46.5	1.82	71.5	2.75	96.5	3.66
22.0	0.87	47.0	1.84	72.0	2.77	97.0	3.67
22.5	0.89	47.5	1.86	72.5	2.79	97.5	3.69
23.0	0.91	48.0	1.88	73.0	2.81	98.0	3.71
23.5	0.93	48.5	1.89	73.5	2.83	98.5	3.73
24.0	0.94	49.0	1.91	74.0	2.85	99.0	3.74
24.5	0.96	49.5	1.93	74.5	2.86	99.5	3.76
25.0	0.98	50.0	1.95	75.0	2.88	100.0	3.78

Temperature, °F

98.6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

				Temperature, °C				37.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.80	125.5	4.66	150.5	5.49	175.5	6.29				
101.0	3.81	126.0	4.68	151.0	5.50	176.0	6.30				
101.5	3.83	126.5	4.69	151.5	5.52	176.5	6.32				
102.0	3.85	127.0	4.71	152.0	5.54	177.0	6.33				
102.5	3.87	127.5	4.73	152.5	5.55	177.5	6.35				
103.0	3.88	128.0	4.74	153.0	5.57	178.0	6.36				
103.5	3.90	128.5	4.76	153.5	5.59	178.5	6.38				
104.0	3.92	129.0	4.78	154.0	5.60	179.0	6.40				
104.5	3.94	129.5	4.79	154.5	5.62	179.5	6.41				
105.0	3.95	130.0	4.81	155.0	5.63	180.0	6.43				
105.5	3.97	130.5	4.83	155.5	5.65	180.5	6.44				
106.0	3.99	131.0	4.84	156.0	5.67	181.0	6.46				
106.5	4.01	131.5	4.86	156.5	5.68	181.5	6.47				
107.0	4.02	132.0	4.88	157.0	5.70	182.0	6.49				
107.5	4.04	132.5	4.89	157.5	5.71	182.5	6.50				
108.0	4.06	133.0	4.91	158.0	5.73	183.0	6.52				
108.5	4.08	133.5	4.93	158.5	5.75	183.5	6.54				
109.0	4.09	134.0	4.94	159.0	5.76	184.0	6.55				
109.5	4.11	134.5	4.96	159.5	5.78	184.5	6.57				
110.0	4.13	135.0	4.98	160.0	5.79	185.0	6.58				
110.5	4.14	135.5	4.99	160.5	5.81	185.5	6.60				
111.0	4.16	136.0	5.01	161.0	5.83	186.0	6.61				
111.5	4.18	136.5	5.03	161.5	5.84	186.5	6.63				
112.0	4.20	137.0	5.04	162.0	5.86	187.0	6.64				
112.5	4.21	137.5	5.06	162.5	5.88	187.5	6.66				
113.0	4.23	138.0	5.08	163.0	5.89	188.0	6.67				
113.5	4.25	138.5	5.09	163.5	5.91	188.5	6.69				
114.0	4.27	139.0	5.11	164.0	5.92	189.0	6.71				
114.5	4.28	139.5	5.13	164.5	5.94	189.5	6.72				
115.0	4.30	140.0	5.14	165.0	5.95	190.0	6.74				
115.5	4.32	140.5	5.16	165.5	5.97	190.5	6.75				
116.0	4.33	141.0	5.18	166.0	5.99	191.0	6.77				
116.5	4.35	141.5	5.19	166.5	6.00	191.5	6.78				
117.0	4.37	142.0	5.21	167.0	6.02	192.0	6.80				
117.5	4.39	142.5	5.23	167.5	6.03	192.5	6.81				
118.0	4.40	143.0	5.24	168.0	6.05	193.0	6.83				
118.5	4.42	143.5	5.26	168.5	6.07	193.5	6.84				
119.0	4.44	144.0	5.28	169.0	6.08	194.0	6.86				
119.5	4.45	144.5	5.29	169.5	6.10	194.5	6.87				
120.0	4.47	145.0	5.31	170.0	6.11	195.0	6.89				
120.5	4.49	145.5	5.32	170.5	6.13	195.5	6.90				
121.0	4.51	146.0	5.34	171.0	6.15	196.0	6.92				
121.5	4.52	146.5	5.36	171.5	6.16	196.5	6.93				
122.0	4.54	147.0	5.37	172.0	6.18	197.0	6.95				
122.5	4.56	147.5	5.39	172.5	6.19	197.5	6.96				
123.0	4.57	148.0	5.41	173.0	6.21	198.0	6.98				
123.5	4.59	148.5	5.42	173.5	6.22	198.5	7.00				
124.0	4.61	149.0	5.44	174.0	6.24	199.0	7.01				
124.5	4.62	149.5	5.46	174.5	6.26	199.5	7.03				
125.0	4.64	150.0	5.47	175.0	6.27	200.0	7.04				

Temperature, °F

98.6

38.0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	1.00	50.5	1.96	75.5	2.89
1.0	0.02	26.0	1.02	51.0	1.98	76.0	2.91
1.5	0.04	26.5	1.04	51.5	2.00	76.5	2.92
2.0	0.06	27.0	1.06	52.0	2.02	77.0	2.94
2.5	0.08	27.5	1.08	52.5	2.04	77.5	2.96
3.0	0.10	28.0	1.10	53.0	2.06	78.0	2.98
3.5	0.12	28.5	1.12	53.5	2.08	78.5	3.00
4.0	0.14	29.0	1.14	54.0	2.09	79.0	3.02
4.5	0.16	29.5	1.16	54.5	2.11	79.5	3.03
5.0	0.18	30.0	1.18	55.0	2.13	80.0	3.05
5.5	0.20	30.5	1.20	55.5	2.15	80.5	3.07
6.0	0.22	31.0	1.21	56.0	2.17	81.0	3.09
6.5	0.24	31.5	1.23	56.5	2.19	81.5	3.11
7.0	0.26	32.0	1.25	57.0	2.21	82.0	3.12
7.5	0.28	32.5	1.27	57.5	2.23	82.5	3.14
8.0	0.30	33.0	1.29	58.0	2.24	83.0	3.16
8.5	0.32	33.5	1.31	58.5	2.26	83.5	3.18
9.0	0.34	34.0	1.33	59.0	2.28	84.0	3.20
9.5	0.36	34.5	1.35	59.5	2.30	84.5	3.21
10.0	0.38	35.0	1.37	60.0	2.32	85.0	3.23
10.5	0.40	35.5	1.39	60.5	2.34	85.5	3.25
11.0	0.42	36.0	1.41	61.0	2.36	86.0	3.27
11.5	0.44	36.5	1.43	61.5	2.37	86.5	3.29
12.0	0.46	37.0	1.45	62.0	2.39	87.0	3.30
12.5	0.48	37.5	1.47	62.5	2.41	87.5	3.32
13.0	0.50	38.0	1.49	63.0	2.43	88.0	3.34
13.5	0.52	38.5	1.50	63.5	2.45	88.5	3.36
14.0	0.54	39.0	1.52	64.0	2.47	89.0	3.37
14.5	0.56	39.5	1.54	64.5	2.49	89.5	3.39
15.0	0.58	40.0	1.56	65.0	2.50	90.0	3.41
15.5	0.60	40.5	1.58	65.5	2.52	90.5	3.43
16.0	0.62	41.0	1.60	66.0	2.54	91.0	3.45
16.5	0.64	41.5	1.62	66.5	2.56	91.5	3.46
17.0	0.66	42.0	1.64	67.0	2.58	92.0	3.48
17.5	0.68	42.5	1.66	67.5	2.60	92.5	3.50
18.0	0.70	43.0	1.68	68.0	2.61	93.0	3.52
18.5	0.72	43.5	1.70	68.5	2.63	93.5	3.53
19.0	0.74	44.0	1.72	69.0	2.65	94.0	3.55
19.5	0.76	44.5	1.73	69.5	2.67	94.5	3.57
20.0	0.78	45.0	1.75	70.0	2.69	95.0	3.59
20.5	0.80	45.5	1.77	70.5	2.71	95.5	3.60
21.0	0.82	46.0	1.79	71.0	2.72	96.0	3.62
21.5	0.84	46.5	1.81	71.5	2.74	96.5	3.64
22.0	0.86	47.0	1.83	72.0	2.76	97.0	3.66
22.5	0.88	47.5	1.85	72.5	2.78	97.5	3.68
23.0	0.90	48.0	1.87	73.0	2.80	98.0	3.69
23.5	0.92	48.5	1.89	73.5	2.82	98.5	3.71
24.0	0.94	49.0	1.91	74.0	2.83	99.0	3.73
24.5	0.96	49.5	1.92	74.5	2.85	99.5	3.75
25.0	0.98	50.0	1.94	75.0	2.87	100.0	3.76

Temperature, °F

100.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

								Temperature, °C	38.0
atü	- kg								
100.5	3.78	125.5	4.64	150.5	5.46	175.5	6.26		
101.0	3.80	126.0	4.66	151.0	5.48	176.0	6.28		
101.5	3.82	126.5	4.67	151.5	5.50	176.5	6.29		
102.0	3.83	127.0	4.69	152.0	5.51	177.0	6.31		
102.5	3.85	127.5	4.71	152.5	5.53	177.5	6.32		
103.0	3.87	128.0	4.72	153.0	5.55	178.0	6.34		
103.5	3.88	128.5	4.74	153.5	5.56	178.5	6.35		
104.0	3.90	129.0	4.76	154.0	5.58	179.0	6.37		
104.5	3.92	129.5	4.77	154.5	5.59	179.5	6.38		
105.0	3.94	130.0	4.79	155.0	5.61	180.0	6.40		
105.5	3.95	130.5	4.81	155.5	5.63	180.5	6.42		
106.0	3.97	131.0	4.82	156.0	5.64	181.0	6.43		
106.5	3.99	131.5	4.84	156.5	5.66	181.5	6.45		
107.0	4.01	132.0	4.86	157.0	5.67	182.0	6.46		
107.5	4.02	132.5	4.87	157.5	5.69	182.5	6.48		
108.0	4.04	133.0	4.89	158.0	5.71	183.0	6.49		
108.5	4.06	133.5	4.91	158.5	5.72	183.5	6.51		
109.0	4.08	134.0	4.92	159.0	5.74	184.0	6.52		
109.5	4.09	134.5	4.94	159.5	5.75	184.5	6.54		
110.0	4.11	135.0	4.96	160.0	5.77	185.0	6.55		
110.5	4.13	135.5	4.97	160.5	5.79	185.5	6.57		
111.0	4.14	136.0	4.99	161.0	5.80	186.0	6.59		
111.5	4.16	136.5	5.01	161.5	5.82	186.5	6.60		
112.0	4.18	137.0	5.02	162.0	5.83	187.0	6.62		
112.5	4.20	137.5	5.04	162.5	5.85	187.5	6.63		
113.0	4.21	138.0	5.06	163.0	5.87	188.0	6.65		
113.5	4.23	138.5	5.07	163.5	5.88	188.5	6.66		
114.0	4.25	139.0	5.09	164.0	5.90	189.0	6.68		
114.5	4.26	139.5	5.11	164.5	5.91	189.5	6.69		
115.0	4.28	140.0	5.12	165.0	5.93	190.0	6.71		
115.5	4.30	140.5	5.14	165.5	5.95	190.5	6.72		
116.0	4.32	141.0	5.15	166.0	5.96	191.0	6.74		
116.5	4.33	141.5	5.17	166.5	5.98	191.5	6.75		
117.0	4.35	142.0	5.19	167.0	5.99	192.0	6.77		
117.5	4.37	142.5	5.20	167.5	6.01	192.5	6.78		
118.0	4.38	143.0	5.22	168.0	6.02	193.0	6.80		
118.5	4.40	143.5	5.24	168.5	6.04	193.5	6.81		
119.0	4.42	144.0	5.25	169.0	6.06	194.0	6.83		
119.5	4.44	144.5	5.27	169.5	6.07	194.5	6.84		
120.0	4.45	145.0	5.29	170.0	6.09	195.0	6.86		
120.5	4.47	145.5	5.30	170.5	6.10	195.5	6.88		
121.0	4.49	146.0	5.32	171.0	6.12	196.0	6.89		
121.5	4.50	146.5	5.33	171.5	6.14	196.5	6.91		
122.0	4.52	147.0	5.35	172.0	6.15	197.0	6.92		
122.5	4.54	147.5	5.37	172.5	6.17	197.5	6.94		
123.0	4.55	148.0	5.38	173.0	6.18	198.0	6.95		
123.5	4.57	148.5	5.40	173.5	6.20	198.5	6.97		
124.0	4.59	149.0	5.42	174.0	6.21	199.0	6.98		
124.5	4.60	149.5	5.43	174.5	6.23	199.5	7.00		
125.0	4.62	150.0	5.45	175.0	6.24	200.0	7.01		

Temperature, °F

100.4

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

39•0

Temperature, °C

atü	- kg	atü	- kg	atü	- kg	atü	- kg
0•5	0•00	25•5	1•00	50•5	1•95	75•5	2•88
1•0	0•02	26•0	1•02	51•0	1•97	76•0	2•89
1•5	0•04	26•5	1•03	51•5	1•99	76•5	2•91
2•0	0•06	27•0	1•05	52•0	2•01	77•0	2•93
2•5	0•08	27•5	1•07	52•5	2•03	77•5	2•95
3•0	0•10	28•0	1•09	53•0	2•05	78•0	2•97
3•5	0•12	28•5	1•11	53•5	2•07	78•5	2•98
4•0	0•14	29•0	1•13	54•0	2•09	79•0	3•00
4•5	0•16	29•5	1•15	54•5	2•10	79•5	3•02
5•0	0•18	30•0	1•17	55•0	2•12	80•0	3•04
5•5	0•20	30•5	1•19	55•5	2•14	80•5	3•06
6•0	0•22	31•0	1•21	56•0	2•16	81•0	3•07
6•5	0•24	31•5	1•23	56•5	2•18	81•5	3•09
7•0	0•26	32•0	1•25	57•0	2•20	82•0	3•11
7•5	0•28	32•5	1•27	57•5	2•22	82•5	3•13
8•0	0•30	33•0	1•29	58•0	2•23	83•0	3•15
8•5	0•32	33•5	1•31	58•5	2•25	83•5	3•16
9•0	0•34	34•0	1•33	59•0	2•27	84•0	3•18
9•5	0•36	34•5	1•34	59•5	2•29	84•5	3•20
10•0	0•38	35•0	1•36	60•0	2•31	85•0	3•22
10•5	0•40	35•5	1•38	60•5	2•33	85•5	3•24
11•0	0•42	36•0	1•40	61•0	2•35	86•0	3•25
11•5	0•44	36•5	1•42	61•5	2•36	86•5	3•27
12•0	0•46	37•0	1•44	62•0	2•38	87•0	3•29
12•5	0•48	37•5	1•46	62•5	2•40	87•5	3•31
13•0	0•50	38•0	1•48	63•0	2•42	88•0	3•32
13•5	0•52	38•5	1•50	63•5	2•44	88•5	3•34
14•0	0•54	39•0	1•52	64•0	2•46	89•0	3•36
14•5	0•56	39•5	1•54	64•5	2•47	89•5	3•38
15•0	0•58	40•0	1•56	65•0	2•49	90•0	3•40
15•5	0•60	40•5	1•57	65•5	2•51	90•5	3•41
16•0	0•62	41•0	1•59	66•0	2•53	91•0	3•43
16•5	0•64	41•5	1•61	66•5	2•55	91•5	3•45
17•0	0•66	42•0	1•63	67•0	2•57	92•0	3•47
17•5	0•68	42•5	1•65	67•5	2•58	92•5	3•48
18•0	0•70	43•0	1•67	68•0	2•60	93•0	3•50
18•5	0•72	43•5	1•69	68•5	2•62	93•5	3•52
19•0	0•74	44•0	1•71	69•0	2•64	94•0	3•54
19•5	0•76	44•5	1•73	69•5	2•66	94•5	3•55
20•0	0•78	45•0	1•75	70•0	2•68	95•0	3•57
20•5	0•80	45•5	1•77	70•5	2•69	95•5	3•59
21•0	0•82	46•0	1•78	71•0	2•71	96•0	3•61
21•5	0•84	46•5	1•80	71•5	2•73	96•5	3•62
22•0	0•86	47•0	1•82	72•0	2•75	97•0	3•64
22•5	0•88	47•5	1•84	72•5	2•77	97•5	3•66
23•0	0•90	48•0	1•86	73•0	2•79	98•0	3•68
23•5	0•92	48•5	1•88	73•5	2•80	98•5	3•69
24•0	0•94	49•0	1•90	74•0	2•82	99•0	3•71
24•5	0•96	49•5	1•92	74•5	2•84	99•5	3•73
25•0	0•98	50•0	1•94	75•0	2•86	100•0	3•75

Temperature, °F

102•2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Temperature, °C						39.0					
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.76	125.5	4.62	150.5	5.44	175.5	6.23				
101.0	3.78	126.0	4.64	151.0	5.46	176.0	6.25				
101.5	3.80	126.5	4.65	151.5	5.47	176.5	6.26				
102.0	3.82	127.0	4.67	152.0	5.49	177.0	6.28				
102.5	3.83	127.5	4.69	152.5	5.51	177.5	6.30				
103.0	3.85	128.0	4.70	153.0	5.52	178.0	6.31				
103.5	3.87	128.5	4.72	153.5	5.54	178.5	6.33				
104.0	3.89	129.0	4.74	154.0	5.55	179.0	6.34				
104.5	3.90	129.5	4.75	154.5	5.57	179.5	6.36				
105.0	3.92	130.0	4.77	155.0	5.59	180.0	6.37				
105.5	3.94	130.5	4.79	155.5	5.60	180.5	6.39				
106.0	3.95	131.0	4.80	156.0	5.62	181.0	6.40				
106.5	3.97	131.5	4.82	156.5	5.63	181.5	6.42				
107.0	3.99	132.0	4.84	157.0	5.65	182.0	6.43				
107.5	4.01	132.5	4.85	157.5	5.67	182.5	6.45				
108.0	4.02	133.0	4.87	158.0	5.68	183.0	6.47				
108.5	4.04	133.5	4.89	158.5	5.70	183.5	6.48				
109.0	4.06	134.0	4.90	159.0	5.71	184.0	6.50				
109.5	4.08	134.5	4.92	159.5	5.73	184.5	6.51				
110.0	4.09	135.0	4.94	160.0	5.75	185.0	6.53				
110.5	4.11	135.5	4.95	160.5	5.76	185.5	6.54				
111.0	4.13	136.0	4.97	161.0	5.78	186.0	6.56				
111.5	4.14	136.5	4.98	161.5	5.79	186.5	6.57				
112.0	4.16	137.0	5.00	162.0	5.81	187.0	6.59				
112.5	4.18	137.5	5.02	162.5	5.83	187.5	6.60				
113.0	4.20	138.0	5.03	163.0	5.84	188.0	6.62				
113.5	4.21	138.5	5.05	163.5	5.86	188.5	6.63				
114.0	4.23	139.0	5.07	164.0	5.87	189.0	6.65				
114.5	4.25	139.5	5.08	164.5	5.89	189.5	6.66				
115.0	4.26	140.0	5.10	165.0	5.90	190.0	6.68				
115.5	4.28	140.5	5.12	165.5	5.92	190.5	6.69				
116.0	4.30	141.0	5.13	166.0	5.94	191.0	6.71				
116.5	4.31	141.5	5.15	166.5	5.95	191.5	6.73				
117.0	4.33	142.0	5.17	167.0	5.97	192.0	6.74				
117.5	4.35	142.5	5.18	167.5	5.98	192.5	6.76				
118.0	4.37	143.0	5.20	168.0	6.00	193.0	6.77				
118.5	4.38	143.5	5.21	168.5	6.02	193.5	6.79				
119.0	4.40	144.0	5.23	169.0	6.03	194.0	6.80				
119.5	4.42	144.5	5.25	169.5	6.05	194.5	6.82				
120.0	4.43	145.0	5.26	170.0	6.06	195.0	6.83				
120.5	4.45	145.5	5.28	170.5	6.08	195.5	6.85				
121.0	4.47	146.0	5.30	171.0	6.09	196.0	6.86				
121.5	4.48	146.5	5.31	171.5	6.11	196.5	6.88				
122.0	4.50	147.0	5.33	172.0	6.12	197.0	6.89				
122.5	4.52	147.5	5.34	172.5	6.14	197.5	6.91				
123.0	4.53	148.0	5.36	173.0	6.16	198.0	6.92				
123.5	4.55	148.5	5.38	173.5	6.17	198.5	6.94				
124.0	4.57	149.0	5.39	174.0	6.19	199.0	6.95				
124.5	4.59	149.5	5.41	174.5	6.20	199.5	6.97				
125.0	4.60	150.0	5.43	175.0	6.22	200.0	6.98				

Temperature, °F

102.2

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C	
atü	- kg	atü	- kg	atü	- kg	atü	- kg
0.5	0.00	25.5	.99	50.5	1.95	75.5	2.86
1.0	0.02	26.0	1.01	51.0	1.96	76.0	2.88
1.5	0.04	26.5	1.03	51.5	1.98	76.5	2.90
2.0	0.06	27.0	1.05	52.0	2.00	77.0	2.92
2.5	0.08	27.5	1.07	52.5	2.02	77.5	2.94
3.0	0.10	28.0	1.09	53.0	2.04	78.0	2.95
3.5	0.12	28.5	1.11	53.5	2.06	78.5	2.97
4.0	0.14	29.0	1.13	54.0	2.08	79.0	2.99
4.5	0.16	29.5	1.15	54.5	2.09	79.5	3.01
5.0	0.18	30.0	1.17	55.0	2.11	80.0	3.03
5.5	0.20	30.5	1.19	55.5	2.13	80.5	3.04
6.0	0.22	31.0	1.20	56.0	2.15	81.0	3.06
6.5	0.24	31.5	1.22	56.5	2.17	81.5	3.08
7.0	0.26	32.0	1.24	57.0	2.19	82.0	3.10
7.5	0.28	32.5	1.26	57.5	2.21	82.5	3.11
8.0	0.30	33.0	1.28	58.0	2.22	83.0	3.13
8.5	0.32	33.5	1.30	58.5	2.24	83.5	3.15
9.0	0.34	34.0	1.32	59.0	2.26	84.0	3.17
9.5	0.36	34.5	1.34	59.5	2.28	84.5	3.19
10.0	0.38	35.0	1.36	60.0	2.30	85.0	3.20
10.5	0.40	35.5	1.38	60.5	2.32	85.5	3.22
11.0	0.42	36.0	1.40	61.0	2.34	86.0	3.24
11.5	0.44	36.5	1.42	61.5	2.35	86.5	3.26
12.0	0.46	37.0	1.43	62.0	2.37	87.0	3.27
12.5	0.48	37.5	1.45	62.5	2.39	87.5	3.29
13.0	0.50	38.0	1.47	63.0	2.41	88.0	3.31
13.5	0.52	38.5	1.49	63.5	2.43	88.5	3.33
14.0	0.54	39.0	1.51	64.0	2.45	89.0	3.35
14.5	0.56	39.5	1.53	64.5	2.46	89.5	3.36
15.0	0.58	40.0	1.55	65.0	2.48	90.0	3.38
15.5	0.60	40.5	1.57	65.5	2.50	90.5	3.40
16.0	0.62	41.0	1.59	66.0	2.52	91.0	3.42
16.5	0.64	41.5	1.61	66.5	2.54	91.5	3.43
17.0	0.66	42.0	1.63	67.0	2.56	92.0	3.45
17.5	0.68	42.5	1.64	67.5	2.57	92.5	3.47
18.0	0.70	43.0	1.66	68.0	2.59	93.0	3.49
18.5	0.72	43.5	1.68	68.5	2.61	93.5	3.50
19.0	0.74	44.0	1.70	69.0	2.63	94.0	3.52
19.5	0.76	44.5	1.72	69.5	2.65	94.5	3.54
20.0	0.78	45.0	1.74	70.0	2.66	95.0	3.56
20.5	0.80	45.5	1.76	70.5	2.68	95.5	3.57
21.0	0.82	46.0	1.78	71.0	2.70	96.0	3.59
21.5	0.84	46.5	1.80	71.5	2.72	96.5	3.61
22.0	0.85	47.0	1.81	72.0	2.74	97.0	3.63
22.5	0.87	47.5	1.83	72.5	2.76	97.5	3.64
23.0	0.89	48.0	1.85	73.0	2.77	98.0	3.66
23.5	0.91	48.5	1.87	73.5	2.79	98.5	3.68
24.0	0.93	49.0	1.89	74.0	2.81	99.0	3.70
24.5	0.95	49.5	1.91	74.5	2.83	99.5	3.71
25.0	0.97	50.0	1.93	75.0	2.85	100.0	3.73

Temperature, °F 104.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6

						Temperature, °C		40.0			
atü	-	kg	atü	-	kg	atü	-	kg	atü	-	kg
100.5	3.75	125.5	4.60	150.5	5.42	175.5	6.21				
101.0	3.77	126.0	4.62	151.0	5.43	176.0	6.22				
101.5	3.78	126.5	4.63	151.5	5.45	176.5	6.24				
102.0	3.80	127.0	4.65	152.0	5.47	177.0	6.25				
102.5	3.82	127.5	4.67	152.5	5.48	177.5	6.27				
103.0	3.83	128.0	4.68	153.0	5.50	178.0	6.28				
103.5	3.85	128.5	4.70	153.5	5.51	178.5	6.30				
104.0	3.87	129.0	4.72	154.0	5.53	179.0	6.32				
104.5	3.89	129.5	4.73	154.5	5.55	179.5	6.33				
105.0	3.90	130.0	4.75	155.0	5.56	180.0	6.35				
105.5	3.92	130.5	4.77	155.5	5.58	180.5	6.36				
106.0	3.94	131.0	4.78	156.0	5.59	181.0	6.38				
106.5	3.96	131.5	4.80	156.5	5.61	181.5	6.39				
107.0	3.97	132.0	4.81	157.0	5.63	182.0	6.41				
107.5	3.99	132.5	4.83	157.5	5.64	182.5	6.42				
108.0	4.01	133.0	4.85	158.0	5.66	183.0	6.44				
108.5	4.02	133.5	4.86	158.5	5.67	183.5	6.45				
109.0	4.04	134.0	4.88	159.0	5.69	184.0	6.47				
109.5	4.06	134.5	4.90	159.5	5.71	184.5	6.48				
110.0	4.08	135.0	4.91	160.0	5.72	185.0	6.50				
110.5	4.09	135.5	4.93	160.5	5.74	185.5	6.51				
111.0	4.11	136.0	4.95	161.0	5.75	186.0	6.53				
111.5	4.13	136.5	4.96	161.5	5.77	186.5	6.54				
112.0	4.14	137.0	4.98	162.0	5.78	187.0	6.56				
112.5	4.16	137.5	5.00	162.5	5.80	187.5	6.58				
113.0	4.18	138.0	5.01	163.0	5.82	188.0	6.59				
113.5	4.19	138.5	5.03	163.5	5.83	188.5	6.61				
114.0	4.21	139.0	5.05	164.0	5.85	189.0	6.62				
114.5	4.23	139.5	5.06	164.5	5.86	189.5	6.64				
115.0	4.25	140.0	5.08	165.0	5.88	190.0	6.65				
115.5	4.26	140.5	5.09	165.5	5.90	190.5	6.67				
116.0	4.28	141.0	5.11	166.0	5.91	191.0	6.68				
116.5	4.30	141.5	5.13	166.5	5.93	191.5	6.70				
117.0	4.31	142.0	5.14	167.0	5.94	192.0	6.71				
117.5	4.33	142.5	5.16	167.5	5.96	192.5	6.73				
118.0	4.35	143.0	5.18	168.0	5.97	193.0	6.74				
118.5	4.36	143.5	5.19	168.5	5.99	193.5	6.76				
119.0	4.38	144.0	5.21	169.0	6.00	194.0	6.77				
119.5	4.40	144.5	5.22	169.5	6.02	194.5	6.79				
120.0	4.41	145.0	5.24	170.0	6.04	195.0	6.80				
120.5	4.43	145.5	5.26	170.5	6.05	195.5	6.82				
121.0	4.45	146.0	5.27	171.0	6.07	196.0	6.83				
121.5	4.46	146.5	5.29	171.5	6.08	196.5	6.85				
122.0	4.48	147.0	5.31	172.0	6.10	197.0	6.86				
122.5	4.50	147.5	5.32	172.5	6.11	197.5	6.88				
123.0	4.52	148.0	5.34	173.0	6.13	198.0	6.89				
123.5	4.53	149.5	5.35	173.5	6.15	198.5	6.91				
124.0	4.55	149.0	5.37	174.0	6.16	199.0	6.92				
124.5	4.57	149.5	5.39	174.5	6.18	199.5	6.94				
125.0	4.58	150.0	5.40	175.0	6.19	200.0	6.95				

Temperature, °F

104.0

Sanitized Copy Approved for Release 2011/05/03 : CIA-RDP78-03639A000500030001-6